

Organization of the NL-42/NL-52 documentation

Documentation for the Sound Level Meter NL-42/NL-52 comes in three parts, as listed below.

- **Instruction Manual (this document)**

Describes operating procedures for the Sound Level Meter NL-42/NL-52, connection and use of peripheral equipment such as a level recorder and printer, and use of the memory card.

- **Serial Interface Manual**

Describes communication with a computer, using the serial interface built into the Sound Level Meter NL-42/NL-52. The manual covers the communication protocol, use of control commands for the sound level meter, format of data output by the sound level meter, and other topics.

- **Technical Notes**

This document provides in-depth information about sound level meter performance, microphone construction and characteristics, influence of extension cables and windscreen on the measurement, and other topics.

* Company names and product names mentioned in this manual are usually trademarks or registered trademarks of their respective owners.

Organization of This Manual

This manual describes how to use the serial interface built into the Sound Level Meter NL-42 and NL-52. Besides the RS-232C serial interface standard, the unit also supports USB. However, correct operation in combination with other USB devices is not assured. If possible, you should avoid connecting other USB devices at the same time.

The manual is divided into four chapters. Chapter 1 covers points that are common to the RS-232C and USB interface. Chapter 2 contains information for users of the RS-232C interface. USB users need not read this chapter. Chapter 3 contains information for users of the USB interface. RS-232C users need not read this chapter. Chapter 4 explains the interface commands. This chapter is for users of either interface. You should read the explanation for the commands that operate the functions you want to use.

Chapter 1 General Information

This chapter contains information that applies both to the RS-232C and USB interface.

Chapter 2 RS-232C

This chapter explains connection to a computer and transfer principles using the RS-232C interface.

Chapter 3 USB

This chapter explains connection to a computer, installing the USB driver and how to use the USB interface.

Chapter 4 Commands

This chapter explains the commands used to control the NL-42 or NL-52. Information is given about command format, functions, and other relevant points.

Contents

| | |
|--|----------|
| Organization of This Manual | iii |
| Chapter 1 General Information | 1 |
| Outline | 2 |
| Communication Cutoff..... | 3 |
| Sleep mode | 3 |
| ECO setting | 3 |
| Power off | 3 |
| Auto shutdown | 3 |
| Rated Values | 4 |
| Chapter 2 RS-232C | 1 |
| Connection to a Computer | 6 |
| Transfer Protocol | 8 |
| Chapter 3 USB | 1 |
| USB | 10 |
| Operating Environment | 11 |
| Installing the USB Driver | 12 |
| Installation procedure | 12 |
| Checking the virtual COM port | 17 |
| Connection to a Computer | 19 |
| Disconnection from the Computer..... | 20 |

| | |
|--------------------------------|----------|
| Chapter 4 Commands..... | 1 |
| Command..... | 22 |
| Command types..... | 22 |
| Command format..... | 22 |
| Echo back | 24 |
| Result code | 24 |
| Command list | 25 |

Chapter 1 General Information

Contents

| | |
|----------------------------|---|
| Outline..... | 2 |
| Communication Cutoff | 3 |
| Sleep mode | 3 |
| ECO setting | 3 |
| Power off | 3 |
| Auto shutdown..... | 3 |
| Rated Values | 4 |

Outline

The Sound Level Meter NL-42 and NL-52 incorporate a serial interface. This interface allows the use of a computer to make measurement parameter settings and to control the measurement. It is also possible to send measurement results (current results as well as data stored in the memory of the sound level meter) to the computer for further processing.

Standard terminal software (Hyper Terminal, etc.) can also be used as communication client.

Communication Cutoff

Sleep mode

When sleep mode is enabled, the unit enters the sleep state after the current block has been sent. In the sleep state, the sound level meter does not send or accept commands.

ECO setting

When ECO setting is selected, it will be enabled after a transmission of current command is completed. After that, the sound level meter does not send or accept commands (ECO setting disables the communication control function).

Power off

During power off processing, communication is terminated after the current command was sent.

Auto shutdown

Same as power off.

Rated Values

Guaranteed values

| Case | Rated Values | Remarks |
|---|--------------|--|
| Sound level meter response time | Max. 3 s | Result code 0004 (state error) response if due to processing reasons |
| Send character interval | Max. 100 ms | – |
| Interval until sound level meter enters idling state after sending data | Max. 200 ms | After receiving data from the sound level meter, wait at least 200 ms before sending the next command (For DOD, at least 1 s) |

Rated values

| Case | Rated Values | If exceeded |
|--|--------------|-------------|
| Block generation wait time after receiving <STX> | No limit | – |
| Receive character interval timeout | No limit | – |

Chapter 2 RS-232C

Contents


| | |
|--------------------------------|---|
| Connection to a Computer | 6 |
| Transfer Protocol | 8 |

Connection to a Computer

Connect The I/O jack on the bottom of the NL-42/NL-52 with a RS-232C connector of a computer, using the optional RS-232C interface cable CC-42R as shown below. The performance of other cables will not be guaranteed. Note that the performance of multiple units connection with RS-232C will not be guaranteed.

Important

Do not connect the cable connector to the I/O jack reversely.



Setting of the sound level meter when using the RS-232C


When using RS-232C, set the communication interface for the sound level meter following the steps below.

1. Press the MENU/ENTER key to bring up the menu list screen.
2. Use the Δ / ∇ / \triangleleft / \triangleright keys to select [I/O] and press the MENU/ENTER key. The I/O screen appears.
3. Use the Δ / ∇ keys to select [Communication Interface] and press the MENU/ENTER key. The communication control function screen appears.

4. Use the Δ/∇ keys to select [RS-232C] and press the MENU/ENTER key.
5. Select the [Baud rate] on the I/O screen and press the MENU/ENTER key. The baud rate screen appears.
6. Use the Δ/∇ keys to select baud rate (9600bps, 19200bps, 38400bps, 57600bps, 115200bps) and press the MENU/ENTER key.
7. Press the START/STOP key to return to the measurement screen.

The CC-42R serial cable uses a 9-pin connector (female).

The cable is optional.



Transfer Protocol

| | |
|---------------------|---|
| Transfer principle: | full duplex |
| Sync principle: | asynchronous |
| Baud rate: | 9600 / 19200 / 33400 / 57600 / 115200 bps |
| Data word length: | 8 bit |
| Stop bits: | 1 bit |
| Parity check: | none |
| Flow control: | X parameter or RTS / CTS (selectable) |

Chapter 3 USB

Contents

| | |
|---------------------------------------|----|
| USB | 10 |
| Operating Environment..... | 11 |
| Installing the USB Driver | 12 |
| Installation procedure | 12 |
| Connection check | 17 |
| Connection to a Computer | 19 |
| Disconnection from the Computer | 20 |

USB

The NL-42/NL-52 can use a USB connection for operation control and transfer of data. To use the USB interface, a USB driver must be installed on the computer.

Please download USB driver from our homepage (<http://www.rion.co.jp/english/>).

Installation and operation procedures are explained in this manual.

Note that the performance of multiple units connection with USB will not be guaranteed.

Operating Environment

Supported Operating Systems

- Microsoft Windows 2000
- Microsoft Windows XP Professional (32 bit)
- Microsoft Windows 7 Professional (32 bit)

Installing the USB Driver

By connecting the NL-42/NL-52 to a computer with a USB cable, the NL-42/NL-52 can be controlled remotely from the computer, and measurement data can be sent to the computer in real time. To enable use of these functions, you must first download driver software from the RION Corporation web site and install this driver on the computer to be used with the NL-42/NL-52. The driver will create a virtual COM port on the computer.

Installation procedure

When connecting the NL-42/NL-52 and the computer for the first time, install the USB driver as follows.

1. Download the latest USB driver from the RION Co., LTD. web site (<http://www.rion.co.jp/english/>).
2. Turn power to the NL-42/NL-52 on, select [I/O] and set [Communication Interface] to “USB”.

| Important |
|--|
| The above steps must be completed BEFORE connecting the USB cable. |

3. Connect the NL-42/NL-52 to the computer with a USB cable.


| Important |
|--|
| Connect the NL-42/NL-52 directly with the USB cable to the computer. If the NL-42/NL-52 is connected via a USB hub, normal operation is not assured. |

4. When the computer detects the NL-42/NL-52, the “Found New Hardware Wizard” appears.


Note

The “Found New Hardware Wizard” appears only the first time you connect the NL-42/NL-52 to the computer. It will not appear during subsequent use.


The screen is the one of WindowsXP. When OS is different, the screen is also different.




5. Select “No, not this time”, and click on “Next>”.




6. Select “Install from a list or specific location (Advanced)”, and click on “Next>”.




7. Select “Search for the best driver in these locations”, and click on “Browse”. Then specify the folder to which you have downloaded the driver in step 1.




8. The “Hardware Installation” dialog box warning appears. Click on “Continue Anyway”.



9. A screen like the one below will be shown until the driver installation is complete.



10. Click on “Finish”.




When step 10 has been completed, USB communication is enabled.


The driver installation creates a virtual COM port in the computer. For information on how to verify that the installation was successful, see the section “Checking the virtual COM port” on next page.

Checking the virtual COM port

1. After installing the driver, set [Communication Interface] to “USB” at the NL-42/NL-52 and connect the USB cable.
2. Open the Device Manager (“Hardware” tab under “Properties” in My Computer).



3. Click on the + at the left of “Ports (COM & LPT)”.




The indication “RION USB to RS232C Converter Virtual COM Port” should be shown as COM port name. If this is not shown, check the connection between the NL-42/NL-52 and the computer (step 1). If there is an “x” over the icon, the port is not functioning normally. Install the driver again.

Connection to a Computer

Connect The USB port on the bottom of the NL-42/NL-52 with a USB port of a computer, using the optional A - mini B USB cable as shown below. The performance of other cables will not be guaranteed.

Important

Be sure to connect the cable only after selecting the [USB] setting.



Setting of the sound level meter when using the USB

When using USB, set the communication interface for the sound level meter following the steps below.

1. Press the MENU/ENTER key to bring up the menu list screen.
2. Use the Δ / ∇ / \triangleleft / \triangleright keys to select [I/O] and press the MENU/ENTER key. The I/O screen appears.
3. Use the Δ / ∇ keys to select [Communication Interface] and press the MENU/ENTER key. The communication control function screen appears.
4. Use the Δ / ∇ keys to select [USB] and press the MENU/ENTER key.
5. Press the START/STOP key to return to the measurement screen.

Disconnection from the Computer

NL-42/NL-52 will be recognized as “removable media”. Consequently, the correct procedure as described below must be followed when disconnecting the unit.

1. Click on the “Safely remove hardware” icon in the right section of the taskbar, and select “Safely remove USB Mass Storage Device - Drive (*1)”.

*1: The drive letter (E in the example shown) will differ, depending on the computer configuration.



2. When the message shown below appears, disconnect the USB cable.



The NL-42/NL-52 is now properly disconnected.

Chapter 4 Commands

Contents

| | |
|--|----|
| Commands..... | 22 |
| Command types..... | 22 |
| Command format | 22 |
| Echo back..... | 24 |
| Result code..... | 24 |
| Command list..... | 25 |
| Command description | |
| Examples for control via external commands | |

Command

Command types

There are two types of commands: setting commands and request commands.

Setting command

This type of command serves for changing the sound level meter status or measurement parameters. Only some commands of this type will produce a response from the sound level meter. The response consists of status information returned after the setting command has been processed.

Request command

This type of command serves for getting information about unit settings and for obtaining measurement data including display data and stored data. The sound level meter returns the requested data.

Command format

Setting command

Command = "command name" + "," + "parameter" + [CR] + [LF]

The basic components of a setting command are the command name and the parameter. A comma is used as delimiter between the command name and parameter, and the setting command is terminated by a [CR]+[LF] (carriage return + line feed). The setting command uses the CSV format.

Prohibited items

- Spaces in a command name may not be omitted.
- Spaces in a command name may not be doubled.
- The “,” (comma) after the command name may not be omitted.
- Japanese full-width characters are not allowed.

Permitted items

- Lower case may be used instead of upper case.
- Upper case may be used instead of lower case.
- Spaces may be inserted immediately before and after the parameter.

Setting command examples

| | | |
|--|---------|---|
| LCD_Auto_Off,Short[CR][LF] ↑ | Valid | Space after “,” may be omitted. |
| lcd_auto_off,_short_[CR][LF] ↑ ↑ ↑ ↑ | Valid | Command name in all lower case is permitted. |
| LCD_Auto_Off,__Short__[CR][LF] ↑ ↑ | Valid | Two or more spaces immediately before or after parameter are permitted. |
| LCDAuto__Off,_Short[CR][LF] ↑ ↑ | Invalid | Spaces in command name may not be omitted. |
| LCD_Auto_Off_Short[CR][LF] ↑ | Invalid | Comma after command name may not be omitted. |

“_” stands for a space.

Request command

Command = "command name" + "?" + [CR] + [LF]

The request command is a structure to put up the “?” behind the command name. The request command is terminated by a [CR]+[LF] (carriage return + line feed). The setting command uses the CSV format.

Prohibited items

- Spaces in a command name may not be omitted.
- Spaces in a command name may not be doubled.

Permitted items

- Lower case may be used instead of upper case.
- Upper case may be used instead of lower case.

Echo back

When the echo back function is set to ON, a string of a transmitted command is sent back from a destination to let operators know that the command has been entered properly.

The Echo command is used to turn ON/OFF the echo back function and check the current setting.

Result code

This is a response data that indicates execution results of commands. The structure of a result code is shown below.

Result code = “R-” + “four-digit number”

The four-digit number following the prefix character “R-” indicates the situations described below.

| Numbers | Contents |
|---------|--|
| 0000 | Normal end This is a response to the situation where the command (setting or request) is executed normally. |
| 0001 | Command error This is a response to the situation where the specified command cannot be recognized. |
| 0002 | Parameter error This is a response to the situation where the number of parameters and the parameter type allowed for the specified command are not met. |
| 0003 | Designation error This is a response to the situation where a setting is made with a command which can only handle requests, or a request is made with a command which can only handle settings. |
| 0004 | Status error This is a response to the situation where the command (setting or request) cannot be executed in a current situation. |

Command list

S: Setting command (command for making a NL-42/NL-52 setting)

R: Request command (command for obtaining status information or measurement data from NL-42/NL-52)

Communication

| Command | Function | See page |
|---------|----------------------|----------|
| Echo | Echo back (S/R)..... | |

System

| Command | Function | See page |
|----------------------|--|----------|
| System Version | System version information (R) | |
| Clock | Current date and time (S/R) | |
| Language | Displayed language (S/R) | |
| Cal Mode | Calibration mode (S/R) | |
| Index Number | Index number (S/R)..... | |
| Key Lock | Key lock (S/R)..... | |
| Touch Panel Lock | Touch panel lock (S/R)..... | |
| Backlight | Backlight (S/R)..... | |
| Backlight Auto Off | Backlight auto off (S/R) | |
| LCD | LCD (S/R) | |
| LCD Auto Off | LCD auto off (S/R) | |
| Backlight Brightness | Backlight brightness (S/R)..... | |
| Battery Type | Battery type (S/R)..... | |
| SD Card Total Size | SD memory card capacity (R) | |
| SD Card Free Size | SD memory card free space (R)..... | |
| SD Card Percentage | SD memory card free space percentage (R) | |

Display

| Command | Function | See page |
|---------------------|---|----------|
| Display Sub Channel | Display sub channel (S/R)..... | |
| Display Ly | Display additional processing (S/R).. .. | |

| | |
|--------------------------|---|
| Display Leq | Display L_{eq} (S/R) |
| Display LE | Display L_E (S/R) |
| Display Lmax | Display L_{max} (S/R) |
| Display Lmin | Display L_{min} (S/R) |
| Display LN1 | Display L_{N1} (S/R) |
| Display LN2 | Display L_{N2} (S/R) |
| Display LN3 | Display L_{N3} (S/R) |
| Display LN4 | Display L_{N4} (S/R) |
| Display LN5 | Display L_{N5} (S/R) |
| Parcentile 1 | Parcentile of L_{N1} (S/R) |
| Parcentile 2 | Parcentile of L_{N2} (S/R) |
| Parcentile 3 | Parcentile of L_{N3} (S/R) |
| Parcentile 4 | Parcentile of L_{N4} (S/R) |
| Parcentile 5 | Parcentile of L_{N5} (S/R) |
| Display Time Level | Display time-level (S/R) |
| Time Level Time Scale | Time scale of time-level display (S/R) |
| Ly Type | Additional processing type (S/R) |
| Output Level Range Upper | Output level range upper (S/R) |
| Output Level Range Lower | Output level range lower (S/R) |

I/O

| Command | Function | See page |
|-------------------------|-------------------------------------|----------|
| AC OUT | AC out (S/R) | |
| DC OUT | DC out (S/R) | |
| Communication Interface | Communication interface (S/R) | |
| Baud Rate | RS-232C baud rate (S/R) | |
| Comparator | Comparator (S/R) | |
| Comparator Level | Comparator level (S/R) | |
| Comparator Channel | Comparator band (S/R) | |

Store

| Command | Function | See page |
|------------|------------------------|----------|
| Store Mode | Store mode (S/R) | |

| | |
|---------------------------------|---|
| Store Name | Store name (S/R) |
| Measurement Time Preset | Measurement time (S/R) |
| Measurement Time (Num) | Measurement time of user setting (number) (S/R) |
| Measurement Time (Unit) | Measurement time of user setting (unit) (S/R) |
| Measurement Start Time | Measurement (operation) start time (R) |
| Measurement Stop Time | Measurement (operation) stop time (R) |
| Manual Address | Manual store address (S/R) |
| Lp Store Interval | L_p store interval (S/R) |
| Leq Calculation Interval Preset | L_{eq} calculation interval (S/R) |
| Leq Calculation Interval (Num) | L_{eq} calculation interval of user setting (number) (S/R) |
| Leq Calculation Interval (Unit) | L_{eq} calculation interval of user setting (unit) (S/R) |
| Timer Auto Start Time | Timer auto start time (S/R) |
| Timer Auto Stop Time | Timer auto stop time (S/R) |
| Timer Auto Interval | Timer auto measurement interval (S/R) |
| Sleep Mode | Sleep mode (S/R) |

Measurement

| Command | Function | See page |
|--------------------------------|---|----------|
| Windscreen Correction | Windscreen correction (S/R) | |
| Diffuse Sound Field Correction | Diffuse sound field correction (S/R) .. | |
| Delay Time | Delay time (S/R) | |
| Back Erase | Back erase (S/R) | |

Operation

| Command | Function | See page |
|---------------------------|--|----------|
| Frequency Weighting | Frequency weighting of main channel (S/R) | |
| Frequency Weighting (Sub) | Frequency weighting of sub channel (S/R) | |
| Time Weighting | Time weighting of main channel (S/R) | |
| Time Weighting (Sub) | Time weighting of sub channel (S/R) | |
| Measurement Elapsed Time | Measurement elapsed time (R) | |
| Underrange L_p | Underrange L_p (R)..... | |
| Underrange L_{eq} | Underrange L_{eq} (R) | |
| Overload L_p | Overload L_p (R) | |
| Overload L_{eq} | Overload L_{eq} (R)..... | |
| Overload Output | Overload output (R)..... | |

Data output

| Command | Function | See page |
|---------|--|----------|
| DOD | Level value shown on display (R) | |
| DRD | Continuous output (R) | |

Command Description

Communication

Echo

Echo back

Setting ON/OFF of echo back

| | |
|-----------------|-----------|
| Setting command | Echo, p1 |
| Parameter | p1= "Off" |
| | p1= "On" |

| | |
|-----------------|-------|
| Request command | Echo? |
|-----------------|-------|

| | |
|---------------|----|
| Response data | d1 |
|---------------|----|

| | |
|----------------|-----------------------------|
| Returned value | Same as for setting command |
|----------------|-----------------------------|

System

System version

System version information

Request system version information

| | |
|-----------------|---------------------|
| Request command | System _ Version?p1 |
| Parameter | p1= "NL" |
| | p1= "EX" |
| | p1= "WR" |

| | |
|---------------|-------------------------|
| Response data | d1= "x.x" (x is 0 to 9) |
|---------------|-------------------------|

When the parameter p1 is omitted, the request command means "System _ Version?NL"

There is no setting command

Clock

Current date and time

Setting current date and time

| | |
|-----------------|--|
| Setting command | Clock, p1/p2/p3 _ p4:p5:p6 |
| Parameter | p1= 2011 to 2099 (year) p2= 1 to 12 (month) p3= 1 to 31 (date) p4= 1 to 23 (time) p5= 0 to 59 (minute) p6= 0 to 59 (second) |
| Request command | Clock? |
| Response data | d1/d2/d3 _ d4:d5:d6 |
| Returned value | Same as for setting command |

Language

Displayed language

Setting displayed language

| | |
|-----------------|---------------------------------|
| Setting command | Language, p1 |
| Parameter | p1= "Japanese" p1= "English" |
| Request command | Language? |
| Response data | d1 |
| Returned value | Same as for setting command |

Cal Mode

Calibration mode

Setting calibration mode

| | |
|-----------------|----------------------------------|
| Setting command | Cal _ Mode, p1 |
| Parameter | p1= "Internal" p1= "Acoustic" |
| Request command | Cal _ Mode? |
| Response data | d1 |
| Returned value | Same as for setting command |

Index Number

Index number

Setting index number

| | |
|-----------------|-----------------------------|
| Setting command | Index _Number, p1 |
| Parameter | p1= 1 to 255 |
| Request command | Index _Number? |
| Response data | d1 |
| Returned value | Same as for setting command |

Key Lock

Key lock

Setting ON/OFF of key lock

| | |
|-----------------|-----------------------------|
| Setting command | Key _Lock, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Key _Lock? |
| Response data | d1 |
| Returned value | Same as for setting command |

Touch Panel Lock

Touch panel lock

Setting ON/OFF of touch panel lock

| | |
|-----------------|-----------------------------|
| Setting command | Touch _Panel _Lock, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Touch _Panel _Lock? |
| Response data | d1 |
| Returned value | Same as for setting command |

Backlight

Backlight

Setting ON/OFF of backlight

| | |
|-----------------|-----------------------------|
| Setting command | Backlight, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Backlight? |
| Response data | d1 |
| Returned value | Same as for setting command |

Backlight Auto Off

Backlight auto off

Setting time of backlight auto off

| | |
|-----------------|---|
| Setting command | Backlight_ Auto_ Off, p1 |
| Parameter | p1= "Short" (30 seconds) p1= "Long" (3 minutes) p1= "Cont" (continue) |
| Request command | Backlight_ Auto_ Off? |
| Response data | d1 |
| Returned value | Same as for setting command |

LCD

LCD

Setting ON/OFF of LCD

| | |
|-----------------|-----------------------------|
| Setting command | LCD, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | LCD? |
| Response data | d1 |
| Returned value | Same as for setting command |

LCD Auto Off

LCD auto off

Setting time of LCD auto off

| | |
|-----------------|--|
| Setting command | LCD _Auto _Off, p1 |
| Parameter | p1= "Off" p1= "Long" (10 minutes) p1= "Short" (1 minute) |
| Request command | LCD _Auto _Off? |
| Response data | d1 |
| Returned value | Same as for setting command |

Backlight Brightness

Backlight brightness

Setting backlight brightness

| | |
|-----------------|--|
| Setting command | Backlight _Brightness, p1 |
| Parameter | p1= "0" p1= "1" p1= "2" p1= "3" |
| Request command | Backlight _Brightness? |
| Response data | d1 |
| Returned value | Same as for setting command |

Battery Type

Battery tipe

Setting battery type

| | |
|-----------------|--------------------------------|
| Setting command | Battery _Type, p1 |
| Parameter | p1= "Alkaline" p1= "Nickel" |
| Request command | Battery _Type? |
| Response data | d1 |
| Returned value | Same as for setting command |

SD Card Total Size

SD memory card capacity

Request capacity of SD memory card

Request command SD _ Card _ Total _ Size?

Response data d1= 0 to 32768 (MByte)

There is no setting command

SD Card Free Size

SD memory card free space

Request free space of SD memory card

Request command SD _ Card _ Free _ Size?

Response data d1= 0 to 32768 (MByte)

There is no setting command

SD Card Percentage

SD memory card free space percentage

Request percentage of free space

Request command SD _ Card _ Percentage?

Response data d1= 0 to 100

There is no setting command

Display

Display Sub Channel

Display sub channel

Setting ON/OFF of sub channel display

Setting command Display _ Sub _ Channel, p1

Parameter p1= "Off"

p1= "On"

Request command Display _ Sub _ Channel?

Response data d1

Returned value Same as for setting command

Display Ly

Display additional processing

Setting ON/OFF of additional processing display

| | |
|-----------------|-----------------------------|
| Setting command | Display \square Ly, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Display \square Ly? |
| Response data | d1 |
| Returned value | Same as for setting command |

Display Leq

Display L_{eq}

Setting ON/OFF of L_{eq} display

| | |
|-----------------|-----------------------------|
| Setting command | Display \square Leq, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Display \square Leq? |
| Response data | d1 |
| Returned value | Same as for setting command |

Display LE

Display L_E

Setting ON/OFF of L_E display

| | |
|-----------------|-----------------------------|
| Setting command | Display \square LE, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Display \square LE? |
| Response data | d1 |
| Returned value | Same as for setting command |

Display L_{\max}

Display L_{\max}

Setting ON/OFF of L_{\max} display

Setting command Display $\square L_{\max}$, p1

Parameter p1= "Off"

p1= "On"

Request command Display $\square L_{\max}$?

Response data d1

Returned value Same as for setting command

Display L_{\min}

Display L_{\min}

Setting ON/OFF of L_{\min} display

Setting command Display $\square L_{\min}$, p1

Parameter p1= "Off"

p1= "On"

Request command Display $\square L_{\min}$?

Response data d1

Returned value Same as for setting command

Display $LN1$

Display L_{N1}

Setting ON/OFF of L_{N1} display

Setting command Display $\square LN1$, p1

Parameter p1= "Off"

p1= "On"

Request command Display $\square LN1$?

Response data d1

Returned value Same as for setting command

Display LN2

Display L_{N2}

Setting ON/OFF of L_{N2} display

| | |
|-----------------|-----------------------------|
| Setting command | Display \square LN2, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Display \square LN2? |
| Response data | d1 |
| Returned value | Same as for setting command |

Display LN3

Display L_{N3}

Setting ON/OFF of L_{N3} display

| | |
|-----------------|-----------------------------|
| Setting command | Display \square LN3, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Display \square LN3? |
| Response data | d1 |
| Returned value | Same as for setting command |

Display LN4

Display L_{N4}

Setting ON/OFF of L_{N4} display

| | |
|-----------------|-----------------------------|
| Setting command | Display \square LN4, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Display \square LN4? |
| Response data | d1 |
| Returned value | Same as for setting command |

Display LN5

Display L_{N5}

Setting ON/OFF of L_{N5} display

Setting command Display \square LN5, p1

Parameter p1= "Off"

p1= "On"

Request command Display \square LN5?

Response data d1

Returned value Same as for setting command

Percentile 1

Percentile of L_{N1}

Setting percentile of L_{N1}

Setting command Percentile \square 1, p1

Parameter p1= 1 to 999

* The percentile can be set 1% steps.

If you want to set the percentile to 10%, input 100.

* The input of 0.1% order is ignored.

Request command Percentile \square 1?

Response data d1

Returned value Same as for setting command

Percentile 2

Percentile of L_{N2}

Setting percentile of L_{N2}

Setting command Percentile \square 2, p1

Parameter p1= 1 to 999

* The percentile can be set 1% steps.

If you want to set the percentile to 10%, input 100.

* The input of 0.1% order is ignored.

Request command Percentile \square 2?

Response data d1

Returned value Same as for setting command

Percentile 3

Percentile of L_{N3}

Setting percentile of L_{N3}

Setting command Percentile $\square 3$, p1

Parameter p1= 1 to 999

* The percentile can be set 1% steps.

If you want to set the percentile to 10%, input 100.

* The input of 0.1% order is ignored.

Request command Percentile $\square 3$?

Response data d1

Returned value Same as for setting command

Percentile 4

Percentile of L_{N4}

Setting percentile of L_{N4}

Setting command Percentile $\square 4$, p1

Parameter p1= 1 to 999

* The percentile can be set 1% steps.

If you want to set the percentile to 10%, input 100.

* The input of 0.1% order is ignored.

Request command Percentile $\square 4$?

Response data d1

Returned value Same as for setting command

Percentile 5

Percentile of L_{N5}

Setting percentile of L_{N5}

Setting command Percentile $\square 5$, p1

Parameter p1= 1 to 999

* The percentile can be set 0.1% steps.

If you want to set the percentile to 10.5%, input 105.

Request command Percentile $\square 5$?

Response data d1

Returned value Same as for setting command

Display Time Level

Display time level

Setting ON/OFF of time-level display

| | |
|-----------------|-----------------------------|
| Setting command | Display _ Time _ Level, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Display _ Time _ Level? |
| Response data | d1 |
| Returned value | Same as for setting command |

Time Level Time Scale

Time scale of time-level display

Setting time scale of time-level display

| | |
|-----------------|-----------------------------------|
| Setting command | Time _ Level _ Time _ Scale, p1 |
| Parameter | p1= "20s" p1= "1m" p1= "2m" |
| Request command | Time _ Level _ Time _ Scale? |
| Response data | d1 |
| Returned value | Same as for setting command |

Ly Type

Additional processing type

Setting additional processing type

| | |
|-----------------|---|
| Setting command | Ly _ Type, p1 |
| Parameter | p1= "Off" p1= "Leq" p1= "Lpeak" p1= "Ltm5" |
| Request command | Ly _ Type? |
| Response data | d1 |
| Returned value | Same as for setting command |

Output Level Range Upper

Output level range upper

Setting output level range upper

The value cannot be set below the value of “Output Level Range Lower”

Setting command Output _ Level _ Range _ Upper, p1

Parameter p1= 70 to 130 (10 dB steps)

Request command Output _ Level _ Range _ Upper?

Response data d1

Returned value Same as for setting command

Output Level Range Lower

Output level range lower

Setting output level range lower

The value cannot be set more than the value of “Output Level Range Upper”

Setting command Output _ Level _ Range _ Lower, p1

Parameter p1= 20 to 80(10 dB steps)

Request command Output _ Level _ Range _ Lower?

Response data d1

Returned value Same as for setting command

I/O

AC OUT

AC out

Setting AC output channel

| | | |
|-----------------|--------------|--------------|
| Setting command | AC _ OUT, p1 | |
| Parameter | p1= "Off" | |
| | p1= "Main" | (Inter lock) |
| | p1= "A" | |
| | p1= "C" | |
| | p1= "Z" | |

| | |
|-----------------|-----------|
| Request command | AC _ OUT? |
|-----------------|-----------|

| | |
|---------------|----|
| Response data | d1 |
|---------------|----|

| | |
|----------------|-----------------------------|
| Returned value | Same as for setting command |
|----------------|-----------------------------|

DC OUT

DC out

Setting ON/OFF of DC output

| | | |
|-----------------|--------------|------|
| Setting command | DC _ OUT, p1 | |
| Parameter | p1= "Off" | |
| | p1= "Main" | (ON) |

| | |
|-----------------|-----------|
| Request command | DC _ OUT? |
|-----------------|-----------|

| | |
|---------------|----|
| Response data | d1 |
|---------------|----|

| | |
|----------------|-----------------------------|
| Returned value | Same as for setting command |
|----------------|-----------------------------|

Communication Interface

Communication interface

Setting communication interface

| | |
|-----------------|--|
| Setting command | Communication_Interface, p1 |
| Parameter | p1= "Off" p1= "USB" p1= "RS232C" |
| Request command | Communication_Interface? |
| Response data | d1 |
| Returned value | Same as for setting command |

Baud Rate

RS-232C baud rate

Setting RS-232C baud rate

| | |
|-----------------|---|
| Setting command | Baud_Rate, p1 |
| Parameter | p1= "9600" p1= "19200" p1= "38400" p1= "57600" p1= "115200" |
| Request command | Baud_Rate? |
| Response data | d1 |
| Returned value | Same as for setting command |

Comparator

Comparator

Setting ON/OFF of comparator

| | |
|-----------------|-----------------------------|
| Setting command | Comparator, p1 |
| Parameter | p1= "Off" p1= "On" |
| Request command | Comparator? |
| Response data | d1 |
| Returned value | Same as for setting command |

Comparator Level

Comparator level

Setting comparator level

| | |
|-----------------|-----------------------------|
| Setting command | Comparator_Level, p1 |
| Parameter | p1= 25 to 130 (1 steps) |
| Request command | Comparator_Level? |
| Response data | d1 |
| Returned value | Same as for setting command |

Comparator Channel

Comparator band

Setting comparator band

| | |
|-----------------|-----------------------------|
| Setting command | Comparator_Channel, p1 |
| Parameter | p1= "Main" p1= "Sub" |
| Request command | Comparator_Channel? |
| Response data | d1 |
| Returned value | Same as for setting command |