

# PMDG B738 Checklist

## Cockpit Prep

### MCDU -- FS ACT -- GND SVCS -- GND POWER REQUEST

Battery (OHP)	ON
Ground Power (OHP)	ON
Nav x 2 (OHP)	NAV
Disp Sel (OHP)	HDG/STS
Emergency Lights (OHP)	ON
Window Heat x4 (OHP)	ON
Probe Heat x2 (OHP)	ON
APU (OHP)	ON/START

### Tablet - Load Flight Plan

### MCDU Set Up

MENU -- FMC -- POS INIT -- Set Position  
ROUTE - FLT PLAN REQUEST - SIMBRIEF -  
SET PAYLOAD - SET FUEL - SELECT RTE -  
LOAD - ACTIVATE - EXEC  
DEP/ARR -- Select RNWY / DEP SID --  
DEP/ARR -- Select RNWY / ARR STAR --  
LEGS - CHECK FOR DISCONS

### MCDU Set Up CONT.....

INIT REF - PERF INIT REQUEST - LOAD - EXEC

Check CRZ ALT - Amend if needed

### Tablet Calculate Take Off Performance

MCDU - N1 LIMIT - ENTER SEL TEMP & SEELECT TO  
TAKEOFF - ENTER FLAPS - CLICK CG TWICE TO POPULATE  
CLICK V1, VR, V2 TO POPULATE  
SET TRIM WHEEL

FD x2 (MCP)	ON
SET BARO (MCP)	LOCAL

Seat Belts (OHP)	ON
Yaw Damper (OHP)	ON
Cabin Pressure (OHP)	CRUIZE ALT
Bus Gen APU GEN x2 (OHP)	CLICK DOWN
Anit Collision Lights (OHP)	ON
APU Bleed (OHP)	ON

## Pushback & Engine Start

### GSX - Request Pushback

### MCDU - MENU - FS ACTIONS - GROUND SERVICES

#### REMOVE GPU CART & WHEEL CHOCKS

Auto Throttle (MCP)	ARM
Speed (MCP)	SET TO V2
LNAV (MCP)	ON
VNAV (MCP)	ON
<u>Set Runway Heading (MCP)</u>	
<u>Set Transition Altitude (MCP)</u>	
Fuel Pump (x4 or x6) (OHP)	ON
Hyd Pumps x2 (OHP)	ON

### Start Pushback

Engine Start (OHP)	Dial 2 = GRD
N2 @20% Fuel Switch 2 (THR PANEL)	ON
<u>Engine Start Dail 2 Auto clicks back to OFF</u>	
Engine Start (OHP)	Dial 1 = GRD
N2 @20% Fuel Switch 1 (THR PANEL)	ON
<u>Engine Start Dail 2 Auto clicks back to OFF</u>	

## Before Taxi / Taxi / Hold Short

### Before Taxi

Bus Trans GEN1 GEN2 (OHP)	ON
APU Bleed (OHP)	OFF
APU (OHP)	OFF
Packs x2 (OHP)	AUTO
Isolation Valve (OHP)	AUTO
Engine Start (OHP)	Dial 1 & 2 = CONT
Taxi Lights (OHP)	ON
Rnwy Turn Off Lights (OHP)	ON AS REQ
Annunciator (MCP)	CHECK NO LIGHTS STAY ON
Flaps (THR PANEL)	SET T/O
Transponder	ALT RTPG OFF

### During Taxi / Hold Short

Position Lights (OHP)	STROBE & STEADY
Landing Lights (OHP)	ON
Terrain (TERR MCP)	ON
DOUBLE CHECK FLAPS / TRIM	
Set Auto Brake	RTO
Transponder	TA/RA

## Take Off / After Take Off

### Line Up / Take Off

Release Parking Brake & Hold on Toe Brake  
Set thrust to 40% N1  
Release Toe Brake  
Push TO GA  
At VR Pull back to Positive Climb  
Raise Landing Gear  
Set Landing Gear to OFF when Retracted  
 At Above 400ft Select AP at Pilots Discretion

### Climb

At '1' on Speed Tape	Retract Flaps Fully
Taxi Lights (OHP)	OFF
RNWX Turn Off Lights (OHP)	OFF
Engine Switches (OHP)	OFF
Auto Brake	OFF
At Transition Alt (MCP)	Set BARO STD
Weather Radar (WX MCP)	ON

### At 10,000ft

Landing Lights (OHP)	OFF
Seat Belts (OHP)	AUTO

### At Cruise

Adjust Heading to Align with Nose Direction

## Decent Planning

### Information Needed

Airport Elevation  
Transition ALT  
ILS Frequency  
Runway Course  
Glideslope Intercept  
Local BARO  
Minimums

### Just Before TOD / Decent Start

#### Complete before 10,000ft

Set Runway Elevation (OHP)  
Set ALT (MCP)  
Set Minimums (MCP)  
 Pre Select Local BARO (MCP)  
 MCDU - DES - FORECAST - DES WINDS REQUEST - EXEC  
 INIT REF - CLICK REQ FLAPS TWICE TO POPULATE  
Set ILS Freq Active in both side of NAV Radio  
Set Course to Runway heading Both Sides (MCP)  
Set Autobrake (MCP)

## Approach

### Passing 10,000ft

Seatbelt Light (OHP)	AUTO
Landing Lights (OHP)	ON

### At Transition Level Set BARO to LOCAL

At or just before 'UP' on Speed Tape Set Flaps '1'  
At '1' on Speed Tape Set Flaps '5'

### Landing Procedure

#### - When on ILS Intercept

Approach Mode (MCP)	ON
Auto Pilot (MCP)	CHECK 'A' ON

### When G/S Alive

Landing Gear	DOWN
Flaps	Set 15
Speedbrake	ARM
Set Speed to Manual	SPD INTV

### Set Speed to REF (15 Bug)

Engine Switches (OHP)	CONT
Flaps	To Landing Setting

### Set Speed to VREF (Landing Flaps Bug)

### Final Approach

AP + Auto Throttle	OFF AT OWN DISCRETION
--------------------	-----------------------

## After Landing

### After Landing

Flaps	UP
Speedbrake	OFF
Weather Radar (WX MPC)	OFF
Autobrake (MCP)	OFF

### After Vacating Runway

Exterior Lights (OHP)	AS NEEDED
Engine Start Switches (OHP)	OFF
Probe Heat Switches (OHP)	OFF
APU (OHP)	START
Transponder	ALT RPTG

### At Gate

Parking Brake	ON
APU Gen (OHP)	ON
Eng Start Levers	OFF
Seatbelt Signs (OHP)	OFF
Anti Collision Light (OHP)	OFF
Fuel Pump Switches (OHP)	OFF
Anti Ice Switches (OHP)	OFF
Hydraulic Switches (OHP)	ENG - ON / ELEC - OFF
Recirculation Fans (OHP)	AUTO
Packs (OHP)	AUTO
Isolation Valve (OHP)	OPEN
Bleed Air Switches (OHP)	ALL ON
Exterior Lights (OHP)	OFF
FD (MCP)	BOTH OFF
Transponder	STBY

### MCDU -- FS ACT -- GND SVCS -- GND POWER REQUEST

Ground Power	ON
APU (OHP)	SHUT DOWN

### Final Shutdown

IRS x2 (OHP)	OFF
Emergency Exit (OHP)	OFF
Window Heat Switches x4 (OHP)	OFF
Packs (OHP)	OFF
Ext Power (OHP)	OFF
Position Lights (OHP)	OFF
Battery (OHP)	OFF