

1 icc2\_shell> man report\_auto\_floorplan\_constraints

2

3 2. Synopsys Commands

Command Reference

4 report\_auto\_floorplan\_constraints

5

6 NAME

7 report\_auto\_floorplan\_constraints

8 Reports constraints set by the set\_auto\_floorplan\_constraints  
9 command.

10

11 SYNTAX

12 status report\_auto\_floorplan\_constraints

13 [-control\_type]

14 [-shape]

15 [-side\_length]

16 [-side\_ratio]

17 [-core\_utilization]

18 [-boundary]

19 [-orientation]

20 [-coincident\_boundary]

21 [-core\_offset]

22 [-row\_core\_ratio]

23 [-flip\_first\_row]

24 [-honor\_pad\_limit]

25 [-site\_def]

26 [-use\_site\_row]

27 [-origin\_offset]

28 [-row\_pattern]

29

30 ARGUMENTS

31 -control\_type

32 Reports the control **type** of the core **or** die. The **default** is  
33 ratio.

34

35 -shape Reports the core boundary shape. The **default** is rectangular (R).

36

37 -side\_length

38 Reports the length of the edges of the core shape.

39

40 -side\_ratio

41 Reports the ratio of the edges of the core shape.

42

43 -core\_utilization

44 Reports the core utilization. The **default** is 0.7.

45

46 -boundary

47 Reports the boundary of the core shape.

48

49 -orientation

50 Reports the orientation of the specified core shape.

51

52 -coincident\_boundary

53 Reports whether to keep the same existing boundary.

54

55 -core\_offset

56 Reports the distance between the side of the core **and** boundary.

57

58 -row\_core\_ratio

59 Reports the channel ratio between **cell** rows. The **default** is 1.0.

60

61 -flip\_first\_row

62 Reports whether the command flips the first row at the bottom of  
63 the core area **for** horizontally placed **cell** rows **or** flips the  
64 leftmost row **for** vertically placed **cell** rows. By **default**, **this**  
65 option is enabled.

66

67 -honor\_pad\_limit

68 Reports whether to adjust the core **and** die size to honor pad-  
69 limited designs.

```
70
71     -site_def
72         Reports the site def name used.
73
74     -use_site_row
75         Reports whether to create the site rows.
76
77     -origin_offset
78         Reports the location of lower-left corner of the die boundary
79         bounding box with respect to the origin of the block.
80
81     -row_pattern
82         Reports the row pattern used for floorplan.
83
```

#### DESCRIPTION

```
85     This command reports the constraints that create a floorplan with a
86     boundary, core, site arrays (or rows), and wire tracks. Before execut-
87     ing this command, you must open a physical design by using the
88     open_block command or create a design by using the read_verilog or
89     read_verilog_outline command.
90
```

#### EXAMPLES

```
92     The following example reports the constraint of utilization to be 0.8.
93
```

```
94     prompt> report_auto_floorplan_constraints -core_utilization
95     1
96
```

```
97     The following example reports the preferred core shape to be rectangle
98     (R).
99
```

```
100     prompt> report_auto_floorplan_constraints -shape
101     1
102
```

```
103     The following example reports the preferred core length to create the
104     floorplan.
105
```

```
106     prompt> report_auto_floorplan_constraints -side_length
107     1
108
```

#### SEE ALSO

```
110     report_auto_floorplan_constraints(2)
111     create_io_ring(2)
112     remove_io_rings(2)
113     report_io_rings(2)
114
```

Version S-2021.06-SP5

Copyright (c) 2022 Synopsys, Inc. All rights reserved.

```
117 icc2_shell>
118
```