

*Before initial operation  
read these instructions  
thoroughly, and retain  
for future reference.*

This manual is primarily intended to give operators instructions for YASNAC MX1 programming, operation and maintenance.

This manual applies to the basic and optional features of YASNAC MX1. The optional features are marked with a dagger. For the specifications of your YASNAC MX1, refer to the machine tool builder's manual.

