

**Instruction Manual**

**PR 4000**

**Power supply/readout unit  
for one Baratron® pressure transducer  
or one mass flow controller/meter**

Version: 01.12.96

# Contents

|   |           |
|---|-----------|
| <b>1. General.....</b>                                | <b>4</b>  |
| 1.1. Purpose.....                                     | 4         |
| 1.2. Technical data .....                             | 4         |
| 1.3. CE compliance .....                              | 5         |
| 1.4. Cables.....                                      | 5         |
| 1.5. Service.....                                     | 5         |
| <b>2. Safety instructions .....</b>                   | <b>6</b>  |
| <b>3. Installation and startup.....</b>               | <b>7</b>  |
| 3.1. Control elements and connectors.....             | 7         |
| 3.1.1. Front panel .....                              | 7         |
| 3.1.2. Back panel .....                               | 8         |
| 3.2. Scope of supply.....                             | 9         |
| 3.2.1. Device version .....                           | 10        |
| 3.3. Installation .....                               | 11        |
| 3.4. Startup.....                                     | 11        |
| <b>4. Operation .....</b>                             | <b>12</b> |
| 4.1. The operating concept.....                       | 12        |
| <b>5. The menus .....</b>                             | <b>14</b> |
| 5.1. The menu tree.....                               | 14        |
| 5.2. The Actual Value/Setpoint menu .....             | 15        |
| 5.3. The Actual Value/Bargraph menu.....              | 16        |
| 5.4. The Actual Value/Totalized menu (optional) ..... | 17        |
| 5.5. The Autozero menu .....                          | 18        |
| 5.6. The Setpoint menu.....                           | 19        |
| 5.7. The Gain menu.....                               | 20        |
| 5.8. The Linearization menu (optional).....           | 21        |
| 5.9. The Input/Output Voltage menu (optional) .....   | 22        |
| 5.10. The Maximum Limit/Minimum Limit menu .....      | 23        |
| 5.11. The Limit Mode/Limit Memory menu.....           | 24        |
| 5.12. The Reset Relays/Leak Test menu (optional)..... | 25        |
| 5.13. The Signal Processing Mode menu .....           | 26        |
| 5.14. The Sensor and Interface menu .....             | 27        |
| 5.15. The Device menu.....                            | 28        |
| 5.16. The Baud Rate and Parity menu.....              | 29        |
| 5.17. The Reset menu .....                            | 30        |
| <b>6. Signal processing .....</b>                     | <b>31</b> |
| <b>7. Special functions .....</b>                     | <b>32</b> |
| 7.1. Leak test (optional).....                        | 32        |
| 7.2. Linearization (optional) .....                   | 33        |
| 7.3. Process monitoring (optional) .....              | 34        |
| 7.3.1. Limit modes.....                               | 34        |
| 7.3.2. Limit memory .....                             | 35        |
| 7.4. Autozero.....                                    | 36        |
| 7.5. Process safeguarding.....                        | 36        |
| 7.6. The digital interface.....                       | 36        |

|   |           |
|---|-----------|
| 7.7. Interfaces.....  | 37        |
| 7.7.1. RS232 interface.....   | 38        |
| 7.7.2. RS485 interface.....   | 38        |
| 7.7.3. Option (IEC 488) .....   | 38        |
| <b>8. External communication.....</b>   | <b>39</b> |
| 8.1. Structure of the multipoint interface according to DIN 66 349 Part 2 ..... | 39        |
| 8.2. Protocols.....   | 40        |
| 8.2.1. RS232 interface.....   | 40        |
| 8.2.2. RS485 interface.....   | 40        |
| 8.2.3. Optional interface .....   | 40        |
| 8.3. Commands .....   | 41        |
| 8.3.1. Structure of the Remote Interface Language .....                         | 41        |
| 8.3.2. Special byte formats .....   | 42        |
| 8.3.3. Commands.....  | 44        |
| 8.3.3.1 <i>Command syntax</i> .....   | 44        |
| 8.3.3.2 <i>General commands</i> .....   | 45        |
| 8.3.3.3 <i>Commands which set process parameters</i> .....                      | 50        |
| 8.3.3.4 <i>Commands which read process parameters</i> .....                     | 57        |
| <b>9. Pin assignment of connectors on the back panel.....</b>                   | <b>64</b> |
| 9.1. Channel 1 (flow configuration).....  | 64        |
| 9.2. Channel 1 (pressure configuration, optional).....                          | 64        |
| 9.3. 20 mA connector (optional) .....   | 65        |
| 9.4. EXTERNAL connector .....   | 65        |
| 9.5. Relay connector .....  | 66        |
| 9.6. RS232 connector.....   | 66        |
| 9.7. RS485 connector.....   | 67        |
| 9.8. IEEE connector.....  | 67        |

# **1. General**

## **1.1. Purpose**

The PR4000 is a device which is specifically designed for operating gas flow controllers/meters and pressure sensors (power supply, display, interfaces).

The device is extremely flexible and can be configured either directly or using a PC.

## **1.2. Technical data**

- Connectable sensors: flow controllers/meters and pressure sensors/controllers (single-channel)
- Digital interfaces: RS232, RS485, IEEE488 (optional)\*
- Electrical isolation of digital interfaces
- Tested according to EN and CE standards
- 2 relays for limit monitoring
- Analog output (16-bit resolution)
- Gas counter (totalizer, optional)
- Leak test (optional)
- Freely selectable units (mbar...SCCM)
- Autozeroing
- Linearization (optional)
- Memory function for minimum and maximum values
- Non-volatile memory, i.e. the last setting remains stored after the device is switched off
- Resolution: 4.5 digits (16 bits)
- Accuracy: 0.01%,  $\pm 1$  digit  
TC, Input: 0.1 mV / K ( $R_{quelle} < 1 \text{ Ohm}$ )  
TC, Output: 0.075 mV / K
- Power supply  
for controllers or sensors: 24 V (1.0 A),  $\pm 15$  V (0.8 A, opt. 1.5 A)\*
- Mains power supply: 115/230 VAC, 60/50 Hz
- Ambient temperature: 15° - 40° C
- Storage temperature: -20° - 70°C
- Power input 60 VA/75 VA/115 VA (acc. to option)

\* Only one option can be installed at a time.

- Fuse Ratings:
 

|                            | 115VAC | 230VAC |
|----------------------------|--------|--------|
| 60 VA ( $\pm 15V$ , 0.5A): | T630mA | T315mA |
| 75 VA (+ 24V, 1A):         | T630mA | T315mA |
| 115VA ( $\pm 15V$ , 1.5A): | T1A    | T500mA |
  
- Intern fuses:
 

|                            | F1    | F2   | F3     |
|----------------------------|-------|--|--------|
| 60 VA ( $\pm 15V$ , 0.5A): | T1.4A | T1.4A  | T100mA |
| 75 VA (+ 24V, 1A):         | T1A   | T1A  | T100mA |
| 115VA ( $\pm 15V$ , 1.5A): | T2.5A | T2.5A  | T100mA |
| Position:                  | Front | <div style="border: 1px solid black; padding: 10px; display: inline-block; text-align: center;">           F2<br/><br/>F1<br/><br/>F3         </div> |        |
|                            |       |  |        |
|                            |       |  |        |
|                            |       |  |        |
  
- Pollution Degree: II
- Installation Category: II
- Weight: approx. 1.5 kg
- Dimensions: 240 mm x 240.5 mm x 88.1 mm (L x W x H)

### **1.3. CE compliance**

The device complies to actual european standards and has the CE label. The device was tested with the following standards:

- EN50011 emissions (group 1, class B)
- EN50082-2 disturbance
  - IEC801-2
  - ENV50140
  - IEC801-4
  - ENV50141
- EN61010 safety

### **1.4. Cables**

The cables applied to the device, needs to fulfill some requirements:

1. The cable must have a shield, which covers all lines.
  2. The connectors must have a metal case, which has contact to the cables shield on the hole circumference of the cable.
  3. The connector must make contact to the devices case (ground), which encloses all lines.
  4. This rules apply to all cables connected to the device (digital interfaces included).
- The power cord must have a VDE label.

### **1.5. Service**

In case of technical problems, please contact a MKS service facility, e.g.:

MKS Instruments, Schatzbogen 43, D-81829 München, Germany

## 2. Safety instructions

The device has been constructed using state-of-the-art technology and is extremely reliable.

It can nevertheless represent a hazard to the user or to third parties if:

- it is operated by unqualified persons
- it is not operated in the proper manner
- it is used for a purpose for which it is not intended

The Instruction Manual and the binding accident precautions, as well as the generally accepted rules of engineering practice, must be observed at all times in the interests of work safety and optimum functioning.



**Only accessories authorized by the manufacturer are allowed to be used.**



**The device must not be operated in rooms containing potentially explosive atmospheres.**



**Only original spare parts and accessories are allowed to be used.**



**The device is only allowed to be opened by an MKS service technicians**

When the device is open, there is a risk of electric shock and consequently danger to life. Internal fuses must always be replaced by an MKS service technician.



**The power supply must always be disconnected before the device is cleaned.**




**A dry cloth must be used to clean the device.**

Failure to observe these safety instructions renders all warranty claims vis-à-vis the manufacturer invalid.

## **3. Installation and startup**

### **3.1. Control elements and connectors**


#### **3.1.1. Front panel**



**3.1.2. Back panel**

The layout of the back panel varies according to the installed option and interfaces. The back panel shown below is merely an example.

Channel 2 is not used in this version.





### ***3.2. Scope of supply***


The scope of supply of the PR4000 is as follows:

- Mains cable (Order No. Y-0984492)
- Mating connector, incl. casing (Order No. ZB-41)
- Instruction Manual (this document)  
German (Order No. Y-1957785)  
English (Order No. Y-1958785)

**3.2.1. Device version**

Several different versions of the device are available, depending on the purpose for which it is to be used and on your particular requirements.

The five parts of the order designation are explained below:



Note: N = not available  
Options cannot be retrofitted by the customer

**Example:**

The following are examples of order designations:

- PR4000-S2V1N                      Version for first-time buyers
- PR4000-E2V1I                    +/- 15V with V.24, electrical isolation and enhanced functions

### **3.3. Installation**

The device must be installed in a dry, heated room.



**The device must be installed such that air can circulate freely while it is in operation. Do not cover the openings at the back of the device and in the base.**

### **3.4. Startup**

Check that the voltage selector switch is set to the correct mains voltage.

The device must be connected to a standard socket outlet with the enclosed cable. If the power supply is isolated externally, the isolation components must be capable of switching at 0.5 A and 230 VAC.

Gas flow controllers and pressure sensors must be connected to the device according to the pin assignment of the connectors on the back panel. If necessary, a PC can be connected to the digital interface (RS232, RS485 or IEEE).

The Power switch must be set to ON in order to switch on the device. The *Actual Value/Setpoint* menu then appears on the display. All settings entered the last time the device was used are still stored.

The parameters must be configured according to your particular requirements before the device is started up for the first time. The procedures for setting these parameters are described in detail below.

## **4. Operation**

### **4.1. The operating concept**

The PR4000 is operated and configured by means of menus (two-line LCD). The menus are organized in a simple tree hierarchy (see 'The menu tree'). All the menus can be accessed and displayed easily: you can change from one menu to another using the up/down arrow keys or return to the main menu at any time by pressing the ESC key.

#### **Switching on Edit mode**

Edit mode can be switched on or off in the menus. You can enter numeric values in Edit mode, alter variables, etc. There are two ways of switching on Edit mode:

1. With the ENTER key
2. With the left/right arrow keys

When you switch on Edit mode, the cursor appears as a flashing underscore below the first or last alphanumeric character. You can move the cursor within a line using the left/right arrow keys or change the preset values with the up/down arrow keys.

If '9' is displayed and you press the up/down arrow keys again to scroll the number, the display automatically creates two digits ('10'); the same applies analogously in the opposite direction.

If, when you exit Edit mode by pressing the ENTER key, the value you have set is outside the valid range, the highest or lowest permitted value is stored instead.

#### **Switching off Edit mode**

You can switch off Edit mode again by pressing the ENTER key. The entered values are not stored until you press the ENTER key.

You can also exit Edit mode with the ESC key. In this case, however, the values are not stored.

#### **Decimal point**

The decimal point is needed to display floating-point numbers and can be set with the *Range (RNG)* function in the *Setpoint* menu. You can mark the decimal point in this menu with the left/right arrow keys and shift it with the up/down keys. The up arrow shifts the cursor to the left, while the down arrow shifts it to the right. The new decimal point setting takes effect in all the menus in which measured values or values directly referred to them are displayed. It does not affect device parameters, such as *Gain*.

#### **Switching the setpoint on and off**

You can switch the setpoint of a controller on and off with the ON and OFF keys. The OFF key has the highest priority of all keys for safety reasons. As soon as you switch off the setpoint, the output voltage becomes slightly negative (-0.5 V). This ensures that if a valve is fitted, it is closed.

### **Programming with a PC or terminal**

All the values which appear on the display refer to processes that are taking place at a particular instant in time. Values that are programmed with a PC or terminal (connected to the digital interface) are displayed immediately. Example: If the setpoint is reprogrammed via the interface, this change is displayed instantly in all the menus concerned.

The keypad can be locked while you program with a PC or terminal.

### **Trigger functions**

Trigger functions (functions which trigger an immediate system response) are displayed immediately (DONE or FAIL). The display time is 0.5 seconds.

### **Negative values**

Negative values are displayed with a preceding minus sign. To enter a negative value, you must continue scrolling when the value 'zero' is displayed. All values from then on will have a negative sign. You can change negative values to positive values in the same way.

## **5. The menus**


### **5.1. *The menu tree***

The PR4000 has the following menus:

1. Actual Value/Setpoint
2. Actual Value/Bargraph
3. Actual Value/Totalized (optional)
4. Autozero
5. Setpoint
6. Gain
7. Linearization (optional)
8. Input/Output Voltage
9. Maximum Limit/Minimum Limit
10. Limit Mode/Limit Memory
11. Reset Relays/Leak Test (optional)
12. Signal Processing Mode
13. Sensor and Interface
14. Device
15. Baud Rate and Parity
16. Reset

The menus are linear, in other words you cannot branch to submenus.

## 5.2. The Actual Value/Setpoint menu



The image shows a yellow rectangular box representing a screen display. Inside the box, there are two lines of text in a monospaced font. The first line reads 'PRES 00.000 mbar' and the second line reads 'SETP 02.000 OFF'.

*Fig. 1: The Actual Value/Setpoint menu*

**The first line** shows the currently valid sensor value. The word 'PRES' in Fig. 1 indicates that the displayed value refers to the pressure of a pressure sensor. It is also possible to connect a flow controller (FLOW) or a temperature sensor (TEMP), etc. You can change the display mode in the *Sensor* menu.

Fig. 1 shows the measured value in millibars. You can set a different measurement unit in the *Setpoint* menu.

The setpoint can be switched on and off **in the second line** (ON/OFF).

It is set to OFF in Fig. 1. You can also alter the value of the setpoint here by switching on Edit mode (with the ENTER key) and then increasing it or reducing it with the up and down arrow keys respectively.

### 5.3. The Actual Value/Bargraph menu




Fig. 2: The Actual Value/Bargraph menu

The **first line** of the menu shows the current pressure (for example).

The **second line** contains a semigraphic consisting of 16 bars. Each bar is made up of seven pixels in the vertical direction and five pixels in the horizontal direction.





Fig. 3: Example of a semigraphic

The top part of the bar shows the current sensor value as a percentage of the upper range value (specified with the Range function). The limits are indicated in the bottom part. In the area between the limits, the complete bar is shaded.



#### **5.4. The Actual Value/Totalized menu (optional)**




*Fig. 4: The Actual Value/Totalized menu*

**The first line** shows the gas flow, for example, in other words in this case the number of cubic centimeters of gas flowing per minute. You can select a different display in the *Sensor* and *Setpoint* menus.

**The second line** indicates the total gas flow computed by the gas counter over a specified period of time (up to 694.5 days). The result is referred to as the 'totalized value'.

If the sensor value is  $< 0$ , the totalizer stops counting (status = OFF). Negative values are thus not subtracted.

### 5.5. The Autozero menu



*Fig. 5: The Autozero menu*

The autozero function can be activated **in the first line**. To do so, switch on Edit mode in this menu and press the ENTER key. The system message 'DONE' then appears briefly to indicate that the autozero function was performed. You can only activate this function if the setpoint is switched off. If you attempt to activate autozero with the setpoint switched on, the word 'FAIL' will appear on the display.

You can activate the optional 'reset totalizer' function **in the second line** in the same way as the autozero function. The system message which appears is likewise 'DONE'. This function resets the totalizer (gas counter) to zero. You can activate it at any time.

## 5.6. The Setpoint menu




Fig. 6: The Setpoint menu

You can set the value of the setpoint **in the first line**.

The measurement unit, the range value and the decimal point can be set **in the second line**.

You must switch on EDIT mode in order to change the measurement unit. You can then mark the unit and select a new one with the up/down arrow keys.

### Changing the measurement unit

You can set the following measurement units in the second line:

| Table 1: Available measurement units |                   |        |                  |         |
|--------------------------------------|-------------------|--------|------------------|---------|
| μbar                                 | mbar              | bar    |                  |         |
| mTorr                                | Torr              | kTorr  |                  |         |
| Pa                                   | kPa               |        |                  |         |
| mH <sub>2</sub> O                    | cH <sub>2</sub> O | PSI    | N/m <sup>2</sup> |         |
| SCCM/CC                              | SLM/L             | SCM/CM | SCFH/CF          | SCFM/CF |
| mA                                   | V                 | %      | C                |         |

mHG == kTorr, mmHg == Torr

CC = cubic centimeter, L = liter, CM = cubic meter, CF = cubic foot  
(the units after the "/" refer to the gas counter)


### Setting the decimal point

For details of how to set the decimal point, please refer to chapter 4.1. *The operating concept*.

#### Please note:

If you shift the decimal point, the change takes effect in all the menus in which measured values or values directly referred to them are displayed. It does not affect device parameters, such as *Gain*.

### 5.7. The Gain menu




*Fig. 7: The Gain menu*

You can define correction values in the *Gain* menu.

You can set the gain value (e.g. the gas correction factor) in **the first line**.  
This factor corrects the deviation of a gas flow controller if a gas other than  $N_2$  is used.

**The second line** shows the value which is valid for the autozero function. You can also set the offset manually here. The offset is the fault voltage which is subtracted from the measured value.

### **5.8. The Linearization menu (optional)**



```
XLIN      0  %  
  
YLIN 00.000 bar
```

*Fig. 8: The Linearization menu*

You can define the linearization values for the X and Y-axes in the Linearization menu.

**The first line** shows the reference point in percent.

**The second line** contains the characteristic value. The interpolation values are distributed equidistantly along the X-axis (10 %).

### 5.9. The Input/Output Voltage menu (optional)




Fig. 9: The Input/Output Voltage menu


You can set the full-scale values for the output voltage (FSOUT; upper range value of the devices) and the input voltage (FSIN) in the Input/Output Voltage menu. Both the values themselves and the measurement units can be defined here.

You can set the measurement units shown in the table below for FSIN (input voltage) **in the first line**. If you are using the mA interface, you must set the resistances accordingly by altering the jumpers inside the device (they are preset by the manufacturer).

| mV                  | mA   | mA 2 | mA 5 | mA 4                | mA 24 | mA 54 |
|---------------------|------|------|------|---------------------|-------|-------|
|                     | 100Ω | 200Ω | 500Ω | 100Ω                | 200Ω  | 500Ω  |
| 0 - 20 mA interface |      |      |      | 4 - 20 mA interface |       |       |

You can set mV or  $\mu$ A as the measurement unit for FSOUT (output voltage) **in the second line**. Physical output is always a voltage.

### **5.10. The Maximum Limit/Minimum Limit menu**




*Fig. 10: The Maximum Limit/Minimum Limit menu*

You can define the limit values (maximum and minimum) for limit monitoring (relays) and the leak test in this menu.

You can only set the values here and not the measurement units.

### 5.11. The Limit Mode/Limit Memory menu



*Fig. 11: The Limit Mode/Limit Memory menu*


The limit mode can be set to one of the following **in the first line**: SLEEP, LIMIT, BAND or LEAK.

The meanings of the modes are explained in detail in chapter 7.3.1. *Limit modes*.

The limit memory can be set to the ON or OFF status **in the second line**. This memory stores a non-recurrent limit violation. If the limit memory is set to ON, it registers a single violation of a limit value. Even if the limit is exceeded several times, only one violation is registered. Please refer to chapter 7.3.2. *Limit memory* for further details.




### 5.12. The Reset Relays/Leak Test menu (optional)



*Fig. 12: The Reset Relays/Leak Test menu (mode 1)*

Activating 'Reset relays' in **the first line** causes the trip limit relays to be reset (trigger function) if the limit memory option is set to ON in the *Limit Mode/Limit Memory* menu. Otherwise, this line has no meaning.


If LIMIT MODE is set to LEAK in the *Limit Mode/Limit Memory* menu, the first line contains the words 'Start Leak Test' instead of 'Reset Relays', as shown below:



*Fig. 13: The Reset Relays/Leak Test menu (mode 2)*

You can set the timeout time for the leak test in both modes **in the second line** of the menu. Please refer to chapter 7.1. *Leak test (optional)* for further details about the start procedure and the leak test itself.

### 5.13. The Signal Processing Mode menu



*Fig. 13: The Signal Processing Mode menu*

The signal processing mode (SIG. MODE) can be set **in the first line** to either independent (INDEP.) or external (EXTERNAL). EXTERNAL means that the setpoint is preset externally as an analog value via the EXTERNAL interface (pin 7). INDEP. means that the setpoint (SETP) is preset via the keyboard or the digital interface.

You can specify the display mode **in the second line**:

| Display       | Suitable for  |
|---------------|---|
| <b>DIRECT</b> | Direct specification of the measured value<br>(as measured) |
| <b>LINEAR</b> | Linearized measured value<br>(cf. linearization table)      |

## 5.14. The Sensor and Interface menu




Fig. 14: The Sensor and Interface menu

The following sensor types can be set **in the first line**:

| Display     | Suitable for       |
|-------------|--------------------|
| <b>PRES</b> | Pressure sensor    |
| <b>FLOW</b> | Flow controller    |
| <b>VOLT</b> | Voltage            |
| <b>CURR</b> | Current            |
| <b>TEMP</b> | Temperature sensor |
| <b>VAL</b>  | Any                |
|             | No display         |


You can only change the sensor display mode in this menu. The sole purpose of the setting is to label the menu; it is not evaluated internally in any other way.

The sensor type is followed by the letter **P** (pressure) or **F** (flow). This letter indicates the connector assignment that has been configured in the PR4000.

**The second line** shows the interface: RS232, RS485, OPTION or NONE.

The software detects the interface installed in the PR4000 automatically; you cannot alter this setting. As OPTION interface an IEC 488 interface is currently available only.

### **5.15. The Device menu**




*Fig. 15: The Device menu*

You can specify the device address **in the first line** (RS485 and IEC 488 only).

The two dashes shown here **in the second line** after to the word MODE (--) indicate that you cannot enter a setting. Otherwise, the mode of the optional interface (e.g. IEC 488) can be set in this line. The interface which is currently configured is displayed.

**5.16. The Baud Rate and Parity menu**



*Fig. 16: The Baud Rate and Parity menu*

The following data transfer rates (in baud) can be set **in the first line**:

|     |      |      |      |      |      |      |      |      |      |
|-----|------|------|------|------|------|------|------|------|------|
| 110 | 1200 | 2400 | 4800 | 9600 | 19k2 | 38k4 | 57k6 | 76k8 | 115k |
|-----|------|------|------|------|------|------|------|------|------|

You cannot alter the baud rate of the OPTION interface.

You can set the parity **in the second line** (RS232 interface only).

The parity can be NONE, EVEN or ODD.

## 5.17. The Reset menu




Fig. 17: The Reset menu

**The first line** (RES) indicates which parameters can be reset. You must return to Edit mode in order to do so.

| Display    | Result   |
|------------|--|
| <b>SYS</b> | Resets the complete system to the default parameters           |
| <b>LIN</b> | Resets the linearization parameters, i.e. sets a straight line |
| <b>STS</b> | Resets the status bits in the second line                      |

The error displays can only be reset by means of STS.

The following *states* can be shown **in the second line**:

| Display  | Meaning  |
|----------|--|
| <b>T</b> | Transmission error (on the serial interface)                       |
| <b>O</b> | Overflow error (the AD converter has reached its saturation limit) |
| <b>R</b> | Range error (value outside 0 - 110 % range)                        |
| <b>H</b> | High relay (active)  |
| <b>L</b> | Low relay (active)   |

The error displays can only be reset by means of STS in the first line.

The letters 'H' and 'L' for high and low relay are only displayed if the relays are active.

## 6. Signal processing

The signal processing program carries out the following steps:

1. The setpoint is normalized.
2. The measured value (input) is normalized and the binary value is converted to a floating-point number.
3. The measured value (normalized input) is corrected with the gain and offset factors and normalized according to the following formula:

$$\text{Normalized actual value} = \frac{\text{GAIN} * (\text{normalized input} - \text{OFFSET})}{\text{FSIN}}$$

4. The display mode of the actual value is defined (e.g. linear).
5. The setpoint is output, corrected with the gain, FSIN, FSOUT and offset factors and renormalized according to the following formula:

$$\text{Output} = \left( \frac{\text{normalized setpoint}}{\text{GAIN}} + \frac{\text{OFFSET}}{\text{FSIN}} \right) * \text{FSOUT}$$

6. The actual value is displayed.

If the setpoint then fails to reach a value greater than zero or if the setpoint switch is set to OFF, a constant output voltage of -500 mV is output. This ensures that if a valve is open, it is closed safely.

## **7. Special functions**

### **7.1. Leak test (optional)**

You can start a leak test in the *Reset Relays/Leak Test* menu of the PR4000. This test determines whether a pressure drop/increase occurs in the system during a defined period of time, despite the fact that all valves are closed. Leaks are thus established by means of changes in pressure rather than the gas flow.

A timeout, which serves to monitor the process, is started simultaneously with the leak test. The leak test is based on the measured value (actual value) at the start time. It reveals whether the measured value remains within defined limits until the timeout expires or whether these limits are violated. The leak test can also be started via the digital interface.

#### **Leak test procedure:**

1. Set the setpoint to OFF.
2. Set LIMIT MODE to LEAK in the *Limit Mode/Limit Memory* menu.  
The words '*Leak Test*' appear in the first line of the next menu.
3. Enter the setpoint for the timeout in the *Reset Relays/Leak Test* menu.
4. Set the leak rate limits in the *Maximum Limit/Minimum Limit* menu.  
The current pressure value (actual value) is taken into account in the setpoint and compared with the limits, which are relative to this setpoint.
5. Start the leak test in the *Reset Relays/Leak Test* menu.  
To do so, switch on Edit mode and confirm the cursor position in the START LEAK TEST line by pressing Enter. This activates the leak test function. If the valve is set to ON, the word 'FAIL' will appear on the display. The PR4000 does not allow a leak test to be run if a valve is open, since this would be nonsensical.
6. The pressure value at the start of the leak test is shown in the Setpoint menu. The first line of this menu now contains the word 'LEAK' instead of 'SETP' (setpoint). 'LEAK' is the initial pressure value.

Please refer to chapter 7.3. *Process monitoring (optional)* for further details about the leak test.



## **7.2. Linearization (optional)**

The linearization function is based on a linearization table comprising 11 equidistant points: 0 %, 10 %, 20 %...100 %.

You can generate a linearization table by selecting a reference point (ref) on the X-axis and entering the associated Y-value (derived from the measured value of the sensor). The linearization function compensates the non-linearity of the sensor by linearly interpolating the values between the individual Y-points in the linearization table.

You can enter values in the linearization table either by specifying the individual X and Y-values in the *Linearization* menu or using a PC.

If an interface is available, the values can be entered in the linearization table automatically. In this case, the current X-value is preset and the autolinearization function activated. The PR4000 then automatically adopts the current measured value as the Y-value.

## **7.3. Process monitoring (optional)**

### **7.3.1. Limit modes**

Four different limit modes can be selected for process monitoring in the *Limit Mode/Limit Memory* menu of the PR4000:

SLEEP, LIMIT, BAND and LEAK.

#### **SLEEP**

No processes are monitored in SLEEP mode.

#### **LIMIT**

LIMIT mode is used to monitor the gas flow, to make sure it remains within the permitted operating limits. If the gas flow rises above the maximum limit or falls below the minimum limit, the corresponding relay is activated. The device interprets limit values as absolute values in LIMIT mode.

#### **BAND**

This mode is similar to LIMIT mode, except that the limit values are interpreted as deviations from the setpoint. The minimum limit represents a negative deviation.

#### **LEAK**

LEAK mode combines process monitoring with a timeout, in order to detect possible leaks in the system (see also chapter 7.1. *Leak test (optional)*).

Monitoring starts two seconds after a mode has been selected (exception: leak test).

The relay logic depends on the active monitoring mode:

| <b>Mode</b>  | <b>Relay condition</b>  |
|--------------|---|
| <b>SLEEP</b> | Relay 1 (low relay) represents the (valve) status of the channel.<br>Relay 2 (high relay) is always inactive.   |
| <b>BAND</b>  | Relay 1 (low relay) represents the (valve) status of the channel.<br>Relay 2 (high relay) is activated if the actual gas flow is outside the defined band.  |
| <b>LIMIT</b> | Relay 1 (low relay) is activated as soon as the gas flow falls below the specified minimum limit.<br>Relay 2 (high relay) is activated as soon as the gas flow rises above the specified maximum limit.             |
| <b>LEAK</b>  | Relay 1 (high relay) is activated for the specified timeout duration.<br>It is deactivated again when the timeout expires.<br>Relay 2 (low relay) is activated if a leak occurs, i.e. if a limit value is violated. |

Truth table:

| Mode  | Relay | Valve | Minimum limit violated | Maximum limit violated | Relay condition |
|-------|-------|-------|------------------------|------------------------|-----------------|
| SLEEP | 1     | OFF   | X                      | X                      | Inactive        |
| SLEEP | 1     | ON    | X                      | X                      | Active          |
| SLEEP | 2     | X     | X                      | X                      | Inactive        |
| BAND  | 1     | OFF   | X                      | X                      | Inactive        |
| BAND  | 1     | ON    | X                      | X                      | Active          |
| BAND  | 2     | X     | NO                     | NO                     | Inactive        |
| BAND  | 2     | X     | X                      | YES                    | Active          |
| BAND  | 2     | X     | YES                    | X                      | Active          |
| LIMIT | 1     | X     | NO                     | X                      | Inactive        |
| LIMIT | 1     | X     | YES                    | X                      | Active          |
| LIMIT | 2     | X     | X                      | NO                     | Inactive        |
| LIMIT | 2     | X     | X                      | YES                    | Active          |

| Mode | Relay | Leak | Timeout    | Limit memory | Relay condition |
|------|-------|------|------------|--------------|-----------------|
| LEAK | 1     | X    | Not active | X            | Inactive        |
| LEAK | 1     | X    | Active     | X            | Active          |
| LEAK | 2     | YES  | Active     | X            | Active          |
| LEAK | 2     | NO   | Active     | X            | Inactive        |
| LEAK | 2     | X    | Expired    | OFF          | Inactive        |
| LEAK | 2     | YES  | Expired    | ON           | Active          |
| LEAK | 2     | X    | Expired    | ON           | Inactive        |

X = Any

There is a hysteresys of 0.5 % of full scale, before the relays will switch back.

### 7.3.2. Limit memory

The limit memory function in the *Limit Mode/Limit Memory* menu can be set to either ON or OFF. The meanings of these two states are as follows:

Limit memory OFF

The relays reflect the actual condition. They are activated if the limit value is exceeded. If the measured value returns to within the permitted limits, the relays are deactivated again.

|                 |   |
|-----------------|---|
| Limit memory ON | If the limit value is violated just once in either direction, a relay is activated and remains active. It can be reset with the reset function in the <i>Reset Relays/Leak Test</i> menu. |
|-----------------|---|

### **7.4. Autozero**

The autozero function can only be selected if the setpoint is set to OFF.

It causes the instantaneous measured value to be adopted as the offset. The zero value is corrected computationally with this offset (error). The correction algorithm is described in detail in chapter 6. *Signal processing*.

You can activate the autozero function via the digital interface (only if the setpoint is set to OFF).

### **7.5. Process safeguarding**

When the device is switched on (i.e. when the Power switch on the front panel is set to ON), all the interface signals present at this time are initially inactive (the setpoint is set to -0.5 V and the relays remain inactive).

When the device is switched off (i.e. when the Power switch on the front panel is set to OFF), all the output channels are deactivated and remain inactive.

### **7.6. The digital interface**

The following signals can be applied to the digital interface (see also chapter 9.5. *Relay connector*) and the corresponding functions activated:

|              |                  |  |
|--------------|------------------|--|
| • VALVE ON   | Setpoint ON/OFF  | The valve is open if pin 4 of the relay connector is also open and the setpoint is set to ON. If pin 4 is closed (i.e. applied to chassis), the valve is also closed. In addition, 5 - 15 V must be applied to pin 12. |
| • AUTOZERO   | Activate         | Pin 5 closed   |
| • RES        | Totalizer = zero | Pin 6 closed   |
| • START LEAK | Start leak test  | Pin 7 closed   |

## **7.7. Interfaces**

The following interfaces can be installed in the device:

- RS232      Point-to-point connection via RS232
- RS485      Protocol via RS485
- OPTION    e.g. IEC 488
- NONE      No interface

The software automatically detects and displays the installed interface.

The interface type determines the meanings of the parameters:

### **RS232**

|  |          |
|--|----------|
| Address ( <i>Device</i> menu):                 | Not used |
| Mode ( <i>Device</i> menu):                    | Not used |
| Baud rate ( <i>Baud Rate and Parity</i> menu): | Used     |
| Parity ( <i>Baud Rate and Parity</i> menu):    | Used     |
| 7 data bits and 1 stop bit                     |          |

### **RS485**

|  |                |
|--|----------------|
| Address ( <i>Device</i> menu):                 | Device address |
| Mode ( <i>Device</i> menu):                    | Not used       |
| Baud rate ( <i>Baud Rate and Parity</i> menu): | Used           |
| Parity ( <i>Baud Rate and Parity</i> menu):    | Not used       |

### **OPTION (e.g. IEC 488)**

|  |                |
|--|----------------|
| Address ( <i>Device</i> menu):                 | Device address |
| Mode ( <i>Device</i> menu):                    | Interface mode |
| Baud rate ( <i>Baud Rate and Parity</i> menu): | Not used       |
| Parity ( <i>Baud Rate and Parity</i> menu):    | Not used       |

Requests and commands are always transferred in blocks, rather than as individual characters.

### **7.7.1. RS232 interface**

The RS232 interface is a serial interface in accordance with the RS232 specifications.

The interface is active if it is displayed on the device.

### **7.7.2. RS485 interface**

The RS485 interface is a serial interface in accordance with the RS485 specifications, with additional electrical isolation. The protocol conforms to DIN 66348, Part 2.

The interface is active if it is displayed on the device.

### **7.7.3. Option (IEC 488)**

The IEC 488 interface is available as an option. It is active if the word 'OPTION' is displayed on the device.


The interface supports the following IEC 488 functions:

AH1, SH1, L2, T4, SR0, PP0, RL0, DC0, DT0, C0

## 8. External communication

### 8.1. Structure of the multipoint interface according to DIN 66 349 Part 2

The connection structure between the PR4000 and the master (e.g. a PC) as well as another device via a bus interface is shown below:



## **8.2. Protocols**

### **8.2.1. RS232 interface**

The protocol is a simple command/answer sequence with no buffering. The various commands and answers are described in detail in chapter 8.3. *Commands*. If the language definition does not include a defined answer, a dummy answer is sent: CR (carriage return, hex 0x0D).

A command answer, CR (carriage return, hex 0x0D) is returned. The carriage return is also used as a tail character. The maximum message length is 12 characters; separators such as blanks, tabs, etc. are not allowed. It is advisable to keep strictly to the ASCII formats.


An RS232 telegram consists of a send text, a received text and a tail character:

```
stxt    CR
rtxt    CR
```

### **8.2.2. RS485 interface**

The protocol conforms to DIN 66348 Part 2. The various commands and answers are described in detail in chapter 8.3. *Commands*. If the language definition does not include a defined answer, a dummy telegram is sent.

The telegram has a more complex structure than that of the RS232 protocol. It consists of a head, the actual send text (stxt) and a tail character:



### **8.2.3. Optional interface**

The protocol is a simple command/answer sequence which is transmitted on the IEC 488 bus. The various commands and answers are described in detail in chapter 8.3. *Commands*. If the language definition does not include a defined answer, a carriage return (hex 0x0D) is generated instead.

The telegram has exactly the same structure as that of the RS232 interface.



## **8.3. Commands**

### **8.3.1. Structure of the Remote Interface Language**

The Remote Interface Language allows to communicate with the PR4000 via the actual interface by for example a PC. This language has a simple command reply structure. All commands may be transmitted either in (a special) binary format or as ASCII code.

**The elements of the syntax description is shown here:**

|                 |   |
|-----------------|---|
| <b>stxt:</b>    | Send text (from PC)                                       |
| <b>rtxt:</b>    | Received text (to PC)                                     |
| <b>[]</b>       | Optional element (e.g. [A] means A is optional)           |
| <b> </b>        | Alternative of different elements (e.g. A B means A or B) |
| <b>@xxx:</b>    | Bytes with fixed format (e.g. @cmd)                       |
| <b>(float):</b> | Binary format of a value                                  |
| <b>0x0004</b>   | Hexadecimal numeric format                                |

#### **Examples for ASCII formats:**

|               |             |   |
|---------------|-------------|---|
| <b>BYTE:</b>  | 000         | Decimal string of three characters            |
| <b>WORD:</b>  | +00000      | Decimal string of five characters and a sign  |
| <b>LONG:</b>  | 000000.0000 | Floating point with eleven characters         |
| <b>FLOAT:</b> | +0.00000    | Floating point with six characters and a sign |

#### **How to handle byte formats:**

This is a typical format of a byte with a fixed format.

|   |   |    |    |    |    |    |    |
|---|---|----|----|----|----|----|----|
| p | 1 | d5 | d4 | d3 | d2 | d1 | d0 |
|---|---|----|----|----|----|----|----|

The first bit of each byte is the parity bit and cannot be reprogrammed. The second bit is normally a one, in order to get a printable character. The bits d5 to d0 can be used for programming.

If, for example, the bits d4 and d2 should be set, you get this binary representation: 01010100b which is equal to the hexadecimal value: 0x54. If go through a ASCII table with this value, you will get the character 'T', which may be entered right on the command line. Some simple parameters are shown as hex. Constants, e.g. 0x31. In this case enter the corresponded ASCII character '1' on the command line.

### 8.3.2. Special byte formats

@cmd:

|   |   |    |    |    |    |    |    |
|---|---|----|----|----|----|----|----|
| p | 1 | d5 | d4 | d3 | d2 | d1 | d0 |
|---|---|----|----|----|----|----|----|

Only one of bits d5 - d2 is allowed to be set at any given time. If several bits are set, only the one with the highest priority is taken into account. Bit d5 has the highest priority and bit d2 the lowest priority.

The bits have the following meanings when set:

- p: Parity bit
- d5: Actual value sent
- d4: Setpoint (external) sent
- d3: Totalized value (total gas flow over a defined period of time) displayed
- d2: Digital I/O sent
- d1: Setpoint set to ON or OFF
- d0: Totalizer (gas counter) reset

A total of four bytes are available for binary transfers - one header byte and three useful data bytes.

#### Special binary format

@head

|   |   |      |      |      |      |      |      |
|---|---|------|------|------|------|------|------|
| p | 1 | b3d7 | b3d6 | b2d7 | b2d6 | b1d7 | b1d6 |
|---|---|------|------|------|------|------|------|

@byte 1

|   |   |      |      |      |      |      |      |
|---|---|------|------|------|------|------|------|
| p | 1 | b1d5 | b1d4 | b1d3 | b1d2 | b1d1 | b1d0 |
|---|---|------|------|------|------|------|------|

@byte 2

|   |   |      |      |      |      |      |      |
|---|---|------|------|------|------|------|------|
| p | 1 | b2d5 | b2d4 | b2d3 | b2d2 | b2d1 | b2d0 |
|---|---|------|------|------|------|------|------|

@byte 3

|   |   |      |      |      |      |      |      |
|---|---|------|------|------|------|------|------|
| p | 1 | b3d5 | b3d4 | b3d3 | b3d2 | b3d1 | b3d0 |
|---|---|------|------|------|------|------|------|

The header byte is filled with:

- bits 7 and 6 of byte 3 = bits 5 and 6,
- bits 7 and 6 of byte 2 = bits 3 and 4,
- bits 7 and 6 of byte 1 = bits 1 and 2.

## Status bytes of the PR4000

### @sts1 (Status 1)

The bits have the following meanings when set:

|   |   |    |    |    |    |    |    |
|---|---|----|----|----|----|----|----|
| p | 1 | d5 | d4 | d3 | d2 | d1 | d0 |
|---|---|----|----|----|----|----|----|

- p: Parity bit
- d5: General error (see status bit 3 for further details)
- d4: Overflow (see status bit 2 for further details)
- d3: Setpoint set to ON and valve open
- d2: Parameter modified by user
- d1: Relay 1 active
- d0: Relay 2 active

If the status has been read, bits d2, d4 and d5 are reset to zero. All the other bits represent current values.

### @sts2 (Status 2)

The bits have the following meanings when set:

|   |   |    |    |    |    |    |    |
|---|---|----|----|----|----|----|----|
| p | 1 | d5 | d4 | d3 | d2 | d1 | d0 |
|---|---|----|----|----|----|----|----|

- p: Parity bit
  - d5: Analog input (1) too high (>+11 V)
  - d4: Analog input (1) too low (<-11 V)
  - d3: Analog input (1) >110 %
  - d2: Analog input (1) < 0
  - d1: Analog input (0) too high (>+11 V)
  - d0: Analog input (0) too low (<-11 V)
- EXTERNAL mode only

Analog input (1) = setpoint (in external mode)  
Analog input (0) = measured value (actual value)

### @sts3 (Status 3)

The bits have the following meanings when set:

|   |   |    |    |    |    |    |    |
|---|---|----|----|----|----|----|----|
| p | 1 | d5 | d4 | d3 | d2 | d1 | d0 |
|---|---|----|----|----|----|----|----|

- p: Parity bit
- d5: Reserved
- d4: Reserved
- d3: Reserved
- d2: Command execution error
- d1: Data transfer error
- d0: Totalizer overflow

If the status has been read, bits d1 and d2 are reset to zero. All the other bits represent current values.

#### **@sts4 (Status 4)**

The bits have the following meanings when set:

|   |   |    |    |    |    |    |    |
|---|---|----|----|----|----|----|----|
| p | 1 | d5 | d4 | d3 | d2 | d1 | d0 |
|---|---|----|----|----|----|----|----|

p: Parity bit  
d5: Digital input 5, reserved  
d4: Digital input 4, reserved  
d3: Digital input 3, start leak test  
d2: Digital input 2, reset integrator  
d1: Digital input 1, autozero  
d0: Digital input 0, valve ON/OFF

d0 to d5 are the actual digital inputs.

The digital inputs are also transferred together with the measured value by the command 0x22 (direct access).

### **8.3.3. Commands**

#### **8.3.3.1 Command syntax**

The binary float format conforms to IEEE 754. The command syntax and notation are described in more detail in chapter 8.3.1. *Structure of the Remote Interface Language*. Commands and answers are represented as follows in this chapter:

**stxt:** Text sent by master (PC)

**rtxt:** Answer from PR4000

Commands begin with the hexadecimal number corresponding to an ASCII character (e.g. 0x23). This is followed by the ASCII character itself (e.g. (#)) and finally a plain text description of the command ('Start signal processing').

Bytes in commands are abbreviated as 'b'. Example: setpoint.b3 denotes byte 3.

In the command 'head, setpoint.b3, setpoint.b2, 0x00head, setpoint.b1, setpoint.b0, 0x00', 'setpoint' consists of 8 bytes: 2x@head, setpoint.b3, setpoint.b2, setpoint.b1, setpoint.b0, 2x 0x00, whereby the value of the last byte is zero because it is not used.

#### **Example:**

The master (PC) sends 10 bytes in this example: command, @cmd, 8 bytes for the setpoint (optional). The binary format of the setpoint consists of 4 bytes (floating-point number in accordance with IEEE 754). The following answers are possible, depending on the bits which are set in @cmd: measured value (actual value) or setpoint or DigOutDigIn or optionally the totalized value.

### 8.3.3.2. General commands

#### *0x21 (!) Update all values*

**stxt:** 0x21 @cmd [setpoint]  
**rtxt:** @sts1 [actual value][[setpoint]][DigOut/DigIn][[totalized value]]

#### **Setpoint:**

Binary (float): @head, setpoint.b3, setpoint.b2, 0x00 @head, setpoint.b1, setpoint.b0, 0x00  
 ASCII FLOAT

#### **Measured value (actual value):**

Binary (float): @head, actual value.b3, actual value.b2, 0H, @head, actual value.b1, actual value.b0, 0x00  
 ASCII FLOAT

#### **Setpoint:**

Binary (float): @head, setpoint.b3, setpoint.b2, 0x00, @head, setpoint.b1, setpoint.b0, 0x00  
 ASCII FLOAT

#### **DigOut/DigIn (8 bits DigOut, 8 bits DigIn):**

Binary (unsigned): @head, 0x00, DigOut/DigIn  
 ASCII: WORD

| DigIn           | Bit |
|-----------------|-----|
| VALVE ON/OFF    | db0 |
| AUTOZERO        | db1 |
| RESET TOTALIZER | db2 |
| START LEAK TEST | db3 |
| ONE OUT         | db4 |
| FLOW PRES       | db5 |
| OPTIONAL        | db6 |
| OPTIONAL        | db7 |

| DigOut        | Bit |
|---------------|-----|
| RELAY0        | db0 |
| RELAY1        | db1 |
| CAL SWITCH0   | db2 |
| CAL SWITCH1   | db3 |
| OPTIONAL      | db4 |
| CLOSE VALVE   | db5 |
| OPTIONAL(PDR) | db6 |
| OPTIONAL(PDR) | db7 |

**Totalized value (optional):**

|         |           |
|---------|-----------|
| Binary: | Cf. ASCII |
| ASCII:  | LONG      |

## *0x22 (") Direct access to sensors*

This command writes directly in the digital/analog converter and stops signal processing. A restart can be initiated with command 0x23.

|              |                    |
|--------------|--------------------|
| <b>stxt:</b> | 0x22 Outgoing data |
| <b>rtxt:</b> | Incoming data      |

**Outgoing data:**

|        |                  |
|--------|------------------|
| ASCII  | Not applicable   |
| out =  | Output channel 1 |
| out2 = | Output channel 2 |

**Incoming data:**

|                 |  |
|-----------------|--|
| Binary (float): | @head, in.b1, in.b0, DigIn, @head, in2.b1, in2.b0, @     |
| ASCII           | Not applicable   |
| in =            | Input channel 1  |
| in2 =           | Input channel 2  |
| 0x000 =         | Full-scale deflection; 0xFFFF = + full-scale deflection. |

## *0x23 (#) Start signal processing*

|              |                                 |
|--------------|---------------------------------|
| <b>stxt:</b> | 0x23                            |
| <b>rtxt:</b> | CR (carriage return; no return) |

Commands 0x21 and 0x24 also start signal processing.

## *0x24 (\$) Update sensor*

|              |                               |
|--------------|-------------------------------|
| <b>stxt:</b> | 0x24 Setpoint                 |
| <b>rtxt:</b> | Measured value (actual value) |

**Setpoint:**

|                 |  |
|-----------------|--|
| Binary (float): | @head, setpoint.b3, setpoint.b2, 0x00, @head, setpoint.b1, setpoint.b0, 0x00 |
| ASCII           | FLOAT  |

**Measured value (actual value):**

|                 |  |
|-----------------|--|
| Binary (float): | @head, actual value.b3, actual value.b2, 0x00, @head, actual value.b1, actual value.b0, 0x00 |
| ASCII           | FLOAT  |

### *0x25 (%) Change format*

This command switches the format between binary and ASCII.

|              |                                 |
|--------------|---------------------------------|
| <b>stxt:</b> | 0x25 nfrmt                      |
| <b>rtxt:</b> | CR (carriage return; no return) |

**nfrmt:**

|        |                                |
|--------|--------------------------------|
| 0x30 = | Binary (special binary format) |
| 0x31 = | ASCII                          |

### *0x26 (&) Read status byte 1*

|              |       |
|--------------|-------|
| <b>stxt:</b> | 0x26  |
| <b>rtxt:</b> | @sts1 |

### *0x27 (') Read status byte 2*

|              |       |
|--------------|-------|
| <b>stxt:</b> | 0x27  |
| <b>rtxt:</b> | @sts2 |

### *0x28 (()) Read status byte 3*

|              |       |                             |
|--------------|-------|-----------------------------|
| <b>stxt:</b> | 0x28  | Reset when the byte is read |
| <b>rtxt:</b> | @sts3 |                             |

### *0x29 (()) Read status byte 4*

|              |       |                             |
|--------------|-------|-----------------------------|
| <b>stxt:</b> | 0x29  | Reset when the byte is read |
| <b>rtxt:</b> | @sts4 |                             |

### *0x2A(\*) Reset system to default values*

|              |                                 |
|--------------|---------------------------------|
| <b>stxt:</b> | 0x2A                            |
| <b>rtxt:</b> | CR (carriage return; no return) |

### *0x2B(+) Reset linearization (optional)*

**stxt:** 0x2B  
**rtxt:** CR (carriage return; no return)

### *0x2C (,) Reset relay*

**stxt:** 0x2C  
**rtxt:** CR (carriage return; no return)

### *0x2D (-) Reset status 3*

**stxt:** 0x2D  
**rtxt:** CR (carriage return; no return)

### *0x2E (.) Reset totalizer*

**stxt:** 0x2E  
**rtxt:** CR (carriage return; no return)

### *0x2F (/) Start leak test*

**stxt:** 0x2F  
**rtxt:** CR (carriage return; no return)

### *0x30 (0) Autozero*

This function interprets the actual measured value as zero and calculates a new offset.

**stxt:** 0x30  
**rtxt:** CR (carriage return; no return)

### *0x31 (1) Autofullscale*

This function interprets the actual measured value as the full-scale deflection and calculates a new gain.

**stxt:** 0x31  
**rtxt:** CR (carriage return; no return)



## *0x32 (2) Autolinearization*

This function interprets the actual measured value as the Y-value for linearization (optional).

**stxt:** 0x32 Interpolation point  
**rtxt:** CR (carriage return; no return)

**Interpolation point:**

Binary, ASCII: (@ + value)  
X-value for linearization

### **8.3.3.3. Commands which set process parameters**

#### ***0x40 (@)Set setpoint***

**stxt:** 0x40 Setpoint  
**rtxt:** CR (carriage return; no return)

**Setpoint:**

Binary (float): @head, setpoint.b3, setpoint.b2, 0x00, @head, setpoint.b1, setpoint.b0, 0x00  
 ASCII: FLOAT

#### ***0x41 (A) Valve ON/OFF***

**stxt:** 0x41 ON/OFF status  
**rtxt:** CR (carriage return; no return)

**ON/OFF status:**

Binary, ASCII: 0x30...0x31 0 = OFF, 1 = ON

#### ***0x42 (B) Set range***

**stxt:** 0x42 Range  
**rtxt:** CR (carriage return; no return)

**Range:**

Changes the range parameter.

Binary (float): @head, range.b3, range.b2, 0x00, @head, range.b1, range.b0, 0x00

#### ***0x43 (C) Set measurement unit***

**stxt:** 0x43 Measurement unit  
**rtxt:** CR (carriage return; no return)

**Measurement unit:**

Binary: @ + value (0-20) The index (0 - 20) corresponds to the order of the measurement units  
 ASCII: BYTE

You can set the following measurement units:

| <b>Table 1: Available measurement units</b> |                     |           |                      |            |
|---|---------------------|-----------|----------------------|------------|
| μbar=0                                      | mbar=1              | bar=2     |                      |            |
| mTorr=3                                     | Torr=4              | kTorr=5   |                      |            |
| Pa=6  | kPa=7               |           |                      |            |
| mH <sub>2</sub> O=8                         | cH <sub>2</sub> O=9 | PSI=10    | N/m <sup>2</sup> =11 |            |
| SCCM/CC=12                                  | SLM/L=13            | SCM/CM=14 | SCFH/CF=15           | SCFM/CF=16 |
| mA=17                                       | V=18                | %=19      | C=20                 |            |

mHG == kTorr, mmHg == Torr

CC = cubic centimeter, L = liter, CM = cubic meter, CF = cubic foot

### *0x44 (D) Set gain*

**stxt:** 0x44 Gain  
**rtxt:** CR (carriage return; no return)

**Gain:**

Binary (float): @head, gain.b3, gain.b2, 0x00, @head, gain.b1, gain.b0, 0x00  
 ASCII: FLOAT

### *0x45(E) Set offset*

**stxt:** 0x45 Offset  
**rtxt:** CR (carriage return; no return)

**Offset:**

Binary (integer): @head, 0x00, offs.b1, offs.b0  
 ASCII: WORD

### *0x46 (F) Set linearization table (optional)*

**stxt:** 0x46 Reference Y-axis  
**rtxt:** CR (carriage return; no return)

**Reference:**

Binary: (@+ value) X-value for linearization (0 - 10)  
 ASCII: BYTE

Important: This reference format is mandatory!

**Y-axis:**

Binary (float): @head, ylin.b3, ylin.b2, 0x00, @head, ylin.b1, ylin.b0, 0x00  
 ASCII: FLOAT

### 0x47 (G) Set full-scale deflection for input voltage

**stxt:** 0x47 fsin Changes the FSIN parameter  
**rtxt:** CR (carriage return; no return)

**Input voltage:**

Binary (unsigned): @head, 0x00, fsin.b1, fsin.b0  
 ASCII: WORD

### 0x48 (H) Set measurement unit for input voltage

**stxt:** 0x48 Measurement unit  
**rtxt:** CR (carriage return; no return)

**Input voltage measurement unit:**

Binary. ASCII: 0x30...0x36

You can set the following measurement units for FSIN (input voltage):

| mV                  | mA   | mA 2 | mA 5 | mA 4                | mA 24 | mA 54 |
|---------------------|------|------|------|---------------------|-------|-------|
|                     | 100Ω | 200Ω | 500Ω | 100Ω                | 200Ω  | 500Ω  |
| 0 - 20 mA interface |      |      |      | 4 - 20 mA interface |       |       |

The index (0 - 6) corresponds to the order of the units.

### 0x49 (I) Set full-scale deflection for output voltage

**stxt:** 0x49 fsout  
**rtxt:** CR (carriage return; no return)

**Output voltage:**

Changes the FSOUT parameter

Binary (unsigned @head, 0x00, fsout.b1, fsout.b0)  
 ASCII: WORD

### 0x4A (J) Set measurement unit for output voltage

**stxt:** 0x4A Measurement unit of output voltage  
**rtxt:** CR (carriage return; no return)

**Output voltage measurement unit:**

Binary. ASCII: 0x30...0x31

mV and μA are the valid measurement units for FSOUT

### *0x4B (K) Set maximum limit*

**stxt:** 0x4B maxlim  
**rtxt:** CR (carriage return; no return)

**maxlim:**

Changes the MAXL parameter

Binary (unsigned): @head, max\_lim.b3, max\_lim.b2, 0x00, @head, max\_lim.b1, max\_lim.b0, 0x00  
 ASCII: FLOAT

### *0x4C (L) Set minimum limit*

**stxt:** 0x4C minlim  
**rtxt:** CR (carriage return; no return)

**minlim:**

Changes the MINL parameter

Binary (unsigned): @head, min\_lim.b3, min\_lim.b2, 0x00, @head, min\_lim.b1, min\_lim.b0, 0x00  
 ASCII: FLOAT

### *0x4D (M) Set limit mode*

**stxt:** 0x4D Limit mode  
**rtxt:** CR (carriage return; no return)

**Limit mode:**

Binary, ASCII: 0x30...0x33

The valid limit modes are SLEEP, LIMIT, BAND and LEAK. The index (0 - 3) corresponds to the order of the units.

### *0x4E (N) Set limit memory (optional)*

**stxt:** 0x4E Limit memory  
**rtxt:** CR (carriage return; no return)

**Limit memory:**

Binary, ASCII: 0x30...0x31

OFF = 0; ON = 1

### *0x4F (O) Set timeout (optional)*

**stxt:** 0x4F Timeout in seconds  
**rtxt:** CR (carriage return; no return)

**Timeout**

Binary (unsigned): @head, 0x00, timeoutb1, timeoutb  
 ASCII: WORD

### *0x50 (P) Set signal processing mode*

**stxt:** 0x50 Signal processing mode  
**rtxt:** CR (carriage return; no return)

**Signal processing mode:**

Binary, ASCII: 0x30...0x31 Index for signal processing mode:  
 0 = independent, 1 = external

### *0x51 (Q) Set display mode*

**stxt:** 0x51 Display  
**rtxt:** CR (carriage return; no return)

**Display:**

Binary, ASCII: 0x30...0x31 Index for display mode (0..1)  
 0 = direct; 1 = linearized

### *0x52 (R) Set sensor type*

**stxt:** 0x52 Sensor type  
**rtxt:** CR (carriage return; no return)

**Day of measured value:**

Binary, ASCII: 0x30...0x36 Index for sensor type (0)

You can set the following sensor types:

| Display     | Sensor type        | Setting |
|-------------|--------------------|---------|
| <b>PRES</b> | Pressure sensor    | 0       |
| <b>FLOW</b> | Flow controller    | 1       |
| <b>VOLT</b> | Voltage            | 2       |
| <b>CURR</b> | Current            | 3       |
| <b>TEMP</b> | Temperature sensor | 4       |
| <b>VAL</b>  | Any                | 5       |
|             | No display         | 6       |

### *0x53 (S) Set interface parameters (optional)*

**stxt:** 0x53 Baud [parity]  
**rtxt:** CR (carriage return; no return)

**Baud:**

Binary, ASCII: 0x30...0x39 Baud index (0..9)

**Parity:**

Binary, ASCII: 0x30...0x32 Parity index (RS232 only, 0...2)

Baud rate

|            |             |             |             |             |             |             |             |             |             |
|------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| <b>110</b> | <b>1200</b> | <b>2400</b> | <b>4800</b> | <b>9600</b> | <b>19k2</b> | <b>38k4</b> | <b>57k6</b> | <b>76k8</b> | <b>115k</b> |
| 0x30       | 0x31        | 0x32        | 0x33        | 0x34        | 0x35        | 0x36        | 0x37        | 0x38        | 0x39        |

The valid parity values are NONE (0x30), EVEN(0x31) and ODD (0x32).

### *0x54 (T) Set device address (optional)*

**stxt:** 0x54 Device address  
**rtxt:** CR (carriage return; no return)

**Address:**

Binary: @ + value (1-31)  
 ASCII: BYTE

### *0x55 (U) Set interface mode (optional)*

**stxt:** 0x55 Interface mode  
**rtxt:** CR (carriage return; no return)

**Interface mode:**

Binary: @ + value (0...maximum interface mode)  
 ASCII: BYTE

### *0x57 (W) Display menu with specified index*

**stxt:** 0x57 Menu  
**rtxt:** CR (carriage return; no return)

**Index for displayed menu:**

|         |                    |  |
|---------|--------------------|--|
| Binary: | @ + value (0...16) | Corresponds to order of                  |
| ASCII:  | BYTE               | menu tree                                |
|         |                    | (see chapter 5.1. <i>The menu tree</i> ) |



### **8.3.3.4. Commands which read process parameters**

#### ***0x60 (') Read setpoint***

**stxt:** 0x60  
**rtxt:** Setpoint

**Setpoint:**

Binary (float): @head, setpoint.b3, setpoint.b2, 0x00, @head, setpoint.b1, setpoint.b0, 0x00  
 ASCII: FLOAT

#### ***0x61 (a) Read valve ON/OFF***

**stxt:** 0x61  
**rtxt:** oos

**oos:**

Binary, ASCII: 0x30...0x31                      ON/OFF status  
 0 = OFF; 1 = ON

#### ***0x62 (b) Read range***

**stxt:** 0x62  
**rtxt:** Range

**Range:**

Binary (float): @head, range.b3, range.b2, 0x00, @head, range.b1, range.b0, 0x00  
 ASCII: FLOAT

#### ***0x63 (c) Read measurement unit***

**stxt:** 0x63  
**rtxt:** Measurement unit

**Measurement unit:**

Binary : @ + value (0 - 23)  
 ASCII: BYTE

#### ***0x64 (d) Read gain***

**stxt:** 0x64  
**rtxt:** Gain

**Gain:**

Binary (float): @head, gain.b3, gain.b2, 0x00, @head, gain.b1, gain.b0, 0x00  
 ASCII: FLOAT

*0x65 (e) Read offset*

**stxt:** 0x65  
**rtxt:** Offset

**Setpoint:**

Binary: (int) @head, 0x00, offsb1, offsb0  
ASCII: FLOAT

*0x66 (f) Read linearization table*

**stxt:** 0x66 Reference  
**rtxt:** ylin

**Reference:**

|         |                    |                              |
|---------|--------------------|------------------------------|
| Binary: | @ + value (0...23) | Inverse curve from K onwards |
| ASCII:  | BYTE               |                              |

**ylin:**

Binary (float): @head, ylin.b3, ylin.b2, 0x00, @head, ylin.b1, ylin.b0, 0x00  
ASCII: FLOAT

### ***0x67 (g) Read full-scale deflection of input voltage***

**stxt:** 0x67  
**rtxt:** Full-scale deflection of input voltage

**Full-scale deflection of input voltage:**

Binary (integer): @head, 0x00, fsinb1, fsinb0  
 ASCII: WORD

### ***0x68 (h) Read measurement unit of input voltage***

**stxt:** 0x68  
**rtxt:** Measurement unit of input voltage

**Measurement unit of input voltage:**

Binary, ASCII: 0x30...0x36                      The index (0 - 6) corresponds to the order of the units.

The valid measurement units for FSIN (input voltage) are listed in the table under *0x48 (H) Set measurement unit for input voltage*.

### ***0x69 (i) Read FSOUT***

**stxt:** 0x69  
**rtxt:** FSOUT

**FSOUT:**

Binary (integer): @head, 0x00, fsoutb1, fsoutb0  
 ASCII: FLOAT

### ***0x6A (j) Read measurement unit of output voltage***

**stxt:** 0x6A  
**rtxt:** Measurement unit of output voltage

**Measurement unit of output voltage:**

Binary, ASCII: 0x30...0x31

mV and  $\mu$ A are the valid measurement units for FSOUT (output voltage).

### ***0x6B (k) Read maximum limit (MAXL)***

**stxt:** 0x6B  
**rtxt:** maxlim

**maxlim:**

Binary (float): @head, max\_lim.b3, max\_lim.b2, 0x00 @head, max\_lim.b1, max\_lim.b0, 0x00  
 ASCII: FLOAT

### *0x6C (l) Read minimum limit (MINL)*

**stxt:** 0x6C  
**rtxt:** minlim

**minlim:**

Binary (float): @head, min\_lim.b3, min\_lim.b2, 0x00 @head, min\_lim.b1, min\_lim.b0, 0x00  
 ASCII: FLOAT

### *0x6D (m) Read limit mode*

**stxt:** 0x6D  
**rtxt:** Limit mode

**Limit mode:**

Binary, ASCII: 0x30...0x33

Index for limit mode (0...3)  
 The valid limit modes are  
 SLEEP, LIMIT, BAND and LEAK

### *0x6E (n) Read limit memory*

**stxt:** 0x6E  
**rtxt:** Limit memory

**Limit memory:**

Binary, ASCII: 0x30...0x31

Index for limit memory  
 0 = OFF, 1 = ON

### *0x6F (o) Read timeout*

**stxt:** 0x6F  
**rtxt:** Timeout

**Timeout:**

Binary (unsigned): @head, 0x00; timeout.b1, timeout.b0      Timeout in seconds  
 ASCII: WORD

### *0x70 (p) Read signal processing mode*

**stxt:** 0x70  
**rtxt:** Signal processing mode

**Signal processing mode:**

Binary, ASCII: 0x30, 0x31      Index for signal processing mode  
 0 = independent, 1 = external

### *0x71(q) Read display mode*

**stxt:** 0x71  
**rtxt:** Display

**Display:**

Binary, ASCII: 0x30, 0x31      Index for display mode  
 0 = direct; 1 = linearized;

### *0x72 (r) Read sensor type*

**stxt:** 0x72  
**rtxt:** Sensor type

**Day of measured value (actual value):**

Binary, ASCII: 0x30...0x36      Index for day of measured value  
 (0...6)

The valid settings for the sensor type are listed in the table under  
 0x52 (R) *Set sensor type*.

### *0x73 (s) Read interface type*

**stxt:** 0x73  
**rtxt:** Interface type, baud, parity

**Interface type:**

Binary, ASCII: 0x30...0x33  
 Index for interface type  
 0 = no interface;  
 1 = RS232;  
 2 = RS 485;  
 3 = OPTION

**Baud:**

Binary, ASCII: 0x30...0x39  
 Index for baud rate (0...9)

The valid settings for the baud rate are listed under  
*0x53 (S) Set interface parameters.*

**Parity:**

Binary, ASCII: 0x30...0x32  
 Index for parity (0...2)  
 NONE = 2,  
 EVEN = 0,  
 ODD = 1

### *0x74 (t) Read device address*

**stxt:** 0x74  
**rtxt:** Device address

**Device address:**

Binary: @ + value (1-31)  
 ASCII: BYTE

### *0x75 (u) Read interface mode*

**stxt:** 0x75  
**rtxt:** Interface mode

**Interface mode:**

Binary: @ + value (0...maximum interface mode)  
 ASCII: BYTE

*0x76 (v) Read ID*

**stxt:** 0x76  
**rtxt:** ID string

*0x7B (}) Lock keyboard*


**stxt:** 0x7B  
**rtxt:** CR (carriage return; no return)

*0x7D(}) Unlock keyboard*

**stxt:** 0x7D  
**rtxt:** CR (carriage return; no return)

## 9. Pin assignment of connectors on the back panel


### 9.1. Channel 1 (flow configuration)



\* Only connected to EXTERNAL connector

\*\* Jumper selection: - connected to EXTERNAL connector  
- connected to "Valve closed" of PR4000 (default setting)


### 9.2. Channel 1 (pressure configuration, optional)



\* Only connected to EXTERNAL connector




**9.3. 20 mA connector (optional)**



Different shunts can be set by altering the jumper positions inside the device:

- None
- 100 ohms
- 200 ohms
- 500 ohms


**9.4. EXTERNAL connector**



The signal specification depends on the sensor which has been configured (aval).

9.5. Relay connector

SUB-D, 15-pole female



Relay data:


|                           |                 |
|---------------------------|-----------------|
| Max. activation current   | 2 A, 1 A        |
| Max. activation voltage   | 30 VDC, 230 VAC |
| Max. activation power     | 20 W            |
| Relay type                | SPDT            |
| Protected against L-loads |                 |

Optocoupler data:

|                      |       |
|----------------------|-------|
| Max. reverse voltage | 5 V   |
| Max. forward current | 20 mA |

9.6. RS232 connector


SUB-D, 15-pole female



All signals to RS232 standard.

**9.7. RS485 connector**

SUB-D, 15-pole female



- Connector compatible with DIN 66349 Part 2
- Terminators can be configured with jumpers

**9.8. IEEE connector**

The IEEE connector is fully compatible with the IEC 488 Standard.