

INSTRUCTIONS FOR USE

Profeel v. 1.17

14. MAY 2021

TOMPPA PAKARINEN, JARKKO OJALA

Contents

Tooltips	2
Importing data	2
Data truncation during import	2
Normalization and interpolation during the import.....	2
CAX correction checkbox (not recommended).....	3
Extracting lower dimension data	4
Quick profile tool	4
Data normalization	6
Profile- and PDD parameters	6
Assigning computed parameters.....	7
Processing tools.....	7
1D	7
2D and 3D processing	8
Adding custom operators	8
Gamma, DTA and DD (Low 1998).....	10
Passing criteria	10
Gamma computation resolution (interp-interval)	10
Isodose limit.....	10
Performing a gamma, DTA and DD analysis.....	11
Saving the data and results	11

Tooltips

Tooltips are supported in this program. Tooltips are revealed by hovering the cursor above the given UI object.

Importing data




Figure 1. Add data button

Data can be imported by clicking the 'Add data' button. Chosen data folder **must** contain only a single data type (may contain multiple files). Different datatypes can be opened by repeating the same process. The supported data types are currently:

- PTW beamscan exports (.mcc)
- IBA Omnipro ASCII exports (.OmmilMRT, .opg)
- PTW software exports (ASCII)
- EGSnrc (.3ddose)
- DICOM RT RD dose files
- Matlab structures (.mat, previous sessions).

The last chosen path will be shown under the UI data button. Imported data will be appended to the UI listbox.

Data truncation during import

2D and 3D data resolution will be automatically lowered if the resolution exceeds a given, hard coded threshold. Lower resolution data is used only to speed up 2D and 3D visualization and as default resolution for gamma, DTA and DD computation.

Normalization and interpolation during the import

Different normalizations are computed during data import. All possible normalizations are computed for 1D data and all applicable normalizations for 2D and 3D data. Failed computations will be printed to the terminal. Data will be automatically linearly interpolated with x10 from the original resolution. Interpolated data will not be displayed in the program, but is used in profile and PDD parameter computation and in data extraction operations.

CAX correction checkbox (not recommended)

Central axis (CAX) is corrected for the profile data only during import, if the checkbox is checked. The correction will not be visualized, but is used in processing. **Preferred method is to import the data without the CAX correction** and if necessary, correct the CAX using shift operator by the amount of CAX deviation (profile parameter). CAX correction checkbox will be modified in future version.

Visualization and removal of data

Imported data is found in the GUI list box (Figure 3). Listbox members are activated for processing and displayed in the UI figure by choosing them from the listbox. Multiple files can be activated simultaneously. Chosen data is shown as **bold** and the word **“**Chosen**”** is added in the end of the file name. All activated data is visualized in the main GUI figure.




Figure 2. Main UI figure with example 1D data

Data is unchosen by re-clicking it.




Figure 3. Imported data will appear to the UI list box

Data can be removed from the program by using the 'Remove data' -button, located under the list box. Button affects all chosen data.

Extracting lower dimension data

Lower dimensions can be extracted from higher dimension data, i.e., 1D line profiles and 2D planes can be extracted from 3D data and 1D-line profiles from 2D data. Extraction is performed from the add line/plane -buttons.




Figure 4. Extracting lower dimension data button locations

Before extraction of 2D planes, the extracted plane and the plane depth are defined. For 2D->1D, the user can also define the extraction range.




Figure 5. 1D profile extraction from 3D dicom RT-file

Note that leaving the extracted axis empty, the whole axis will be extracted. Extracted range is chosen with syntax a:b, where a and b correspond to the range limits. Profile and PDD parameters are automatically computed for extracted 1D data.

Note 1. If the requested 2D plane depth does not exist in the data, the plane will be interpolated from the requested position.

Note 2. For 1D planes, data is extracted from the nearest existing point in the data structure's x10 interpolated data. The extracted positions are added to the filename.

Quick profile tool

1D line profiles can be interactively previewed by using the quick profile tool




Figure 6. Quick profile can be dragged and rotated

Quick profiles can also be used to inspect Gamma, DTA and DD results.




Figure 7. Quick profile from DTA 2D result. DTA and dose profiles are shown in the same figure

Data normalization

Data can be normalized in multiple different ways. Normalizations are chosen from the drop box under Normalization and analysis panel.




Figure 8. Normalization options

- 'No normalization' is the default option
- 'CAX normalization' normalizes the data to the central axis (0-position). Only for 1D profiles
- 'Max 100%' normalizes the data to the maximum value found in the data
- 'Distance/%' normalizes the set axis point (distance) to the set percentage
- 'Mean value from range' normalizes the data to the mean value of a given range
- 'Normalize to value' normalizes the data (100%) to a set value

Profile- and PDD parameters

The program tries automatically to detect profile and PDD (1D only). Corresponding parameters are computed and presented in the UI. Parameters are computed based on IEC 60976 recommendations (IEC 2011).

Profile & PDD parameters										
	CAX dev [cm]	Sym [%]	Homog. [%]	Dmax [%]	Dmin [%]	Dev [%]	Field size [cm]	Pen R [cm]	Pen L [cm]	
PTW5_MC_Y_profil_6X_10x10_Excelista.txt	-0.0050	100.3064	102.8840	100.6101	97.7898	2.2102	10.4100	0.4000	0.3800	
PTW10_PTW_Y_profil_6X_10x10.txt	-0.0050	100	102.7668	100.4831	97.7778	2.2222	10.4100	0.4100	0.3900	
	R100 [cm]	R80 [cm]	R50 [cm]	D100 [%]	D200 [%]	Ds [%]	J100/200			
PTW5_PTW_PDD_6X_10x10_normalized.txt	1.5000	6.4200	14.9000	65.7495	37.3236	47.8461	1.7616			
PTW7_PTW_PDD_6X_10x10_raw.txt	1.3100	6.4200	14.8500	65.5602	37.3029	47.7178	1.7575			

Figure 9. Profile and PDD parameters

Profile parameters:

- CAX dev [cm] = Offset between computed CAX and data position axis
- Sym [%] = Symmetry is defined inside the flattened region as $\max(d(x)/d(-x))$
- Homog. [%] = Homogeneity is the relative max-min dose -deviation within the flattened region
- Dmax [%] = Maximum dose
- Dmin [%] = Minimum dose
- Dev [%] = Dose deviation between CAX and the minimum dose within the flattened region
- Fieldsize [cm] = Fieldsize is 50% dose value from the central axis
- PenR & PenL [cm] = Distance between the 80%-20% dose values

- Flattened region is defined (IEC) for field sizes $\geq 5\text{cm}$. For smaller fields the program computes the flattened region as for $5\text{cm} \leq \text{fieldsize} \leq 10\text{cm}$.

PDD parameters:

- R100, R80, R50 [cm] = 100 %, 80 % and 50 % dose depths from the surface
- D100, D200 [%] = Relative doses at depths of 10 and 20 cm from the surface
- Ds [%] = Surface dose relative to the maximum
- J100/200 = Quality parameter, ratio between doses at 10 and 20 cm

Assigning computed parameters

If the automatic profile/PDD recognition fails, data can be assigned as profile or PDD from tool bar menu. Profile/PDD parameters are re-computed automatically.




Figure 10. Assigning the curve type manually

Processing tools

Data can be processed with processing tools found under the data processing UI panel. All activated data will be processed.




Figure 11. Processing options for 1D, 2D and 3D data

1D

1D data is shifted along the position axis by inserting the shift length in cm to the edit box. Shift is executed from the Shift-button. Data position axis is updated to the data structure.

Data can be mirrored either along the 0-axis point (includes axis shift) or axis can be inverted.

Data can be filtered by using Savitzky-Golay smoothing filter. Using the filter requires the user to set the polynomial order and frame length (must be larger or equal to the order).




Figure 12. Savitzky-Golay pop-up window

Processing is always executed for each existing data normalization and to the interpolated data saved in the data structure.

2D and 3D processing

- Data can be mirrored (axis inverted) in each dimension.
- Savitzky-Golay filtering is applicable also for 2D data.
- 2D and 3D data can be manually scaled
- Original resolution can be displayed by unchecking the “low res. Visualization” button.
- 3D data plane can be changed by clicking the “Y<->Z”, “X<->Z” or “Rot.” buttons. Two first buttons will swap the chosen axes, which corresponds to 3D rotation: E.g., “Y<->Z” will swap the displayed (default) Y-axis to Z-axis, i.e., XZ plane is displayed.
- Rot. -button will rotate the displayed plane along the 3rd axis. Note that position axes are always presented in ascending order, regardless of the data orientation!

Adding custom operators

All data can be processed with custom made operators.




Figure 13. Add operators button location

Clicking ‘Add operators’ button will open a file browser. Choose a custom made ASCII function file, containing the processing instructions. Function.txt files should contain the processing instructions as presented in the example file:

```

pxyzABS = Fdose.*((DforwardCH + DbackCH10x10)/(DforwardCH + DbackCH))*(DcalXYZabs / DcalXYZ)*U*N;
DforwardCH,DbackCH10x10,DbackCH,DcalXYZabs,DcalXYZ
DbackCH,U,N

id:Example 1 TB 6X
DforwardCH = 4.12E-13
DbackCH10x10 = 0.43E-6
DcalXYZabs = 4.0213
DcalXYZ = 9.543777

id:Example 2 TB 6XFFF
DforwardCH = 7.34E-13
DbackCH10x10 = 1.1E-6
DcalXYZabs = 5.123
DcalXYZ = 8.54

id:Example 3 TB 6X
DforwardCH = 1E-13
DbackCH10x10 = 3E-6
DcalXYZabs = 5.111
DcalXYZ = 9.45

end

```

Figure 14. Example file for creating a custom data processing function

- 1st line should include the function, which operates the data. The program evaluates the function directly as Matlab syntax.
- 2nd line contains the predefined variable names.
- 3rd line contains the variables, which will be prompted. Also, data unit will be prompted by default.
- Lines starting with 'id: name' will be interpreted as ids for different variable sets. All variables in the 2nd line should be defined under each id. There is no maximum limit for different variable sets (ids). All id's are added to a dropdown menu as shown in the Figure 15 for the example file.




Figure 15. Variable set id list

Choosing e.g. "Example 1_TB_6X" would use variables under this id, while evaluating the function in the 1st line.

Use end -keyword to terminate the file.

Gamma, DTA and DD (Low 1998)

Distance to agreement (DTA) is computed for 1D and 2D data by searching the nearest point with same dose between two dose distributions (reference and target). DTA is computed either using interpolation and a threshold value ('brute force'), or by finding dose points crossing the reference line/plane and solving the DTA at the cross section ('analytical'). Dose difference (DD) is computed as an absolute value for each data point (subtraction) and as relative value to the reference data. Passing criteria, computation resolution and isodose limit can be modified by the user.




Figure 16. Gamma, DTA and DD analysis tools

Gamma computation is performed by minimizing the squared sum of the gamma components (DTA, DD) relative to gamma criteria for each data point. Profeel uses an open-source gamma function to compute gamma indices (Geurts, 2014).

Passing criteria

Gamma analysis passing criteria can be changed from the edit boxes next to gamma analysis - button. Criteria is also used directly for the passing criteria in DTA and DD computation.

Gamma computation resolution (interp-interval)

The computation grid resolution can be lowered or increased by setting value to the 'Interp-interval (mm)' edit box. Lowering the resolution will speed up the analysis substantially. The default resolution equals the data display resolution.

Isodose limit

Minimum dose included in the analysis can be defined from the Min γ -dose/% -edit box for 2D data.




Figure 17. DD analysis using the isodose limit

Performing a gamma, DTA and DD analysis

Reference and the target data are chosen from the listbox by clicking them, respectively. If you wish to compute only DTA and DD, leave the checkbox 'only DTA/DD' chosen. If unchecked -> gamma parameter will be computed additionally to DTA and DD.

For **1D** gamma (Geurts, 2014), DTA and DD curves are presented after computation and the results (pass percentage) will be presented in the figure legend. The results and computed data are saved in the reference data structure. DTA and DD results and data are exported as CSV, when .CSV export is used.

For **2D** data gamma index (Geurts, 2014), DTA and DD are computed either from raw data ('low resolution' unchecked) or from low resolution data ('low resolution' checked). Consider low-resolution computation for large files. Gamma, DTA and DD computation results are displayed by clicking a corresponding checkbox ('gam', 'DTA', 'DD'). Note that gamma, DTA and DD results are activated only for the reference data, after the 2D gamma computation. Gamma data and results are saved to the reference data structure, which can be saved in the MATLAB workspace folder. Unlike in 1D case, the gamma data is not exported as CSV, but only the gamma computation results (pass percentage for gamma index, DTA and relative DD).

Each data structure may contain multiple gamma results (user prompt).




Figure 18. User prompt for multiple gamma results

Where the indices gamma_i_j corresponds the main UI listbox indices.

Saving the data and results




Figure 19. Data export buttons

Data can be saved as .mat file. The saved file is a structure set, containing all imported and computed data.

1D data, gamma, DTA and DD results can be exported as .csv file. New exports with same filenames won't append existing files but create a new file with indexed filename: "filename_n".

REFERENCES

IEC - International Electrotechnical Commission. Medical electrical equipment - Dosimeters with ionization chamber as used in radiotherapy. IEC Standard 60976, Genève: IEC, 2011.

Low DA, Harms WB, Mutic S, Purdy JA. A technique for the quantitative evaluation of dose distributions. Med Phys. 1998. 25(5):656-61. doi: 10.1118/1.598248. PMID: 9608475

Geurts, Mark. 2014. CalcGamma() MATLAB-function. Available at:
<https://github.com/mwgeurts/gamma>