



18 - CD20D3 - 20

# Installer's Guide

## Upflow / Horizontal and Downflow / Horizontal, Gas-Fired, Direct Vent, 2-Stage Condensing Furnaces with Variable Speed Inducer

\*UY060R9V3W

\*UY100R9V4W

\*DY060R9V3W

\*DY100R9V4W

\*UY080R9V3W

\*UY120R9V5W

\*DY080R9V3W

\*DY120R9V5W

\*\_\_First letter may be "A" or "T"


**ALL phases of this installation must comply with NATIONAL, STATE AND LOCAL CODES**



**IMPORTANT** — This Document is **customer property** and is to remain with this unit.  
Please return to service information pack upon completion of work.




\*UY-R9V-V



AIR  
FLOW

UPFLOW

\*DY-R9V-V




DOWNFLOW

AIR  
FLOW




AIR  
FLOW

UPFLOW/HORIZONTAL



DOWNFLOW/HORIZONTAL

AIR  
FLOW



## SAFETY SECTION

The following safety practices and precautions must be followed during the installation, servicing, and operation of this furnace.

1. Use only with the type of gas approved for this furnace. Refer to the furnace rating plate.
2. Install this furnace only in a location and position as specified in "Location and Clearances" (page 3), of these instructions.
3. Provide adequate combustion and ventilation air to the furnace space as specified in "Air for Combustion and Ventilation" (pages 7-8), of these instructions.
4. Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified in the "Venting" section (pages 13-22), of these instructions.
5. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections, as specified in "Gas Piping" (page 28), of these instructions.
6. Always install the furnace to operate within the furnace's intended temperature-rise range with a duct system which has an external static pressure within the allowable range, as specified on the unit rating plate. Airflow with temperature rise for cfm versus static is shown in the Service Facts accompanying this furnace.
7. When a furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by a duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.
8. A gas-fired furnace for installation in a residential garage must be installed as specified in "Location and Clearances" section (page 3), of these instructions.
9. The furnace may be used for temporary heating of buildings or structures under construction only when the following conditions have been met:
  - a. The furnace venting system must be complete and installed per manufacturer's instructions.
  - b. The furnace is controlled only by a room thermostat (no field jumpers).
  - c. The furnace return air duct must be complete and sealed to the furnace and clean air filters are in place.
  - d. The furnace input rate and temperature rise must be verified to be within nameplate marking.
  - e. 100% of the furnace combustion air requirement must come from outside the structure.
  - f. The furnace return air temperature range is between 55 and 80 degrees Fahrenheit.
  - g. Clean the furnace, duct work, and components upon substantial completion of the construction process, and verify furnace operating conditions including ignition, input rate, temperature rise and venting, according to the manufacturer's instructions.

Safety signal words are used to designate a degree or level of seriousness associated with a particular hazard. The signal words for safety markings are **DANGER**, **WARNING**, and **CAUTION**.

- a. **DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This signal word is limited to the most extreme situations.
- b. **WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- c. **CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It is also used to alert against unsafe practices and hazards involving only property damage.

### WARNING

#### **CARBON MONOXIDE POISONING HAZARD**

**Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death.**

The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation:

1. Seal any unused openings in the venting system.
2. Inspect the venting system for proper size and horizontal pitch, as required in the National Fuel Gas Code, ANSI Z223.1/NFPA 54 or the CAN/CGA B149 Installation Codes and these instructions. Determine that there is no blockage or restriction, leakage, corrosion and other deficiencies which could cause an unsafe condition.
3. As far as practical, close all building doors and windows and all doors between the space in which the appliance(s) connected to the venting system are located and other deficiencies which could cause an unsafe condition.
4. Close fireplace dampers.
5. Turn on clothes dryers and any appliance not connected to the venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they are operating at maximum speed. Do not operate a summer exhaust fan.
6. Follow the lighting instructions. Place the appliance being inspected into operation. Adjust the thermostat so appliance is operating continuously.
7. If improper venting is observed during any of the above tests, the venting system must be corrected in accordance with the National Fuel Gas Code, ANSI Z221.1/NFPA 54 and/or CAN/CGA B149 Installation Codes.
8. After it has been determined that each appliance connected to the venting system properly vents where tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-fired burning appliance to their previous conditions of use.

### WARNING

#### **FIRE OR EXPLOSION HAZARD**

**Failure to follow the safety warnings exactly could result in serious injury, death or property damage.**

**Improper servicing could result in dangerous operation, serious injury, death, or property damage.**

### CAUTION

**To prevent shortening its service life, the furnace should not be used as a "Construction Heater" during the finishing phases of construction until the requirements listed in item 9, a-g of the safety section of this publication have been met. Condensate in the presence of chlorides and fluorides from paint, varnish, stains, adhesives, cleaning compounds, and cement create a corrosive condition which may cause rapid deterioration of the heat exchanger.**

## GENERAL INSTALLATION INSTRUCTIONS

The manufacturer assumes no responsibility for equipment installed in violation of any code or regulation.

It is recommended that Manual J of the Air Conditioning Contractors Association (ACCA) or A.R.I. 230 be followed in estimating heating requirements. When estimating heating requirements for installation at altitudes above 2000 ft., remember the gas input must be reduced (See GAS INPUT ADJUSTMENT).

**Material in this shipment has been inspected at the factory and released to the transportation agency without known damage. Inspect exterior of carton for evidence of rough handling in shipment. Unpack carefully after moving equipment to approximate location. If damage to contents is found, report the damage immediately to the delivering agency.**

Codes and local utility requirements governing the installation of gas fired equipment, wiring, plumbing, and flue connections must be adhered to. In the absence of local codes, the installation must conform with latest edition of the National Fuel Gas Code ANSI Z223.1 • National Installation Code, CAN/CGA B149.1. The latest code may be obtained from the American Gas Association Laboratories, 8501 E. Pleasant Valley Rd., Cleveland, Ohio 44131.

These furnaces have been classified as CATEGORY IV furnaces in accordance with latest edition of ANSI Z21.47 standards • CAN/CGA 2.3. Category IV furnaces operate with positive vent static pressure and with a flue loss less than 17 percent. These conditions require special venting systems, which must be gas tight and water tight. These Category IV Direct Vent furnaces are approved for installation in Manufactured/Mobile housing when used with BAYMFGH100A.

### LOCATION AND CLEARANCES

The location of the furnace is normally selected by the architect, the builder, or the installer. However, before the furnace is moved into place, be sure to consider the following requirements:

1. Is the location selected as near the chimney or vent and as centralized for heat distribution as practical?
2. Do all clearances between the furnace and enclosure equal or exceed the minimums stated in Clearance Table on the Outline Drawings.
3. Is there sufficient space for servicing the furnace and other equipment? A minimum of 24 inches front accessibility to the furnace must be provided. Any access door or panel must permit removal of the largest component.
4. Are there at least 3 inches of clearance between the furnace combustion air openings in the front panel and any closed panel or door provided?
5. Are the ventilation and combustion air openings large enough and will they remain unobstructed? If outside air is used, are the openings set above the highest snow accumulation level? (See the Air for Combustion and Ventilation section)
6. Allow sufficient height in supply plenum above the furnace to provide for cooling coil installation, if the cooling coil is not installed at the time of this furnace installation.
7. A furnace shall be installed so electrical components are protected from water.
8. If the furnace is installed in a **residential garage**, it must be installed so that the burners, and the ignition source are located not less than 18 inches above the floor and the furnace must be located or protected to avoid physical damage from vehicles.

## Contents

### Installation Instructions

|  |              |
|--|--------------|
| General Installation Instructions        | 3            |
| Location and Clearances                  | 3            |
| <b>Outline Drawing</b>                   | <b>4-5</b>   |
| Upflow Installation                      | 6            |
| Downflow Installations                   | 6            |
| Horizontal Installation                  | 6            |
| Air for Combustion and Ventilation       | 7            |
| Duct Connections                         | 8            |
| Return Air Filters                       | 9            |
| General Venting Information              | 13           |
| Venting Materials                        | 15           |
| High Altitude Derate                     | 16           |
| Horizontal Venting Through the Wall      | 17           |
| Downward Venting                         | 18           |
| Venting Through the Roof                 | 22           |
| Venting Routed Through a Masonry Chimney | 23           |
| Electrical Connections                   | 24           |
| <b>Field Wiring Diagrams</b>             | <b>24-26</b> |
| Condensate Drain Instructions            | 27           |
| Gas Piping                               | 29           |
| Combustion and Input Check               | 30           |

### Start-up and Adjustment

|                                       |    |
|---------------------------------------|----|
| Preliminary Inspections               | 32 |
| Lighting Instructions                 | 32 |
| Sequence of Operation                 | 33 |
| Control and Safety Switch Adjustments | 33 |
| Airflow Adjustment                    | 33 |

### Abnormal Conditions

### IFC Error Flash Codes

|                     |    |
|---------------------|----|
| Fault Code Recovery | 36 |
|---------------------|----|

#### IMPORTANT:

*The furnace must be installed level. The only allowable variation would be slightly to the left and/or forward in upflow installations or slightly toward the front in horizontal installations. This is necessary for proper condensate drainage.*

### ⚠ CAUTION


**Do not install the furnace in a corrosive or contaminated atmosphere. Failure to follow this warning could result in early equipment failure.**

### ⚠ WARNING

**Do not install the furnace directly on carpeting, tile or other combustible material other than wood flooring. For vertical downflow application, subbase (BAYBASE205) must be used between the furnace and combustible flooring. When the downflow furnace is installed vertically with a cased coil, a subbase is not required.**

**\*UY-R9V-W OUTLINE DRAWING**




(ALL DIMENSIONS ARE IN INCHES)



From Dwg. 21C341884 Rev. 1

**\*DY-R9V-W DOWNFLOW / HORIZONTAL OUTLINE DRAWING**

(ALL DIMENSIONS ARE IN INCHES)



| MODEL<br>(SEE NOTE 1)          | DIM "A" | DIM "B"  | DIM "C" | DIM "D" |
|--------------------------------|---------|----------|---------|---------|
| *DY060R9V3***<br>*DY080R9V3*** | 17-1/2" | 2-1/4"   | 16-1/4" | 16"     |
| *DY100R9V4***                  | 21"     | 2-1/2"   | 19-3/4" | 19-1/2" |
| *DY120R9V5***                  | 24-1/2" | 2-15/16" | 23-1/4" | 23"     |

- \* PREFIX MAY BE "A" OR "T"
- \*\* SUFFIX LETTER MAY BE "D" - 0 THRU 9
- \*\*\* SUFFIX LETTER MAY BE "W" - 0 THRU 9


NOTES:  
1. DIAMETER OF VENT PIPE MAY BE LIMITED TO 2-1/2" OR 3" ON SOME MODELS AT DIFFERENT ALTITUDES. REFER TO THE VENT LENGTH TABLE FOR PROPER APPLICATION.

| MINIMUM CLEARANCE TO COMBUSTIBLE MATERIALS            |        |
|---|--------|
| <b>DOWNFLOW</b>                                       |        |
| SIDES   | 0 IN.  |
| REAR  | 0 IN.  |
| FRONT   | 3 IN.  |
| TOP   | 1 IN.  |
| FLUE  | 0 IN.  |
| <b>HORIZONTAL (FLUE DISCHARGE ON THE LEFT) ALCOVE</b> |        |
| SIDES   | 0 IN.  |
| RIGHT   | 0 IN.  |
| LEFT  | 0 IN.  |
| REAR  | 6 IN.  |
| FRONT   | 18 IN. |
| TOP   | 1 IN.  |
| FLUE  | 0 IN.  |
| <b>CLOSET</b>   |        |
| SIDES   | 1 IN.  |
| RIGHT   | 1 IN.  |
| LEFT  | 1 IN.  |
| REAR  | 3 IN.  |
| FRONT   | 3 IN.  |
| TOP   | 1 IN.  |
| FLUE  | 0 IN.  |


# Installer's Guide

## UPFLOW INSTALLATION

Standoffs and screws (See Figure 1) are included with the cased coils for attachment to the furnace. There are clearance alignment holes near the bottom of the coil wrapper. Drill screws are used to engage the furnace top flanges. The standoff is inserted into the cabinet alignment hole. The drill screws are inserted through the standoffs then screwed into the furnace flange. The coil is always placed downstream of the furnace airflow.



## DOWNFLOW INSTALLATIONS



## WARNING

Do not install the furnace directly on carpeting, tile or other combustible material other than wood flooring. For vertical downflow application, subbase (BAYBASE205) must be used between the furnace and combustible flooring. When the downflow furnace is installed vertically with a cased coil, a subbase is not required.

REQUIRED FLOOR OPENING: (DOWNFLOW)  
SEE FIGURE 3 AND TABLE 1





TABLE 1

| CABINET WIDTH | RETURN DUCT WIDTH | FLOOR OPENING |         | PLENUM OPENING |         |
|---------------|-------------------|---------------|---------|----------------|---------|
|               |                   | "A"           | "B"     | "C"            | "D"     |
| 14-1/2"       | 13-1/4"           | 13-5/8"       | 20-1/8" | 12-5/8"        | 19-3/8" |
| 17-1/2"       | 16-1/4"           | 16-5/8"       | 20-1/8" | 15-5/8"        | 19-3/8" |
| 21"           | 19-3/4"           | 20-1/8"       | 20-1/8" | 19-1/8"        | 19-3/8" |
| 24-1/2"       | 23-1/4"           | 23-5/8"       | 20-1/8" | 22-5/8"        | 19-3/8" |

## HORIZONTAL INSTALLATION

The coil and furnace must be fully supported when used in the horizontal position. It is always recommended that an auxiliary drain pan be installed under a horizontally installed evaporator coil or 90% gas furnace. Connect the auxiliary drain line to a separate drain line (no trap is needed in this line).


Three brackets (with screws) are included with downflow furnaces for installation to stabilize and secure the furnace and TXC cased coil in the **horizontal position**. See Figure 4. The coil is placed downstream of the furnace, with the apex of the coil pointing in the direction of the airflow for **horizontal installation**. The cased coil is secured to the furnace and both the furnace **and** the cased coil must be properly supported. The brackets mount using the rear screws on the coil case and use the screws provided to secure the bracket to the furnace. The remaining bracket is placed as close to center as possible (horizontally) between the coil case front and the furnace bottom channel (for downflow/horizontal furnace). Use four of the screws provided to secure the bracket. The upflow furnace, converted to horizontal, aligns and attaches the TXC coil as in Figure 1. However, the coil requires additional support.




The furnace may be installed in an attic or crawl space in the horizontal position by placing the furnace *on the left side* (as viewed from the front in the vertical position). The horizontal furnace installation in an attic should be on a service platform large enough to allow for proper clearances on all sides and service access to the front of the furnace (See Figure 5 & Clearance Tables, pages 4-5). Line contact is only permissible between lines formed by intersections of the top and two sides of the furnace casing and building joists, studs, or framing.

The furnace may be placed horizontally in a crawl space on a pad or other noncombustible material which will raise the unit for sufficient protection from moisture. **The furnace must be supported at both ends and the middle when installed horizontally. The furnace must also be elevated approximately 4-6 inches to allow clearance for the condensate drain to exit the cabinet in the horizontal position.**

The horizontal furnace may also be suspended from the joists using 3/8" all-thread rods with pieces of angle iron underneath the furnace to form a hanging rack at both ends and the midpoint. The rods need to be of sufficient length to allow for proper clearances from combustible materials. The angle iron needs to be at least 32" in length to allow for access to service panels.





## AIR FOR COMBUSTION AND VENTILATION

If these furnaces are installed in a nondirect vent capacity then the adequate flow of combustion and ventilating air must not be obstructed from reaching the furnace. Air openings provided for combustion air must be kept free of obstructions which restrict the flow of air. Airflow restrictions affect the efficiency and safe operation of the furnace. Keep this in mind should you choose to remodel or change the area which contains your furnace. Furnaces must have a free flow of air for proper performance.

Provisions for combustion and ventilation air shall be made in accordance with latest edition of Section 5.3, Air for Combustion and Ventilation, of the National Fuel Gas Code, ANSI Z223.1 — CAN/CGA B149.1 or applicable provisions of the local building codes. Special conditions created by mechanical exhausting of air and fireplaces must be considered to avoid unsatisfactory furnace operation.

### OUTSIDE AIR IS RECOMMENDED

The use of indoor air for most applications is acceptable, unless **there is the presence of corrosive chemicals or contamination**. Certain types of installation will **require** the use of outside air for combustion.

The following types of installations will **require** use of OUTDOOR AIR for combustion, due to chemical exposures:

- \* Commercial buildings
- \* Buildings with indoor pools
- \* Furnaces installed in "confined" laundry rooms
- \* Furnaces installed in "confined" hobby or craft rooms
- \* Furnaces installed near chemical storage areas.

Exposure to the following substances in the combustion air supply will also require OUTDOOR AIR for combustion:

- \* Permanent wave solutions
- \* Chlorinated waxes and cleaners
- \* Chlorine based swimming pool chemicals
- \* Water softening chemicals
- \* Deicing salts or chemicals
- \* Carbon Tetrachloride
- \* Halogen type refrigerants
- \* Cleaning solvents (such as perchloroethylene)
- \* Printing inks, paint removers, varnish, etc.
- \* Hydrochloric acid
- \* Cements and glues
- \* Antistatic fabric softeners for clothes dryers
- \* Masonry acid washing materials

Furnace locations may be in a "**confined space**" or an "**unconfined space**".


*Unconfined space* is defined in Figure 6. These spaces may have adequate air by infiltration to provide air for combustion and ventilation. Buildings with tight construction (for example, weather stripping, heavily insulated, caulked, vapor barrier, etc.), may need additional air to be provided as described for *confined space*.

*Confined spaces* are installations with less than 50 cu. ft. of space per 1000 BTU/hr input from all equipment installed. Air for combustion and ventilation requirements can be supplied from inside the building as in Figure 8 or from the outdoors, as in Figure 9.

⑦

**MINIMUM AREA IN SQUARE FEET  
FOR UNCONFINED SPACE INSTALLATIONS**

| FURNACE<br>MAXIMUM BTUH<br>INPUT RATING | WITH 8 FT. CEILING<br>MINIMUM AREA IN SQUARE FEET<br>OF UNCONFINED SPACE |
|---|--|
| 60,000                                  | 375  |
| 80,000                                  | 500  |
| 100,000                                 | 625  |
| 120,000                                 | 875  |







1. All air from inside the building as in Figure 9: The confined space shall be provided with two permanent openings communicating directly with an additional room(s) of sufficient volume so that the combined volume of all spaces meets the criteria for an unconfined space. The total input of all gas utilization equipment installed in the combined space shall be considered in making this determination. Refer to Table 2 for minimum open areas requirements.
2. All air from outdoors as in Figure 10: The confined space shall be provided with two permanent openings, one commencing within 12 inches of the top and one commencing within 12 inches of the bottom of the enclosure. The openings shall communicate directly, or by ducts, with the outdoors or spaces (crawl or attic) that freely communicate with the outdoors. Refer to Table 2, for minimum open areas requirements.

**TABLE 2**  
**MINIMUM FREE AREA IN SQUARE INCHES**  
**EACH OPENING (FURNACE ONLY)**

| Furnace<br>Maximum<br>BTUH/INPUT<br>Rating | Air<br>From<br>Inside | Air From Outside |                    |
|--|-----------------------|------------------|--------------------|
|  |                       | Vertical<br>Duct | Horizontal<br>Duct |
| 60,000                                     | 100                   | 15               | 30                 |
| 80,000                                     | 100                   | 20               | 40                 |
| 100,000                                    | 100                   | 25               | 50                 |
| 120,000                                    | 120                   | 30               | 60                 |

# Installer's Guide



## DUCT CONNECTIONS

Air duct systems should be installed in accordance with standards for air conditioning systems, National Fire Protection Association Pamphlet No. 90. They should be sized in accordance with ACCA Manual D or whichever is applicable.

Central furnaces, when used in connection with cooling units, shall be installed in parallel or on the upstream side of the cooling coil to avoid condensation in the heat exchanger. With a parallel flow arrangement, the dampers or other means used to control flow of air shall be adequate to prevent chilled air from entering the furnace, and if manually operated, must be equipped with means to prevent operation of either unit unless the damper is in full heat or cool position.

On any job, flexible connections of nonflammable material may be used for return air and discharge connections to prevent transmission of vibration. Though these units have been specifically designed for quiet, vibration free operation, air ducts can act as sounding boards and could, if poorly installed, amplify the slightest vibration to the annoyance level.

When the furnace is located in a utility room adjacent to the living area, the system should be carefully designed with returns to minimize noise transmission through the return air grille. Although these furnaces are designed with large blowers operating at moderate speeds, any blower moving a high volume of air will produce audible noise which could be objectionable when the unit is located very close to a living area. It is often advisable to route the return air ducts under the floor or through the attic. Such design permits the installation of air return remote from the living area (i.e. central hall).

When the furnace is installed so that the supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by a duct(s) sealed to the furnace and terminating outside the space containing the furnace.

## RETURN AIR DUCT SYSTEMS

**Where there is no complete return duct system, the return connection must be run full size from the furnace to a location outside the utility room, basement, attic, or crawl space.**

***Do Not*** install return air through the back of the furnace cabinet.

***Do Not*** install return air through the side of the furnace cabinet on horizontal applications.

## NOTE:

**Minimum return air temperature is 50° F.**

All return air duct systems should provide for installation of return air filters.

1. Set the furnace in place.
2. For upflow side return installations, remove the insulation around the opening in the blower compartment.
3. The side panels of the upflow furnace include locating notches that are used as guides for cutting an opening for return air, refer to Figure 11 and the outline drawing on page 4 for duct connection dimensions for various furnaces.
4. If a 3/4" flange is to be used for attaching the air inlet duct, add to cut where indicated by dotted lines in Figure 11. Cut corners diagonally and bend outward to form flange.
5. If flanges are not required, and a filter frame is installed, cut between locating notches (See Figure 11).
6. The bottom panel of the upflow furnace must be removed for bottom return air.



Remove the filter and lay the furnace on its back. Remove the two 1/4" hex screws securing the bottom front channel to the cabinet. Lower the front edge of the bottom front channel and pull forward to remove the channel. The bottom return air panel will now easily slide out of the cabinet. Reinstall the bottom front channel and filter for upflow bottom return installations.

7. The filter retainer is factory supplied for upflow bottom return. Use the filter retainer on side or bottom if filter is to be used within the furnace cabinet on upflow only installations.
8. **The horizontal installation of the upflow furnace requires an external filter section. Do NOT use the bottom return filter within the furnace. Filter kits are available for horizontal applications.**
9. Connect duct work to furnace. See Outline Drawing for supply and return duct size and location. Flexible duct connectors are recommended to connect both supply and return air ducts to the furnace. If only the front of the furnace is accessible, it is recommended that both supply and return air plenums are removable.

## RETURN AIR FILTERS

### TYPICAL UPFLOW RETURN AIR FILTER INSTALLATIONS

Filters are factory supplied for these furnaces. These furnaces require high velocity type air filters. The filters may be located within the furnace blower compartment for UPFLOW furnaces in either a BOTTOM or SIDE (left side or right side) return air inlet. Some filters may need to be trimmed for side or bottom filter use.

TABLE 3

| MODELS NUMBERS           | CABINET WIDTH | FILTER QTY & SIZE  |
|--------------------------|---------------|--------------------|
| *UY060R9V3<br>*UY080R9V3 | 17-1/2"       | 1 - 17" X 25" X 1" |
| *UY100R9V4               | 21"           | 1 - 20" X 25" X 1" |
| *UY120R9V5               | 24-1/2"       | 1 - 24" X 25" X 1" |

\* First letter may be "A" or "T"  
 \*\* NOTE - On 5 ton airflow models, if the airflow requirement exceeds 1800 CFM, these models will require return air openings and filters on both sides; OR 1 side and the bottom; OR just the bottom.

#### NOTE:



**On upflow 5 ton airflow models, if the airflow requirement exceeds 1800 CFM, these models will require return air openings and filters on both sides; OR 1 side and the bottom; OR just the bottom.**

The upflow furnace blower door has a hinge at the bottom which allows the door to tilt forward for filter replacement without the door being removed (See Figure 12). The furnace filter in the bottom or side configuration can be removed by simply turning the two latches on the blower door and tilting the door forward.


The filter rails are spring loaded for automatic adjustment to allow standard size, locally obtainable replacement filters. The filter rack itself slides to adjust to the required width needed for bottom or side return (See Figure 13).

### BOTTOM FILTER RACK INSTALLATION

With the filter removed, the filter rack is compressed and then inserted into the bottom of the furnace. The retaining screw/pin on each side inserts into engagement holes at the bottom of the furnace cabinet side.



# Installer's Guide




## FILTER RACK INSTALLATION FOR SIDE RETURN AIR ON UPFLOW FURNACES (Left or Right)

### NOTE:

The filter rack installation is not allowed for right side return on the following models: \*UY060R9V3 & \*UY080R9V3.




If side air return is desired, it is necessary to move the filter rack from the bottom of the furnace and reinstall it on the side. The following instructions should be used:



- Open or remove the blower door.
- Remove the filter.
- Compress the filter rack to disengage the retaining pins/screws from the furnace sides and slide the filter rack out.
- Leave the bottom panel in place.
- After the side cutout is made following the directions in the "Return Air Duct Connections" section on pages 8 and 9, compress the filter rack and reinstall in the side of the furnace. Confirm that the upper retaining pin/screw locks into the engagement hole in



the blower deck and the lower pin/screw rests against the side of the bottom panel. See Figures 15-19.


- Reinstall the furnace filter on the side inserting the chamfer end first.






## RETURN AIR FILTERS FOR UPFLOW FURNACE IN HORIZONTAL CONFIGURATION

When the Upflow Furnace is installed in the horizontal configuration, the return air filters must be installed exterior to the cabinet. Remote filter grilles may be used for homeowner convenience or the filters may be installed in the duct work upstream of the furnace. See Figure 20.




## BLOWER DOOR / HINGE REMOVAL

If clearance or other problems create a problem in using the tilting door, the blower door hinge may be removed without creating any problems with the seal of the furnace. To remove the blower door, tilt the door forward 2 to 3 inches and pull up. To remove the tilt feature, simply remove the lower hinge as shown in Figure 20. The bottom of the blower door will catch in the bottom of the furnace front channel for door replacement.



## ALTERNATE UPFLOW FILTER CLIP / BRACKET INSTALLATION

1. Determine the location to be used. The furnace cabinet has dimples for location of the alternate furnace clips (*Side return only*). Pre-drill clearance holes with a 3/16" drill. Bottom return holes are pre-drilled.
2. Install the clips in front and rear of the desired location using the screws provided. The filter clip with the leaf spring mounts in the rear of the cabinet.



# Installer's Guide

## INSTALLING THE FILTER

The filter may need to be cut to fit the unit depending on the location of the return air filter.

A score line and the words "CUT HERE" are located on the end of the filter. If your application requires cutting the filter, do so as indicated by the score mark.

| UNIT SIZE | RETURN AIR |             |
|-----------|------------|-------------|
|           | BOTTOM     | SIDE        |
| 17-1/2"   | DO NOT CUT | DO NOT CUT  |
| 21"       | DO NOT CUT | CUT ON LINE |
| 24-1/2"   | DO NOT CUT | CUT ON LINE |

## TYPICAL DOWNFLOW FURNACE RETURN AIR FILTER INSTALLATIONS

Two filters are factory supplied for each downflow furnace. These furnaces require high velocity type air filters. Downflow furnace filters must be located outside the furnace cabinet. Typical installations are shown in Figure 23. Tables 5 and 6 provide information for installation of the filter retaining brackets shipped with downflow furnaces.

TABLE 4

| MODELS NUMBERS           | CABINET WIDTH | FILTER QTY & SIZE  |
|--------------------------|---------------|--------------------|
| *DY060R9V3<br>*DY080R9V3 | 17-1/2"       | 2 - 14" X 20" X 1" |
| *DY100R9V4               | 21"           | 2 - 16" X 20" X 1" |
| *DY120R9V5               | 24-1/2"       | 2 - 16" X 20" X 1" |

\*First letter may be "A" or "T"

TABLE 5

## LOCATING FILTER RETAINER BRACKETS IN DUCTWORK

| CABINET WIDTH | RETURN DUCT WIDTH | DIMENSION "A" | DIMENSION "B" | FILTER BRACKET LOCATION* |
|---------------|-------------------|---------------|---------------|--------------------------|
| 17-1/2"       | 16-1/4"           | 15"           | 14"           | 14-3/8"                  |
| 21"           | 19-3/4"           | 19-1/2"       | 14"           | 13-1/8"                  |
| 24-1/2"       | 23-1/4"           | 22"           | 14"           | 13-5/8"                  |

\* LOCATION DIMENSION IS FROM END OF DUCT AGAINST THE FURNACE TO THE SCREW HOLES FOR THE BRACKET.




TABLE 6

| MINIMUM CLEARANCE FROM COMBUSTIBLE MATERIALS FOR UPFLOW/HORIZONTAL AND DOWNFLOW/ HORIZONTAL FURNACES |                 |                   |                           |
|--|-----------------|-------------------|---------------------------|
| FURNACE SURFACE  | UNIT LOCATION   |                   |                           |
|  | VERTICAL CLOSET | HORIZONTAL CLOSET | HORIZONTAL ALCOVE / ATTIC |
| SIDES  | 0"              | 1"                | 0"                        |
| BACK   | 0"              | 3"                | 6"                        |
| TOP  | 1"              | 1"                | 1"                        |
| FRONT  | 3"              | 3"                | 18"                       |
| VENT   | 0"              | 0"                | 0"                        |

NOTE: CLEARANCE REQUIRED AT TOP OF PLENUM IS 1"

## GENERAL VENTING INFORMATION

THIS FURNACE MUST BE VENTED TO THE OUTDOORS. THESE FURNACES ARE INDUCED DRAFT VENTED AND MUST **NOT** BE CONNECTED TO ANY VENT SERVING ANOTHER APPLIANCE. PLEASE NOTE THAT THESE FURNACES USE **POSITIVE-PRESSURE** VENT SYSTEMS.

Proper venting is essential to obtain maximum efficiency from a condensing furnace. Proper installation of the vent system is necessary to assure drainage of the condensate and prevent deterioration of the vent system.

American Gas Association has certified the design of condensing furnaces for a minimum of 0" clearance from combustible materials with a single wall plastic vent pipe.

The recommended system is assembled from 2", 2-1/2", or 3" plastic pipe and fittings (See Table 7, page 15). Where the system is routed to the outdoors through an existing masonry chimney containing flue products from another gas appliance, or where required by local codes, then 3" venting of Type 29-4C stainless steel must be used in place of PVC material.

These furnaces have been classified as CATEGORY IV furnaces in accordance with ANSI Z21.47 "latest edition" standards. Category IV furnaces operate with positive vent pressure and with a vent gas temperature less than 140° F. above the dewpoint. These conditions require special venting systems, which must be gas tight and water tight.

### NOTE:

**When an existing furnace is removed from a venting system serving other gas appliances, the venting system is likely to be too large to properly vent the remaining attached appliances.**

The following steps shall be followed with each appliance remaining connected to the common venting system placed in operation, while the other appliances remaining connected to the common venting system are not in operation.

1. Seal any unused openings in the common venting system.
2. Visually inspect the venting system for proper size and horizontal pitch and determine there is no blockage or restriction, leakage, corrosion or other deficiencies which could cause an unsafe condition.
3. Insofar as is practical, close all building doors and windows and all doors between the space in which the appliances remaining connected to the common venting system are located and other spaces of the building. Turn on clothes dryers and any appliances not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan, close fireplace dampers.
4. Follow the lighting instructions. Place the appliance being inspected in operation. Adjust thermostat so appliance will operate continuously.
5. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle, or smoke from a cigarette, cigar, or pipe.
6. After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return door, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous conditions of use.



If improper venting is observed during any of the above tests, the remaining common venting system must be corrected. Correction could require rerouting or resizing the remaining vent system.

### HORIZONTAL INSTALLATION

(UPFLOW / HORIZONTAL OR DOWNFLOW / HORIZONTAL)

#### NOTE:

**In horizontal venting when the factory supplied "off-set" (2X3 reducing coupling) is used for 3" vent pipe installation, make sure the marking "Top" is located on the top side of the pipe. The straight side must be on bottom for proper condensate drainage. This coupling is factory supplied only with the following models: \*UC120 & \*DC120, \*UX120 & \*UY120, \*UX100 & \*UY100, \*UX808C960, and all \*DX & \*DY models.**



The following warning complies with State of California law, Proposition 65.

## ⚠ WARNING

### Hazardous Gases!

**Exposure to fuel substances or by-products of incomplete fuel combustion is believed by the state of California to cause cancer, birth defects, or other reproductive harm.**

Carbon monoxide, fire or smoke can cause serious bodily injury, death, and/or property damage.

A variety of potential sources of carbon monoxide can be found in a building or dwelling such as gas-fired clothes dryers, gas cooking stoves, water heaters, furnaces and fireplaces. The U.S. Consumer Product Safety Commission recommends that users of gas-burning appliances install carbon monoxide detectors as well as fire and smoke detectors per the manufacturer's installation instructions to help alert dwelling occupants of the presence of fire, smoke or unsafe levels of carbon monoxide. These devices should be listed by Underwriters Laboratories, Inc. *Standards for Single and Multiple*

# Installer's Guide

Station Carbon Monoxide Alarms, UL 2034 or CSA International Standard, Residential Carbon Monoxide Alarming Devices, CSA 6.19

## NOTE:

The manufacturer of your furnace does not test any detectors and makes no representations regarding any brand or type of detector.

## IMPORTANT:

These furnaces may be installed as Direct Vent (sealed combustion) or as Nondirect vent (single pipe). The furnaces are shipped **DIRECT VENT** with sealed combustion.

For **DIRECT VENT APPLICATION**: The furnaces must be vented to the exterior of the house and combustion air **MUST** come through the inlet air pipe **FROM OUTSIDE AIR**. The pipes **DO NOT** have to exit the exterior of the house together or on the same side of the house.

For **NONDIRECT VENT APPLICATION**: The furnace shall be vented to the exterior of the house, but combustion air may enter from the surrounding area as long as combustion air requirements are met. (See **AIR FOR COMBUSTION AND VENTILATION**)

## FURNACE VENT/INLET PIPE INSTALLATION

There are many different variations of the vent/inlet air pipe combination. The vent/inlet air combination used for installation of these furnaces depends on the needs of the location. However, these guidelines must be followed:

1. The furnace must vent outside the structure.
2. Furnace combustion air requirements must be met for nondirect, single pipe applications (See example 2 below).
3. For direct vent application of these furnaces, the vent pipe and air inlet pipe do not have to exit in the same air space or even on the same surface of the structure. However, the longest individual pipe will decide the value for the longest allowable equivalent vent/inlet air length as shown in the vent length table.


## NOTE:

**BAYVENT200B accessories can be used for inlet and outlet terminals when the pipes do not exit the structure together.**

The following are **EXAMPLES ONLY**:

### EX. 1 —


Example 1 shows that the vent may go vertical while the inlet air may be on any side of the structure. The vent pipe would decide the maximum equivalent length for the pipe depending on the furnace and pipe size.



### EX. 2 —


Example 2 shows the vent pipe exhausting through the roof and the inlet air coming from the interior of the house (See Note). The inlet air coming from the interior of the house must meet combustion requirements for area, etc., as shown

in the section **AIR FOR COMBUSTION AND VENTILATION** in this Installer's Guide.




### EX. 3 —

Example 3 shows the vent exiting one side of the house while the inlet air is on the opposite side of the structure. Here the vent pipe length must be within the allowable length for the size of furnace and size of the vent pipe. This example demonstrates that the pipes do not have to exit on the same side of the structure.



### EX. 4 —

The inlet air does not have to come from outside the structure. Example 4 shows the inlet air (See Note), may come from the attic if the requirements for combustion air are met as shown in the section **AIR FOR COMBUSTION AND VENTILATION**.





## NOTE:

If only the flue gas pipe is to the outside of the structure, a straight section of pipe (long enough to exit the furnace cabinet) must be attached to the inlet air side with an elbow (which is 5 to 10 equiv. ft.) installed on the end to prevent dust and debris from falling directly into the furnace.

TABLE 7

**PVC VENT FITTING MATERIAL** These fittings are available from your Gas Furnace Distributors.



## PLASTIC PIPE DESIGNATIONS

### PVC

| ASTM STANDARD | PIPE TYPE       | ALLOWABLE TEMPERATURE | MARKING    |
|---------------|-----------------|-----------------------|------------|
| F891          | CELLULAR CORE   | *158                  | ASTM F891  |
| D2665         | DWV PIPE        | **158                 | ASTM D2665 |
| D1785         | SCH 40, 80, 120 | **158                 | ASTM D1785 |
| D2241         | SDR SERIES      | ***158                | ASTM D2241 |

### CPVC

| ASTM STANDARD | PIPE TYPE  | ALLOWABLE TEMPERATURE | MARKING    |
|---------------|------------|-----------------------|------------|
| D2846         | CPVC 41    | **212                 | ASTM D2846 |
| F441          | SCH 40, 80 | **212                 | ASTM F441  |
| F442          | SDR SERIES | **212                 | ASTM F442  |

### ABS

| ASTM STANDARD | PIPE TYPE                | ALLOWABLE TEMPERATURE | MARKING    |
|---------------|--------------------------|-----------------------|------------|
| D2661         | SCH 40 DWV               | ***180                | ASTM D2661 |
| F628          | SCH 40 DWV CELLULAR CORE | ***180                | ASTM F628  |

\* - Allowable temperatures based on classifications covered in ASTM D4396 [Deflection Temps Under Load (264 PSI)]

\*\* - Allowable temperatures based on classifications covered in ASTM D1784 [Deflection Temps Under Load (264 PSI)]

\*\*\* - Allowable temperatures based on classifications covered in ASTM D3965 [Deflection Temps Under Load (264 PSI)]

## VENT FITTING MATERIAL – PLASTIC

Gas and liquid tight single wall vent fittings, designed for resistance to corrosive flue condensate, **MUST** be used throughout.

Listed in Table 7 are 2", 2-1/2", and 3" size fittings that meet these requirements. The materials listed are various grades of PVC and ABS plastic.

**PIPE JOINTS:** All joints must be fastened and sealed to prevent escape of combustion products into the building.

### NOTE:

*It is recommended that the first joints from the furnace be connected and sealed with high temperature RTV. This will enable the pipes to be removed later without cutting.*

*Be sure to properly support these joints.*

## BONDING OF PVC

Commercially available solvent cement for PVC must be used to join PVC pipe fittings. Follow instructions on container carefully.

Pipe and Fittings – ASTM D1785, D2466, D2661, & D2665

PVC Primer and Solvent Cement – ASTM D2564.

Procedure for Cementing Joints Ref – ASTM D2855

1. Cut pipe square, remove ragged edges and burrs. Chamfer end of pipe, then clean fitting socket and pipe joint area of all dirt, grease, moisture or chips.
2. After checking pipe and socket for proper fit, wipe socket and pipe with cleaner-primer. Apply a liberal coat of primer to inside surface of socket and outside of pipe. **DO NOT ALLOW PRIMER TO DRY BEFORE APPLYING CEMENT.**
3. Apply a thin coat of cement evenly in the socket. Quickly apply a heavy coat of cement to the pipe end and insert pipe into fitting with a slight twisting movement until it bottoms out.
4. Hold the pipe in the fitting for 30 seconds to prevent tapered socket from pushing the pipe out of the fitting.
5. Wipe all excess cement from the joint with a rag. Allow 15 minutes before handling. Cure time varies according to fit, temperature and humidity.

### NOTE:

**Follow venting instructions carefully when using PVC cement.**

### IMPORTANT:

*All joints must be water tight. Flue condensate is somewhat acidic, and leaks can cause equipment damage.*

# Installer's Guide


Connection of the pipe and collar of the combustion air inlet should just be a friction fit. It is recommended that the inlet air joint be sealed with RTV type sealant to allow the joint to be separated for possible future service. The inlet and vent pipes must be properly supported throughout the entire length.

Connection of the vent pipe to the vent collar should also be accomplished using RTV type sealant. This type sealant provides a connection which remains flexible and can be separated in the future if service needs require the removal of the vent pipe for service or clearance.

## ⚠ WARNING

### CARBON MONOXIDE POISONING HAZARD

Failure to follow the installation instructions for the venting system being placed into operation could result in carbon monoxide poisoning or death.



**VENT LENGTH TABLE**

| ALTITUDE          | MAXIMUM TOTAL EQUIVALENT LENGTH IN FEET<br>FOR VENT AND INLET AIR (SEE NOTES) |               |                  |
|-------------------|---|---------------|------------------|
| 0-7,000 Feet      | 2 INCH PIPE   | 2.5 INCH PIPE | 3 or 4 INCH PIPE |
| UY/DY060R9V3      | 200   | 200           | 200              |
| UY/DY080R9V3      | 50  | 120           | 200              |
| UY/DY100R9V4      | Not Allowed   | 60            | 200              |
| UY/DY120R9V5      | Not Allowed   | Not Allowed   | 200              |
| 7,000-9,500 Feet  | 2 INCH PIPE   | 2.5 INCH PIPE | 3 or 4 INCH PIPE |
| UY/DY060R9V3      | 100   | 100           | 100              |
| UY/DY080R9V3      | 25  | 60            | 100              |
| UY/DY100R9V4      | Not Allowed   | 30            | 100              |
| UY/DY120R9V5      | Not Allowed   | Not Allowed   | 100              |
| 9,500-12,000 Feet | 2 INCH PIPE   | 2.5 INCH PIPE | 3 or 4 INCH PIPE |
| UY/DY060R9V3      | 50  | 50            | 50               |
| UY/DY080R9V3      | Not Allowed   | 30            | 50               |
| UY/DY100R9V4      | Not Allowed   | Not Allowed   | 50               |
| UY/DY120R9V5      | Not Allowed   | Not Allowed   | 50               |

NOTES: \* - First letter may be "A" or "T"

1. Minimum vent length for all models: 3' horizontal or 3' vertical.

2. DO NOT MIX PIPE DIAMETERS IN THE SAME LENGTH OF PIPE OUTSIDE THE FURNACE CABINET, (Except adapters at the top of the furnace). If different inlet and vent pipe sizes are used, the vent pipe must adhere to the maximum length limit shown in the table above (See note 6 below for exception). The inlet pipe can be of a larger diameter, but never smaller than the vent pipe.

3. MAXIMUM PIPE LENGTHS MUST NOT BE EXCEEDED! THE LENGTH SHOWN IS NOT A COMBINED TOTAL, IT IS THE MAXIMUM LENGTH OF EACH (Vent or Inlet air pipes).

4. One SHORT radius 90° elbow is equivalent to 10' of 3" pipe and one LONG radius elbow is equivalent to 6' of 3" pipe. One 90° elbow is equivalent to 7½' of 2½" pipe or 5' of 2" pipe. Two 45° elbows equal one 90° elbow.

5. The termination tee or bend must be included in the total number of elbows. If the BAYVENT100A termination kit is used, the equivalent length of pipe is 5 feet. BAYVENT200A equivalent length is 0 feet.

6. Pipe adapters are field supplied. Downflow models, UY100, and UY120 include 2" X 3" pipe adapter.

### HIGH ALTITUDE DERATE

Input ratings (BTUH) of these furnaces are based on sea level operation and should not be changed at elevations up to 2,000 ft.

If the installation is 2,000 ft. or above, the furnace input rate (BTUH) shall be reduced 4% for each 1,000 ft. above sea level.

The furnace input rate shall be checked by clocking the gas flow rate (CFH) and multiplying by the heating value ob-

tained from the local utility supplier for the gas being delivered at the installed altitude. Input rate changes can be made by adjusting the manifold pressure (min 3.0 - max 3.7 in. W.C. - Natural Gas) or changing orifices (orifice change may not always be required).



**TABLE 8**  
**PART NUMBERS FOR REPLACEMENT ORIFICES**

| DRILL SIZE | PART NUMBER | DRILL SIZE | PART NUMBER |
|------------|-------------|------------|-------------|
| 44         | ORF00501    | 54         | ORF00555    |
| 45         | ORF00644    | 55         | ORF00693    |
| 46         | ORF00909    | 56         | ORF00907    |
| 47         | ORF00910    | 57         | ORF00908    |
| 48         | ORF01099    | 58         | ORF01338    |
| 49         | ORF00503    | 59         | ORF01339    |
| 50         | ORF00493    |            |             |

If the desired input rate cannot be achieved with a change in manifold pressure, then the orifices must be changed. LP installations will require an orifice change.

**Important:**

Reinstall the propane orifices to the same depth as the orifices supplied with the equipment.

See Table 9 for help in selecting orifices if orifice change is required. Furnace input rate and temperature rise should be checked again after changing orifices to confirm the proper rate for the altitude.

The Vent Length Table on page 16 shows the required vent lengths for installations at various altitudes. An optional high altitude kit is available for installations above 5000 feet (Installations above 12,000 feet are not allowed).

**TABLE 9**


| Orifice<br>Twist Drill<br>Size If<br>Installed<br>At Sea<br>Level | ALTITUDE ABOVE SEA LEVEL<br>and Orifice Required At Other Elevations |      |      |      |      |      |      |      |       |  |
|---|--|------|------|------|------|------|------|------|-------|--|
|   | 2000   | 3000 | 4000 | 5000 | 6000 | 7000 | 8000 | 9000 | 10000 |  |
| 42  | 42   | 43   | 43   | 43   | 44   | 44   | 45   | 46   | 47    |  |
| 43  | 44   | 44   | 44   | 45   | 45   | 46   | 47   | 47   | 48    |  |
| 44  | 45   | 45   | 45   | 46   | 47   | 47   | 48   | 48   | 50    |  |
| 45  | 46   | 47   | 47   | 47   | 48   | 48   | 49   | 49   | 50    |  |
| 46  | 47   | 47   | 47   | 48   | 48   | 49   | 49   | 50   | 51    |  |
| 47  | 48   | 48   | 49   | 49   | 49   | 50   | 50   | 51   | 52    |  |
| 48  |  |      |      |      |      |      |      |      |       |  |
| 53  |  |      |      |      |      |      |      |      |       |  |
| 54  | 54   | 55   | 55   | 55   | 55   | 56   | 56   | 56   | 56    |  |
| 55  | 55   | 55   | 55   | 56   | 56   | 56   | 56   | 56   | 57    |  |
| 56  | 56   | 56   | 57   | 57   | 57   | 58   | 59   | 59   | 60    |  |
| 57  | 58   | 59   | 59   | 60   | 60   | 61   | 62   | 63   | 63    |  |
| 58  | 59   | 60   | 60   | 61   | 62   | 62   | 63   | 63   | 64    |  |

From National Fuel Gas Code - Table F-4

**HORIZONTAL VENTING**

**NOTE:**

Vent termination kit BAYAIR30AVENTA or BAYVENT200B may be used in addition to the horizontal and vertical termination options shown in the following figures.



## ⚠ CAUTION


When the vent pipe is exposed to temperatures below freezing, i.e., when it passes through unheated spaces, etc., the pipe must be insulated with 1/2 inch (22.7 mm) thick Armaflex-type insulation or equal. If the space is heated sufficiently to prevent freezing, then the insulation would not be required. If domestic water pipes are not protected from freezing then it is assumed the space meets the condition of a heated space.

26

## DOWNWARD VENTING




Furnace may be in vertical or horizontal configuration.

All horizontal pipes must be supported at a maximum of 3 foot intervals



### NOTES:



- Condensate trap for vent pipe must be a minimum of 6 inches in height.
- Condensate trap for vent and inlet pipe must be connected into a condensate drain pump; an open or vented drain; or it can be connected to the outlet hose of the furnace's condensate trap. Outdoor draining of the furnace and coil condensate is permissible if allowed by local codes. Caution should be taken to prevent drains from freezing or causing slippery conditions that could lead to personal injury. Excessive draining of condensate may cause saturated ground conditions that may result in damage to plants.
- The condensate trap should be primed at initial start up prior to heating season operation.



# Installer's Guide

| Non-Direct Vent Terminal Clearances   |  |  |  |
|---|--|--|--|
|   |  | Canadian Installations   | US Installations   |
| A=  | Clearance above grade, veranda, porch, deck, or balcony  | 12 inches (30 cm)  | 12 inches (30 cm)  |
| B=  | Clearance to window or door that may be opened   | 6 inches (15 cm) for appliances $\leq$ 10,000 Btuh (3 kw),<br>12 inches (30 cm) for appliances $>$ 10,000 Btuh (3 kw)<br>and $\leq$ 100,000 Btuh (30 kw),<br>36 inches (91 cm) for appliances $>$ 100,000 Btuh (30 kw) | 4 feet (1.2m) below or to the side of opening;<br>1 foot (0.3m) above opening. |
| C=  | Clearance to permanently closed window   | *  | *  |
| D=  | Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal | *  | *  |
| E=  | Clearance to unventilated soffit   | *  | *  |
| F=  | Clearance to outside corner  | *  | *  |
| G=  | Clearance to inside corner   | *  | *  |
| H=  | Clearance to each side of center line extended above meter/regulator assembly  | 3 feet (91 cm) with a height 15 feet (4.5 m) above the meter/regulator assembly  | *  |
| I=  | Clearance to service regulator vent outlet   | 3 feet (91 cm)   | *  |
| J=  | Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance   | 6 inches (15 cm) for appliances $\leq$ 10,000 Btuh (3 kw),<br>12 inches (30 cm) for appliances $>$ 10,000 Btuh (3 kw)<br>and $\leq$ 100,000 Btuh (30 kw),<br>36 inches (91 cm) for appliances $>$ 100,000 Btuh (30 kw) | 4 feet (1.2 m) below or to side of opening;<br>1 foot (300 m) above opening    |
| K=  | Clearance to a mechanical air supply inlet   | 6 feet (1.83m)   | 3 feet (91 cm) above if within<br>10 feet (3m) horizontally                    |
| L=  | Clearance above a paved sidewalk or paved driveway located on public property  | 7 feet (2.13 m) †  | 7 feet (2.13 m)  |
| M=  | Clearance under veranda, porch, deck, or balcony   | 12 inches (30 cm) ‡  | *  |
| Notes:  |  |  |  |
| 1. In accordance with the current CSA B149.1 Natural Gas and Propane Installation Code.   |  |  |  |
| 2. In accordance with the current ANSI Z223.1/NFPA 54 National Fuel Gas Code.   |  |  |  |
| †. A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwelling and serves both dwellings. |  |  |  |
| ‡. Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.  |  |  |  |
| * Clearance in accordance with local installation codes and the requirements of the gas supplier and the manufacturer's Installation Instructions.      |  |  |  |

| Direct Vent Terminal Clearances   |  |  |   |
|---|--|--|---|
|   |  | Canadian Installations   | US Installations  |
| A=  | Clearance above grade, veranda, porch, deck, or balcony  | 12 inches (30 cm)  | 12 inches (30 cm)   |
| B=  | Clearance to window or door that may be opened   | 6 inches (15 cm) for appliances $\leq$ 10,000 Btuh (3 kw),<br>12 inches (30 cm) for appliances $>$ 10,000 Btuh (3 kw)<br>and $\leq$ 100,000 Btuh (30 kw),<br>36 inches (91 cm) for appliances $>$ 100,000 Btuh (30 kw) | 6 inches (15 cm) for appliances $\leq$ 10,000 Btuh (3 kw),<br>9 inches (23 cm) for appliances $>$ 10,000 Btuh (3 kw)<br>and $\leq$ 50,000 Btuh (15 kw),<br>12 inches (30 cm) for appliances $>$ 50,000 Btuh (15 kw) |
| C=  | Clearance to permanently closed window   | *  | *   |
| D=  | Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal | *  | *   |
| E=  | Clearance to unventilated soffit   | *  | *   |
| F=  | Clearance to outside corner  | *  | *   |
| G=  | Clearance to inside corner   | *  | *   |
| H=  | Clearance to each side of center line extended above meter/regulator assembly  | 3 feet (91 cm) with a height 15 feet (4.5 m) above the meter/regulator assembly  | *   |
| I=  | Clearance to service regulator vent outlet   | 3 feet (91 cm)   | *   |
| J=  | Clearance to nonmechanical air supply inlet to building or the combustion air inlet to any other appliance   | 6 inches (15 cm) for appliances $\leq$ 10,000 Btuh (3 kw),<br>12 inches (30 cm) for appliances $>$ 10,000 Btuh (3 kw)<br>and $\leq$ 100,000 Btuh (30 kw),<br>36 inches (91 cm) for appliances $>$ 100,000 Btuh (30 kw) | 6 inches (15 cm) for appliances $\leq$ 10,000 Btuh (3 kw),<br>9 inches (23 cm) for appliances $>$ 10,000 Btuh (3 kw)<br>and $\leq$ 50,000 Btuh (15 kw),<br>12 inches (30 cm) for appliances $>$ 50,000 Btuh (15 kw) |
| K=  | Clearance to a mechanical air supply inlet   | 6 feet (1.83m)   | 3 feet (91 cm) above if within 10 feet (3m) horizontally  |
| L=  | Clearance above a paved sidewalk or paved driveway located on public property  | 7 feet (2.13 m) †  | *   |
| M=  | Clearance under veranda, porch, deck, or balcony   | 12 inches (30 cm) ‡  | *   |
| Notes:  |  |  |   |
| 1. In accordance with the current CSA B149.1 Natural Gas and Propane Installation Code.   |  |  |   |
| 2. In accordance with the current ANSI Z223.1/NFPA 54 National Fuel Gas Code.   |  |  |   |
| †. A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwelling and serves both dwellings. |  |  |   |
| ‡. Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.  |  |  |   |
| * Clearance in accordance with local installation codes and the requirements of the gas supplier and the manufacturer's Installation Instructions.      |  |  |   |




## HORIZONTAL VENTING THROUGH WALL

These furnaces may be installed as **direct vent** (as shipped) or as **nondirect vent**. Installation must conform to national, state, and local codes.

The vent & inlet terminals must be located at least 12" minimum above normally expected snow accumulation level.

Avoid areas where staining or condensate drippage may be a problem.




Location of the vent/wind terminal should be chosen to meet the requirements of Figure 29 for either direct or nondirect vent applications.

**PITCH** - Venting through the wall must maintain 1/4" per foot pitched upward to insure that condensate drains back to the furnace.

# Installer's Guide

**FLUE GAS DEGRADATION** – The moisture content of the flue gas may have a detrimental effect on some building materi-







als. This can be avoided by using the roof or chimney venting option. When wall venting is used on any surface that can be affected by this moisture, it is recommended that a corrosion resistant shield (24 inches square) be used behind the vent terminal. This shield can be wood, plastic, sheet metal, etc. Also, silicone caulk all cracks, seams and joints within 3 feet of the vent terminal.

## COMBUSTIBLE MATERIAL WALL


A minimum clearance of 1" to combustible materials must be maintained when using single wall stainless steel venting. See Figure 31.

Shield material to be a minimum of 24 gauge stainless or aluminized sheet metal. Minimum dimensions are 12"x12". Shield must be fastened to both inside and outside of wall. Use screws or anchor type fasteners suited to the outside or inside wall surfaces.



37

SEAL BETWEEN FLANGE, PIPE,  
COUPLING AND METAL PANEL  
WITH HI TEMP RTV SILICONE SEALANT



CLEARANCE  
(0" ACCEPTABLE FOR PVC VENT PIPE)  
(1" ACCEPTABLE FOR TYPE 29-4C STAINLESS STEEL VENT PIPE)

## NONCOMBUSTIBLE MATERIAL WALL

The hole through the wall must be large enough to maintain pitch of vent and properly seal.

Use cement mortar seal on inside and outside of wall.

See Figure 32 above.

## VENTING THROUGH THE ROOF

When penetrating roof with a 2" PVC vent pipe, a 2" electrical conduit flashing may be used for a weather tight seal.

Lubricate flexible seal on flashing before PVC pipe is pushed through the seal. (Field Supplied)

### NOTE:


**No vent cap as shown in Figure 33 is the preferred method for vertical vent termination in extremely cold climates.**

**In extreme climate conditions, insulate the exposed pipe**

above the roof line with Armaflex type insulation.

38

## PVC PLASTIC VENTING – ONLY THROUGH UNUSED CHIMNEY



### ⚠ CAUTION


Do not run vent through chimney for wood burning or oil furnaces or incinerators or any other gas appliance.

### IMPORTANT –

The single wall flue pipe joints must be sealed.

The 90° elbow connection to vertical pipe must be sealed to prevent condensate leakage to base of masonry chimney.

## TYPE 29-4C STAINLESS STEEL VENTING – USED THROUGH CHIMNEY THAT VENTS ANOTHER GAS APPLIANCE



### ⚠ CAUTION

Do not run vent through chimney for wood burning or oil furnaces or incinerators.

If remaining free area between single wall flue pipe and masonry chimney is to be used for another gas appliance venting area must be sufficient to vent that appliance and that appliance must be connected to chimney with separate entry openings.

### IMPORTANT –

The single wall flue pipe joints must be sealed.

The 90° elbow connection to vertical pipe must be sealed to prevent condensate leakage to base of masonry chimney.

# Installer's Guide

## VENT FITTING MATERIAL – STAINLESS STEEL

Gas and liquid tight single wall metal vent fitting, designed for resistance to corrosive flue condensate such as Type 29-4C MUST be used throughout.

These fittings and fitting accessories are to be supplied locally.


## DIRECTION OF STAINLESS STEEL FITTING

All stainless steel fitting must be installed with male end towards the furnace.


All horizontal stainless steel sections must be positioned with the seam on top.

All long horizontal sections must be supported to prevent sagging.

FIELD WIRING DIAGRAM FOR VARIABLE SPEED 2 STAGE FURNACE  
1 STAGE HEATING  
USING A 1 STAGE HEATING THERMOSTAT  
NO COOLING




FIELD WIRING DIAGRAM FOR VARIABLE SPEED 2 STAGE FURNACE  
2 STAGE HEATING  
USING A 2 STAGE HEATING THERMOSTAT  
NO COOLING





## FIELD WIRING DIAGRAM FOR VARIABLE SPEED 2 STAGE FURNACE 1 STAGE HEATING, 1 STAGE COOLING USING A 1 STAGE HEATING, 1 STAGE COOLING THERMOSTAT (OUTDOOR SECTION WITHOUT TRANSFORMER)




INTER-COMPONENT WIRING

----- 24 V. } FIELD  
LINE V. } WIRING  
----- 24 V. } FACTORY  
LINE V. } WIRING


### NOTES:

1. BE SURE POWER AGREES WITH EQUIPMENT NAMEPLATE(S).
2. LOW VOLTAGE (24 V. WIRING) TO BE NO. 18 A.W.G. MIN.
3. GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
4. SET THERMOSTAT HEAT ANTICIPATOR PER UNIT WIRING DIAGRAM.
5. THESE LEADS PROVIDE 115 V. POWER FOR CONNECTION OF ELECTRONIC AIR CLEANER AND HUMIDIFIER MAX. LOAD 1.0 AMPS EACH.
6. THIS WIRE IS ONLY FOR THERMOSTATS REQUIRING CONNECTION TO TRANSFORMER COMMON TERMINAL.
7. THE "Y" TERMINAL FROM THE THERMOSTAT MUST BE WIRED TO THE "Y" TERMINAL OF THE FURNACE CONTROL FOR PROPER BLOWER OPERATION DURING COOLING.
8. SET DIP SWITCHES WITH POWER OFF PER INSTALLATION INSTRUCTIONS TO SET AIRFLOW AND INDOOR FAN OFF DELAYS.
9. OPTIONAL HUMIDISTAT IS TO BE CONNECTED BETWEEN R AND BK. FACTORY INSTALLED JUMPER R TO BK ON THE CIRCUIT BOARD MUST BE CUT IF OPTIONAL HUMIDISTAT IS USED. THE JUMPER MUST ALSO BE CUT WHEN APPLYING AN AIRFLOW COMMAND SIGNAL TO THE BK INPUT SUCH AS WITH THE VARIABLE SPEED, SINGLE-ZONE AND MULTI-ZONE SYSTEM CONTROLLERS. ON SINGLE SPEED COOLING ONLY/NON-HEAT PUMP SYSTEMS, JUMPER Y TO O FOR PROPER OPERATION OF THE DELAY PROFILES AND THE HUMIDISTAT. FOR TWO COMPRESSOR OR TWO SPEED SYSTEMS, JUMPER YLO TO O.



From Dwg. B342022 Rev. 1

## FIELD WIRING DIAGRAM FOR VARIABLE SPEED 2 STAGE FURNACE 2 STAGE HEATING, 1 STAGE COOLING USING A 2 STAGE HEATING, 1 STAGE COOLING THERMOSTAT (OUTDOOR SECTION WITHOUT TRANSFORMER)




INTER-COMPONENT WIRING

----- 24 V. } FIELD  
LINE V. } WIRING  
----- 24 V. } FACTORY  
LINE V. } WIRING

### NOTE:


- 1.) BE SURE POWER AGREES WITH EQUIPMENT NAMEPLATE(S).
- 2.) LOW VOLTAGE (24V. WIRING) TO BE NO. 18AWG MIN.
- 3.) GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL BUILDING CODES.
- 4.) SET THERMOSTAT HEAT ANTICIPATOR PER UNIT WIRING DIAGRAM.
- 5.) THESE LEADS PROVIDE 115V. POWER FOR CONNECTION OF ELECTRONIC AIR CLEANER AND HUMIDIFIER, MAX. LOAD 1.0 AMPS EACH.
- 6.) THIS WIRE IS ONLY FOR THERMOSTATS REQUIRING CONNECTION TO TRANSFORMER COMMON TERMINAL.
- 7.) THE "Y" TERMINAL FROM THE THERMOSTAT MUST BE WIRED TO THE "Y" TERMINAL OF THE FURNACE CONTROL FOR PROPER BLOWER OPERATION DURING COOLING.
- 8.) SET DIP SWITCHES WITH POWER OFF PER INSTALLATION INSTRUCTIONS TO SET AIRFLOW AND INDOOR FAN OFF DELAYS.
- 9.) OPTIONAL HUMIDISTAT IS TO BE CONNECTED BETWEEN "R" AND "BK". FACTORY INSTALLED JUMPER "R" TO "BK" ON THE CIRCUIT BOARD MUST BE CUT IF OPTIONAL HUMIDISTAT IS USED. THE JUMPER MUST ALSO BE CUT WHEN APPLYING AN AIRFLOW COMMAND SIGNAL TO THE "BK" INPUT SUCH AS WITH THE VARIABLE SPEED SINGLE-ZONE AND MULTI-ZONE SYSTEM CONTROLLERS. ON SINGLE SPEED COOLING ONLY / NON-HEAT PUMP SYSTEMS, JUMPER "Y" TO "O" FOR PROPER OPERATION OF THE DELAY PROFILES AND THE HUMIDISTAT. FOR TWO COMPRESSOR OR TWO SPEED SYSTEMS, JUMPER "YLO" TO "O".



From Dwg. B342020 Rev. 0


# Installer's Guide

## FIELD WIRING DIAGRAM FOR VARIABLE SPEED 2 STAGE FURNACE 2 STAGE HEATING, 2 STAGE COOLING (OUTDOOR SECTION WITHOUT TRANSFORMER)



### NOTES:

1. BE SURE POWER AGREES WITH EQUIPMENT NAMEPLATE(S).
2. LOW VOLTAGE (24 V. WIRING) TO BE NO. 18 A.W.G. MIN.
3. GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
4. SET THERMOSTAT HEAT ANTICIPATOR PER UNIT WIRING DIAGRAM.
5. THESE LEADS PROVIDE 115 V. POWER FOR CONNECTION OF ELECTRONIC AIR CLEANER AND HUMIDIFIER MAX. LOAD 1.0 AMPS EACH.
6. THIS WIRE IS ONLY FOR THERMOSTATS REQUIRING CONNECTION TO TRANSFORMER COMMON TERMINAL.
7. THE "Y2" TERMINAL FROM THE THERMOSTAT MUST BE WIRED TO THE "Y" TERMINAL OF THE FURNACE CONTROL FOR PROPER BLOWER OPERATION DURING COOLING.
8. SET DIP SWITCHES WITH POWER OFF PER INSTALLATION INSTRUCTIONS TO SET AIRFLOW AND INDOOR FAN OFF DELAYS.
9. OPTIONAL HUMIDISTAT IS TO BE CONNECTED BETWEEN R AND BK. FACTORY INSTALLED JUMPER R TO BK ON THE CIRCUIT BOARD MUST BE CUT IF OPTIONAL HUMIDISTAT IS USED. THE JUMPER MUST ALSO BE CUT WHEN APPLYING AN AIRFLOW COMMAND SIGNAL TO THE BK INPUT SUCH AS WITH THE VARIABLE SPEED SINGLE-ZONE AND MULTI-ZONE SYSTEM CONTROLLERS, ON SINGLE SPEED COOLING ONLY/NON-HEAT PUMP SYSTEMS, JUMPER Y TO O FOR PROPER OPERATION OF THE DELAY PROFILES AND THE HUMIDISTAT. FOR TWO COMPRESSOR OR TWO SPEED SYSTEMS, JUMPER YLO TO O.




## CONDENSATE DRAIN INSTRUCTIONS

### CAUTION

It is recommended that a drain pan be installed under the furnace to prevent property damage, personal injury or death from leaking condensate.

Evaporator and furnace condensate drain piping may be manifolded together. A primary drain vent stack must be installed and terminated below the outlet of the secondary heat exchanger drain connection to prevent water from damaging furnace controls if the primary drain outlet plugs up. Where the furnace is installed above a finished ceiling, the primary drain vent stack must be installed such that overflow from the vent stack opening will flow into an auxiliary drain pan in order to prevent water damage to the finished ceiling below.



## VERTICAL APPLICATIONS

**Upflow furnace** - The connection tubing for left and right side drainage is shipped in the blower compartment. Install the connection tubing from the trap to the side of the unit and trim all excess tubing to avoid kinks.

**Downflow furnace** - The furnace is shipped with the left side drainage setup. To change the right side drain, remove the drain lines from the trap, rotate the trap 180° so it exits to the right, reconnect the lines, and run a 1/2" CPVC pipe from the trap out through the right side knock-out. Use RTV silicone sealant to connect the CPVC pipe to the trap for ease of removing to clean the trap.



Right side

**UPFLOW (VERTICAL)**

## HORIZONTAL APPLICATIONS


**Upflow and Downflow furnaces** - All horizontal applications are left side only. It is always recommended that the auxiliary drain pan be installed under a horizontally installed evaporator and/or 90% gas furnace. Connect the auxiliary drain pan to a separate drain line (no trap is needed in this line).

The trap must be repositioned to the exterior of the cabinet. Remove the trap from its present location and reposition the trap outside of the unit, through the long circular hole, next to



Left side

**UPFLOW (VERTICAL)**



Use Inducer Drain hose without extension

**UPFLOW HORIZONTAL 17" UNITS  
(Left side only)**



Use extension hose here


**UPFLOW HORIZONTAL 21" & 24" UNITS  
(Left side only)**

# Installer's Guide


the secondary recuperative cell. Remove the larger drain line (from the secondary cell) and trim to fit between the secondary cell and the new trap location. On upflow units, plug the hole in the blower deck where the tube went through.

Remove the hose from the induced blower and reposition into the other drain tap of the inducer, which is located 90° clockwise around the inducer. Move the cap from that drain tap to the unused drain tap. On upflow units, plug the hole in the blower deck where the tube went through. This tube on downflow units will need to be cut to fit between the inducer and the trap. On upflow units, this tube may need to be extended, using the tubing shipped with the furnace.


Connections must be made to an **OPEN/VENTED DRAIN**. Outdoor draining of the furnace and coil condensate is



**DOWNFLOW (VERTICAL)**



**DOWNFLOW (VERTICAL)**



**DOWNFLOW (HORIZONTAL)**

permissible if allowed by local codes. Caution should be taken to prevent drains from freezing or causing slippery conditions that could lead to personal injury. Excessive draining of condensate may cause saturated ground conditions that may result in damage to plants.

**NOTE:**




*Use 1/2" or larger PVC or CPVC pipe and fittings as required for drain connections (fittings, pipe and solvent cement not provided).*

**NOTE:**

*A corrosion resistant condensate pump must be used if a pump is required for a specific drain system.*

**IMPORTANT:**

*The condensate drain should be installed with provisions to prevent winter freeze-up of the condensate drain line. Frozen condensate will block drains, resulting in furnace shutdown. If the drain line cannot be installed in a conditioned space, then UL listed heat tape should be applied as required to prevent freezing (per manufacturer's instructions). The heat tape should be rated at 5 or 6 watts per foot at 120 volts. Self-regulating (preferred) or thermostatically controlled heat tape is required.*



## ⚠ CAUTION

Use a backup wrench on the gas valve when installing gas piping to prevent damage to the gas valve and manifold assembly.

# Installer's Guide

All pipe joints must be fastened and sealed to prevent escape of combustion products into the building.

## VENTING ROUTED THROUGH A MASONRY CHIMNEY

### ELECTRICAL CONNECTIONS

Make wiring connections to the unit as indicated on enclosed wiring diagram. As with all gas appliances using electrical power, this furnace shall be connected into a permanently live electric circuit. It is recommended that furnace be provided with a separate "circuit protection device" electric circuit. The furnace must be electrically grounded in accordance with local codes or in the absence of local codes with the National Electrical Code, ANSI/NFPA 70 or CSA C22.1 Electrical Code, if an external electrical source is utilized. **The integrated furnace control is polarity sensitive.** The hot leg of the 120V power supply must be connected to the black power lead as indicated on the wiring diagram. Provision for hooking up an electronic air cleaner and/or humidifier is provided on the integrated control.

Refer to the SERVICE FACTS literature and unit wiring diagram attached to furnace.

### GAS PIPING

The upflow/horizontal furnace is shipped standard for left side installation of gas piping. A knockout is provided on the right side for an alternate gas piping arrangement. See Figure 42.

The installation of piping shall be in accordance with piping codes and the regulations of the local gas company. Pipe joint compound must be resistant to the chemical reaction with liquefied petroleum gases.

Refer to piping Table 10, for delivery sizes. Connect gas supply to the unit, using a ground joint union and a manual shut-off valve as shown in Figures 43 & 44. National codes require a condensation drip leg to be installed ahead of the controls as shown in Figures 43 & 44.

The furnace and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psig (3.5 kPa).

The furnace must be isolated from the gas supply piping by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.5 kPa).

### NOTE:

**Maximum pressure to the gas valve for natural gas is 13.8" W.C. Minimum pressure is 5.0" W.C. Maximum pressure to the gas valve for propane is 13.8" W.C. Minimum pressure is 11.0" W.C.**

**TABLE 10  
NATURAL GAS ONLY**

| TABLE OF CUBIC FEET PER HOUR OF GAS<br>FOR VARIOUS PIPE SIZES AND LENGTHS |                |     |     |     |     |     |     |
|---|----------------|-----|-----|-----|-----|-----|-----|
| PIPE<br>SIZE  | LENGTH OF PIPE |     |     |     |     |     |     |
|   | 10             | 20  | 30  | 40  | 50  | 60  | 70  |
| 1/2   | 132            | 92  | 73  | 63  | 56  | 50  | 46  |
| 3/4   | 278            | 190 | 152 | 130 | 115 | 105 | 96  |
| 1   | 520            | 350 | 285 | 245 | 215 | 195 | 180 |
| 1-1/4   | 1050           | 730 | 590 | 520 | 440 | 400 | 370 |

This table is based on pressure drop of 0.3 inch W.C. and 0.6 SP.GR. gas

**All gas fittings must be checked for leaks using a soapy solution before lighting the furnace. DO NOT CHECK WITH AN OPEN FLAME!**

**TABLE 11  
ORIFICE SIZES**

| INPUT<br>RATING<br>BTUH | NUMBER<br>OF<br>BURNERS | MAIN BURNER ORIFICE<br>DRILL SIZE |        |
|-------------------------|-------------------------|-----------------------------------|--------|
|                         |                         | NAT. GAS                          | LP GAS |
| 60,000                  | 3                       | 45                                | 56     |
| 80,000                  | 4                       | 45                                | 56     |
| 100,000                 | 5                       | 45                                | 56     |
| 120,000                 | 6                       | 45                                | 56     |

### COMBUSTION AND INPUT CHECK

(See also High Altitude Derate, page 16)

1. Make sure all gas appliances are off except the furnace.
2. Clock the gas meter with the furnace operating (determine the dial rating of the meter) for one revolution.
3. Match the "Sec" column in the gas flow (in cfh) Table 13 with the time clocked.
4. Read the "Flow" column opposite the number of seconds clocked.
5. Use the following factors if necessary:

For 1 Cu. Ft. Dial Gas Flow CFH =  
Chart Flow Reading ÷ 2

For 1/2 Cu Ft. Dial Gas Flow CFH =  
Chart Flow Reading ÷ 4

For 5 Cu. Ft. Dial Gas Flow CFH =  
10X Chart Flow Reading ÷ 4




6. Multiply the final figure by the heating value of the gas obtained from the utility company and compare to the nameplate rating. This must not exceed the nameplate rating.
7. Changes can be made by adjusting the manifold pressure (See Table 12), or changing orifices (orifice change may not always be required). To adjust the manifold pressure:
  - a. Turn off all electrical power to the system.
  - b. Attach a manifold pressure gauge to the outlet pressure tap marked "OUT PRESS TAP" on White-Rodgers gas valve model 36E or boss marked "OUT P" on White-Rodgers gas valve model 36G. (See Figure 45 for White-Rodgers gas valve model 36E and Figure 46 for White-Rodgers gas valve model 36G). For the gas valve model 36E, measurements require removal of the plug and installation of a barbed fitting. Attach flexible tubing and a manometer to the barbed fitting. For the gas valve model 36G, do not remove the pressure tap test screw. Loosen the pressure tap test screw one turn and install flexible tubing and a manometer directly onto the outlet pressure boss.
  - c. The other side of the manifold pressure gauge must be referenced to the burner box as shown in Figure 48.
  - d. Turn on system power and energize valve.
  - e. For the White-Rodgers gas valve model 36E:
    1. Adjust low fire by removing the low adjustment seal screw (See Figure 45).
    2. To increase outlet pressure, turn the 3/32" socket set screw clockwise. To decrease outlet pressure, turn the set screw counterclockwise. Adjust

regulator until pressure shown on manometer matches the pressure specified in Table 12.

3. Replace low adjustment seal screw and tighten securely.
4. Cycle the valve several times to verify regulator setting.
5. Adjust high fire by removing the high adjustment seal screw (See Figure 45).
6. To increase outlet pressure, turn the 3/32" socket set screw clockwise. To decrease outlet pressure, turn the set screw counterclockwise. The final manifold pressure setting shall be as specified in Table 12 with an input of no more than nameplate rating and no less than 93% of the nameplate rating, unless the unit is derated for high altitude.
7. Replace high adjustment seal screw and tighten securely.
8. Cycle the valve several times to verify regulator setting.

f. For the White-Rodgers gas valve model 36G:

1. Adjust low fire by removing the low adjustment regulator cover screw (See Figure 46).
2. To increase outlet pressure, turn the regulator adjust screw clockwise. To decrease outlet pressure, turn the regulator adjust screw counterclockwise. Adjust regulator until pressure shown on manometer matches the pressure specified in Table 12.
3. Replace and tighten the regulator cover screw securely.
4. Cycle the valve several times to verify regulator setting.
5. Adjust high fire by removing the high adjustment regulator cover screw (See Figure 46).
6. To increase outlet pressure, turn the regulator adjust screw clockwise. To decrease outlet pressure, turn the regulator adjust screw counterclockwise. The final manifold pressure setting shall be as specified in Table 12 with an input of no more than nameplate rating and no less than 93% of the nameplate rating, unless the unit is derated for high altitude.




7. Replace high adjustment regulator cover screw and tighten securely.
8. Cycle the valve several times to verify regulator setting.
- g. Turn off all electrical power to the system.
- h. Remove the manometer and flexible tubing. Remove the barbed fitting and replace the plug or tighten the pressure test screw.
- i. Turn on electrical power to the system and energize valve.
- j. Using a leak detection solution or soap suds, check for leaks at plug or pressure boss screw.

**NOTE:**


The manifold pressure must be referenced to the burner box. The burner box pressure tap equalizes the gas valve pressure regulator. Manifold pressure is checked by

48

## CORRECT METHOD OF CHECKING DIRECT VENT MANIFOLD PRESSURE WITH BURNER BOX REFERENCED



Separate the tube at the unit Tee and reconnect with a short piece of field supplied tube and another Tee with the "U" Manometer attached. Be sure to reconnect unit tubing to original position after testing the manifold pressure!



Field supplied barbed fitting with manometer tube is attached to the "OUTLET PRESSURE TAP" on the outlet side of the gas valve.

### CAUTION

Return all tubing, caps, and/or plugs to original positions when pressure checks are completed.

installing a tee (field supplied) in the tubing, between the tee coming from the burner box tube and the gas valve, in addition to the regular gas valve pressure tap on the outlet side of the gas valve. See Figure 48.

### CAUTION

Replace and/or tighten all plugs removed or loosened when adjusting gas pressure. Leak check the fittings before placing the furnace into regular service. Failure to follow this warning could result in fire, explosion, or property damage.

Table 11 lists the main burner orifices used with the furnace. If a change of orifices is required to correct the furnace input rating refer to Table 14.

TABLE 12

| FINAL MANIFOLD PRESSURE SETTINGS (inches w.c.) |                |                |
|--|----------------|----------------|
| FUEL   | 2nd Stage Max. | 1st Stage Max. |
| NATURAL GAS                                    | 3.5" W.C.      | 1.7" W.C.      |
| LP GAS   | 10.5" W.C.     | 6.0" W.C.      |

TABLE 13

| GAS FLOW IN CUBIC FEET PER HOUR |      |      |      |      |      |      |      |
|---------------------------------|------|------|------|------|------|------|------|
| 2 CUBIC FOOT DIAL               |      |      |      |      |      |      |      |
| SEC.                            | FLOW | SEC. | FLOW | SEC. | FLOW | SEC. | FLOW |
| 8                               | 900  | 29   | 248  | 50   | 144  | 82   | 88   |
| 9                               | 800  | 30   | 240  | 51   | 141  | 84   | 86   |
| 10                              | 720  | 31   | 232  | 52   | 138  | 86   | 84   |
| 11                              | 655  | 32   | 225  | 53   | 136  | 88   | 82   |
| 12                              | 600  | 33   | 218  | 54   | 133  | 90   | 80   |
| 13                              | 555  | 34   | 212  | 55   | 131  | 92   | 78   |
| 14                              | 514  | 35   | 206  | 56   | 129  | 94   | 76   |
| 15                              | 480  | 36   | 200  | 57   | 126  | 96   | 75   |
| 16                              | 450  | 37   | 195  | 58   | 124  | 98   | 73   |
| 17                              | 424  | 38   | 189  | 59   | 122  | 100  | 72   |
| 18                              | 400  | 39   | 185  | 60   | 120  | 104  | 69   |
| 19                              | 379  | 40   | 180  | 62   | 116  | 108  | 67   |
| 20                              | 360  | 41   | 176  | 64   | 112  | 112  | 64   |
| 21                              | 343  | 42   | 172  | 66   | 109  | 116  | 62   |
| 22                              | 327  | 43   | 167  | 68   | 106  | 120  | 60   |
| 23                              | 313  | 44   | 164  | 70   | 103  | 124  | 58   |
| 24                              | 300  | 45   | 160  | 72   | 100  | 128  | 56   |
| 25                              | 288  | 46   | 157  | 74   | 97   | 132  | 54   |
| 26                              | 277  | 47   | 153  | 76   | 95   | 136  | 53   |
| 27                              | 267  | 48   | 150  | 78   | 92   | 140  | 51   |
| 28                              | 257  | 49   | 147  | 80   | 90   | 144  | 50   |

TABLE 14

### PART NUMBERS FOR REPLACEMENT ORIFICES

| DRILL SIZE | PART NUMBER | DRILL SIZE | PART NUMBER |
|------------|-------------|------------|-------------|
| 44         | ORF00501    | 54         | ORF00555    |
| 45         | ORF00644    | 55         | ORF00693    |
| 46         | ORF00909    | 56         | ORF00907    |
| 47         | ORF00910    | 57         | ORF00908    |
| 48         | ORF01099    | 58         | ORF01338    |
| 49         | ORF00503    | 59         | ORF01339    |
| 50         | ORF00493    |            |             |



## REINSTALLATION OF THE BURNER BOX COVER

Figure 47 shows the correct way to reinstall the burner box cover if adjustment or replacement of the flame sensor, hot surface igniter, or main burner orifices have required removal of the cover.

## START-UP AND ADJUSTMENT

### PRELIMINARY INSPECTIONS

#### **WARNING**

Disconnect power to the unit before removing the blower door. Allow a minimum of 10 seconds for IFC power supply to drain to 0 volts. Failure to follow this warning could result in property damage, personal injury or death.

#### With gas and electrical power "OFF"

1. Duct connections are properly sealed
2. Filters are in place
3. Venting is properly assembled
4. Blower door is in place

Turn the main gas valve toggle switch (See Figures 44 & 45) within the unit to the "OFF" position. Turn the external gas valve to "ON". Purge the air from the gas lines. After purging, Check all gas connections for leaks with a soapy solution — **DO NOT CHECK WITH AN OPEN FLAME.** Allow 5 minutes for any gas that might have escaped to dissipate. LP Gas being heavier than air may require forced ventilation. Turn the knob on the gas valve in the unit to the "ON" position.

### LIGHTING INSTRUCTIONS

#### **WARNING**

**DO NOT attempt to manually light the burner. Failure to follow this warning could result in property damage, personal injury or death.**

Lighting instructions appear on each unit. Each installation must be checked out at the time of initial start up to insure proper operation of all components. Check out should include putting the unit through one complete cycle as outlined below.

Turn on the main electrical supply and set the thermostat above the indicated temperature. The ignitor will automatically heat, then the gas valve is energized to permit the flow of gas to the burners. After ignition and flame is established, the flame control module monitors the flame and supplies power to the gas valve until the thermostat is satisfied.

#### TO SHUT OFF

For complete shutdown: Turn the gas cock knob on the main gas valve to the "OFF" position (See Figures 41-43). Disconnect the electrical supply to the unit.

#### **CAUTION**

If this is done during the cold weather months, provisions must be taken to prevent freeze-up of all water pipes and water receptacles.

**Whenever your house is to be vacant, arrange to have someone inspect your house for proper temperature. This is very important during freezing weather. If for any reason your furnace should fail to operate damage could result, such as frozen water pipes.**

## SEQUENCE OF OPERATION

### Thermostat call for heat (2-stage thermostat)

#### Call for 1st stage only:

W1 thermostat contacts close signaling the control module to run its self-check routine. After the control module has verified that the 1st stage pressure switch contacts are open and the limit switch(es) contacts are closed, the draft blower will be energized.

As the induced draft blower comes up to speed, the pressure switch contacts will close and the ignitor warm up period will begin. The ignitor will heat for approx. 20 seconds, then the gas valve is energized in 1st stage to permit gas flow to the burners.

The flame sensor confirms that ignition has been achieved within the 4 second ignition trial period.

As the flame sensor confirms that ignition has been achieved, the delay to fan ON period begins timing and after approx. 45 seconds the indoor blower motor will be energized at low speed and will continue to run during the heating cycle.

#### Call for 2nd stage after 1st stage:

W2 thermostat contacts close signaling a call for 2nd stage heat. After a 30 second delay, the induced draft blower will be energized on high speed and the 2nd stage pressure switch contacts will close. The gas valve is energized in 2nd stage and the indoor blower motor in high speed.

#### 2nd stage satisfied, 1st stage still called:

W2 thermostat contacts open signaling that 2nd stage heating requirements are satisfied.

The induced draft blower is reduced to low speed allowing the 2nd stage pressure switch contacts to open and the gas valve is reduced to 1st stage. The indoor blower motor is reduced to low speed.

#### 1st stage satisfied:

W1 thermostat contacts open signaling that 1st stage heating requirements are satisfied. The gas valve will close and the induced draft blower will be de-energized. The indoor blower motor will continue to run for the fan off period (Field selectable at 60, 100, 140 or 180 seconds), then will be de-energized by the control module.

### Thermostat call for heat (1-stage Thermostat)

W1/W2 (jumpered) thermostat contacts close signaling a call for heat. 1st stage sequence of operation remains the same as above. 2nd stage heat will energize after the stage delay timer (field selectable at .5, 5, 10 or 15 minutes) has expired.

#### Thermostat satisfied:

W1/W2 (jumpered) contacts open signaling the control module to close the gas valve. The induced draft blower is switched to low speed and de-energized after the post purge timer has expired. The indoor blower motor will continue to operate after the flames are extinguished and then is switched to low heat speed for the FAN-OFF period.

## CONTROL AND SAFETY SWITCH ADJUSTMENTS

### LIMIT SWITCH CHECK OUT

The limit switch is a safety device designed to close the gas valve should the furnace become overheated. Since proper operation of this switch is important to the safety of the unit, it **must be checked out on initial start up by the installer.**

To check for proper operation of the limit switches, set the thermostat to a temperature higher than the indicated temperature to bring on the gas valve. Restrict the airflow by

# Installer's Guide


blocking the return air (disconnecting the indoor blower may trip the inducer limit). When the furnace reaches the maximum outlet temperature as shown on the rating plate, the burners must shut off. If they do not shut off after a reasonable time and overheating is evident, a faulty limit switch is probable and the limit switch must be replaced. After checking the operation of the limit control, be sure to remove the paper or cardboard from the return air inlet. Refer to Service Facts for additional instructions.

## AIRFLOW ADJUSTMENT

Check inlet and outlet air temperatures to make sure they are within the ranges specified on the furnace rating nameplate. If the airflow needs to be increased or decreased, see

\* - **This setting is equivalent to BAY24X045 relay benefit.**

\*\* - **This selection provides ENHANCED MODE, which is a ramping up and ramping down of the blower speed to provide improved comfort, quietness, and potential energy savings. See Wiring Diagram notes on the unit or in the Service Facts for complete wiring setup for ENHANCED MODE. The graph which follows, shows the ramping process.**



See Wiring Diagram on the unit or in the Service Facts for complete wiring setup for Enhanced Mode.

the Airflow Label on the furnace or the unit's Service Facts for information on changing the speed of the blower motor for your specific model. Blower speed changes are made on the Integrated Furnace Control (IFC).

There is a bank of 8 dip switches located near the thermostat connections to the Integrated Furnace Control. The dip switches work in pairs to match the airflow for the outdoor unit size (tons), cooling airflow adjustment, cooling off-delay options, and furnace heating airflow adjustment.

## ⚠ WARNING

Disconnect power to the unit before removing the blower door. Allow a minimum of 10 seconds for IFC power supply to drain to 0 volts. Failure to follow this warning could result in property damage, personal injury or death.

## INDOOR BLOWER TIMING

**Heating:** The integrated furnace control module controls the indoor blower. The blower start is fixed at 45 seconds after ignition. The FAN-OFF period is field selectable by dip switches SW-2, #1 and #2 at 60, 100, 140, or 180 seconds. The factory setting is 100 seconds.

W1-W2 stage delay (jumped together) is field selectable by dip switch SW-1, #1 and #2 at .5, 5, 10 or 15 minutes. The factory setting is 10 minutes. (See wiring diagram).

**Cooling:** The fan delay-off period is set by dip switches on the Integrated Furnace Control. The options for cooling delay off is field selectable by dip switches #5 and #6.

The following table and graph explain the delay-off settings:

## COOLING OFF - DELAY OPTIONS

| SWITCH SETTINGS |         | SELECTION   | NOMINAL AIRFLOW |
|-----------------|---------|-------------|-----------------|
| 5 - OFF         | 6 - OFF | NONE        | SAME            |
| 5 - ON          | 6 - OFF | 1.5 MINUTES | 100% *          |
| 5 - OFF         | 6 - ON  | 3 MINUTES   | 50%             |
| 5 - ON          | 6 - ON  | **          | 50 - 100%       |

This unit is equipped with a blower door switch which cuts power to the blower and gas valve causing shutdown when the door is removed. Operation with the door removed or ajar can permit the escape of dangerous fumes. All panels must be securely closed at all times for safe operation of the furnace.

## NOTE TO INSTALLER

Review the following warnings with the owner. Review contents of USER'S INFORMATION MANUAL with the owner.

## ROOM AIR THERMOSTAT

### HEAT ANTICIPATOR ADJUSTMENT

Set the thermostat heat anticipator according to the current flow measured, or the settings found in the notes on the furnace wiring diagram (found in the SERVICE FACTS or inside the furnace casing).

## INSTRUCTIONS TO THE OWNERS

**In the event that electrical, fuel, or mechanical failures occur, the owner should immediately turn the gas supply off at the manual gas valve, located in the burner compartment. Also turn off electrical power to the furnace and contact the service agency designated by your dealer.**

## BURNER BOX TEMPERATURE LIMIT DEVICE

All models are equipped with a manual reset temperature limit located on the burner box. In case of excessive temperature, the limit will open and cause the circuit to open which shuts off all flow of gas.

## ABNORMAL CONDITIONS

1. **EXCESSIVE COMBUSTION PRESSURE (WIND IN EXCESS OF 40 M.P.H.) VENT OR FLUE BLOCKAGE**  
On a call for heat, the variable speed draft inducer must first ramp up to speed and close the pressure switch before the ignition sequence is allowed to begin. If the pressure switch does not close, the motor will ramp up to maximum speed and continue to operate there for about 1 minute. After one minute the integrated furnace control will turn the motor off for about 30 seconds then back on in an attempt to reestablish proper operation. This condition is indicative of a highly restricted or blocked inlet or outlet vent pipe or a failed pressure switch.

If pressure against induced draft blower outlet becomes excessive, the pressure switch will open. If the pressure switch is open for more than 3.5 seconds, the variable

speed draft inducer will speed up and attempt to reclose the pressure switch.

If the pressure switch is not closed within 12 seconds or if the maximum speed of the motor is reached, the draft inducer sends a fault signal to the integrated furnace control. If the unit is operating in second stage, an inducer fault will cause the furnace control to transition the system to first stage and it will operate there for 10 minutes before attempting to run again in second stage. If the unit is operating in first stage, an inducer fault will cause the furnace control to shut the system down and wait 30 seconds before attempting to reestablish operation in first stage.

## 2. LOSS OF FLAME

If loss of flame occurs during a heating cycle, or flame is not present at the sensor, the flame control module will close the gas valve. The flame control module will then recycle the ignition sequence, then if ignition is not achieved, it will shut off the gas valve and lock out the system.

## 3. POWER FAILURE

If there is a power failure during a heating cycle, the system will restart the ignition sequence automatically when power is restored, if the thermostat still calls for heat.

## 4. GAS SUPPLY FAILURE

If loss of flame occurs during a heating cycle, the system integrated control module will recycle the ignition sequence, then if ignition is not achieved, the integrated control module will shut off the gas valve and lock out the system.

## 5. INDUCED DRAFT BLOWER FAILURE

Please refer to the variable speed draft inducer troubleshooting manual for diagnostic assistance.

## 6. CONDENSATE DRAIN BLOCKAGE

If the condensate drain is blocked, either by debris, improper draining, or by freezing condensate, the pressure switch will sense the accumulation of condensate in the furnace drain pan.

The unit will not operate properly until the condensate drain has been cleared, and the condensate flows freely.

## 7. RESET AFTER LOCKOUT

When the integrated control module has shut the system down and gone into lockout, the system must be manually reset before the unit will restart. The system can be reset by turning the system power off for more than 1 second, or by removing 24VAC from the control for more than 1 second, or by removing the thermostat call for heat for more than 1 second but less than 20 seconds.

## 8. RESET AFTER BURNER BOX LIMIT SHUTDOWN

If the furnace shuts down, one thing that can be checked is the burner box temperature limit switch. It is located on the bottom of the burner box. The vent and combustion air inlet terminations should be checked for blockage. If blockage exists, clear the problem and then the reset button may be depressed. **If there is no blockage of the terminations, the limit switch must be reset by a qualified servicer.**

# Installer's Guide

| INTEGRATED FURNACE CONTROL RED LED "ERROR" FLASH CODES |   |
|--|---|
| 2 Flashes ---  | System Lockout (Retries or Recycles exceeded)   |
| 3 Flashes ---  | Draft Pressure Error - Possible problems:<br>a) Venting problem<br>b) Pressure switch problem<br>c) Inducer problem |
| 4 Flashes ---  | Open Temperature Limit Switch   |
| 5 Flashes ---  | Flame sensed when no flame should be present  |
| 6 Flashes ---  | 115 volt AC power reversed, ignitor (Triac) fault, poor grounding or system voltage too low                         |
| 7 Flashes ---  | Gas valve circuit error   |
| 8 Flashes ---  | Low flame sense   |
| 9 Flashes ---  | Open Inducer Limit switch   |
| 10 Flashes ---   | Inducer communication error   |
| Solid ---  | Internal GV error or Low TH voltage   |
| Solid Red w/Solid Green "STATUS" LED                   | Continuous Reset caused by a blown fuse or internal error.  |

## FAULT CODE RECOVERY

On power up, last 4 faults, if any, will be flashed on the red LED. The newest fault detected will flash first and the oldest last. There will be a 2 second delay between fault code flashes. Solid red LED error codes will not be displayed.

The Green LED will be on solid during last fault recovery. At any other time the control is powered, the Green LED indicator light will operate as shown in Table 14 and the red LED will flash LitePort data (one flash) every 20 seconds.

TABLE 15

| INTEGRATED FURNACE CONTROL<br>GREEN "STATUS" LED FLASH CODES |                           |
|--|---------------------------|
| Flashing Slow ---  | Normal - No call for Heat |
| Flashing Fast ---  | Normal - Call for Heat    |

## Fault Code Reset

The last 4 fault codes can be erased from memory by powering up the control with "G" energized and then applying "R" to the "W1" terminal 3 times within 6 seconds. The control will acknowledge the reset by turning on the red LED for 2 seconds.

