

August 2, 2020

Problem: Top Solenoid Lock causes circuit to reset since second stage

Predicted causes:

1. Current from camera wire causes magnetic field to interfere with hall sensor (?)
2. Solenoid lock has problems causing circuit to reset, wires not given enough space, too tight (most likely)

13, 2, 4, 5

Basically the problem is that Arduino keeps resetting once it gets to the small solenoid lock