

---

```
function T0 = calcStagTemp(M, gamma, T)
%
T0 = T * (1 + (((gamma - 1) / 2) * M^2));
end
```

*Published with MATLAB® R2015b*