



## HAAS SERVICE AND OPERATOR MANUAL ARCHIVE

### HL-Series Service Manual 96-8710 January 15 1996

- This content is for illustrative purposes.
- Historic machine Service Manuals are posted here to provide information for Haas machine owners.
- Publications are intended for use only with machines built at the time of original publication.
- As machine designs change the content of these publications can become obsolete.
- You should not do mechanical or electrical machine repairs or service procedures unless you are qualified and knowledgeable about the processes.
- Only authorized personnel with the proper training and certification should do many repair procedures.

**WARNING: Some mechanical and electrical service procedures can be extremely dangerous or life-threatening. Know your skill level and abilities.**

**All information herein is provided as a courtesy for Haas machine owners for reference and illustrative purposes only. Haas Automation cannot be held responsible for repairs you perform. Only those services and repairs that are provided by authorized Haas Factory Outlet distributors are guaranteed.**

**Only an authorized Haas Factory Outlet distributor should service or repair a Haas machine that is protected by the original factory warranty. Servicing by any other party automatically voids the factory warranty.**



## TROUBLESHOOTING

This section is intended for use in determining the solution to a known problem. Solutions given are intended to give the individual servicing the CNC a pattern to follow in, first, determining the problem's source and, second, solving the problem.

The troubleshooting tips are organized in this section according to the area of the CNC that may be giving sign of a problem. (Ex.: Out-of round circles in drilling will be found under the heading General Machine Operation - Accuracy).

If the problem you are experiencing cannot be found under the heading you expect, please try several other possible headings. If the problem is still not found, contact Haas Automation for further details.

### BEFORE YOU BEGIN:

#### • USE COMMON SENSE

Many problems are easily overcome by correctly evaluating the situation. All machine operations are composed of a program, tools, and tooling. You must look at all three before blaming one as the fault area. If a bored hole is chattering because of an overextended boring bar, don't expect the machine to correct the fault. Don't suspect machine accuracy if the vise bends the part. Don't claim hole mis-positioning if you don't first center-drill the hole.

#### • FIND THE PROBLEM FIRST

Many mechanics tear into things before they understand the problem, hoping that it will appear as they go. We know this from the fact that more than half of all warranty returned parts are in good working order. If the spindle doesn't turn, remember that the spindle is connected to the gear box, which is connected to the spindle motor, which is driven by the spindle drive, which is connected to the I/O BOARD, which is driven by the computer. The moral here is don't replace the spindle drive if the belt is broken. Find the problem first; don't just replace the easiest part to get to.

#### • DON'T TINKER WITH THE MACHINE

There are hundreds of parameters, wires, switches, etc., that you can change in this machine. Don't start randomly changing parts and parameters. Remember, there is a good chance that if you change something, you will incorrectly install it or break something else in the process. Consider for a moment changing the processor's board. First, you have to download all parameters, remove a dozen connectors, replace the board, reload and reconnect, and if you make one mistake or bend one tiny pin it WON'T WORK. You always need to consider the risk of accidentally damaging the machine anytime you work on it. It is cheap insurance to double-check a suspect part before physically changing it. The less work you do on the machine the better.

## 1. GENERAL MACHINE OPERATION

### 1.1 MACHINE NOT RUNNING



#### **Machine cannot be powered on.**

- Check input voltage to machine.
- Check main circuit breaker at top right of electrical cabinet; switch must be at the on position.
- Check overvoltage fuses.
- Check wiring to POWER OFF button on front control panel.
- Check wiring to AUTO OFF relay to IOPCB.
- IOPCB may need replacement.
- POWER PCB may need replacement.



#### **Machine can be powered on, but turns off by itself.**

- Check settings #1 and #2 for Auto Off Timer or Off at M30.
- Check alarm history for OVERVOLTAGE or OVERHEAT shutdown.
- Check AC power supply lines for intermittent supply.
- Check wiring to POWER OFF button on front control panel.
- Check Parameter 57 for Power Off at E-STOP.
- IOPCB may need replacement.
- MOTIF PCB may need replacement.



#### **Machine turns on, keyboard beeps, but no CRT display.**

- Check for green POWER LED at front of CRT.
- Check for power connections to CRT from IOPCB.
- Check video cable (760) from VIDEO PCB to CRT.
- Replace CRT.



#### **Any LED on Microprocessor PCB goes out (except HALT).**

- Replace Microprocessor PCB.
- Replace VIDEO PCB .
- Replace MOTIF PCB .



#### **Machine turns on, CRT works, but no keyboard keys work.**

- Check keyboard cable (700) from VIDEO to KBIF PCB.
- Replace keypad.
- Replace KBIF PCB .

## 1.2 VIBRATION

Vibration is a subjective evaluation with perceptions varying among individuals, making it difficult to determine in mild cases if there is an actual problem. In obvious cases, it is a matter of determining the source which is not easy, since all parts rotate together and sound can be transferred readily. Vibrations also need to be distinguished from noise such as a bad bearing. We will assume that vibrations would be something that could be felt by putting your hand on the spindle ring. One crude method of measurement would be to take an indicator on a magnetic base extended 10 inches between the turret and spindle ring and observe the reading of the indicator. A reading of more than .001 would indicate excessive vibration. The two common sources of noise are the spindle and axis drives. Most complaints about vibration, accuracy, and finish can be attributed to incorrect machining practices such as poor quality or damaged tooling, incorrect speeds or feeds, or poor fixturing. Before concluding that the machine is not working properly, ensure that good machining practices are being observed. These symptoms will not occur individually (Ex. A machine with backlash may vibrate heavily, yielding a bad finish.). Put all of the symptoms together to arrive at an accurate picture of the problem.

◇ **Machine vibrates while spindle is on and is not cutting. Sometimes only at specific RPM.**

If the spindle alone causes vibration of the machine this is usually caused by the belt/pulley drive system.

◇ **Machine vibrates while jogging the axis with the hand wheel.**

The HAAS control uses very high gain accelerations curves. This vibration as you jog is simply the servos quickly trying to follow the handle divisions. If this is a problem, try using a smaller division on the handle. You will notice the vibration more at individual clicks than when you are turning the handle faster. This is normal.

◇ **The machine vibrates excessively in a cut.**

This is a tough one to call because machining practices come into play. Generally speaking, the least rigid element of a cut is the tool because it is the smallest part. In order to eliminate the machine as the source of the problem, you need to check the spindle and the backlash of the axes as described in the following sections. Once machining practices have been eliminated as the source of vibration, observe the machine in both operation and "cutting air." Move the axes (individually) without the spindle turning and then turn the spindle without moving the axes. Isolate whether the vibration comes from the headstock or from an axis.

## 1.3 ACCURACY

Before you complain of an accuracy problem, please make sure you follow these simple do's and don'ts.

- Don't use a wiggler test indicator for linear dimensions. They measure in an arc and have sine/cosine errors over larger distances.
- Don't use magnetic bases as accurate test stops. The high accel/decel of the axis can cause them to move.
- Don't attach test points to the sheet metal of the spindle head.
- Don't check for thermal growth with an indicator on a long extension magnetic base.
- Do insure that test indicators and stops are absolutely rigid and mounted to machined casting surfaces.
- Do check a suspected error with another indicator or method for verification.
- Do ensure that the indicator is parallel to the axis being checked to avoid tangential reading errors.
- Do center drill holes before using jobber length drills if accuracy is questioned.
- Once machining practices have been eliminated as the source of the problem, determine specifically what the machine is doing wrong.

NOTE: Out of round diameters occur when the tooling or machining practices are incorrect. Bores will be out of round due to tool deflection much more frequently than due to spindle bearing problems

Lathes always cut parallel with the Z-axis. Bores will be tapered if the tooling is inappropriate, speeds and feeds incorrect or coolant not getting to the cutting tool when required. In rare cases, the spindle may be out of alignment due to a crash.

## 1.4 FINISH



### **Machining yields a poor finish.**

- Check for backlash.
- Check the condition of the tooling and the spindle
- Check turret alignment.
- Is the turret clamped?
- Is the tooling tight?

## 2. SPINDLE

### 2.1 NOT TURNING



#### Spindle not turning.

- If there are any alarms, see See Alarm Section.
- Check that the spindle turns freely when machine is off.
  - If spindle drive does not light the RUN LED, check forward/reverse commands from IOPCB.
  - Check that the drawtube piston is not bound against the spindle shaft.
- Check the wiring of analog speed command from MOTIF PCB to spindle drive (cable 720).
- If spindle is still not turning, replace MOTIF PCB.
- Disconnect the drive belt . If the spindle will not turn, it is seized and must be replaced.

**NOTE:** Before using the replacement spindle, the cause of the previous failure must be determined.

### 2.2 NOISE

Most noises attributed to the spindle actually lie in the motor or drive belt of the machine. Isolate the sources of noise as follows:



#### Excessive noise coming from the spindle head area.

- Remove the left end covers and check the machine's drive belt tension.
  - If the noise persists, turn the drive belt over on the pulleys. If the noise is significantly different, the belt is at fault.
  - If the noise does not change, remove the belt and go on to the next step.
- Run the motor with the drive belt disconnected. If the noise persists, the problem lies with the motor. If it disappears, go on to the next step.
- Check for the correct amount of lubrication to the spindle bearings (1cc per hour) in an air mist lubricated spindle.

## 3. SERVOS

### 3.1 NOT OPERATING

All problems that are caused by servo motor failures should also register an alarm. Check the alarm history to determine the problem's cause before any action is taken.

#### ◇ **Servo motor is not functioning.**

- Check the power cable from rear electrical cabinet to ensure connection is tight.
- Encoder is faulty or contaminated (Alarms 139-142, 153-156, 165-168, 182-185).
- Open circuit in motor (Alarms 139-142, 153-156, 182-185).
- Motor has overheated, resulting in damage to the interior components (Alarms 135-138, 176).
- Wiring is broken, shorted, or missing shield (Alarms 153-156, 175, 182-185).
- Dust in the motor from brushes has shorted out the motor (Alarms 153-156, 175, 182-185).
- Motor has overheated; no damage to the interior components. OVERHEAT alarm has been triggered. After thorough check of motor (DO NOT DISASSEMBLE!), take necessary steps to eliminate the problem and alarm to resume operation. If motor is still inoperable, replace motor assembly
- Check for broken or loose coupling between the servo motor and the lead screw.
- Check for a damaged lead screw.

**NOTE:** If a lead screw fails, it is most often due to a failed bearing sleeve.

### 3.2 NOISE

Lead screw noise is usually caused by a lack of lubrication and is usually accompanied by heating. Other causes are misalignment, bearing sleeve damage, or ball nut damage. Check the alarm history of the machine and look for axis overcurrent and following error alarms.

**NOTE:** Do not replace lead screws or bearing sleeves without due consideration; they are extremely durable and reliable. Verify that customer complaints are not due to tooling, programming, or fixturing problems.

#### ◇ **Servo motor noise.**

- Noise is caused by motor brushes. No problems will occur and noise should eventually go away.
- Noise is caused by bearings. Rolling, grinding sound is heard coming from the motor. ENSURE NOISE IS NOT COMING FROM THE BRUSHES.
- If motor noise is caused by motor bearings, replace motor.

#### ◇ **Lead screw noise.**

- Ensure oil is getting to the lead screw through the lubrication system.
- Check for damage to the bearing sleeve.
- Disconnect the servo motor from the lead screw and rotate the lead screw by hand. If the noise persists, the lead screw may need replacing.
- Run the axis back and forth. The motor will get very hot if the bearing sleeve is damaged. If so, turn the axis by hand and feel for roughness in the lead screw. Loosen the clamp nuts at both ends of the lead screw. If the symptom disappears, replace the bearing sleeve. Be certain to check for damage to the lead screw shaft where the bearing sleeve is mounted.

- If the noise persists, the lead screw is damaged and must be replaced. When replacing the lead screw in an older machine, always replace the bearing sleeve with the current angular contact design bearing sleeve.
- Check the lead screw for misalignment.

Misalignment in the lead screw itself will tend to cause the lead screw to tighten up and make excessive noise at both ends of the travel. The ballnut may get hot. Misalignment radially at the yoke where the lead screw ball nut mounts is indicated by heating up of the ball nut on the lead screw, and noise and tightness throughout the travel of the lead screw. Misalignment at the yoke where the ball nut mounts is indicated by noise and tightness at both ends of the travel of the lead screw. The ball nut may get hot.

### 3.3 ACCURACY/BACKLASH

Accuracy complaints are usually related to tooling, programming, or fixturing problems. Eliminate these possibilities before working on the machine.

#### ◇ Poor Z-axis accuracy.

- Check for backlash in the lead screw as outlined below.
- Check for a loose encoder on the servo motor. Also, ensure the key in the motor or the lead screw is in place and the coupling is tight.

#### Initial Preparation-

Turn the lathe ON. ZERO RET the machine and move the carriage to the approximate center of its travel in the Z-axis. Move the turret to the approximate center of the X-axis travel.

#### X-AXIS:

1. Place a dial indicator and base on the spindle retaining ring with the tip of the indicator positioned on the outside diameter of the turret, as shown in Fig. 3-1.




Fig. 3-1 Dial indicator in position to check X-axis.




2. Set dial indicator and the "Distance to go" display in the HANDLE JOG mode to zero as follows:
  - Zero the dial indicator.
  - Press the MDI button on the control panel.
  - Press the HANDLE JOG button on the control panel.The "Distance to go" display on the lower right hand corner should read: X=0 Z=0
3. Set the rate of travel to .001 on the control panel and jog the machine .010 in the positive (+) X direction. Jog back to zero (0) on the display. The dial indicator should read zero (0)  $\pm$  .0001.
4. Repeat step three in the negative (-) direction.

**TOTAL DEVIATION BETWEEN THE DIAL INDICATOR AND THE CONTROL PANEL DISPLAY SHOULD NOT EXCEED .0002.**

An alternate method for checking backlash is to place the dial indicator as shown in Fig. 3-1 and manually push on the turret in both directions. The dial indicator should return to zero after releasing the turret. NOTE: The servos must be on to check backlash by this method.

**Z-AXIS:**

1. Place a dial indicator and base on the spindle retaining ring with the indicator tip positioned on the face of the turret as shown in Fig. 3-2.



*Fig. 3-2 Dial indicator in position to check Z-axis.*

2. Set dial indicator and the "Distance to go" display in the HANDLE JOG mode to zero as follows:
  - Zero the dial indicator.
  - Press the MDI button on the control panel.
  - Press the HANDLE JOG button on the control panel. The "Distance to go" display on the lower right hand corner should read: X=0 , Z=0
3. Set the rate of travel to .001 on the control panel and jog the machine .010 in the positive (+) Y direction. Jog back to zero (0) on the display. The dial indicator should read zero (0)  $\pm$  .0001.
4. Repeat step three in the negative (-) direction.

**TOTAL DEVIATION BETWEEN THE DIAL INDICATOR AND THE CONTROL PANEL DISPLAY SHOULD NOT EXCEED .0002.**

An alternate method for checking backlash is to place the dial indicator as shown in Fig. 3-2 and manually push on the turret in both directions. The dial indicator should return to zero after releasing the turret.

NOTE: The servos must be on to check backlash by this method.

**3.4 VIBRATION****Excessive servo motor vibration.**

- Check all Parameters of the suspected axis against the Parameters as shipped with the machine. If there are any differences, correct those and determine how the Parameters were changed. PARAMETER LOCK should normally be on.
- A bad motor can cause vibration if there is an open or short in the motor. A short would normally cause a GROUND FAULT or OVERCURRENT alarm; check the ALARMS. An ohmmeter applied to the motor leads should show between 1 and 3 ohms between leads, and over 1 megohm from leads to chassis.

**3.5 OVERHEATING****Servo motor overheating.**

- If a motor OVERHEAT alarm occurs (ALARMS 135-138), check the Parameters for an incorrect setting. Axis flags in Parameters 1, 15, or 29 can invert the overheat switch (OVER TEMP NC).
- If the motor is actually getting hot to the touch, there is excessive load on the motor. Check the user's application for excessive load or high duty cycle. Check the lead screw for binding.

**3.6 FOLLOWING ERROR****Following error alarms occur on one or more axes sporadically.**

- Check DC bus voltage on diagnostics page #2. If it is at the low side of the recommended voltages, change the transformer tap to the next lower voltage group as explained in the Installation Manual.
- Check motor wiring.
- Driver card may need replacement.
- Servo motor may need replacement.
- Check for binding in motion of lead screw.

## 4. HYDRAULIC SYSTEM

### 4.1 HYDRAULIC PRESSURE

- ◇ **"Low hydraulic pressure" alarm (134).**
  - Check for any leaks.
  - Check that the oil level is above the black line.
  - Check that the oil pressure is within 50-500 psi. If the hydraulic unit needs to be replaced, see "Hydraulic Unit Removal/Installation" section.
  - Check that the temperature is less than 150 degrees. If the hydraulic unit needs to be replaced, see "Hydraulic Unit Removal/Installation" section.

### 4.2 HYDRAULIC CHUCK

- ◇ **Chuck won't clamp/unclamp.**
  - Check for alarm condition.
  - Check display for "low hydraulic pressure" alarm 134.
  - Check that the oil pressure gauge is within 50-500 psi..
  - Check that the oil filter gauge is less than 20 psi.
  - Use a voltage meter to check the solenoid circuit breaker.
    - Replace solenoid valve if faulty.

### 4.3 NOISE IN HYDRAULIC POWER UNIT

- ◇ **Hydraulic power unit noise.**

NOTE: Noise in hydraulic unit should decrease a few minutes after start up.

  - Check for leaks in hose.
  - Check that the oil level is above the black line.
  - Check for loose pieces/hardware.
  - Check for debris in motor/cooling fins.

## 5. ALARMS

Any time an alarm is present, the lower right hand corner will have a blinking "ALARM". Push the ALARM display key to view the current alarm. All alarms are displayed with a reference number and a complete description. If the RESET key is pressed, one alarm will be removed from the list of alarms. If there are more than 18 alarms, only the last 18 are displayed and the RESET must be used to see the rest. The presence of any alarm will prevent the operator from starting a program.

Note that tool changer alarms can be easily corrected by first correcting any mechanical problem, pressing RESET until the alarms are clear, selecting ZERO RET mode, and selecting AUTO ALL AXES. Some messages are displayed while editing to tell the operator what is wrong but these are not alarms. See the editing topic for those errors.

### 5.1 ALARM LIST

The following alarm list shows the alarm numbers, the text displayed along with the alarm, and a detailed description of the alarm, what can cause it, when it can happen, and how to correct it.

Alarm number and text:	Possible causes:
101 Motor Interface	Internal circuit board problem. The MOTIF PCB in the #2 PCB Failure processor stack is tested at power-on. Call your dealer.
102 Servos Off	Indicates that the servo motors are off, the tool changer is disabled, the coolant pump is off, and the spindle motor is stopped. Caused by EMERGENCY STOP, motor faults, tool changer problems, or power fail.
103 X Servo Error Too Large	Too much load or speed on X-axis motor. The difference between the motor position and the commanded position has exceeded a parameter. The motor may also be stalled, disconnected, or the driver failed. The servos will be turned off and a RESET must be done to restart. This alarm can be caused by problems with the driver, motor, or the slide being run into the mechanical stops.
104 B Servo Error Too Large	same as 103.
105 Z Servo Error Too Large	same as 103.
106 A Servo Error Too Large	same as 103.
107 Emergency Off	EMERGENCY STOP button was pressed. Servos are also turned off. After the E-STOP is released, the RESET button must be pressed at least twice to correct this; once to clear the E-STOP alarm and once to clear the Servos Off alarm.
108 X Servo Overload	Excessive load on X-axis motor. This can occur if the load on the motor over a period of several seconds or even minutes is large enough to exceed the continuous rating of the motor. The servos will be turned off when this occurs. This can be caused by running into the mechanical stops but not

## ALARMS

	much past them. It can also be caused by anything that causes a very high load on the motors.
109 B Servo Overload	same as 108.
110 Z Servo Overload	same as 108.
111 A Servo Overload	same as 108.
112 No Interrupt	Electronics fault. Call your dealer.
113 Turret Unlock Fault	The turret took longer to unlock and come to rotation position than allowed for in Parameter 62. The value in Parameter 62 is in milliseconds. This may occur if the air pressure is too low, the tool turret clamp switch is faulty, or there is a mechanical problem.
114 Turret Lock Fault	The turret took longer to lock and seat than allowed for in Parameter 63. The value in Parameter 63 is in milliseconds. This may occur if the air pressure is too low, the tool turret clamp switch is faulty, or there is a mechanical problem.
115 Turret Rotate Fault	Tool motor not in position. During a tool changer operation the tool turret failed to start moving or failed to stop at the right position. Parameters 62 and 63 can adjust the time-out times. This alarm can be caused by anything that jams the rotation of the turret.
116 Spindle Orientation Fault	Spindle did not orient correctly. During a spindle orientation function, the spindle is rotated until the lock pin drops in; but the lock pin never dropped. Parameters 66, 70, 73, and 74 can adjust the time-out times. This can be caused by a trip of circuit breaker CB4, a lack of air pressure, or too much friction with the orientation pin.
117 Spindle High Gear Fault	Not used.
118 Spindle Low Gear Fault	Not used.
119 Over Voltage	Incoming line voltage is above maximum (about 255 volts when wired for 240 or 235 when wired for 208). The servos will be turned off and the spindle, tool changer, and coolant pump will stop. If this condition remains for 4.5 minutes, an automatic shutdown will begin.
120 Low Air Pressure	Air pressure dropped below 80 PSI for a period of time defined by Parameter 76. Check your incoming air pressure for at least 100 PSI and ensure that the regulator is set at 85 PSI.
121 Low Lub or Low Pressure	Way lube is low or empty or there is no lube pressure or too high a pressure. Check tank at rear of machine and below control cabinet. Also check connector P5 on the side of the control cabinet. Check that the lube lines are not blocked.

122	Control Overheat	The control internal temperature is above 150 degrees F. This can be caused by almost anything in the control overheating. But is usually caused by overheat of the two regen resistors for servos and spindle drive. This alarm will also turn off the servos, spindle drive, coolant pump, and tool changer. One common cause of this overheat condition is an input line voltage too high. If this condition remains for 4.5 minutes, an automatic shutdown will begin.
123	Spindle Drive Fault	Overheat or failure of spindle drive or motor. The exact cause is indicated in the LED window of the spindle drive inside the control cabinet. This can be caused by a stalled motor, shorted motor, overvoltage, undervoltage, overcurrent, overheat of motor, or drive failure.
124	Low Battery	Memory batteries need replacing within 30 days. This alarm is only generated at power on and indicates that the 3.3 volt Lithium battery is below 2.5 volts. If this is not corrected within about 30 days, you may lose your stored programs, parameters, offsets, and settings.
125	Tool Turret Fault	Tool shuttle not initialized at power on, CYCLE START or spindle motion command. This means that the tool shuttle was not fully retracted to the Out position.
126	Gear Fault	Not used.
127	Door Fault	The control failed to detect a high at the A DOOR input after an M85 was commanded and the A DOOR input was not received before a certain period of time. The units are in milliseconds.
128	Tool In Turret	Not used.
129	M Fin Fault	M-Fin was active at power on. Check the wiring to your M code interfaces. This test is only performed at power-on.
130	Chuck Unclamped	The control detected that the chuck is unclamped. This is a possible fault in the air solenoids, relays on the IO Assembly, or wiring.
131	Tool Not Clamped	Tool Release Piston is not Home. This is a possible fault in the air solenoids, relays on the IO Assembly, the draw bar assembly, or wiring.
132	Power Down Failure	Machine did not turn off when an automatic power-down was commanded. Check wiring to POWIF card on power supply assembly, relays on the IO assembly, and the main contactor K1.
133	Spindle Locked	Shot pin did not release. This is detected when spindle motion is commanded. Check the solenoid that controls the air to the lock, relay 2-8, the wiring to the sense switch, and the switch.
134	Low Hydraulic Pressure	Hydraulic pressure is sensed to be low. Check pump pressure and hydraulic tank oil level.

## ALARMS

- |                                   |                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 135 X Motor Over Heat             | Servo motor overheat. The temperature sensor in the motor indicates over 150 degrees F. This can be caused by an extended overload of the motor such as leaving the slide at the stops for several minutes.                                                                                                                                                       |
| 136 B Motor Over Heat             | same as 135.                                                                                                                                                                                                                                                                                                                                                      |
| 137 Z Motor Over Heat             | same as 135.                                                                                                                                                                                                                                                                                                                                                      |
| 138 A Motor Over Heat             | same as 135.                                                                                                                                                                                                                                                                                                                                                      |
| 139 X Motor Z Fault               | Encoder marker pulse count failure. This alarm usually indicates that the encoder has been damaged and encoder position data is unreliable. This can also be caused by loose connectors at P1-P4.                                                                                                                                                                 |
| 140 Spindle Z Fault               | same as 139.                                                                                                                                                                                                                                                                                                                                                      |
| 141 Z Motor Z Fault               | same as 139.                                                                                                                                                                                                                                                                                                                                                      |
| 142 A Motor Z Fault               | same as 139.                                                                                                                                                                                                                                                                                                                                                      |
| 143 Spindle Not Locked            | Shot pin not fully engaged when a tool change operation is being performed. Check air pressure and solenoid circuit breaker CB4. This can also be caused by a fault in the sense switch that detects the position of the lock pin.                                                                                                                                |
| 144 Time-out-<br>Call Your Dealer | Time allocated for use prior to payment exceeded. Call your dealer.                                                                                                                                                                                                                                                                                               |
| 145 X Limit Switch                | Axis hit limit switch or switch disconnected. This is not normally possible as the stored stroke limits will stop the slides before they hit the limit switches. Check the wiring to the limit switches and connector P5 at the side of the main cabinet. Can also be caused by a loose encoder shaft at the back of the motor or coupling of motor to the screw. |
| 146 B Limit Switch                | same as 145.                                                                                                                                                                                                                                                                                                                                                      |
| 147 Z Limit Switch                | same as 145.                                                                                                                                                                                                                                                                                                                                                      |
| 148 A Limit Switch                | Normally disabled for rotary axis.                                                                                                                                                                                                                                                                                                                                |
| 149 Spindle Turning               | Spindle not at zero speed for tool change. A signal from the spindle drive indicating that the spindle drive is stopped is not present while a tool change operation is going on.                                                                                                                                                                                 |
| 150 I Mode Out Of<br>Range        | Internal software error; call your dealer.                                                                                                                                                                                                                                                                                                                        |
| 151 Low Coolant                   | P7 is broken or disconnected.                                                                                                                                                                                                                                                                                                                                     |
| 152 Self Test Fail                | Control has detected an electronics fault. All motors and solenoids are shut down. This is most likely caused by a fault of the processor board stack at the top left of the control. Call your dealer.                                                                                                                                                           |
| 153 X-axis Z<br>Ch Missing        | Broken wires or encoder contamination. All servos are turned off. This can also be caused by loose connectors at P1-P4.                                                                                                                                                                                                                                           |

154	Spindle Z Ch Missing	same as 153.
155	Z-axis Z Ch Missing	same as 153.
156	A-axis Z Ch Missing	same as 153.
157	Motor Interface PCB Failure	Internal circuit board problem. The MOTIF PCB in the processor stack is tested at power-on. Call your dealer.
158	Video/Keyboard PCB Failure	Internal circuit board problem. The VIDEO PCB in the processor stack is tested at power-on. This could also be caused by a short in the front panel membrane keypad. Call your dealer.
159	Keyboard Failure	Keyboard shorted or button pressed at power on. A power-on test of the membrane keypad has found a shorted button. It can also be caused by a short in the cable from the main cabinet or by holding a switch down during power-on.
160	Low Voltage	The line voltage to control is too low. This alarm occurs when the AC line voltage drops below 190 when wired for 230 volts or drops below 165 when wired for 208 volts.
161	X-Axis Over Current or Drive Fault	Current in X servo motor beyond limit. Possibly caused by a stalled or overloaded motor. The servos are turned off. This can be caused by running a short distance into a mechanical stop. It can also be caused by a short in the motor or a short of one motor lead to ground.
162	B-axis Over Current or Drive Fault	same as 161.
163	Z-axis Over Current or Drive Fault	same as 161.
164	A-axis Over Current or Drive Fault	same as 161.
165	X Zero Ret Margin Too Small	This alarm will occur if the home/limit switches move or are misadjusted. This alarm indicates that the zero return position may not be consistent from one zero return to the next. The encoder Z channel signal must occur between 1/8 and 7/8 revolution of where the home switch releases. This will not turn the servos off but will stop the zero return operation.
166	B Zero Ret Margin Too Small	Same as 165.
167	Z Zero Ret Margin Too Small	Same as 165.
168	A Zero Ret Margin Too Small	Not normally enabled for A-axis.



## ALARMS

169	Spindle Direction Fault	Problem with rigid tapping hardware. The spindle started turning in the wrong direction.
170	Phase Loss L1-L2	Problem with incoming line voltage between legs L1 and L2. This usually indicates that there was a transient loss of input power to the machine.
171	Phase Loss L2-L3	Problem with incoming line voltage between legs L2 and L3.
172	Phase Loss L3-L1	Problem with incoming line voltage between legs L3 and L1.
173	Spindle Ref Signal Missing	The Z channel pulse from the spindle encoder is missing for hard tapping synchronization.
174	Tool Load Exceeded	The tool load monitor option is selected and the maximum load for a tool was exceeded in a feed. This alarm can only occur if the tool load monitor function is installed in your machine.
175	Ground Fault Detected	A ground fault condition was detected in the 115V AC supply. This can be caused by a short to ground in any of the servo motors, the tool change motors, the fans, or the oil pump.
176	Over heat Shutdown	An overheat condition persisted for 4.5 minutes and caused an automatic shutdown.
177	Over voltage Shutdown	An overvoltage condition persisted for 4.5 minutes and caused an automatic shutdown.
178	Divide by Zero	Software Error; Call your dealer.
179	Low Pressure Spindle Coolant	Spindle coolant oil is low or low pressure condition in lines.
182	X Cable Fault	Cable from X-axis encoder does not have valid differential signals.
183	Spindle Cable Fault	Same as 182.
184	Z Cable Fault	Same as 182.
185	A Cable Fault	Same as 182.
186	Spindle Not Turning	Trying to feed while spindle is in the stopped position.
187	B Servo Error Too Large	Same as 103.
188	B Servo Overload	Same as 108.
189	B Motor Overheat	Same as 135.
190	B Motor Z Fault	Same as 139.
191	B Limit Switch	Same as 145.

192	B Axis Z Ch Missing	Same as 153.
193	B Axis Overcurrent or Drive Fault	Same as 161.
194	B Zero Ret Margin Too Small	Same as 165.
195	B Cable Fault	Same as 182.
197	100 Hours Unpaid Bill	Call your dealer.
198	Spindle Stalled	Control senses that no spindle fault has occurred, the spindle is at speed, yet the spindle is not turning. Possibly the belt between the spindle drive motor and spindle has slipped or is broken.
199	Negative RPM	Internal software error; call your dealer.
201	Parameter CRC Error	Parameters lost maybe by low battery. Check for a low battery and low battery alarm.
202	Setting CRC Error	Settings lost maybe by low battery. Check for a low battery and low battery alarm.
203	Lead Screw CRC Error	Lead screw compensation tables lost maybe by low battery. Check for CRC Error low battery and low battery alarm.
204	Offset CRC Error	Offsets lost maybe by low battery. Check for a low battery and low battery alarm.
205	Programs CRC Error	Users program lost maybe by low battery. Check for a low battery and low battery alarm.
206	Internal Program Error	Software Error; Call your dealer.
207	Queue Advance Error	Software Error; Call your dealer.
208	Queue Allocation Error	Software Error; Call your dealer.
209	Queue Cutter Comp Error	Software Error; Call your dealer.
210	Insufficient Memory	Not enough memory to store users program. Check the space available in the LIST PROG mode and possibly delete some programs.
211	Odd Prog Block	Software Error; Call your dealer.
212	Program Integrity Error	Software Error; Call your dealer.
213	EPROM CRC Error	Electronics fault; Call your dealer.

## ALARMS

214	No. of Programs Changed	Indicates that the number of programs disagrees with the internal variable that keeps count of the loaded programs. Call your dealer.
215	Free Memory PTR Changed	Indicates the amount of memory used by the programs counted in the system disagrees with the variable that points to free memory. Call your dealer.
216	EPROM Speed Failure	Indicates that an EPROM internal driver has weakened so that data read from that EPROM may be unreliable. Call your dealer.
235	Macro Variable File CRC Error	Macro variables lost maybe by low battery. Check for a low battery and low battery alarm. Reload the macro variable file.
240	Empty Prog or No EOB	Software Error; Call your dealer.
241	Invalid Code	RS-232 load bad. Data was stored as comment. Check the program being received.
242	No End	Check input file for a number that has too many digits.
243	Bad Number	Data entered is not a number.
244	Missing )	Comment must end with a " ) ".
245	Unknown Code	Check input line or data from RS-232. This alarm can occur while editing data into a program or loading from RS-232.
246	String Too Long	Input line is too long. The data entry line must be shortened.
247	Cursor Data Base Error	Software Error; Call your dealer.
248	Number Range Error	Number entry is out of range.
249	Prog Data Begins Odd	Software Error; Call your dealer.
250	Program Data Error	Same as 249.
251	Prog Data Struct Error	Same as 249.
252	Memory Overflow	Same as 249.
257	Program Data Error	Same as 249.
258	Invalid DPRNT Format	Macro DPRNT statement not structured properly.
259	Bad Language Version	Call your dealer.
260	Bad Language CRC	Indicates FLASH memory has been changed. Call your dealer.
261	B Motor Z Fault	Same as 139.
262	B Axis Z Ch Missing	Same as 153.

302	Invalid R In G02 or G03	Check your geometry with the HELP page. R must be less than or equal to half the distance from start to end within an accuracy of 0.0010 inches.
303	Invalid X, B, or Z In G02 or G03	Check your geometry with the HELP page.
304	Invalid I, J, or K In G02 or G03	Check your geometry with the HELP page. Radius at start must match radius at end of arc within 0.0010 inches.
305	Invalid Q In Canned Cycle	Q in a canned cycle must be greater than zero.
306	Invalid I, J, K, or Q In Canned Cycle	I, J, K, and Q in a canned cycle must be greater than zero.
307	Subroutine Nesting Too Deep	Subprogram nesting is limited to nine levels. Simplify your program.
308	Invalid Tool Offset	A tool offset not within the range of the control was used.
309	Exceeded Max Feed Rate	Use a lower feed rate.
310	Invalid G Code	G code not defined and is not a macro call.
311	Unknown Code	Possible corruption of memory by low battery. Call your dealer.
312	Program End	End of subroutine reached before M99. Need an M99 to return from subroutine.
313	No P Code In M97, M98, or G65	Must put subprogram number in P code.
314	Subprogram or Macro Not In Memory	Check that a subroutine is in memory or that a macro is defined.
315	Invalid P Code In M97, M98 or M99	The P code must be the name of a program stored in memory without a decimal point for M98 and must be a valid N number for M99.
316	X Over Travel Range	X-axis will exceed stored stroke limits. This is a parameter in negative direction and is machine zero in the positive direction. This will only occur during the operation of a user's program.
317	B Over Travel Range	same as 316.
318	Z Over Travel Range	same as 316.
319	A Over Travel Range	Not normally possible with A-axis.
320	No Feed Rate Specified	Must have a valid F code for interpolation functions.

## ALARMS

- |     |                                    |                                                                                                                                                                                                                    |
|-----|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 321 | Auto Off Alarm                     | A fault turned off the servos automatically; occurs in debug mode only.                                                                                                                                            |
| 322 | Sub Prog Without M99               | Add an M99 code to the end of program called as a subroutine.                                                                                                                                                      |
| 324 | Delay time Range Error             | P code in G04 is over 1000.0 or over 9999.                                                                                                                                                                         |
| 325 | Queue Full                         | Control problem; call your dealer.                                                                                                                                                                                 |
| 326 | G04 Without P Code                 | Put a Pn.n for seconds or a Pn for milliseconds.                                                                                                                                                                   |
| 327 | No Loop For M Code Except M97, M98 | L code not used here. Remove L Code.                                                                                                                                                                               |
| 328 | Invalid Tool Number                | Tool number must be between 1 and 24.                                                                                                                                                                              |
| 329 | Undefined M Code                   | That M code is not defined and is not a macro call.                                                                                                                                                                |
| 330 | Undefined Macro                    | Call Macro name O90nn not in memory. A macro call definition is in parameters and was accessed by user program but that macro was not loaded into memory.                                                          |
| 331 | Range Error                        | Number too large.                                                                                                                                                                                                  |
| 332 | H and T Not Matched                | This alarm is generated when Setting 15 is turned ON and an H code number in a running program does not match the tool number in the spindle. Correct the Hn codes, select the right tool, or turn off Setting 15. |
| 333 | X-axis Disabled                    | Parameters have disabled this axis. Not normally possible in Lathe.                                                                                                                                                |
| 334 | B-axis Disabled                    | same as 333.                                                                                                                                                                                                       |
| 335 | Z-axis Disabled                    | same as 333.                                                                                                                                                                                                       |
| 336 | A-axis Disabled                    | Parameters have disabled this axis. Must enable A-axis to program it or remove programming of A-axis. The A-axis can be disabled permanently by Parameter 43 or temporarily by Setting 30.                         |
| 337 | Line Referenced By P Not Found     | Subprogram is not in memory, or P code is incorrect.                                                                                                                                                               |
| 338 | Invalid IJK and XYZ in G02 or G03  | There is a problem with circle definition; check your geometry.                                                                                                                                                    |
| 339 | Multiple Codes                     | Only one M, X, Y, Z, A, Q, etc. allowed in any block or two G codes in the same group.                                                                                                                             |
| 340 | Cutter Comp Begin With G02 or G03  | Select cutter comp earlier.                                                                                                                                                                                        |
| 341 | Cutter Comp End With G02 or G03    | Disable cutter comp later.                                                                                                                                                                                         |

342	Cutter Comp Path Too Small	Geometry not possible. Check your geometry with the HELP page.
343	Display Queue Record Full	A block exists that is too long for displaying queue. Shorten title block.
344	Cutter Comp With G18 and G19	Cutter comp only allowed in XY plane (G17).
345	Diff Step Ratio On G17 Plane	Parameters 5 and 19 must be same value.
346	Diff Step Ratio On G18 Plane	Parameters 5 and 33 must be same value.
347	Diff Step Ratio On G19 Plane	Parameters 19 and 33 must be same value.
348	Illegal Spiral Motion	Linear axis path is too long. For helical motions, the linear path must not be more than the length of the circular component.
349	Prog Stop W/O Cancel Cutter Comp	Information message only. Fix or Ignore.
350	Cutter Comp Look Ahead Error	There are too many non-movement blocks between motions when cutter comp is being used. Remove some intervening blocks.
351	Buffered Block Range Error	Software error. Call your dealer.
352	Aux Axis Power Off	Aux B, C, U, V, or W axis indicate servo off. Check auxiliary axes. Status from control was OFF.
353	Aux Axis No Home	A ZERO RET has not been done yet on the aux axes. Check auxiliary axes. Status from control was LOSS.
354	Aux Axis Disconnected	Aux axes not responding. Check auxiliary axes and RS-232 connections.
355	Aux Axis Position Mismatch	Mismatch between machine and aux axes position. Check aux axes and interfaces. Make sure no manual inputs occur to aux axes.
356	Aux Axis Travel Limit	Aux axes are attempting to travel past their limits.
357	Aux Axis Disabled	Aux axes are disabled.
358	Multiple Aux Axis	Can only move one auxiliary axis at a time.
359	Invalid I, J, or K In G12 or G13	Check your geometry with the HELP page.

## ALARMS

360	Tool Changer Disabled	Check Parameter 57. Not a normal condition for the Lathe.
361	Gear Change Disabled	Not used.
362	Tool Usage Alarm	Tool life limit was reached. To continue, reset the usage count in the Current Commands display and press RESET.
363	Coolant Locked Off	Override is off and program tried to turn on coolant.
364	No Circ Interp Aux Axis	Only rapid or feed is allowed with aux axes.
367	Cutter Comp Interference	G01 cannot be done with tool size.
368	Groove Too Small	Tool too big to enter cut.
369	Tool Too Big	Use a smaller tool for cut.
370	Pocket Definition Error	Check geometry for G150.
371	Invalid I, J, K, OR Q	Check G150.
372	Tool Change In Canned Cycle	Tool change not allowed while canned cycle is active.
373	Invalid Code in DNC	A code found in a DNC program could not be interpreted because of restrictions to DNC.
374	Missing XBZA in G31 or G36	G31 skip function requires an X, B, Z, or A move.
375	Missing Z or H in G37	G37 auto offset skip function requires H code, Z value, and tool offset enabled. X, B, and A values not allowed.
376	No Cutter Comp In Skip	Skip G31 and G37 functions cannot be used with cutter compensation.
377	No Skip in Graph/Sim	Graphics mode cannot simulate skip function.
378	Skip Signal Found	Skip signal check code was included but skip was found when it was not expected.
379	Skip Signal Not Found	Skip signal check code was included but skip was not found when it was expected.
380	X, B, A, or G49 Not Allowed in G37	G37 may only specify Z-axis and must have tool offset defined.

- |                                            |                                                                                                                                                                          |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 381 G43 or G44 Not Allowed in G36 or G136  | Auto work offset probing must be done without tool offset.                                                                                                               |
| 382 D Code Required in G35                 | A Dnn code is required in G35 in order to store the measured tool diameter.                                                                                              |
| 383 Inch Is Not Selected                   | G20 was specified but settings have selected metric input.                                                                                                               |
| 384 Metric Is Not Selected                 | G21 was specified but settings have selected inches.                                                                                                                     |
| 385 Invalid L, P, or R Code In G10invalid. | G10 was used to changes offsets but L, P, or R code is missing or                                                                                                        |
| 386 Invalid Address Format                 | An address A..Z was used improperly.                                                                                                                                     |
| 387 Cutter Comp Not Allowed With G103      | If block buffering has been limited, Cutter comp cannot be used.                                                                                                         |
| 388 Cutter Comp Not Allowed With G10       | Coordinates cannot be altered while cutter comp is active. Move G10 outside of cutter comp. enablement.                                                                  |
| 389 G17, G18, G19 Illegal in G68           | Planes of rotation cannot be changed while rotation is enabled.                                                                                                          |
| 390 No Spindle Speed                       | S code has not been encountered. Add an S code.                                                                                                                          |
| 391 Feature Disabled                       | An attempt was made to use a control feature not enabled by a parameter bit. Set the parameter bit to 1.                                                                 |
| 392 B Axis Disabled                        | Same as 333.                                                                                                                                                             |
| 393 Invalid Motion In G74 or G84           | Rigid Tapping can only be in the Z minus G74 or G84 direction. Make sure that the distance from the initial position to the commanded Z depth is in the minus direction. |
| 394 Canned Cycle Using P & Q is Active     | A canned cycle using P & Q is already executing. A canned cycle can not be executed by another PQ canned cycle.                                                          |
| 395 Invalid Code In Canned Cycle           | Any canned cycle requiring a PQ path sequence may not have an M code in the same block. That is G70, G71, G72, and G73.                                                  |
| 396 Conflicting Axes                       | An Incremental and Absolute command can not be used in the same block of code. For example, X and U cannot be used in the same block.                                    |
| 397 Invalid D Code                         | In the context that the D code was used it had an invalid value. Was it positive ?                                                                                       |
| 399 Invalid U Code                         | In the context that the U code was used it had an invalid value. Was it positive ?                                                                                       |



## ALARMS

403	RS-232 Too Many Progs	Cannot have more than 100 programs in memory.
404	RS-232 No Program Name	Need name in programs when receiving ALL; otherwise has no way to store them.
405	RS-232 Illegal Prog Name	Check files being loaded. Program name must be Onnnn and must be at beginning of a block.
406	RS-232 Missing Code	A receive found bad data. Check your program. The program will be stored but the bad data is turned into a comment.
407	RS-232 Invalid Code	Check your program. The program will be stored but the bad data is turned into a comment.
408	RS-232 Number Range Error	Check your program. The program will be stored but the bad data is turned into a comment.
409	RS-232 Invalid N Code	Bad Parameter or Setting data. User was loading settings or parameters and something was wrong with the data.
410	RS-232 Invalid V Code	Bad parameter or setting data. User was loading settings or parameters and something was wrong with the data.
411	RS-232 Empty Program	Check your program. Between % and % there was no program found.
412	RS-232 Unexpected End of Input	Check Your Program. An ASCII EOF code was found in the input data before program receive was complete. This is a decimal code 26.
413	RS-232 Insufficient Memory	Program received doesn't fit. Check the space available in the LIST PROG mode and possibly delete some programs.
414	RS-232 Buffer Overflow	Data sent too fast to CNC. This alarm is not normally possible as this control can keep up with even 38400 bits per second.
415	RS-232 Overrun	Data sent too fast to CNC. This alarm is not normally possible as this control can keep up with as much as 38400 bits per second.
416	RS-232 Parity Error	Data received by CNC has bad parity. Check parity settings, number of data bits and speed. Also check your wiring.
417	RS-232 Framing Error	Data received was garbled and proper framing bits were not found. One or more characters of the data will be lost. Check parity settings, number of data bits and speed.
418	RS-232 Break	Break condition while receiving. The sending device set the line to a break condition. This might also be caused by a simple break in the cable.
419	Invalid Function For DNC	A code found on input of a DNC program could not be interpreted.

420	Program Number Mismatch	The O code in the program being loaded did not match the O code entered at the keyboard. Warning only.
430	Floppy Unexpected End of Input	Check your program. An ASCII EOF code was found in the input data before program receive was complete. This is a decimal code 26.
431	Floppy No Prog Name	Need name in programs when receiving ALL; otherwise has no way to store them.
432	Floppy Illegal Prog Name	Check files being loaded. Program must be Onnnn and must be at the beginning of a block.
433	Floppy Empty Prog Name	Check your program. Between % and % there was no program found.
434	Floppy Insufficient Memory	Program received doesn't fit. Check the space available in the LIST PROG mode and possibly delete some programs.
435	Floppy Abort	Could not read disk.
436	Floppy File Not Found	Could not find floppy file.
501	Too Many Assignments In One Block	Only one assignment "=" is allowed per block. Divide block in error into multiple blocks.
502	[ Or = Not First Term In Expressn	An expression element was found where it was not preceded by "[" or "=", that start expressions.
503	Illegal Macro Variable Reference	A macro variable number was used that is not supported by this control, use another variable.
504	Unbalanced Paren. In Expression	Unbalanced brackets, "[" or "]", were found in an expression. Add or delete a bracket.
505	Value Stack Error	The macro expression value stack pointer is in error. Call your dealer.
506	Operand Stack Error	The macro expression operand stack pointer is in error. Call your dealer.
507	Too Few Operands On Stack	An expression operand found too few operands on the expression stack. Call your dealer.
508	Division By Zero	A division in a macro expression attempted to divide by zero. Re-configure expression.
509	Illegal Macro Variable Use	See "Macros" section for valid variables.
510	Illegal Operator or Function Use	See "Macros" section for valid operators.

## ALARMS

511	Unbalanced Right Brackets	Number of right brackets not equal to the number of left brackets.
512	Illegal Assignment Use	Attempted to write to a read-only macro variable.
513	Var. Ref. Not Allowed With N Or O	Alphabetic addresses N and O cannot be combined with macro variables. Do not declare N#1, etc.
514	Illegal Macro Address Reference	A macro variable was used incorrectly with an alpha address. Same as 513.
515	Too Many Conditionals In a Block	Only one conditional expression is allowed in any WHILE or IF-THEN block.
516	Illegal Conditional Or No Then	A conditional expression was found outside of an IF-THEN, WHILE, or M99 block.
517	Exprsn. Not Allowed With N Or O	A macro expression cannot be concatenated to N or O. Do not declare O[#1], etc.
518	Illegal Macro Exprsn Reference	An alpha address with expression, such as A[#1+#2], evaluated incorrectly. Same as 517.
519	Term Expected not found.	In the evaluation of a macro expression an operand was expected and not found.
520	Operator Expected	In the evaluation of a macro expression an operator was expected and not found.
521	Illegal Functional Parameter	An illegal value was passed to a function, such as SQRT[ or ASIN[.
522	Illegal Assignment Var Or Value	A variable was referenced for writing. The variable referenced is read only.
523	Conditional Req'd Prior To THEN	THEN was encountered and a conditional statement was not processed in the same block.
524	END Found With No Matching DO	An END was encountered without encountering a previous matching DO. DO-END numbers must agree.
525	Var. Ref. Illegal During Movement	Variable cannot be read during axis movement.
526	Command Found On DO/END Line	A G-code command was found on a WHILE-DO or END macro block. Move the G-code to a separate block.
527	= Not Expected Or THEN Required	Only one Assignment is allowed per block, or a THEN statement is missing.

- |     |                                   |                                                                                                                                                                                                                                                       |
|-----|-----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 528 | Parameter Precedes G65            | On G65 lines all parameters must follow the G65 G-code. Place parameters after G65.                                                                                                                                                                   |
| 529 | Illegal G65 Parameter             | The addresses G, L, N, O, and P cannot be used to pass parameters.                                                                                                                                                                                    |
| 530 | Too Many I, J, or K's In G65      | Only 10 occurrences of I, J, or K can occur in a G65 subroutine call. Reduce the I, J, or K count.                                                                                                                                                    |
| 531 | Macro Nesting Too Deep            | Only four levels of macro nesting can occur. Reduce the amount of nested G65 calls.                                                                                                                                                                   |
| 532 | Unknown Code In Pocket Pattern    | Macro syntax is not allowed in a pocket pattern subroutine.                                                                                                                                                                                           |
| 533 | Macro Variable Undefined          | A conditional expression evaluated to an UNDEFINED value, i.e. #0. Return True or False.                                                                                                                                                              |
| 534 | DO Or END Already In Use          | Multiple use of a DO that has not been closed by and END in the same subroutine. Use another DO number.                                                                                                                                               |
| 535 | Illegal DPRNT Statement           | A DPRNT statement has been formatted improperly, or DPRNT does not begin block.                                                                                                                                                                       |
| 536 | Command Found On DPRNT Line       | A G-code was included on a DPRNT block. Make two separate blocks.                                                                                                                                                                                     |
| 537 | RS-232 Abort On DPRNT             | While a DPRNT statement was executing, the RS-232 communications failed.                                                                                                                                                                              |
| 538 | Matching END Not Found            | A WHILE-DO statement does not contain a matching END statement. Add the proper END statement.                                                                                                                                                         |
| 539 | Illegal Goto                      | Expression after "GOTO" not valid.                                                                                                                                                                                                                    |
| 540 | Macro Syntax Not Allowed          | A section of code was interpreted by the control where macro statement syntax is not permitted. In lathe controls PQ sequences describing part geometry cannot use macro statements in the part path description.                                     |
| 600 | Code Not Expected In This Context | During program interpretation, the control found code out of context. This may indicate an invalid address code found in a PQ sequence. It may also indicate faulty memory hardware or lost memory. Look at the highlighted line for improper G-code. |
| 601 | Maximum PQ Blocks Exceeded        | The maximum number of blocks making up a PQ sequence was exceeded. Currently, no more than 65535 blocks can be between P and Q.                                                                                                                       |
| 602 | Non Monotonous PQ Blocks          | The path defined by PQ was not monotonic in the X axis. A monotonic path in X is one which does not change direction starting from the first motion block.                                                                                            |

### ALARMS

- |     |                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 603 | Non Monotonous PQ Blocks in Z       | The path defined by PQ was not monotonic in the Z axis. A monotonic path is one which does not change direction starting from the first motion block.                                                                                                                                                                                                                                                                                                                                                    |
| 605 | Invalid Tool Nose Angle in a G76    | An invalid angle for the for the cutting tool tip was specified. This will occur block if the A address has a value that is not from 0 to 120 degrees.                                                                                                                                                                                                                                                                                                                                                   |
| 606 | Invalid A Code                      | An invalid angle for linear interpolation was specified. This will occur in a G01 block if the A address was congruent to 0 or 180 degrees.                                                                                                                                                                                                                                                                                                                                                              |
| 607 | Invalid W Code                      | In the context that the W code was used it had an invalid value. Was it positive ?                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 608 | G01 or G00 Expected                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 609 | Tailstock Restricted Zone           | When the axes move into the tailstock restricted zone at any time during program execution. To eliminate the problem, change the program or Settings 93 and 94 to open up the restricted zone.                                                                                                                                                                                                                                                                                                           |
| 610 | G71/G72 Domain Nesting Exceeded     | The number of troughs nested has exceeded the control limit. Currently, no more than 10 levels of trough can be nested. Refer to the explanation of G71 for a description of trough nesting.                                                                                                                                                                                                                                                                                                             |
| 611 | G71/G72 Type I Alarm                | <p>When G71 or G72 is executing and the control detects a problem in the defined PQ path. It is used to indicate which method of roughing has been selected by the control. It is generated to help the programmer when debugging G71 or G72 commands.</p> <p>The control often selects Type I roughing when the programmer has intended to use Type II roughing. To select Type II, add R1 to the G71/G72 command block (in YASNAC mode), or add a Z axis reference to the P block (in FANUC mode).</p> |
| 612 | G71/G72 Type II Alarm               | This alarm is similar to Alarm 611, but indicates that the control has selected Type II roughing.                                                                                                                                                                                                                                                                                                                                                                                                        |
| 613 | Command Not Allowed In Cutter Comp. | A command (M96, for example) in the highlighted block cannot be executed while cutter comp. is invoked.                                                                                                                                                                                                                                                                                                                                                                                                  |
| 614 | Invalid Q Code                      | A Q address code used a numeric value that was incorrect in the context used. Q used to reference tip codes in G10 can be 0...9. In M96 Q can reference only bits 0 to 31. Use an appropriate value for Q                                                                                                                                                                                                                                                                                                |
| 615 | No Intersection to Offsets in CC    | While cutter comp was in effect, a geometry was encountered whose compensated paths had no solution given the tool offset used. This can occur when solving circular geometries. Correct the geometry or change the tool radius                                                                                                                                                                                                                                                                          |

# **MECHANICAL SERVICE**

# 1. TURRET

## 1.1 LATHE TURRET CRASH RECOVERY PROCEDURE

The following procedure describes how to clear the turret when a tool change is attempted with the quick change wrench still in the turret. In the future, this procedure will be replaced with a front panel, single-key sequence.

1. Move to Parameter 43 on the Parameters Display. This is the tool turret motor parameters. Change INVIS AXIS from "1" to "0" (zero).
2. Setting 7, "Parameter Lock", must be OFF. Move to the Alarm Display and type "DEBUG" and then press the WRITE key. Verify that the debug line is displayed.
3. Press the MDI key. Enter "M43" into MDI and press CYCLE START. This will unlock the turret by pushing it in the Z-direction.
4. Press the HANDLE JOG key, and then the POSIT key to get into the Position Display and Jog mode. The A axis should be displayed below the X and Z axes.
5. Press the BLANK key, which is just left of the X+ key and above the Z- key. A message should indicate that the A axis is being jogged.
6. Turn the JOG handle until the obstruction is cleared and the turret rotates freely. If an OVERCURRENT alarm is received, reset the control and turn the JOG handle in the opposite direction.
7. Move to Parameter 43 on the Parameter Display and change INVIS AXIS back to "1".
8. Turn the control power off and then back on. The turret can now be positioned by pressing either POWER UP or AUTO ALL AXES.

NOTE: If alarms 111 or 164 occur after the obstruction is cleared, you may need to adjust the turret motor coupling.

## 1.2 TURRET MOTOR COUPLING ADJUSTMENT

NOTE: The turret must be at tool #1 to perform this procedure.

1. Remove the sliding tool changer cover.
2. Go to Setting 7 and turn off the Parameter Lock.
3. Go to Parameter 43 and change "Z CH ONLY" to "1".
4. Loosen the turret motor coupling clamp screw closest to the motor.
5. Press the ZERO RETURN button, then the A button, and the ZERO SINGLE AXIS button. This will cause the motor to go to the first encoder Z pulse.
6. Move the turret motor coupling back and forth to find the center of it's backlash, and tighten the clamp screw as close to the center of the backlash as possible.

NOTE: If it is tight (no backlash) it will be necessary to force it in one direction or the other until it pops into it's backlash area. If it gets tighter when it is turned, STOP; this is the wrong direction.

7. Change Parameter 43, "Z CH ONLY" back to "0" (zero).
8. Press the ZERO RETURN button, A button, and ZERO SINGLE AXIS button. This will home the turret at tool #1.
9. Press the EMERGENCY STOP button and turn the turret motor coupling back and forth to verify that the backlash is centered.
10. Go to Setting 7 and turn on the Parameter Lock.
11. Replace the sliding tool changer cover.




Figure 1-1 Turret motor adjustment.



## 1.3 TURRET ALIGNMENT VERIFICATION

### TOOLS REQUIRED:

A BAR APPROXIMATELY 12"x 4"x 1" (GROUND TO WITHIN 0.0001" ON THE 1" WIDTH SIDE)

MAGNETIC INDICATOR BASE

DIAL INDICATOR (0.0005" OR LESS RESOLUTION)

1. Remove all tool holders and fittings from the turret.
2. Clean the turret pockets and tool holders.
3. Place the turret at tool #1.
4. Place a clean and undamaged tool holder loosely (do not thread nuts) in pocket #2, and another in pocket #5.
5. Place the 12" x 4" x 1" bar across the small diameter of the 2 tool holders (ground side down).
6. Jog the X axis to the center of it's travel.
7. Place the magnetic indicator base on the Z axis way cover. Place the indicator at the center of the bottom edge of the bar.
8. Jog the X axis so the indicator is at one end of the bar, and zero the indicator.
9. Jog the X axis to the other end of the bar, and check your reading (tolerance is 0.0010" TIR).

NOTE: If the reading is greater than the tolerance specified see the following sections.




Figure 1-2 Turret alignment

## 1.4 TURRET ALIGNMENT OF THE OUTER COUPLING

1. Change Parameter 76 from "500" to "50,000" and disconnect the main air line.
2. Remove the sliding tool changer cover and the turret assembly cover.
3. Loosen, and then retighten by hand the 10 turret coupling bolts located on the front of the turret.
4. Put a 3/4" wrench on the bolt at the end of the air cylinder. Pull forward until the turret starts to unclamp, then push it back in until the turret no longer moves in the clamped position.

NOTE: This is to relieve some of the pressure on the coupling but not to separate the 2 couplings. If the shaft will not move back after pulled forward, reconnect the main air line and then attempt to move it back.

5. Tap on the appropriate tool holder (#2 or #5) to align the bar in the X axis plane.
6. Retighten the turret bolts, jog the X axis back to center, remove the bar, and reconnect the main air line.
7. Press the ZERO RETURN button, then the A button and the ZERO SINGLE AXIS button. The turret will then home and reclamp at tool #1.
8. Go to Step 1 of section 1.3 Turret Alignment Verification and verify your readings. When the readings are within tolerance, change Parameter 76 from "50,000" back to "500" and reinstall all covers.

NOTE: If turret cannot be adjusted enough to be within tolerance, it may be necessary to adjust the inner coupling to center. If it will not adjust at all, either the couplings have been separated too much or there is still too much tension on the couplings. Refer to the next two sections.




Figure 1-3 Turret clamp / unclamp position.

## 1.5 CENTERING INNER TURRET COUPLING (WITHOUT BRASS PLUG)

NOTE: This procedure is only to be performed if there is not enough adjustment to perform an outer coupling alignment.

NOTE: If the turret has a 1/4" brass plug, proceed to the next section.

1. Pull the turret air cylinder all the way forward (unclamp) and place something snugly between the back of the turret shaft and the casting to keep the turret shaft from shifting.
2. Remove the 4 bolts from the center turret shaft cover.
3. To gain access to the rear coupling, either remove the turret or install a turret shaft extension and slide the turret onto it. (Be careful not to loosen the key way, it will be facing down at this point.)
4. Loosen the 10 bolts on the inner coupling and center the coupling to the bolt holes. Retighten them to 25 ft-lbs.
5. Install the thrust bearing and both thrust bearing washers to the shoulder of the turret shaft.
6. Go to Parameter 43 and change the INVIS AXIS to zero. Then go to the alarms page, type "DEBUG" and press the WRITE button. Push the HANDLE JOG button. Press the key in the lower right corner of the jog keys (it's unmarked and directly below the "Z+" jog key). Then jog the A axis so the key way slot is on top. NOTE: This can only be done while the turret is unclamped.
7. Reinstall the turret and turret shaft cover. Make sure that the turret makes it over the O-ring before the bolts are tightened completely. If the bolts tighten up and the O-ring is still visible, one of the thrust washers is not on the shoulder of the turret shaft.
8. Return to Step 1 of the "Turret Alignment Verification" section and verify your readings.
9. When the turret alignment is complete, go to the alarms page and type "DEBUG" and press the WRITE button. Change Parameter 43, "INVIS AXIS" to 1 and Parameter 76 to 500.

## 1.6 CENTERING THE INNER TURRET COUPLING (IF EQUIPPED WITH 1/4" BRASS PLUG)

NOTE: This procedure is only to be performed if there is not enough adjustment to perform an outer coupling alignment.

NOTE: This procedure is to be performed if the turret is equipped with a 1/4" brass plug.

1. Remove the 1/4" brass plug to gain access to the rear coupling.
2. Pull the turret air cylinder all the way forward (unclamp) with a wrench.
3. Go to Parameter 43 and change the INVIS AXIS to zero. Then go to the alarms page, type "DEBUG" and press the WRITE button. Push the HANDLE JOG button. Press the key in the lower right corner of the jog keys (it's unmarked and directly below the "Z+" jog key). NOTE: This can only be done while the turret is unclamped.
4. Loosen, then lightly retighten all ten inner coupling bolts (jogging the A axis for access) and center the coupling to the bolt holes.
5. Clamp the couplings by pushing the turret air cylinder back to it's original position.
6. Return to Step 1 of the "Turret Alignment Verification" section and verify your readings.
7. When coupling is in place, unlock the turret, as in Step 2.
8. Tighten all ten inner coupling bolts (jogging the A axis for access) and torque them to 25 ft-lbs.
9. Replace the 1/4" brass plug.
10. Relock the turret.
11. Repeat step 6.
12. When the turret alignment is complete, go to the alarms page and type "DEBUG" and press the WRITE button. Change Parameter 43, "INVIS AXIS" to 1 and Parameter 76 to 500.

## 2. SPINDLE

### 2.1 REMOVAL

NOTE: POWER OFF THE MACHINE BEFORE PERFORMING THE FOLLOWING PROCEDURE.

1. Remove the chuck or collet nose from the Lathe.
2. Remove the necessary covers to gain access to the spindle assembly.
3. For machines equipped with a Hydraulic Cylinder follow these steps for removal:
  - Disconnect oil return hose and coolant drain hose after powering OFF machine.
  - Loosen the clamp and unclamp hoses then remove.
  - Loosen the twelve SHCS from the adapter and detach hydraulic cylinder.
  - Loosen eight SHCS of adapter and detach from spindle shaft.
  - Skip to Step 14 and proceed with spindle removal.




Figure 2-1 Hydraulic cylinder.

4. Remove the two adjusting rings and the lock ring from the spindle assembly.
5. Unscrew the drawtube and pull straight out being careful of the threads.
6. Unclamp the Lathe, remove the retaining ring from the ID Housing, then reclamp the Lathe.
7. Remove the air hose from the machine.
8. Turn the power OFF.
9. Disconnect the air hose from the cylinder.




Figure 2-2 Spindle Housing (side view)

10. Unscrew the four SHCS holding the cylinder and piston then slide off.
11. Slide off the OD housing with bellville washers.
12. Unscrew the eight SHCS then slide off the ID spring housing from the spindle shaft.
13. Unscrew the four SHCS then remove the washers, blue springs and the floating clamp plate.
14. Unplug the encoder. Unscrew the encoder bracket and remove the encoder then remove the belt.
15. Loosen the four SHCS holding the spindle motor. Slide the motor up by squeezing the belts. Tighten the SHCS and remove the drive belts from the spindle assembly.
16. Loosen the SHCS and remove spindle drive pulley.
17. Note the direction of the flat sides of the fittings for lubricating the spindle bearings. Disconnect the two lubrication hoses and unscrew the fittings from the spindle housing.
18. Unscrew the six SHCS holding the spindle assembly retaining ring and detach.
19. Use the draw bar to assist in removing the spindle assembly. Slide the draw bar through the spindle assembly then rock the bar and push the assembly toward the turret. It may be hard at first but should get easier as the bearings are free from their seats. When the front bearing is free, verify that the threads are passing through the assembly as not to damage them.

NOTE: If machine is equipped with a hydraulic cylinder, the cylinder and drawtube detach as one unit.

## 2.2 INSTALLATION

1. Place the draw tube in the spindle to assist in positioning it.

NOTE: If machine is equipped with a hydraulic cylinder drawtube skip Steps 1 and 5 because drawtube is attached to the hydraulic cylinder.

2. Clean and oil the bearing bore of the spindle housing.
3. Ensure the two oil mist holes in the spindle line up with those in the spindle housing.
4. Carefully place the spindle into the spindle housing, pulley end first. The spindle is in place when it cannot be pushed in any further by hand. If the spindle fit is too tight, remove and reinstall.
5. Remove the drawtube.
6. Place the retainer ring on the spindle with the O-ring toward the spindle. Ensure that the drain holes are at the bottom of the retainer ring and that the O-ring remains in place.
7. Insert the six retainer ring mounting bolts and torque to 50 ft-lbs.

NOTE: The bolts should be torqued in a star pattern.

CAUTION: Do not use Loctite on these bolts or else serious damage could result.




Figure 2-3 Spindle retaining bolts

8. Ensure that the spindle can spin freely and the spindle and housing oil mist holes are aligned. If not, remove the retainer ring and spindle and reinstall.
9. Screw the oil mist nozzles in by hand, ensuring that the holes on the nozzles and those in the spindle housing are aligned correctly.

10. Tighten the hex nut on the nozzles, ensuring the nozzles do not spin. After tightening the nuts, verify the nozzle oil mist holes are still positioned correctly.

11. Attach the two 1/4" nylon tubes onto the swivel fittings.

12. Install the spindle drive assembly.

13. Install the drive belts onto the spindle and motor pulleys.

14. Remove all slack in the belts, then tighten the four motor mounting bolts.

NOTE: The motor must be forced downward to get the proper tension on the belts (gravity alone is not sufficient).

15. Place the 3/8" timing belt on the spindle pulley, with the other end on the encoder pulley.

16. Mount the encoder onto the spindle housing below the spindle shaft with two mounting bolts.

17. For machines equipped with a hydraulic cylinder drawtube, follow these steps for installation:

- Align and attach the adapter onto the spindle shaft then screw in the eight adapter mounting bolts.
- Slide the hydraulic cylinder into spindle shaft. Insert and tighten the twelve bolts.
- Attach and clamp the oil drain hose and coolant drain hose onto hydraulic cylinder drawtube.
- Attach and screw in clamp and unclamp hoses.
- Set the magnetic base on top of the spindle housing with the indicator touching the top of the black indicator button. The black indicator button is located at the top of the hydraulic cylinder.
- Spin the hydraulic cylinder and verify that the run out is under 0.003 inches. If run out is over 0.003 inches, spin the hydraulic cylinder to its high point and tap cylinder with a rubber mallet.
- Skip to Step 34 to complete installation.




Figure 2-4 Adapter plate.

18. Set the floating clamp plate on the pulley end of the spindle with the counterbore holes facing the motor.

19. Place a blue spring onto each of the four floating clamp plate mounting bolts. Insert them through the holes in the floating clamp plate and the round spacers into the standoff clamp cylinders.



20. Slide the ID spring housing onto the spindle shaft and tighten the eight SHCS.

NOTE: Ensure that the ID spring housing is appropriately aligned with the spindle shaft because of the tight fit.




Figure 2-5 ID spring housing

21. The space between the ID spring housing and the floating clamp plate should be {0.005-0.030} inches.

22. Set the magnetic base on the floating clamp plate with the indicator touching the top of the ID housing shaft.

23. Spin the ID spring housing shaft to ensure the indicator never reads greater than 0.003 inches.




Figure 2-6 Indicating ID spring housing shaft

24. Grease the shaft of the ID spring housing.

25. Grease all sides of the 14 belleville washers.
  26. Place the belleville washers on the ID spring housing shaft with the first one concave towards the housing and with them alternating, so that each one is facing in an opposite direction.
  27. Slide the Outside Diameter (OD) spring housing over the belleville washers.
  28. Place the compression springs onto the 4 studs of the drawtube cylinder.
  28. Place the drawtube cylinder on the OD spring housing with the springs facing the housing. Ensure the 1/4" air nozzle is at the bottom of the drawtube cylinder.
  29. Insert the four drawtube cylinder mounting bolts through the holes in the cylinder, through the cylinder spacers, and into the floating clamp plate.
- CAUTION: These bolts must be very tight, or serious damage could occur.
30. Connect the 1/4" air line to the fitting on the drawtube cylinder.
  31. Reconnect the main air line in the rear.
  32. Step on the chuck actuator foot pedal. When the assembly moves forward, a groove on the ID spring housing will become visible. Place the retainer ring in this groove.
  33. Step on the foot pedal again to ensure that the spindle assembly moves smoothly.
  34. Secure the drain box to the left front panel with the five mounting bolts.
  35. Replace the left end panel with the 18 mounting bolts.
  36. Secure the drain box to the left end panel with four bolts.

## **2.3 SPINDLE ALIGNMENT**

### **TOOLS NEEDED:**

Three magnetic base indicators  
250 ft-lb torque wrench  
Spindle head alignment shaft

NOTE: This procedure should only be run after the turret has been aligned.

1. Remove the door.
2. Loosen the 18 left front panel mounting bolts, then remove the panel.
3. Attach the alignment shaft to the spindle with 3 hex bolts and sweep concentricity to .0000 (front and back of test bar).

4. Set up a magnetic base indicator, with the base on the turret face and the indicator on the side of the shaft closest to the operator, at the spindle end of the shaft.
5. Jog the turret until the tangent to the X-axis is found on the shaft.
6. Spin the spindle and verify that the indicator reads zero for an entire revolution.
7. Jog the indicator to the turret end of the shaft and repeat Step 6. Read the maximum indication at this end of the shaft.
8. Set the indicator for one half of this deviation, and place it at the turret end of the shaft.
9. Loosen (break free) the eight spindle mounting bolts.  
NOTE: The spindle adjusting bolts can not be moved until the mounting bolts are loosened.
10. Loosen the lock nuts and adjust the spindle adjusting bolts until the indicator reads zero NTE 0.0004 / 10". Turn the adjusting bolt(s) to move the corresponding side of the spindle up or down.




Figure 2-7 Spindle Alignment (Indicator placement)

11. Mount the indicator onto the alignment shaft by placing its mounting pin in the hole at the end of the shaft.
12. Place the indicator just barely inside pocket #1. Rotate the turret so the indicator moves to the exact opposite side of the pocket, parallel to the X-Axis. If the indicator does not read zero at either side, jog the X-axis until it does.
13. When these two readings equal zero, check the top and bottom of the pocket (tolerance within 0.001).
14. If these readings are within tolerance, the spindle does not need adjustment. Go to Step 20.
15. If these readings are not within tolerance, the spindle position must be adjusted.
16. Set up two more magnetic base indicators on the turret, with one indicator on each end of the alignment shaft (on the top of the shaft).

17. Turn the adjusting bolts located at the bottom of the spindle housing to adjust the center line of the spindle to the center of the tool pocket. While doing so, ensure the indicators to not show any change in the position of the spindle shaft.
18. Once the readings for pocket #1 are all within tolerance, torque the eight spindle mounting bolts to 250 ft-lbs carefully so as not to change the spindle's position. Tighten the bolts at approximately the same rate by tightening those opposite each other.
19. Screw the jam nuts up to the spindle housing until tight.
20. Write down the Parameter 215 -(carousel offset) "Machine X Coordinate" from the control panel, to use as a center point if the test has to be reperformed.
21. Repeat Steps 4-7 to ensure that the shaft has remained horizontal. If the shaft has moved, return to Step 11 and recheck the pocket position.
22. Test the other pockets in the same way as pocket #1 (Step 11). The tolerances for these are 0.003 inches.  
NOTE: Inside the pockets, there may be a slight bump, made when the pins near the pockets were machined.
23. Replace the drain box and left front panel.
24. Reinstall the door.




Figure 2-8 Adjustment bolts for spindle alignment.

## 3. DOOR

### 3.1 REMOVAL

NOTE: This procedure is for doors on HL-1/2 (S/N 60013 or later)

1. ZERO RETURN all axes.
2. POWER OFF machine.
3. Slide coolant tank out from under machine.
4. Remove the (11) screws to the lower front panel.
5. Remove door splash guard.
6. Remove door switch trip bracket.
7. Remove the (17) screws to the top front panel.
8. Remove the door rollers. The door must be closed in order to access the rollers.
9. Brace the control arm in order to remove any load from the top front panel.
10. Slide the top front panel forward approx. 1-1/2".
11. Remove the rollers, springs and hardware from the door.
12. Slide the door towards the turret housing, working the left end past the door seal channel.
13. Remove the door from the machine.

## 3.2 INSTALLATION

14. Install the rollers, springs and hardware to door.

15. Using 18GA. wire or equivalent, stretch the springs so all the rollers are aligned. Tie the wire in order to hold the springs in place during assembly.

NOTE: Tighten the top roller bolts, but leave the bottom bolts loose.


16. Install door onto bottom rail, then lift the door to engage top rail.

17. Slide the top front panel back and reinstall screws.

18. Cut the wire supports.

19. Tighten bottom roller bolts.

20. Reinstall the panels, brackets and splash guard.



*Fig 3-1 Roller preparation for installation*

## 4. LUBE AIR PANEL




Figure 4-1 Lube Air Panel (Front View)

### 4.1 LUBE AIR PANEL COMPONENTS

The following is a list of the Lube Air Panel Assembly components, each with a description of its specific function.

1. **Oil Pressure Gauge** - Indicates the pressure (in psi) at which the oil is pumped from the reservoir.
2. **Oil Pump** - Pumps the oil from the reservoir to various parts of the lathe. Every 30 minutes the pump cycles and pumps 2.8 to 3.8 cc of oil (at approximately 20 psi).
3. **Oil Reservoir** - Stores the oil (Vactra #2) that is used for lubrication in the linear guides and lead screws. Oil is also mixed with air and sent to the spindle bearing for lubrication and cooling.
4. **Oil Filter** - Filters the oil from the reservoir before it is pumped to the necessary areas.
5. **Air Pressure Gauge** - Indicates the pressure (in psi) at which the air is being regulated.
6. **Air Filter** - Filters the air before it is sent to the solenoid valves.
7. **Air Pressure Regulator** - Maintains the air supplied from the outside source (via the main air line) at a constant, desired pressure (approximately 85-90 psi).
8. **Air Solenoid Assembly** - 4-way 2-position valve that controls the air to the turret air cylinder.

9. **Air Solenoid Assembly** - 3-way 2-position valve that controls the air to the drawtube air cylinder.
10. **Power Cable** - Supplies power to the Lube Air Panel from the main control box.
11. **Power Cable** - Supplies power to the chuck actuator foot pedal.




Figure 4-2 Lube Air Panel (Rear View)

The following is a list of the Lube Air Panel Assembly components on the rear of the panel, each with a description of its specific function.

1. **Air Pressure Switch** - Monitors the air supply pressure, and sends a signal to the control panel to "alarm out", or stop, the machine when the air pressure falls below 70 psi.
2. **Solenoid Valve** - Opens when the spindle is turning to permit air to be sent to the spindle bearings.
3. **Air Regulator** - Maintains the correct air pressure (15 psi) being sent to the spindle bearings.
4. **Oil Mist Ports** - Connect to nylon tubing that carries the oil-air mist to the spindle bearings. One port supplies the front spindle bearing, and one supplies the rear bearing.
5. **Air Pressure Gauge** - Indicates the pressure of the air being mixed with oil and supplied to the spindle bearings.
6. **Connector Plate** - Contains all of the connectors for the Lube Air Panel.
7. **Pressure Switch** - Monitors the oil supply pressure, and sends a signal to the control panel to stop the machine if the pressure drops below the minimum level for a set period of time.
8. **Oil Line** - Carries oil to the ports, where it is then sent to the lead screws, linear guides, and spindle bearings.



9. **Oil Ports** - Connect to nylon tubing that carries the oil to the lead screws and linear guides.
10. **Flowmeters** - Maintain the correct amount of oil dropping from the upper ports to the lower ports where they are mixed with air and sent to the spindle bearings.

## 4.2 LUBE PANEL REMOVAL

IMPORTANT! POWER OFF THE MACHINE BEFORE PERFORMING THE FOLLOWING PROCEDURE.

1. Remove the rear panel
2. Disconnect the main air line.
3. Disconnect the following switches:
  - X and Z limit switches
  - clamp / unclamp switches
  - foot and door switches
4. Disconnect spindle air line.
5. Disconnect oil line at lube panel.
6. Disconnect fan wire and remove the connector from the conduit.  
NOTE: All plastic ties must be cut in order to remove the lube air panel.
7. Disconnect air blast line.
8. Disconnect limit switches from lube panel.
9. Remove all conduits.
10. Remove the mounting screws located at the top of the lube panel.

If removing HL-2 lube panel:

11. Disconnect oil line to tailstock.
12. Disconnect main oil line.

## 5. HYDRAULIC POWER UNIT REPLACEMENT

### 5.1 REMOVAL

CAUTION! POWER OFF THE MACHINE BEFORE PERFORMING THIS PROCEDURE.

1. Remove necessary panels to access the hydraulic unit.

2. Loosen and disconnect clamp and unclamp hoses.

NOTE: Right clamp/unclamp hose of hydraulic unit is attached to bottom port of hydraulic cylinder and left hose is attached to top port. The ports are located on the side of the hydraulic cylinder.

3. Unclamp and remove oil return hose from hydraulic unit and hydraulic cylinder.

NOTE: The oil return hose is shrink-fitted and should be replaced with a new one whenever removed.

4. Disconnect pressure switch cable and solenoid valve cable.

5. Disconnect pump motor cable.

6. Loosen and remove the four bolts from base of unit then slide hydraulic unit out.




Figure 5-1 Hydraulic power unit

## 5.2 INSTALLATION

CAUTION! POWER OFF THE MACHINE BEFORE PERFORMING THIS PROCEDURE.

1. Slide hydraulic power unit into place and attach with four mounting bolts.
2. Connect pump motor cable.
3. Connect pressure switch cable and solenoid valve cable.
4. Replace oil return hose and clamp to hydraulic unit and hydraulic cylinder.

NOTE: The oil return hose is shrink-fitted and should be replaced with a new one whenever removed.

5. Connect the clamp and unclamp hoses.

NOTE: Right clamp/unclamp hose of hydraulic unit is attached to bottom port of hydraulic cylinder and left hose is attached to top port. The ports are located on the side of the hydraulic cylinder.

6. Replace any panels that were removed to access the hydraulic unit.



# **ELECTRICAL SERVICE**


# 1. SOLENOIDS

**PLEASE READ THIS SECTION IN ITS ENTIRETY BEFORE ATTEMPTING TO REPLACE ANY SOLENOID ASSEMBLIES.**

## 1.1 PNEUMATIC CHUCK CLAMP/UNCLAMP SOLENOID

### REMOVAL:

1. Turn machine power off and remove the air supply from the machine.
2. Disconnect the two air hoses from the pneumatic chuck clamp/unclamp solenoid (see Figure 1-1).
3. Unplug the solenoid electrical lead at the switch bracket (located on the rear of the lube air panel).
4. Remove the two SHCS holding the assembly to the bracket and remove the assembly.



*Fig. 1-1 Front view of lube/air panel.*

### INSTALLATION:

5. Replace the air solenoid assembly and attach to the bracket with the two SHCS. Tighten securely.
6. Reconnect the electrical connection to the solenoid at the switch bracket.
7. Reconnect the two air lines, ensuring that all connections are tight and do not leak.
8. Restore the air supply to the machine.

## ELECTRICAL SERVICE

## 1.2 TURRET CLAMP/UNCLAMP SOLENOID

**REMOVAL:**

1. Turn machine power off and remove the air supply from the machine.
2. Disconnect the three air hoses from the turret clamp/unclamp solenoid (see Figure 1-1).
3. Unplug the solenoid electrical lead at the switch bracket (located on the rear of the lube air panel).
4. Remove the two SHCS holding the assembly to the bracket and remove the assembly.


**INSTALLATION:**

5. Replace the air solenoid assembly and attach to the bracket with the two SHCS. Tighten securely.
6. Reconnect the electrical connection to the solenoid at the switch bracket.
7. Reconnect the three air lines, ensuring that all connections are tight and do not leak.
8. Restore the air supply to the machine.

## 1.3 SPINDLE LUBE AIR SOLENOID


**REMOVAL:**

1. Turn the machine power off and remove the air supply from the machine.



*Fig. 1-2 Rear view of lube/air panel.*

2. Disconnect the lube line from the spindle lube air solenoid assembly.
3. Disconnect the electrical leads from the main air line pressure switch.
4. Unscrew the solenoid assembly pressure gauge from the assembly.
5. Unscrew the entire solenoid assembly from the T-fitting.



*Fig. 1-3 Top view of spindle lube/air solenoid assembly.*

## INSTALLATION

6. Reattach the solenoid assembly at the T-fitting.
7. Reattach the pressure gauge onto the solenoid assembly.
8. Reconnect the lube line to the assembly.
9. Reconnect the electrical leads to the main air line pressure switch.
10. Restore the air supply to the machine.



## 2. LINE VOLTAGE ADJUSTMENTS

**PLEASE READ THIS SECTION IN ITS ENTIRETY BEFORE ATTEMPTING TO ADJUST THE LINE VOLTAGE.**

### TOOLS REQUIRED:

LARGE FLAT TIP SCREWDRIVER

DIGITAL VOLTMETER


### ADJUSTING VOLTAGE

**NOTE:** The machine must have air pressure at the air gauge or an interlock will prevent it from powering up.

**CAUTION!** Working with the electrical services required for the lathe can be extremely hazardous. The electrical power must be off and steps must be taken to ensure that it will not be turned on while you are working with it. In most cases this means turning off a circuit breaker in a panel and then locking the panel door. However, if your connection is different or you are not sure how to do this, check with the appropriate personnel in your organization or otherwise obtain the necessary help BEFORE you continue.

**WARNING!** The electrical panel should be closed and the three screws on the door should be secured at all times except during installation and service. At those times, only qualified electricians should have access to the panel. When the main circuit breaker is on, there is high voltage throughout the electrical panel (including the circuit boards and logic circuits) and some components operate at high temperatures. Therefore extreme caution is required.

1. Hook up the three power lines to the terminal on top of the main switch at upper right of electrical panel and the separate ground line to the ground bus to the left of the terminals. It is not necessary to be concerned with phase rotation (which wire is connected to L1, L2, and L3).



*Fig. 2-1 Power lines; hookup location.*

**NOTE:** Make sure that the service wires actually go into the terminal-block clamps. [It is easy to miss the clamp and tighten the screw. The connection looks fine but the machine runs intermittently or has other problems, such as servo overloads. To check, simply pull on the wires after the screws are tightened.

2. After the line voltage is connected to the machine, make sure that main circuit breaker (at top-right of rear cabinet) is off

(rotate the shaft that connects to the breaker counterclockwise until it snaps off). Turn on the power at the source. Using an accurate digital voltmeter and appropriate safety procedures, measure the voltage between all three pair phases at the main circuit breaker and write down the readings. The voltage must be between 195 and 260 volts or 353 and 480 volts, depending on which transformer is in the machine.

NOTE: Wide voltage fluctuations are common in many industrial areas; you need to know the minimum and maximum voltage which will be supplied to the machine while it is in operation. U.S. National Electrical Code specifies that machines should operate with a variation of +5% to -5% around an average supply voltage. If problems with the line voltage occur, or low line voltage is suspected, an external transformer may be required. If you suspect voltage problems, the voltage should be checked every hour or two during a typical day to make sure that it does not fluctuate more than +5% or -5% from an average.




Fig. 2-2 Transformer connections.

**CAUTION!** Make sure that the main breaker is set to OFF and the power is off at your supply panel BEFORE you change the transformer connections. Make sure that all three black wires are moved to the correct terminal block and that they are tight.



3. Check the connections on the transformer at the bottom-right corner of the rear cabinet. The three black wires labeled 74, 75, and 76 must be moved to the terminal block triple which corresponds to the average voltage measured in step 2 above. There are four positions for the input power to this transformer. The input voltage range for each terminal block is as follows:

Fig. 2-3 Transformers with 195-210V (left) and 452-480V (right) range.

### ELECTRICAL SERVICE


195 to 210 right side  
211 to 226 right center  
227 to 243 left center  
244 to 260 left side

353 to 376 right side  
377 to 400 right center  
401 to 425 left center  
452 to 480 left side



4. Set the main switch to on (rotate the shaft that engages the handle on the panel door clockwise until it snaps into the on position). Check for evidence of problems, such as the smell of overheating components or smoke. If such problems are indicated, set the main switch to off immediately and call the factory before proceeding.
5. After the power is on, measure the voltage across the upper terminals on the contactor K1 (located below the main circuit breaker). It should be the same as the measurements where the input power connects to the main breaker. If there are any problems, call the factory.

Fig. 2-4 Measure voltage here.



6. Check the DC voltage displayed in the second page of Diagnostic data on the CRT. It is labeled DC BUS. This voltage must be between 155 and 175 volts. If the voltage is outside these limits, turn off the power and recheck the incoming power and the transformer wiring (repeat steps 2 and 3). If the voltage is still incorrect, turn off the power and call the factory.
7. Turn off the power (rotate the shaft that engages the handle on the panel door counterclockwise until it snaps into the off position). Also, set the main switch handle on the panel door to off. (Both the handle and the switch must be set to off before the door can be closed). Close the door, latch the latches, and turn the power back on.

## 3. FUSE REPLACEMENT

**PLEASE READ THIS SECTION IN ITS ENTIRETY BEFORE ATTEMPTING TO REPLACE ANY FUSES.**


### TOOLS REQUIRED:

REPLACEMENT FUSES

## 3.1 OVERVOLTAGE FUSES

**WARNING!** The electrical panel will have residual voltage, even after power has been shut off and/or disconnected. Never work inside this cabinet until the small red CHARGE light on the servo drive assembly goes out. The servo drive assembly is on the left side of the main control cabinet and about halfway down. This light is at the top of the circuit card at the center of the assembly. Until this light goes out, there are dangerous voltages in the assembly **EVEN WHEN POWER IS SHUT OFF**.

1. Turn machine power off.
2. Turn the main switch (upper right of electrical cabinet) to the off position.



*Fig. 3-1 Unscrew the three screws to open the cabinet door. (Newer control cabinets require a key)*

3. Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel. Wait until at least the red CHARGE light on the servo drive assembly goes out before beginning any work inside the electrical cabinet.
4. On the POWER SUPPLY board there are three fuses located in a row at the upper right of the board; these are the overvoltage fuses. An orange light will be on to indicate the blown fuse(s).
5. Using a flat tip screwdriver, turn the fuse(s) counterclockwise to remove and replace the blown fuse(s) with ones having the same type and rating ( $\frac{1}{2}$  amp, type AGC, 250V).

**CAUTION!** When the left fuse is blown, it is still possible to operate the machine, thereby making an overvoltage situation possible. **VERIFY** absolute voltage to the machine does not exceed 260 volts.

## 3.2 OPERATOR'S LAMP FUSE

1. Turn the main switch (upper right of electrical cabinet) to the off position.

### ELECTRICAL SERVICE

- Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel. Wait until at least the red CHARGE light on the servo drive assembly goes out before beginning any work inside the electrical cabinet.
- The Operator's Lamp Fuse is located at the lower left of the Power Supply Board. An orange light will be on to indicate the blown fuse.





Fig. 3-3 Power supply board; fuse locations.

- Using a flat tip screwdriver, turn the fuse counterclockwise to remove and replace the blown fuse with ones having the same type and rating (operator's lamp: ½ amp, type AGC, 250V).

### 3.3 SERVO DRIVER & SDIST FUSES

- Turn the main switch (upper right of electrical cabinet) to the off position.

- Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel. Wait until at least the red CHARGE light on the servo drive assembly goes out before beginning any work inside the electrical cabinet.
- On the SERVO DRIVE ASSEMBLY, there are three fuses on the SDIST panel, and three individual fuses on each of the SERVO DRIVE boards (See Fig. 3-4; the F3 fuses are not shown).
- On the SDIST panel, use a flat tip screwdriver to turn the fuse(s) counterclockwise to remove. Replace the blown fuse(s) with ones having the same type and rating (FU1, FU2: ½ amp, type AGC, 250V; FU3: 5 amp, type ABC, 250V).
- On each of the SERVO DRIVER boards, the fuses (F1, F2, F3) may be replaced by simply pulling out the fuses by hand and replacing with fuses of the same type and rating (F1, F2: 20 amp, type ABC, 250V; F3: 10 amp, type ABC, 250V).



## 4. PCB REPLACEMENT

**PLEASE READ THIS SECTION IN ITS ENTIRETY BEFORE ATTEMPTING TO REPLACE ANY PCB 'S.**

## **4.1 MICROPROCESSOR, VIDEO, MOTIF & KEYBOARD**

NOTE: The arrangement of these boards may differ from the order of replacement that follows. The steps for replacement will only differ in which board may need to be removed before getting to the necessary board.

WARNING! The electrical panel will have residual voltage, even after power has been shut off and/or disconnected . Never work inside this cabinet until the small red CHARGE light on the servo drive assembly goes out. The servo drive assembly is on the left side of the main control cabinet and about halfway down. This light is at the top of the circuit card at the center of the assembly. Until this light goes out, there are dangerous voltages in the assembly **EVEN WHEN POWER IS SHUT OFF.**

### **MOTIF BOARD -**

1. Turn machine power off.
2. Turn the main switch (upper right of electrical cabinet) to the off position.
3. Loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel. Wait until at least the red CHARGE light on the servo drive assembly goes out before beginning any work inside the electrical cabinet.
4. Disconnect all leads to the Motor Interface (MOTIF) board. Ensure all cables are properly labeled for reconnecting later. Figure 4-1 shows all cable numbers and the locations on the MOTIF board.
5. After all cables have been disconnected, unscrew the standoffs, taking care to hold the board in place until all standoffs have been removed.

NOTE: If the VIDEO, KEYBOARD or PROCESSOR boards need replacing, please skip the next step.

6. Replace the Motor Interface (MOTIF) board, attaching it to the VIDEO and KEYBOARD (beneath the MOTIF board) with the standoffs.
7. Reconnect all leads (previously removed) to their proper connections.




Fig. 4-1 Motor Interface board.

### VIDEO BOARD AND KEYBOARD -

8. Remove the MOTIF board as described in steps 1-5.
9. Disconnect all leads to the Video board and Keyboard. Ensure all cables are properly labeled for reconnecting later. The following illustration shows all cable numbers and the locations on the Video and Keyboard.
10. After all cables have been disconnected, unscrew the standoffs, taking care to hold the board in place until all standoffs have been removed.




Fig. 4-2 Video board.



NOTE: If the PROCESSOR board need replacing, please skip the next step.

11. Replace the Video and Keyboard, attaching it to the PROCESSOR board (beneath the Video and Keyboard) with the standoffs.
12. Reconnect all leads (previously removed) to their proper connections (refer to Fig. 4-2).

### PROCESSOR BOARD -

13. Remove the MOTIF board as described in steps 1-5, and the Video and Keyboard as described in steps 8-9.
14. Disconnect all leads to the Processor (68020) board. Ensure all cables are properly labeled for reconnecting later. The following illustration shows all cable numbers and the locations on the 68030 board.
15. After all cables have been disconnected, unscrew the standoffs, taking care to hold the board in place until all standoffs have been removed.
16. Replace the Processor (68030) board, attaching it to the electrical cabinet (beneath the 68030 board) with the standoffs




Fig. 4-3 Processor board.

17. Reconnect all leads (previously removed) to their proper connections (refer to Fig. 4-3).

### 4.2 SERVO DRIVER & SDIST

**WARNING!** The electrical panel will have residual voltage, even after power has been shut off and/or disconnected. Never work inside this cabinet until the small red CHARGE light on the servo drive assembly goes out. The servo drive assembly is on the left side of the main control cabinet and about halfway down. This light is at the top of the circuit card at the center of the assembly. Until this light goes out, there are dangerous voltages in the assembly **EVEN WHEN POWER IS SHUT OFF**.

1. Turn machine power off.
2. Turn the main switch (upper right of electrical cabinet) to the off position.
3. Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel. Wait until at least the red CHARGE light on the servo drive assembly goes out before beginning any work inside the electrical cabinet.

### SDIST BOARD -

4. Disconnect all leads to the Servo Distribution (SDIST) board. Ensure all cables are clearly marked for reconnecting later. The following illustration (Fig. 4-4) shows all cable numbers and the locations on the SDIST board.

**NOTE:** The connection labeled "860A" on the board should be used for the cable marked "860B". Some boards, the connection for cable 920 has been incorrectly marked as "1030".

Please note its location for future reference.




Fig. 4-4 SDIST board.

**NOTE:** On some SDIST boards, there may be cables attached to the capacitors with a plastic strap. This will have to be cut off and the cables moved aside in order to remove the board. It will be necessary to replace this strap after the board is replaced.

## ELECTRICAL SERVICE

5. After all cables have been disconnected, remove the eight screws attaching the board to the cabinet. Take care to hold the board in place until all screws have been removed.
6. Replace the SDIST board, attaching it with the eight screws previously removed, using one of the screws as a grounding connection.
7. Reconnect all leads (previously removed) to their proper connection (refer to Fig. 4-4).

## SERVO DRIVER BOARDS -




Fig. 4-5 Servo DRIVER boards.

1. Follow all precautions noted previously before working in the electrical cabinet.
2. Turn the main switch (upper right of electrical cabinet) to the off position.
3. Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel.
4. Disconnect all leads to the Servo Driver (DRIVER) board that you wish to replace. Ensure all cables are properly labeled for reconnecting later. Figure 4-6 shows all cable numbers and the locations on the DRIVER boards (X, Y, Z, A).

NOTE: When replacing any DRIVER board, it will be necessary to disconnect all leads on all DRIVER boards in order to remove or replace the board.

5. Remove the board by first removing the two screws that fasten it to the cabinet. Take care to hold the board in place until both screws have been removed.
6. Replace the DRIVER board, attaching it to the cabinet with the two screws previously removed.
7. Reconnect all leads to all boards at this time (refer to Fig. 4-5 for proper connections). Ensure the red and black leads go to the appropriate connections.

## 4.3 I/O BOARD

1. Follow all precautions noted previously before working in the electrical cabinet.
2. Turn the main switch (upper right of electrical cabinet) to the off position.
3. Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel.
4. Disconnect all leads to the Input/Output board and move aside for removal. Ensure all cables are properly labeled for reconnecting later. The following illustration shows all cable numbers and the locations on the I/O board.
5. Remove the board by first removing the twelve screws that fasten it to the cabinet. Take care to hold the board in place until all screws have been removed.
6. Replace the I/O board, attaching it to the cabinet with the twelve screws previously removed.
7. Reconnect all leads to the I/O board at this time (refer to Fig. 4-6 for proper connections)




Fig. 4-6 I/O board.

### 4.4 POWER & LOW VOLTAGE SUPPLY

#### POWER BOARD -

1. Follow all precautions noted previously before working in the electrical cabinet (See warning at beginning of "Servo Driver & SDIST" section).
2. Turn the main switch (upper right of electrical cabinet) to the off position.
3. Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel.
4. Disconnect all leads to the Power Distribution (POWER) board and move aside for removal. Ensure all cables are properly labeled for reconnecting later. The illustration on the following page shows all cable numbers and the locations on the POWER board.
5. After all cables have been disconnected, remove the seven screws holding the POWER board to the cabinet and remove the board. Take care to hold the POWER board in place until all screws have been removed.

NOTE: If you need to replace the LOW VOLTAGE POWER SUPPLY board, please skip the next step.

6. Replace the POWER board, attaching it with the seven screws previously removed. Don't forget to use the lower left screw for a ground connection.
7. Reconnect all cables to the POWER board at their proper location (refer to Fig. 4-7).




Fig. 4-7 Power Distribution (POWER) board.

**LOW VOLTAGE POWER SUPPLY -**


8. Remove the Power Distribution (POWER) board as described in steps 1-5.
9. Disconnect all leads to the Low Voltage Power Supply (LVPS) board. Ensure all cables are properly labeled for reconnecting later. The following illustration shows all cable numbers and the locations on the LVPS board.
10. After all cables have been disconnected, unscrew the two standoffs at the bottom of the board. Unscrew the remaining two screws at the top of the LVPS board, taking care to hold the board in place until all screws have been removed.
11. Replace the LVPS board, attaching it to the cabinet with the two screws and two standoffs previously removed
12. Replace the POWER board as described in steps 6-7.

**4.5 RS-232 DB25**

1. Follow all precautions noted previously before working in the electrical cabinet (See warning at beginning of "Servo Driver & SDIST" section).
2. Turn the main switch (upper right of electrical cabinet) to the off position.
3. Using a large flat tip screwdriver, loosen the three screws on the cabinet door and then open the door enough to safely work on the electrical panel.

NOTE: It is suggested to make use of a step ladder high enough to allow you to work from the top of the electrical cabinet. It will be necessary, when replacing the RS-232 DB25 board, to work from the inside and outside of the cabinet at the same time.

4. On the left side of the cabinet, at the top of the side panel are two serial port connections labeled "SERIAL PORT #1" and "SERIAL PORT #2", SERIAL PORT #1 being the upper connection.



*Fig. 4-8 RS-232 DB25 board.*

5. To remove the RS-232 DB25 board, unscrew the two hex screws (on the exterior of the cabinet) holding the connector to the cabinet. From the inside of the cabinet, pull the connector through the panel, and disconnect the cable (see Fig. 4-9 for location).
6. Replace the RS-232 DB25 board by first connecting the appropriate cable to the board (850 to SERIAL PORT #1, 850A to SERIAL PORT #2, then inserting the board (cable side up) through the left side panel. Attach with the two hex screws previously removed. Ensure the board for Serial Port #1 is the upper connector and the board for Serial Port #2 is the lower connector.
6. Replace the KBIF board, using the four screws previously removed, starting at the top right. Attach the screw and standoff loosely, then all other screws and standoffs, until all are mounted. Tighten down completely.
7. Reconnect all cables to the KBIF board at their proper locations.

## **5. FRONT PANEL**

**PLEASE READ THIS SECTION IN ITS ENTIRETY BEFORE ATTEMPTING TO REPLACE ANY COMPONENT OF THE CONTROL PANEL.**

### **5.1 CRT ASSEMBLY REPLACEMENT**

1. Turn the power off and disconnect power to the machine.
2. Remove the screws holding the cover panel on the back of the control panel. Take care to hold the cover panel in place until all screws have been removed.
3. At this time, remove the end cap on the support arm and unplug the white cable at the connection inside, then unplug the black cable at the connection in the control panel. It may be necessary to cut straps off the black cable's connector to unplug.
4. Unscrew the four hex nuts on the bottom row of the CRT bracket and remove, along with the washers. Set aside in a safe place.
5. While holding up the CRT assembly, remove the four hex nuts on the top row of the CRT bracket, along with the washers.

CAUTION! Take extreme care to not drop or damage the CRT assembly when removing from the control panel.

6. CAREFULLY pull the CRT assembly out toward the rear until it is clear of the control panel and all wiring. Set CRT assembly down in a safe place so as not to damage.
7. Replace by sliding the new assembly onto the eight bolts (four each on top and bottom). Starting with the bottom right, place the washers and hex nuts on the bolts to hold in place. Refer to Fig. 5-1 for the order of replacement. Once all washers have been attached and nuts have been hand-tightened, tighten down completely with the socket.






Fig. 5-1 Interior of control panel (rear).

8. Plug the black cable and white cable into the matching cables. Feed the white cable through the opening in the top of the control panel.
9. Replace the back cover panel and attach with the four screws previously removed.

## 5.2 JOG HANDLE REPLACEMENT

The JOG handle is actually a 100-line-per-revolution encoder. We use 100 steps per revolution to move one of the servo axes. If no axis is selected for jogging, turning of the crank has no effect. When the axis being moved reaches its travel limits, the handle inputs will be ignored in the direction that would exceed the travel limits.

Parameter 57 can be used to reverse the direction of operation of the handle.

1. Turn the machine power off.
2. Remove the screws holding the cover panel on the back of the control panel. Take care to hold the cover panel in place until all screws have been removed.
3. Unplug the cable leading to the jog handle encoder. IMPORTANT! The blank pin side of the connector must face as shown in Fig. 5-2 when reconnecting; otherwise, damage may occur to the machine.




Fig. 5-2 Jog handle encoder.

- Using the 5/64" allen wrench, loosen the two screws holding the knob to the control panel and remove.




Fig. 5-3 Jog Handle removal

- Remove the three screws holding the jog handle encoder to the control panel and remove.
- Replacement is reverse of removal. Keep in mind the important notice in step three.

### 5.3 SWITCH REPLACEMENT

NOTE: This section is applicable for the POWER ON, POWER OFF, EMERGENCY STOP, CYCLE START, and FEED HOLD switches.

- Turn the machine power off.
- Remove the four screws holding the cover panel on the back of the control panel. Take care to hold the cover panel in place until all screws have been removed.

3. Disconnect all leads to the switch's connectors. Ensure all leads are properly marked for reconnecting later. Refer to Fig. 5-1 for proper locations.
4. Unscrew the two small set screws, one on top and one on the bottom, and turn the switch counterclockwise to loosen. Separate from the front portion and pull out.
5. For replacement, screw the front and rear portions together (reverse of removal) and tighten down the two small set screws when the switch is properly positioned.

NOTE: The POWER ON, POWER OFF, and EMERGENCY STOP switches must all have the connectors on the bottom of the switch.

6. Reconnect all leads to the correct switch.

## 5.4 SPINDLE LOAD METER REPLACEMENT

1. Turn the power off and disconnect power to the machine.
2. Remove the four screws holding the cover panel on the back of the control panel. Take care to hold the cover panel in place until all screws have been removed.
3. Disconnect the two leads at the back of the spindle load meter assembly. Ensure the two leads are properly marked for reconnecting later.
4. Unscrew the four screws that hold the spindle load meter assembly to the control panel. Take care to hold the assembly in place until all screws have been removed. Remove the assembly.
5. Installation is reverse of removal. Ensure leads go the correct location.

## 5.5 KEYPAD REPLACEMENT

1. Turn the power off and disconnect power to the machine.
2. Remove the four screws holding the rear cover panel to the back of the control panel. Take care to hold the cover panel in place until all screws have been removed.
3. Remove all switches, spindle load meter, and the jog handle as described in the previous sections.
4. Unplug the keypad's 24-pin ribbon cable from the Keyboard Interface board.
5. Remove the screws from the front of the control panel. Take care to hold the front cover panel and bezel spacer in place until all screws have been removed. Remove the two pieces and set aside in a safe place.
6. Using a flat, blunt tool, such as putty knife, pry the keypad away from the control panel. Pull the ribbon cable through the opening in the control to remove.
7. To replace, first put the bezel spacer in place and fasten temporarily with screws in the top corners.




Fig. 5-4 Keypad installation.

8. Insert the ribbon cable through the opening in the control panel and place the keypad in the upper right corner of the lower opening and press to the control panel to mount. Plug the ribbon cable into the Keyboard Interface board, taking care to not bend the pins on the board.
9. While holding the bezel spacer in place, remove the two screws holding the spacer, put the front cover panel in place, and fasten with all screws previously removed.
10. Reinstall all switches, spindle load meter, and the jog handle as described in the previous sections.
11. Replace the rear cover panel and fasten with the screws that were previously removed.

## 4.6 KEYBOARD INTERFACE

1. Follow all precautions noted previously before working in the control cabinet (See warning at beginning of "Front Panel" section).
2. Turn the main switch (upper right of electrical cabinet) to the off position.
3. Remove the four screws on the back of the control box, then remove the cover panel. Take care to hold the panel in place until all screws have been removed.
4. Disconnect all leads to the Keyboard Interface (KBIF) board. Ensure all cables are properly labeled for reconnecting later. Refer to Fig. 4-10 for locations.
5. After all cables have been disconnected, unscrew the four screws holding the KBIF board to the control box. Take care to hold the board in place until all screws have been removed. Place the screws and standoffs aside for later use.
6. Replace the KBIF board, using the four screws previously removed, starting at the top right. Attach the screw and standoff loosely, then all other screws and standoffs, until all are mounted. Tighten down completely.
7. Reconnect all cables to the KBIF board at their proper locations




Fig. 5-5 Keyboard Interface

## 6. SPINDLE ENCODER REPLACEMENT

**PLEASE READ THIS SECTION IN ITS ENTIRETY BEFORE ATTEMPTING TO REMOVE OR REPLACE ENCODER.**

### REMOVAL -


1. Loosen the eight motor fan panel mounting bolts (on left end of machine), then remove the panel.
2. Loosen the two encoder mounting bolts and slide the encoder up until there is slack in the belt.
3. Remove the encoder.
4. Inspect the encoder belt for any damage. If replacement is necessary, refer to the "Spindle" section for removal.

### INSTALLATION -

5. Place the belt onto the pulley.
6. Mount the new encoder and tighten the bolts.

NOTE: When tightening the bolts, ensure the belt remains loose around the pulleys. If the belt is too tight, it could damage the encoder.

7. Replace the motor fan panel.



*Figure 6-1 Encoder belt locations.*



# TECHNICAL REFERENCE

## TABLE OF CONTENTS

1. SPINDLE OPERATION .....	229
2. SERVOS BRUSH / BRUSHLESS .....	229
3. INPUT/OUTPUT ASSEMBLY .....	235
4. CONTROL PANEL .....	238
5. MICROPROCESSOR ASSEMBLY .....	243
6. RESISTOR ASSEMBLY .....	243
7. POWER SUPPLY ASSEMBLY .....	243
8. POWER TRANSFORMER ASSEMBLY (T1) .....	246
9. FUSES .....	247
10. SPARE USER M CODE INTERFACE .....	247
11. LUBRICATION PUMP .....	248
12. SWITCHES .....	249
13. DIAGNOSTIC DATA .....	250
14. DISCRETE INPUTS / OUTPUTS .....	251



## 1. SPINDLE OPERATION

Spindle speed is selectable from 50 to 3750 RPM on the lathe.

The spindle is hardened and ground with a A2-6 spindle nose.

## 2. SERVO BRUSH / BRUSHLESS

### 2.1 SERVO ENCODERS (BRUSH)

Attached to each DC servo motor, there is an incremental encoder that is 2000 lines per revolution. These encoders also supply a Z channel pulse once per revolution. The encoders and Z channel are continuously monitored to ensure the number of pulses matches for each revolution of the motor. If the encoders become contaminated, these pulse counts will be wrong and an alarm will be generated. This ensures that the data from the encoders is reliable. There can never be a loss of servo position due to accumulated encoder errors. The alarms generated will indicate that either the Z pulse occurred and the encoder pulse was wrong or, after one and one half motor revolutions, the Z pulse did not occur.

Encoder faults can be caused by contamination of the encoder or by a wiring problem. If the encoder is contaminated, it must be replaced. Wiring problems may be a broken wire, shorted wire, or missing shield. All wires to the encoder are enclosed in their own shielded cable. In addition, all power wires to the motor are enclosed in a separately shielded cable. Failure of either of these shields may cause noise in the encoder circuits and result in the encoder fault alarms.

Never connect or disconnect the servo motor cables with the control powered as this will cause an apparent encoder fault.

The servo motor encoders are differential line drivers. This means that the A, B, and Z signals are transmitted to the control as signal pairs. A cable test is performed on these signals to ensure the differential pair are always present.

### 2.2 SERVO CHARACTERISTICS (BRUSH)

This machine is not capable of instantly changing speed. That is, it takes some non-zero time to accelerate and decelerate. Acceleration and deceleration in this machine have both a constant accel/decel mode and an exponential mode. Constant acceleration is used at the beginning of a rapid move and at the end of any move whose speed exceeds the exponential accel/decel time constant.

Constant acceleration is a type of motion when the amount of speed change over time is constant. This constant is set by Parameters 7, 21, 35, and 49. It has units of encoder increments per second per second.

Exponential acceleration and deceleration is a type of motion where the speed is proportional to the distance remaining in a programmed travel. The exponential accel/decel time constant is set by Parameters 113, 114, 115, and 116. It has units of 0.0001 seconds. The speed limit at which exponential accel/decel is not available is defined by the relationship between Parameters 7 and 113 (for the X-axis). Thus if Parameter 7 is 1200000 steps/sec/sec and Parameter 113 is 750 (0.075 seconds); the maximum velocity for accurate interpolation should be:

$$1200000 \times 0.075 = 90000 \text{ steps/second}$$

For a 2000 line encoder and 6 mm screw, this would be:

$$60 \times 90000 / 33866 = 159 \text{ inches/minute}$$

In the normal feed cutting mode, with G64 active, giving continuous cutter motion, deceleration of the axes in motion begins at some distance away from the end point. If look-ahead has provided another motion, the acceleration for that motion will begin at the same instant. This means that two motions, at right angles to each other, will not produce a perfectly square corner. The corner will be rounded. It also means that if the two motions are parallel or nearly parallel, there will be a smooth transition from one stroke to the next.

Rapid moves have a slightly different operation when continuous cutter mode is active. Acceleration for the next motion is started when the axes being moved all fall within the "In Position Limit" Parameters 101, 102, 103, and 104. These parameters have units of encoder steps. Rapid moves will also decelerate at the constant accel/decel limit until the speed drops below that for exponential accel/decel (see example above giving 159 inches per minute). Parameter 57 can be used to override this.

To prevent the rounding of corners, you can specify exact stop either with G09 (non-modal) or with G61 (modal). When either of these is active in a motion, all of the axes are brought to an exact stop, at zero speed, before the next motion is started.

The tool path in a circular move (G02 or G03) is not changed by the exponential acceleration/deceleration so there is no error introduced in the radius of the cut unless the speed exceeds that for exponential accel/decel (see example above giving 159 inches per minute).

## **2.3 SERVO DRIVE ASSEMBLY (BRUSH)**

The servo drive assembly is on the left side of the main control cabinet and about halfway down. Never work on the servo drive assembly until the small red CHARGE light goes out. This light is at the top of the circuit card at the center of the assembly. Until this light goes out, there are dangerous voltages in the assembly EVEN WHEN POWER IS SHUT OFF. This assembly contains four servo drive cards, a Servo Distribution card, and a fan.

## **2.4 160 VOLT DC POWER SUPPLY (BRUSH)**

The Servo Distribution card contains a DC power supply that produces an unregulated voltage between 145 and 175 volts. This is derived from the three-phase 115V AC coming from transformer T1. The nominal 160V DC is supplied to the four servo drive cards for the X, Y, Z, and A axes and to the tool changer. This supply is filtered by two capacitors in parallel for a total of 4000 Mfd. A soft charge-up of these capacitors is provided by a small resistor that is bypassed by a relay when the servos are on.

The negative side of the 160V power supply is always connected to chassis ground. This means that when the relays on SDIST are released, all DC power is disconnected and the drives are safe. This also includes the tool changer that uses the 160V buss to drive the tool changer motors.

The minimum DC buss voltage is 145V and anything lower will result in an alarm. The maximum voltage is 185V and anything above this will cause heating of the servo regen load resistor. Anything above 190V will cause an alarm.

## 2.5 SERVO COOLING FAN (BRUSH)

There is a cooling fan on the servo drive assembly to help cool the servo drive cards. It blows air up past the servo drive cards in order to support convection cooling. The fan power is supplied from SDIST by P7.

## 2.6 SERVO DISTRIBUTION PCB (SDIST)

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

The Servo Distribution PCB is used to provide the 160V DC buss for the servo drives, the low voltage AC power for the drives, and to monitor the supply voltage for the servos.

There are three pots on this card. They are:

- R2 This pot adjusts the buss voltage at which the regen load resistor is applied as a load to the power supply. This will consume any excess power caused by the regenerative effects of decelerating the servo motors. This should be set to turn on the load between 183 and 187V DC.
- R11 This pot adjusts the fraction of the buss voltage that is sent to the Motor Interface PCB A-to-D converter. This is a full scale 5V input and the program will interpret full scale as 200V on the buss.
- R15 This pot adjusts the voltage at which an overvoltage alarm discrete is generated. This should be set to alarm between 188 and 192V DC (about 265 AC).

The red "CHARGE" LED is also mounted on the SDIST PCB. It indicates that the supply capacitors still contain a charge. The discharge resistors provide a load through this LED. It will dim and appear off when the voltage is below 20 volts. The connectors on the SDIST PCB are:

- P1 Low voltage AC power to X drive card (570)
- P2 Low voltage AC power to Y drive card (580)
- P3 Low voltage AC power to Z drive card (590)
- P4 Low voltage AC power to A drive card (600)
- P5 12V DC from power supply (860A)
- P7 115V AC to fan
- P8 160V DC supply to tool changer(80)
- P9 Voltage monitor to A-D (980)
- P10 Regen load resistor (920)
- P11 Relay #1 contacts from IOPCB (110)
- P12 Overvoltage status to IOPCB (970)
- P13 Ground fault detect signal to IOPCB (1060)
- TB1 Three phase 115V AC to SDIST
- TB2 +160V DC and return to each servo drive card

There are three fuses mounted on the SDIST PCB; FU1 and FU2 protect the primaries of the fan and transformers. They are ½ amp, 240V AC, AGC type. FU3 protects the regenerative load circuit from a short circuit.

## 2.7 SERVO DRIVE PCB'S (DRIVER)

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

The servo drive PCB's are H drive with PWM control. There are eight states used in the H drive providing free-wheeling current during PWM and very low current ripple. The PWM frequency is 16 kHz. All drive cards are current limited at 20 to 22 amps. They operate from a nominal supply voltage of 160 volts. The peak power output is thus about 3000 watts, or 4 H.P. The continuous power output is, however, limited by a microprocessor based fuse setting, overcurrent shutdown, and motor thermal protection. Short circuit protection is provided by the drive card and, if sustained for over 0.01 second, the microprocessor will shut the servo drives off and generate an alarm.

The motor output circuit is fuse protected at 20 amps but this will only blow if there is a drive failure as the current limit circuit is much faster than the fuses.

The PWM signal is provided by the Motor Interface PCB along with direction and H drive state control. The processor also monitors the overcurrent status from the drive card.

The connectors on the servo drive cards are:

- P8 160V DC from SDIST PCB
- P1 low voltage AC power from SDIST PCB
- P3 PWM and H drive control signals from Motor Interface and overcurrent sense back
- P2 Power connection to servo motor

There are three fuses on each servo drive card. One is in series with each leg of the servo motor. These fuses are type ABC and are rated at 20 amps, 200V DC. A third fuse on each driver card limits the plus (+) side of the power supplied to each card; this fuse is an ABC, 250V.

## 2.8 SERVO ENCODERS (BRUSHLESS)

Some Haas machines are equipped with brushless motors, which provides for better performance, and no maintenance. In addition to the performance differences, these machines differ from brush type machines, which have already been discussed, in the following areas:

The brushless motors have 8192 line encoders built in, which result in differences in acceleration parameters 7, 21, 35, 49 and 157. The exponential accel/decel time is set by parameters 115, 116 and 168.

"In Position" parameters 101, 102, 103, 104 and 165 are also affected brushless motors.

The motor controller board has a dedicated processor which does all the servo control algorithm.

There is no servo distribution board anymore, therefore there is no CHARGE light present. Care should still be taken however, since there are high voltages present on the amplifiers, even when power is shut off. The high voltage comes from the spindle drive, which does have a CHARGE light.

The servo drive cards are replaced by Brushless Servo Amplifiers, and are controlled differently.

A low voltage power supply card is added to the servo drive assembly to supply the low voltage requirement to the amplifiers.

The CNC software is version 9.xx.

The user interface and motion profiling have not changed however, and the user should not see any functional differences between a brush type machine and a brushless machine.

## 2.9 SERVO CHARACTERISTICS (BRUSHLESS)

Servo characteristics are explained in detail in the previous chapter. The following is an example of how to achieve 130 inches/minute.

The exponential accel/decel time constant is set by Parameters 113, 114, 115, 116 and 168. It has units of 0.0001 seconds. The speed limit at which exponential accel/decel is not available is defined by the relationship between Parameters 7 and 113 (for the X-axis). Thus if Parameter 7 is 8000000 steps/sec/sec and Parameter 113 is 375 (0.0375 seconds); the maximum velocity for accurate interpolation should be:

$$8000000 \times 0.0375 = 300000 \text{ steps/second}$$

For a 8192 line encoder and 6 mm screw, this would be:

$$60 \times 300000 / 138718 = 130 \text{ inches/minute}$$

## 2.10 SERVO AMPLIFIERS (BRUSHLESS)

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

The brushless servo amplifier is a PWM based current source. The PWM outputs control the current to a three phase brushless motor. The PWM frequency is 16 KHz. The amplifiers are current limited to 30 amps peak. However there are fuse limits both in hardware and software to protect the amplifiers and motors from over current. The nominal voltage for these amplifiers is 320 volts. Therefore the peak power is about 9600 watts or 13 H.P. The amplifiers also have short circuit and over temperature and over heat protection.

There is a 10 amp supply fuse for failure protection. This fuse is relatively slow, therefore it can handle the 30 amp peak. Actual continuous current limit to the motor is controlled by software.

Commands to the amplifier are +/-5 volts current in two legs of the motor and a digital enable signal. A signal from the amplifier indicates drive fault or sustained high current in stalled motor.

The connectors on the amplifiers are:

- +H.V. + 320 volts DC
- H.V. 320 volts return
- A motor lead phase A
- B motor lead phase B
- C motor lead phase C
- J1 Three pin Molex connector used for +/-12 and GND.
- J2 Eight pin Molex connector used for input signals.

## 3. INPUT/OUTPUT ASSEMBLY

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

The IOPCB contains a circuit for electronically turning the tool changer power on and off. This prevents any arcing of the tool changer relays and increases their life tremendously. This includes an adjustable current limit to the tool changer. Potentiometer R45 adjusts the current limit to the tool changer motors. R45 should be set to limit current to between four and six amps.

The IOPCB also contains a circuit for sensing a ground fault condition of the servo power supply. If more than 0.5 amps is detected flowing through the grounding connection of the 160V DC buss, a ground fault alarm is generated and the control will turn off servos and stop.

Relay K6 is for the coolant pump 230V AC. It is a plug-in type and is double-pole. Relays K9 through K12 are also plug in types for controlling the tool changer.

The Input/Output Assembly consists of a single printed circuit board called the IOPCB.

The connectors on the IOPCB are:

P1	16-pin relay drivers from MOCON 1 to 8 (510)
P2	16-pin relay drivers from MOCON 9 to 16 (520)
P3	16-pin relay drivers from MOCON 17 to 24 (M21-M24) (540)
P4	34-pin inputs to MOCON (550)
P5	Servo power on relay 1-1 (110)
P6	230V AC from CB3 (930)
P7	230V AC to coolant pump (940)
P8	Auto-off relay 1-7 (170)
P9	Spindle drive commands (710)
P10	Spindle fan and oil pump 115V AC (300)
P12	115V AC to spindle head solenoids (880A)
P13	Tool changer status inputs (820)
P14	Low TSC(900)
P15	Spindle head status inputs (890)
P16	Emergency stop input (770)
P17	Low Lube input (960)
P18	Over Voltage Input (970)
P19	Low Air Input (950)
P20	Overheat input (830)
P21	Spindle drive status inputs (780)
P22	M-FIN input (100)
P23	Footswitch (190)
P24	Spare 2 (790)
P25	Spare 3 (200)
P26	Spare terminals for M21 to M24
P27	Door lock (1040)
P28	115V AC from CB4 (910)
P29	A-axis brake solenoid output (390)
P30	Tool changer shuttle motor output (810A)
P31	230 VAC for Chip Conveyor (160)
P33	115V AC three-phase input from power supply assembly (90)
P34	115V AC to CRT (90A)
P35	115V AC to heat exchanger (90B)
P36	115V AC to CB4 (90C)
P37	115V AC spare (870)
P38	Door open (1050)
P39	Tool changer turret motor output (810)
P40	(770A) A/B
P43	Ground fault sense signal input (1060) Axis Brake
P44	5TH axis brake (319)

### TECHNICAL REFERENCE

P45	HTC Shuttle
P46	Chip Conveyor (140)
P47	Skip input signal (1070)
P48	spare 1
P49	spare 2
P50	Spigot Motor (200)
P51	16 PIN Relay drivers 17-24 (530)
P52	spare 1
P53	Spigot Sense (180)
P54	Servo Brake (350)
P55	Red/green lights (280)
P56	Thru spindle coolant pump (940A)
P57	115V spare
P58	115V spare

## 4. CONTROL PANEL

### 4.1 JOG HANDLE

The JOG handle is actually a 100-line-per-revolution encoder. We use 100 steps per revolution to move one of the servo axes. If no axis is selected for jogging, turning of the crank has no effect. When the axis being moved reaches its travel limits, the handle inputs will be ignored in the direction that would exceed the travel limits.

Parameter 57 can be used to reverse the direction of operation of the handle.

### 4.2 POWER ON/OFF SWITCHES

The POWER ON switch engages the main contactor. The on switch applies power to the contactor coil and the contactor thereafter maintains power to its coil. The POWER OFF switch interrupts power to the contactor coil and will always turn power off. POWER ON is a normally open switch and POWER OFF is normally closed. The maximum voltage on the POWER ON and POWER OFF switches is 24V AC and this voltage is present any time the main circuit breaker is on.

### 4.3 SPINDLE LOAD METER

The Load meter measures the load on the spindle motor as a percentage of the rated continuous power of the motor. There is a slight delay between a load and the actual reflection of the meter. The eighth A-to-D input also provides a measure of the spindle load for cutter wear detection. The second page of diagnostic data will display % of spindle load. The meter should agree with this display within 5%. The spindle drive display #7 should also agree with the load meter within 5%.

There are different types of spindle drive that are used in the control. They are all equivalent in performance but are adjusted differently.

### 4.4 EMERGENCY STOP SWITCH

The EMERGENCY STOP switch is normally closed. If the switch opens or is broken, power to the servos will be removed instantly. This will also shut off the tool changer, spindle drive, and coolant pump. The EMERGENCY STOP switch will shut down motion even if the switch opens for as little 0.005 seconds.

Be careful of the fact that Parameter 57 contains a status switch that, if set, will cause the control to be powered down when EMERGENCY STOP is pressed.

You should not normally stop a tool change with EMERGENCY STOP as this will leave the tool changer in an abnormal position that takes special action to correct.

Note that tool changer alarms can be easily corrected by first correcting any mechanical problem, pressing RESET until the alarms are clear, selecting ZERO RETURN mode, and selecting "AUTO ALL AXES".

If the shuttle should become jammed, the control will automatically come to an alarm state. To correct this, push the EMERGENCY STOP button and remove the cause of the jam. Push the RESET key to clear any alarms. Push the ZERO RETURN and the AUTO ALL AXES keys to reset the Z-axis and tool changer. Never put your hands near the tool changer when powered unless the EMERGENCY STOP button is pressed.

## 4.5 KEYBOARD BEEPER

There is a speaker inside the control panel that is used as an audible response to pressing keyboard buttons and as a warning beeper. The beeper is a one kHz signal that sounds for about 0.1 seconds when any keypad key, CYCLE START, or FEED HOLD is pressed. The beeper also sounds for longer periods when an auto-shut down is about to occur and when the "BEEP AT M30" setting is selected.

If the beeper is not audible when buttons are pressed, the problem could be in the keypad, keyboard interface PCB or in the speaker. Check that the problem occurs with more than one button and check that the speaker volume is not turned down.

# 5. MICROPROCESSOR ASSEMBLY

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

The microprocessor assembly is in the rear cabinet at the top left position. It contains three large boards. They are: microprocessor, the keyboard and the MOCON. All three boards of the processor assembly receive power from the low voltage power supply. The three PCB's are interconnected by a local buss on dual 50-pin connectors. At power-on of the control, some diagnostic tests are performed on the processor assembly and any problems found will generate alarms 157 or 158. In addition, while the control is operating, it continually tests itself and a self test failure will generate Alarm 152.

## 5.1 MICROPROCESSOR PCB (68EC030)

The Microprocessor PCB contains the 68EC030 processor running at 40 MHz, one 128K EPROM; between 256K and 8MB of CMOS RAM and between 512K and 1MB of FAST STATIC RAM. It also contains a dual serial port, a five year battery to backup RAM, buffering to the system buss, and eight system status LED's.

Two ports on this board are used to set the point at which an NMI\* is generated during power down and the point at which RESET\* is generated during power down.

The eight LED's are used to diagnose internal processor problems. As the system completes power up testing, the lights are turned on sequentially to indicate the completion of a step. The lights and meanings are:

+5V +5V logic power supply is present. (Normally On)

If this light does not come on, check the low voltage power supply and check that all three phases of 230V input power are present.

HALT Processor halted in catastrophic fault. (Normally Off)

If this light comes on, there is a serious problem with the processor PCB. Check that the EPROM is plugged in. Test the card with the buss connectors off.



**POR** Power-on-reset complete. (Normally On)

If this light does not come on, there is a serious problem with the processor PCB. Check that the EPROM is plugged in. Test the card with the buss connectors off.

**SIO** Serial I/O initialization complete. (Normally On)

If this light does not come on, there is a problem with the serial ports. Disconnect anything on the external RS-232 and test again.

**MSG** Power-on serial I/O message output complete. (Normally On)

If this light does not come on, there is a problem with serial I/O or interrupts. Disconnect anything on the external RS-232 and test again.

**CRT** CRT/VIDEO initialization complete. (Normally On)

If this light does not come on, there is a problem communicating with the VIDEO PCB. Check the buss connectors and ensure the VIDEO PCB is getting power.

**PGM** Program signature found in memory.(Normally On)

If this light does not come on, it means that the main CNC program package was not found in memory or that the auto-start switch was not set. Check that switch S1-1 is on and the EPROM is plugged in.

**RUN** PROGRAM RUNNING WITHOUT FAULT EXCEPTION.(Normally On)

If this light does not come on or goes out after coming on, there is a problem with the microprocessor or the software running in it. Check all of the buss connectors to the other two PCB's and ensure all three cards are getting power.

There 1 two-position DIP switch on the processor PCB labled S1. Switch S1-1 must be ON to auto-start the CNC operational program. If S1-1 is OFF, the PGM light will remain off.

Switch S2-1 is used to enable FLASH. If it is disabled it will not be possible to write to FLASH.

The processor connectors are:

- J1 Address buss
- J2 Data buss
- J4 Serial port #1 (for upload/download/DNC) (850)
- J5 Serial port #2 (for auxiliary 5th axis) (850A)
- J3 Power connector
- J6 Battery

## 5.2 MEMORY RETENTION BATTERY

The memory retention battery is initially soldered into the processor PCB. This is a 3.3V Lithium battery that main tains the contents of CMOS RAM during power off periods. Prior to this battery being unusable, an alarm will be generated indicating low battery. If the battery is replaced within 30 days, no data will be lost. The battery is not needed when the machine is powered on. Connector J6 on the processor PCB can be used to connect an external battery.

## 5.3 VIDEO KEYBOARD FLOPPY PCB WITHOUT FLOPPY

The VIDEO and KB PCB generates the video data signals for the monitor and the scanning signals for the key board. In addition, the keyboard beeper is generated on this board. There is a single jumper on this board used to select inverse video.

The video PCB connectors are:

- P1 Power connector
- J3 Keyboard (700)
- J4 Address bus
- J5 Data
- J8 RAM or ROM chip select
- J10 Floppy V+
- J11 SPARE
- J12 Floppy
- J13 Video (760)
- J14 RS422 B
- J15 RS422 A

### 5.4 MOTOR INTERFACE PCB (MOTIF)

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

The Motor Interface PCB provides all of the interfaces to motors and discrete inputs and outputs. It contains a single pot R54 to adjust the output of the D-A converter. The MOTIF PCB connectors are:

- P1 Data buss
- P2 X drive control and overcurrent sense (610)
- P4 Z drive control and overcurrent sense (630)
- P5 A drive control and overcurrent sense (640)
- P6 X-axis encoder, Z, home, and overheat (660)
- P8 Z-axis encoder, Z, home, and overheat (680)
- P9 A-axis encoder, Z, home, and overheat (690)
- P10 32 discrete inputs (550)
- P11 Relay drives 1 to 8 (510)
- P12 Relay drives 9 to 16 (520)
- P13 Relay drives 17 to 24 (530)
- P14 Relay drives 25 to 32 (540)
- P15 Power connector (+5,+12+)
- P16 D-to-A output and -12V DC (720)
- P17 A-to-D inputs for DC buss voltage (980)
- P18 Jog Crank input and aux 1,2 (750)
- P19 Address buss
- P20 Spindle encoder inputs (1000)
- P21 A-to-D input for spindle temperature (1020)
- P22 A-to-D input for spindle load monitor (730B)
- P24 Home switch inputs X, Z (990)

### 5.5 MOTOR CONTROLLER (MOCON) BRUSHLESS

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

The brushless machining centers are equipped with a microprocessor based brushless motor controller board (MOCON) that replaces the motor interface in the brush type controls. It runs in parallel with the main processor, receiving servo commands and closing the servo loop around the servo motors.

**TECHNICAL REFERENCE**

In addition to controlling the servos and detecting servo faults, the motor controller board, (MOCON), is also in charge of processing discrete inputs, driving the I/O board relays, commanding the spindle and processing the jog handle input. Another significant feature is that it controls 6 axes, so there is no need for an additional board for a 5 axis machine.

P1	Data Bus
P2	X amplifier control and fault sensing (610)
P3	Y amplifier control and fault sensing (620)
P4	Z amplifier control and fault sensing (630)
P5	A amplifier control and fault sensing (640)
P32	B amplifier control and fault sensing (640B)
P33	C amplifier control and fault sensing (640C)
P6	X encoder input (660)
P7	Y encoder input (670)
P8	Z encoder input (680)
P9	A encoder input (690)
P30	B encoder input (690B)
P31	C encoder input (690C)
P18	Jog encoder input (750)
P20	Spindle encoder input (1000)
P10	Inputs from I/O board (550)
P11	I/O relays K1-8 (510)
P12	I/O relays K9-16 (520)
P13	I/O relays K17-24 (530)
P14	I/O relays K25-32 (540)
P15	Low Voltage Power (860)
P16	Spindle command output (720)
P19	Address bus
P17	A to D converter spare
P21	A to D converter spare
P22	A to D converter spare
P23	A to D converter spare
P26	A to D converter spare
P27	A to D converter spare
P28	A to D converter spindle load (730B)
P29	A to D converter spare
P24	Axis home switches (990)

## 5. SPINDLE DRIVE ASSEMBLY

The spindle drive is located in the main cabinet on the right side and halfway down. It has a blue cover on it. It operates from three-phase 200 to 240V AC. It has a 5 H.P. continuous rating, a 7.5 H.P. five-minute rating, and a 9 H.P. one-minute rating. The spindle drive is protected by CB1 at 30 amps. Never work on the spindle drive until the small red CHARGE light goes out. Until this light goes out, there are dangerous voltages inside the drive, even when power is shut off.

For all other data on the spindle drive, refer to the supplied documentation for your drive.

## 6. RESISTOR ASSEMBLY

The Resistor Assembly is located on top of the control cabinet. It contains the servo and spindle drive regen load resistors.

### 6.1 SPINDLE DRIVE REGEN RESISTOR

A 15-ohm, 900-watt resistor or 20-ohm, 600 watt resistor is used by the spindle drive to dissipate excess power caused by the regenerative effects of decelerating the spindle motor. If the spindle motor is accelerated and decelerated again in rapid succession repeatedly, this resistor will get hot. In addition, if the line voltage into the control is above 255V, this resistor will begin to heat. This resistor is overtemp protected at 100° C. At that temperature, an alarm is generated and the control will begin an automatic shutdown. If the resistor is removed from the circuit, an alarm may subsequently occur because of an overvoltage condition inside the spindle drive.

### 6.2 SERVO DRIVE REGEN RESISTOR

A 500-ohm, 100-watt resistor is used by the servo drives to dissipate excess power caused by the regenerative effects of decelerating the servo motors. If the servo motors are accelerated and decelerated again in rapid succession repeatedly, this resistor will get hot. In addition, if the line voltage into the control is above 255V, this resistor will begin to heat. This resistor is overtemp protected at 100° C. At that temperature, an automatic control shutdown is begun. If that resistor is removed from the circuit, an alarm may subsequently occur because of an overvoltage condition for the servo buss.

### 6.3 OVERHEAT SENSE SWITCH

There is an overtemperature sense switch mounted near the above-mentioned regen resistors. This sensor is a normally-closed switch that opens at about 100° C. It will generate an alarm and all motion will stop. After four minutes of an overheat condition, an automatic shutdown will occur in the control.

## 7. POWER SUPPLY ASSEMBLY

**NOTE: REFER TO PCB AND CABLE LOCATION SECTION FOR BOARD DIAGRAMS.**

All power to the control passes through the power supply assembly. It is located on the upper right corner of the control cabinet.

### 7.1 MAIN CIRCUIT BREAKER CB1

Circuit breaker CB1 is rated at 30 amps and is used to protect the spindle drive and to shut off all power to the control. The locking On/Off handle on the outside of the control cabinet will shut this breaker off when it is unlocked. A trip of this breaker indicates a SERIOUS overload problem and should not be reset without investigating the cause of the trip. These 30 amps could correspond to as much as 15 horsepower.

### 7.2 MAIN CONTACTOR K1

Main contactor K1 is used to turn the control on and off. The POWER ON switch applies power to the coil of K1 and after it is energized, an auxiliary switch on K1 continues to apply power to the coil. The POWER OFF switch on the front panel will always remove power from this contactor.

When the main contactor is off, the only power used by the control is supplied through two ½ amp fuses to the circuit that activates the contactor. An overvoltage or lightning strike will blow these fuses and shut off the main contactor.

The power to operate the main contactor is supplied from a 24V AC control transformer that is primary fused at ½ amp. This ensures that the only circuit powered when the machine is turned off is this transformer and only low voltage is present at the front panel on/off switches.

### 7.3 LOW VOLTAGE POWER SUPPLY

The low voltage power supply provides +5V DC, +12V DC, and -12V DC to all of the logic sections of the control. It operates from 115V AC nominal input power. It will continue to operate correctly over a 90V AC to 133V AC range.

### 7.4 POWER PCB (POWER)

The low voltage power distribution and high voltage fuses and circuit breakers are mounted on a circuit board called the POWER PCB. The following connectors are on it:

P1	Five-pin brings 230V AC three ph from main breaker
P2	On/Off connections to front panel (740)
P3	Coil and aux connections to contactor K1
P4	Auto-off connection to IOPCB (170)
P5	Low voltage control transformer to power K1
P6	230V AC from CB3 to coolant pump (930)
P7	115V AC from CB4 to IOPCB for solenoids (910)
P8	115V AC /T1 (90)
P9	Tool changer fuse circuit from FU5 to IOPCB (840)
P10	+5/+12/Gnd form low volt supply to logic boards (860)
P11	+5/+12/Gnd form low volt supply to logic boards (860)
P12	+5/+12/Gnd form low volt supply to logic boards (860)
P13	+5/+12/Gnd form low volt supply to logic boards (860)
P14	12V AC to operator's lamp (800A)
P15	230V AC from contactor K1 for coolant pump (70)
P16	Low voltage power from power supply
P17	+12V DC to IOPCB (860A)
P18	Not used
P19	Connector to op. lamp transformer T4 (290)
P20	115V AC to low voltage supply
P21	-12V DC to processor PCB
P22	-12V DC to MOTIF PCB
P26	+12V DC option connector
P27	+5/+12/Gnd form low volt supply to logic boards (860)
P30	12V AC OP Lamp (800)
P31	+12V (860A)

For older internal transformer with 208/230 taps:

TB1	230V AC from contactor K1
TB2	230V AC to T1 primary

## 7.5 POWER-UP LOW VOLTAGE CONTROL TRANSFORMER (T5)

The low voltage control transformer, T5, supplies power to the coil of the main contactor K1. It guarantees that the maximum voltage leaving the Power Supply assembly when power is off is 12V AC to earth ground. It is connected via P5 to the POWER PCB.

## 7.6 SECONDARY CIRCUIT BREAKERS

Three more circuit breakers are on the Power supply assembly.

CB2 controls the 115volt power from the main transformer to the servo transformers and, if tripped, will turn off the servo motors and air solenoids. CB2 could be blown by a severe servo overload.

CB3 controls the power to coolant pump only. It can be blown by an overload of the coolant pump motor or a short in the wiring to the motor.

CB4 controls the 115V AC to the air solenoids, 4th axis brake, and the oiler. It is never expected to trip. If it does trip, it is likely caused by a short circuit in the wiring on the I/O assembly or the wiring to the solenoids on the spindle head.

## 7.7 OPERATOR'S LAMP TRANSFORMER

Transformer T4 supplies low voltage to the operator's lamp. The primary is 115V AC and the secondary is 10V AC. The primary is protected at ½ amp by F6. It is connected to the POWER PCB by connector P19.

# 8. POWER TRANSFORMER ASSEMBLY (T1)

The power transformer assembly is used to convert three-phase 190/260V to three-phase 115V and is primarily used by the servo drives. The video monitor, solenoids, fans, and oiler also use 115V AC. This transformer's maximum input voltage is 260V @ 60 Hertz, and 240V @ 50 Hertz. It is located in the main cabinet in the lower right corner. It is rated at 12KVA and its primary is protected to 40 amps.

This transformer has four voltage connections that allow for a range of inputs from 195V to 260V. The transformer has an autotransformer primary to supply 240V, three-phase to the spindle drives other 240V applications.




Fig. 12-1 Polyphase bank transformer.

## 8.1 PRIMARY CONNECTION TO T1

Input power to T1 is supplied through CB1, the 40 amp three-phase main circuit breaker. Three-phase 230 to T1 is connected to the first three terminals of TB10.

## 8.2 VOLTAGE SELECTION TAPS

There are four labeled plastic terminal blocks. Each block has three connections for wires labeled 74, 75, and 76. Follow the instructions printed on the transformer.

## 8.3 SECONDARY CONNECTION TO T1

The secondary output from T1 is 115V AC three-phase. CB2 protects the secondary of transformer T1 and is rated at 25 amps.

## 8.4 OPTIONAL 480 TRANSFORMER

Voltage Selection Taps for the 480 Transformer:

Right to left:

353 to 376

377 to 400

401 to 425

426 to 451

452 to 480\*

\* 480 V transformer has additional terminal block

# 9. FUSES

The servo drive (DRIVER) cards have three fuses on each of the X, Y, Z, and A PCB's (F1, F2, F3). If these fuses are ever blown, the associated motor will stop. This will only happen if there is a failure of the drive card and the user should never attempt to replace these fuses.

The POWER PCB contains three 1/2-amp fuses located at the top right (FU1, FU2, FU3). If the machine is subject to a severe overvoltage or a lightning strike, these fuses will blow and turn off all of the power. Replace these fuses only with the same type and ratings. The other two fuses protect the tool changer (FU5) and the operator's lamp (FU6).

On the servo drive assembly, there is a printed circuit board (SDIST) containing three one-amp fuses (FU1, FU2, FU3). Two of these fuses protect the contactor and small transformers. They are never expected to blow. The third fuse protects the regen load circuit load from shorts.

FUSE NAME	TYPE	RATING	VOLTAGE (amps)	LOCATION
FU1	AGC	½	250V	POWER pcb, upper right
FU2	AGC	½	250V	" "
FU3	AGC	½	250V	" "
LAMP	AGC	½	250V	" lower left
FU1	AGC	½	250V	SDIST pcb, right center
FU2	AGC	½	250V	" "
FU3	AGC	5	250V	" top center
F1	ABC	20	250V	SDRIVER pcb's (X, Y, Z, A)
F2	ABC	20	250V	"
F3	ABC	10	250V	"
FU1	ABC	5	250V	I/O PCB
FU2	ABC	5	250V	I/O PCB
FU3	ABC	5	250V	I/O PCB
FU4	ABC	5	250V	I/O PCB

## 10. SPARE USER M CODE INTERFACE

The M code interface uses outputs M21-24 and one discrete input circuit. M codes M21 through M24 will activate relays labled M21-24. These relay contacts are isolated from all other circuits and may switch up to 120V AC at one amp. The relays are SPDT.

**WARNING!** Power circuits and inductive loads must have snubber protection.

The M-FIN circuit is a normally open circuit that is made active by bringing it to ground. The one M-FIN applies to all eight of the user M codes.

The timing of a user M function must begin with all circuits inactive, that is, all circuits open. The timing is as follows:

The Diagnostic Data display page may be used to observe the state of these signals.

### 10.1 M FUNCTION RELAYS

The IOPCB contains position for four relays (M21-M24) and all are available to the user. In addition, M21 is already wired out to P12 at the side of the control cabinet. This is a four-pin DIN connector and includes the M-FIN signal.

### 10.2 M-FIN DISCRETE INPUT

The M-FIN discrete input is a low voltage circuit. When the circuit is open, there is +12V DC at this signal. When this line is brought to ground, there will be about 10 milliamps of current. M-FIN is discrete input #10 and is wired from input #10 on the Inputs PCB on the Input/Output Assembly. The return line for grounding the circuit should also be picked up from that PCB. For reliability, these two wires should be routed in a shielded cable where the shield is grounded at one end only. The diagnostic display will show this signal a "1" when the circuit is open and a "0" when this circuit is grounded.



### **10.3 TURNING M FUNCTIONS ON AND OFF**

The eight optional M code relays can also be separately turned on and off using M codes M51-M54 and M61-M64. M51 to M54 will turn on one of the eight relays and M61 to M64 will turn the relays off. M51 and M61 correspond to M21, etc.

## **11. LUBRICATION PUMP**

The lubrication pump is powered whenever the spindle is on or any axes are in motion. It operates from 115V AC. On a cyclic basis, it will pump oil to the screws and guides. It cycles at least once every 30 minutes and pumps 2.8cc- 3.8cc of lubrication.

### **11.1 LOW LUBRICATION AND LOW PRESSURE SENSE SWITCHES**

There is a low lube sense switch in the oil tank. When the oil is low, an alarm will be generated. This alarm will not occur until the end of a program is reached. There is also a lube pressure switch that senses the lube pressure. Parameter 117 controls the lube pressure check. If Parameter 117 is not zero, the lube pressure is checked for cycling high within that period. Parameter 117 has units of , 1/50 seconds; so 30 minutes gives a value of 90000. Parameter 57, bit "Oiler on/off", indicates the lube pump is only powered when the spindle fan is powered. The lube pressure is only checked when the pump is on.

## **12. SWITCHES**

### **12.1 LAMP ON/OFF SWITCH**

An on/off switch is supplied for the operator's lamp. It is located on the side of the control cabinet below all of the motor connectors.

### **12.2 DOOR OPEN SENSE SWITCH**

The DOOR OPEN sense switch is a magnetic reed switch type. The switch is in the open position when the door is open and closed when the door is fully closed.

### **12.3 LIMIT SWITCHES**

#### **TURRET CLAMP/UNCLAMP SWITCHES**

There are two switches used to sense the position of the turret. They are both normally closed and one will activate at the end of travel during unclamping and the other during clamping. When both switches are closed, it indicates that the turret is between positions.

The diagnostic display can be used to display the status of the relay outputs and the switch inputs.

#### **DOOR HOLD SWITCH**

The switch is normally closed. When the door opens, the switches will open and the machine will stop with a "Door Hold" function. When the door is closed again, operation will continue normally.

If the door is open, you will not be able to start a program. Door hold will not stop a tool change operation, will not turn off the spindle, and will not turn off the coolant pump.

The door hold function can be temporarily disabled with Setting 51, but this setting will return to OFF when the control is turned off.

Prior to performing an AUTO POWER UP or an AUTO ALL AXES operation, there are no travel limits. Thus, you can jog into the hard stops in either direction for X and Z. After a ZERO RETURN has been performed, the travel limits will operate unless an axis hits the limit switch. When the limit switch is hit, the zero returned condition is reset and an AUTO ALL AXES must be done again. This is to ensure that if you hit the limit switch, you can still move the servo back away from it.

The limit switches are normally closed. When a search for zero operation is being performed, the X, Y, and Z axes will move towards the limit switch unless it is already active (open); then they will move away from the switch until it closes again; then they will continue to move until the encoder Z channel is found. This position is machine zero.

Auto search for zero in the Z-axis is followed by a rapid move from the limit switch position down to the tool change position. This makes the Z-axis a little different from the other axes.

### What Can Go Wrong With Limit Switches?

If the machine is operated without connector P5, a LOW LUBE and DOOR OPEN alarm will be generated. In addition, the Home search will not stop at the limit switch and will instead run into the physical stops on each axis.

If the switch is damaged and permanently open, the zero search for that axis will move in the negative direction at about 0.5 in/min until it reaches the physical travel stops at the opposite end of travel.

If the switch is damaged and permanently closed, the zero search for that axis will move at about 10 in/min in the positive direction until it reaches the physical stops.

If the switch opens or a wire breaks after the zero search completes, an alarm is generated, the servos are turned off, and all motion stops. The control will operate as though the zero search was never performed. The RESET can be used to turn servos on but you can jog that axis only slowly.

### TURRET HOME SWITCH

The tool rotation turret has a switch that is activated when tool #1 is in the cutting position. At POWER ON this switch indicates that tool #1 is in the cutting position. If this switch is not active at power-on, the first tool change will rotate the turret until the switch engages and then move to the selected tool. The diagnostic display will show this status of this input switch as "TOOL #1". A "1" indicates that tool #1 is in position.

## 13. DIAGNOSTIC DATA

The ALARM MSGS display is the most important source of diagnostic data. At any time after the machine completes its power-up sequence, it will either perform a requested function or stop with an alarm. Refer to the alarms list for , their possible causes, and some corrective action.

If there is an electronics problem, the controller may not complete the power-up sequence and the CRT will remain blank. In this case, there are two sources of diagnostic data; these are the audible beeper and the LED's on the processor PCB. If the audible beeper is alternating a ½ second beep, there is a problem with the main control program stored in EPROM's on the processor PCB. If any of the processor electronics cannot be accessed correctly, the LED's on the processor PCB will or will not be lit.

If the machine powers up but has a fault in one of its power supplies, it may not be possible to flag an alarm condition. If this happens, all motors will be kept off and the top left corner of the CRT will have the message:

POWER FAILURE ALARM

and all other functions of the control will be locked out.

When the machine is operating normally, a second push of the PARAM/DGNOS key will select the diagnostics display page. The PAGE UP and PAGE DOWN keys are then used to select one of two different displays. These are for diagnostic purposes only and the user will not normally need them. The diagnostic data consists of 32 discrete input signals, 32 discrete output relays and several internal control signals. Each can have the value of 0 or 1. In addition, there are up to three analog data displays and an optional spindle RPM display. Their number and functions are:

## 14. DISCRETE INPUTS / OUTPUTS

### DISCRETE INPUTS

#	Name	Description	#	Name	Description
1	TT UNL	Tool Turret Unlock	17	SP LOK	Spindle Locked
2	TT LOK	Tool Turret lock	18	SP FLT	Spindle Drive Fault
3	spare		19	SP ST*	Spindle Not Stopped
4	LO CNT	Low Coolant	20	SP AT*	Spindle Not At Speed
5	A DOOR	Auto door	21	LO HYDR	Low hydraulic pres.
6	SP HIG	Spindle In High	22	spare	
7	SP LOW	Spindle In Low	23	spare	
8	EM STP	Emergency Stop	24	spare	
9	DOOR S	Door Open Switch	25	UNCLA*	Remote chuck unclamp
10	M-FIN*	Not M Func Finish	26	LOPH A	Low voltage phase a
11	OVERVT	Over voltage	27	spare	
12	LO AIR	Low Air Pressure	28	spare	
13	LO LUB	Low Lube Oil	29	GR FLT	Ground fault
14	OVERHT	Regen Overheat	30	SKIP	Skip Signal
15	spare		31	spare	
16	spare		32	CNVYR*	Conveyor Overload

### DISCRETE OUTPUTS

#	Name	Description	#	Name	Description
1	SRV PO	Servo Power On	17	spare	
2	SP FOR	Spindle Forward	18	spare	
3	SP REV	Spindle Reverse	19	spare	
4	SP RST	Spindle Reset	20	spare	
5	A DOOR	Auto. Door	21	TT OUT	Tool Turret Out
6	COOLNT	Coolant Pump	22	spare	
7	AUT OF	Auto Turn Off	23	spare	
8	SP FAN	Spind Motor Fan	24	spare	
9	spare		25	M21	
10	spare		26	M22	
11	spare		27	M23	
12	spare		28	M24	
13	SP HIG	Spindle High Gear	29	GRBCN	Green beacon
14	SP LOW	Spindle Low Gear	30	REDBCN	Red beacon
15	SP UNC	Spindle unclamped	31	CNVENA	Chip conv. enable 16
	SP LOK	Spindle LockED	32	CNVREV	Chip conv. reverse

The 32 inputs are numbered the same as the 32 connections on the inputs printed circuit board. The last eight outputs are reserved for expansion by HAAS.

The second page of diagnostic data is displayed using the PAGE UP and PAGE DOWN keys. It contains:

### INPUTS 2

Name	Description	Name	Description
X Z CH	X-axis Z Channel	X ZIRQ	X-axis Z channel interrupt
B Z CH	B-Axis Z Channel	B ZIRQ	B-axis Z channel interrupt
Z Z CH	Z-axis Z Channel	Z ZIRQ	Z-axis Z channel interrupt
A Z CH	A-axis Z Channel	A ZIRQ	A-axis Z channel interrupt
X HOME	X-axis Home/Lim Switch	1K IRQ	1 kHz Interrupt
B HOME	B-axis Home	Z IRQ	Z channel interrupt
Z HOME	Z-axis Home	BZIRQ	Spindle Z interrupt
A HOME	A-axis Home	SELF T	Self-Test Input
X OVRH	X Motor OverTemp	X CABL	Broken cable to X encoder
B OVRH	B Motor OverTemp	B CABL	Broken cable to B encoder
Z OVRH	Z Motor OverTemp	Z CABL	Broken cable to Z encoder
A OVRH	A Motor OverTemp	A CABL	Broken cable to A encoder
OVC X	X Drive Overcurrent	spare	
OVC B	B Drive Overcurrent	spare	
OVC Z	Z Drive Overcurrent	spare	
OVC A	A Drive Overcurrent	AD EOC	A-to-D End of Conversion

#### ANALOG DATA

Name	Description
DC BUSS	DC Servo Buss Voltage
SP TEMP	Spindle temperature F
SP LOAD	Spindle load in %
AUX TMP	Not used
SP SPEED	Spindle RPM CW or CCW

# PARAMETERS

Parameters are seldom-modified values that change the operation of the machine. These include servo motor types, gear ratios, speeds, stored stroke limits, lead screw compensations, motor control delays and macro call selections. These are all rarely changed by the user and should be protected from being changed by the parameter lock setting. If you need to change parameters, contact HAAS or your dealer. Parameters are protected from being changed by Setting 7.

The Settings page lists some parameters that the user may need to change during normal operation and these are simply called "Settings". Under normal conditions, the parameter displays should not be modified. A complete list of the parameters is provided here.

There are 226 parameters in this control. The first 56 apply to the individual servo axes, 14 each. The first 14 of these will be described. The other axes parameters (15 through 56) are identical in function.

## PARAMETER LIST

### Parameter 1 X SWITCHES

Parameter 1 is a collection of single-bit flags used to turn servo related functions on and off. The left and right cursor arrows are used to select the function being changed. All values are 0 or 1 only. The function names are:

REV ENCODER	Used to reverse the direction of encoder data.
REV POWER	Used to reverse direction of power to motor.
DISABLED	Used to disable any axis.
Z CH ONLY	With A only, indicates that no home switch.
AIR BRAKE	With A only, indicates that air brake is used.
DISABLE Z T	Disables encoder Z test (for testing only).
SERVO HIST	Graph of servo error (for diagnostics only).
INV HOME SW	Inverted home switch (N.C. switch).
INV Z CH	Inverted Z channel (normally high).
CIRC. WRAP.	With A only, causes 360 wrap to return to 0.
NO I IN BRAK	With A only, removes I feedback when brake is active.
LOW PASS +1X	Adds 1 term to low pass filter.
LOW PASS +2X	Adds two terms to low pass filter.
OVER TEMP NC	Selects a normally closed overheat sensor in motor.
CABLE TEST	Enables test of encoder signals and cabling.
Z TEST HIST	History plot of Z channel test data.
SCALE FACT/X	If set to 1, the scale ratio is interpreted as divided by X; where X depends on bits SCALE/X LO and SCALE/X HI.
INVIS AXIS	Used to create an invisible axis.
ROT ALM LMSW	Rotary alarms at the limit switch.
ROT TRVL LIM	Rotary travel limits are used.
UNDEFINED	
UNDEFINED	
UNDEFINED	
TORQUE ONLY	For HAAS only.
3 EREV/MREV	For HAAS only.

### PARAMETERS

2 EREV/MREV  
UNDEFINED  
BRUSH MOTOR  
LINEAR DISPL

For HAAS only.

Enables the brushless motor option.  
This bit changes the display from degrees to inches (or millimeters) on the A and B axes.

SCALE/X LO  
SCALE/X HI

With SCALE/X HI bit, determines the scale factor used in bit SCALE FACT/X,  
With SCALE/X LO bit, determines the scale factor used in bit SCALE FACT/X. See below:

HI	LO	
0	0	3
0	1	5
1	0	7
1	1	9

Parameter	2	X	P GAIN Proportional gain in servo loop.
Parameter	3	X	D GAIN Derivative gain in servo loop.
Parameter	4	X	I GAIN Integral gain in servo loop.
Parameter	5	X	RATIO (STEPS/UNIT) The number of steps of the encoder per unit of travel. Encoder steps supply four times their line count per revolution. Thus a 2000 line encoder and a 6mm pitch screw give: $2000 \times 4 \times 25.4 / 6 = 33867$
Parameter	6	X	MAX TRAVEL (STEPS) Max negative direction of travel from machine zero in encoder steps. Does not apply to A-axis. Thus a 20 inch travel and 2000 line encoder and 6 mm pitch screw give: $20.0 \times 33867 = 677340$
Parameter	7	X	ACCELERATION Maximum acceleration of axis in steps per second per second.
Parameter	8	X	MAX SPEED Max speed for this axis in steps per second.
Parameter	9	X	MAX ERROR Max error allowed in servo loop before alarm is generated. Units are encoder steps.
Parameter	10	X	FUSE LEVEL Fuse level in % of max power to motor. Applies only when motor in motion.
Parameter	11	X	BACK EMF Back EMF of motor in volts per 1000 RPM times 10. Thus a 63 volt/KRPM

			motor gives 630.
Parameter	12	X	<p>STEPS/REVOLUTION</p> <p>Encoder steps per revolution of motor. Thus a 2000 line encoder gives:  <math>2000 \times 4 = 8000</math>.</p>
Parameter	13	X	<p>BACKLASH</p> <p>Backlash correction in encoder steps.</p>
Parameter	14	X	<p>DEAD ZONE</p> <p>Dead zone correction for driver electronics. Units are 0.0000001 seconds.</p>
Parameter	15	B	<p>SWITCHES</p> <p>See Parameter 1 for description.</p>
Parameter	16	B	<p>P GAIN</p> <p>See Parameter 2 for description.</p>
Parameter	17	B	<p>D GAIN</p> <p>See Parameter 3 for description.</p>
Parameter	18	B	<p>I GAIN</p> <p>See Parameter 4 for description.</p>
Parameter	19	B	<p>RATIO (STEPS/UNIT)</p> <p>See Parameter 5 for description.</p>
Parameter	20	B	<p>MAX TRAVEL (STEPS)</p> <p>See Parameter 6 for description.</p>
Parameter	21	B	<p>ACCELERATION</p> <p>See Parameter 7 for description.</p>
Parameter	22	B	<p>MAX SPEED</p> <p>See Parameter 8 for description.</p>
Parameter	23	B	<p>MAX ERROR</p> <p>See Parameter 9 for description.</p>
Parameter	24	B	<p>FUSE LEVEL</p> <p>See Parameter 10 for description.</p>
Parameter	25	B	<p>BACK EMF</p> <p>See Parameter 11 for description.</p>
Parameter	26	B	<p>STEPS/REVOLUTION</p> <p>See Parameter 12 for description.</p>
Parameter	27	B	<p>BACKLASH</p> <p>See Parameter 13 for description.</p>



**PARAMETERS**

Parameter	28	B	DEAD ZONE See Parameter 14 for description.
Parameter	29	Z	SWITCHES See Parameter 1 for description.
Parameter	30	Z	P GAIN See Parameter 2 for description.
Parameter	31	Z	D GAIN See Parameter 3 for description.
Parameter	32	Z	I GAIN See Parameter 4 for description.
Parameter	33	Z	RATIO (STEPS/UNIT) See Parameter 5 for description.
Parameter	34	Z	MAX TRAVEL (STEPS) See Parameter 6 for description.
Parameter	35	Z	ACCELERATION See Parameter 7 for description.
Parameter	36	Z	MAX SPEED See Parameter 8 for description.
Parameter	37	Z	MAX ERROR See Parameter 9 for description.
Parameter	38	Z	FUSE LEVEL See Parameter 10 for description.
Parameter	39	Z	BACK EMF See Parameter 11 for description.
Parameter	40	Z	STEPS/REVOLUTION See Parameter 12 for description.
Parameter	41	Z	BACKLASH See Parameter 13 for description.
Parameter	42	Z	DEAD ZONE See Parameter 14 for description.
Parameter	43		TURRET SWITCHES See Parameter 1 for description. Turret parameters take effect if Setting 30 (TURRET ENABLE) is on.

Parameter 44	TURRET P GAIN See Parameter 2 for description.
Parameter 45	TURRET D GAIN See Parameter 3 for description.
Parameter 46	TURRET I GAIN See Parameter 4 for description.
Parameter 47	TURRET RATIO (STEPS/UNIT) See Parameter 5 for description.
Parameter 48	TURRET MAX TRAVEL (STEPS) See Parameter 6 for description.
Parameter 49	TURRET ACCELERATION See Parameter 7 for description.
Parameter 50	TURRET MAX SPEED See Parameter 8 for description.
Parameter 51	TURRET MAX ERROR See Parameter 9 for description.
Parameter 52	TURRET FUSE LEVEL See Parameter 10 for description.
Parameter 53	TURRET BACK EMF See Parameter 11 for description.
Parameter 54	TURRET STEPS/REVOLUTION See Parameter 12 for description.
Parameter 55	TURRET BACKLASH See Parameter 13 for description.
Parameter 56	TURRET DEAD ZONE See Parameter 14 for description.

Parameters 57 through 128 are used to control other machine dependent functions. They are:

Parameter 57	COMMON SWITCH 1 Parameter 57 is a collection of general purpose single bit flags used to turn some functions on and off. The left and right cursor arrows are used to select the function being changed. All values are 0 or 1 only. The function names are:
REV CRANK	Reverses direction of jog handle.
DISABLE T.C.	Disables tool changer operations.
DISABLE G.B.	Disables gear box functions.
POF AT E-STP	Causes power off at EMERGENCY STOP.

### PARAMETERS

RIGID TAP	Indicates hardware option for rigid tap.
REV SPIN ENC	Reverses sense direction of spindle encoder.
SYNC THREADS	Threads will repeat between passes.
EX ST MD CHG	Selects exact stop in moves when mode changes.
UNDEFINED	Not presently used.
SP DR LIN AC	Selects linear deceleration for rigid tapping. 0 is quadratic.
PH LOSS DET	When enabled, will detect a phase loss.
UNDEFINED	Not presently used.
OVER T IS NC	Selects control over temp sensor as N.C.
SKIP OVERSHT	Causes Skip (G31) to act like Fanuc and overshoot sense point.
NONINV SP ST	Non-inverted spindle stopped status.
SP LOAD MONI	Spindle load monitor option is enabled.
SP TEMP MONI	Spindle temperature monitor option is enabled.
UNDEFINED	Not presently used.
ENABLE DNC	Enables DNC selection from MDI.
ENABLE BGEDT	Enables BACKGROUND EDIT mode.
ENA GRND FLT	Enables ground fault detector.
KEYBD SHIFT	Enables use of keyboard with shift functions.
ENABLE MACRO	Enables macro functions.
INVERT SKIP	Invert sense of skip to active low=closed.
HANDLE CURSR	Enable use of jog handle to move cursor.
NEG WORK OFS	Selects use of work offsets in negative direction.
UNDEFINED	Not presently used.
ENA CONVERSE	Enables conversational programming.
OILER ON/OFF	Enables oiler power when servos or spindle is in motion.
NC OVER VOLT	Inverts sense of over voltage signal.
ALT CHAR SET	Enables alternate character set on CRT.
DOOR STOP SP	Enables functions to stop spindle and manual ops at door switch.

Parameter 58	LEAD COMPENS SHIFT Shift factor when applying lead screw compensation. Lead screw compensation is based on a table of 256 offsets; each +/-127 encoder steps. A single entry in the table applies over a distance equal to two raised to this parameter power encoder steps.
Parameter 59	MAX FEED RATE (INCH) Maximum feed rate in inches per minute.
Parameter 60	TURRET IN POS DELAY Amount of time to delay after the turret rotates to the tool position. This delay allows the turret to settle.
Parameter 61	TURRET LOCK DELAY Amount of time to delay after the turret is sensed to be locked. This delay allows for mechanical settling.
Parameter 62	TURRET UNLK ERRTIME Maximum delay allowed for tool turret to unlock. Units are milliseconds. After this time, an alarm is generated.

Parameter	63	<p>TURRET LOCK ERRTIME</p> <p>Maximum delay allowed for tool turret to lock. Units are milliseconds. After this time, an alarm is generated.</p>
Parameter	64	<p>TOOL CHANGE OFFSET</p> <p>For turret, displacement from home switch to tool 0.</p>
Parameter	65	<p>NUMBER OF TOOLS</p> <p>Number of tool positions in tool changer. This number must be 10 or 12 for the present lathe configuration.</p>
Parameter	66	<p>SPINDLE ORI DELAY</p> <p>Maximum delay allowed when orienting spindle. Units are milliseconds. After this time, an alarm is generated.</p>
Parameter	67	<p>GEAR CHANGE DELAY</p> <p>Maximum delay allowed when changing gears. Units are milliseconds. After this time, an alarm is generated.</p>
Parameter	68	<p>A DOOR OPEN ERRTIME</p> <p>Maximum delay allowed for the automatic door to open once it is commanded. After this time, an alarm is generated.</p>
Parameter	69	<p>AIR BRAKE DELAY</p> <p>Delay provided for air to release from brake prior to moving. Units are milliseconds.</p>
Parameter	70	<p>MIN SPIN DELAY TIME</p> <p>Minimum delay time in program after commanding new spindle speed and before proceeding. Units are milliseconds.</p>
Parameter	71	<p>SPIN STALL DET DLAY</p> <p>Time to delay after spindle is started before spindle stall checking is started. Each unit represents 1/50 of a second.</p>
Parameter	72	<p>UNDEFINED</p> <p>Not presently used.</p>
Parameter	73	<p>SP HIGH G/MIN SPEED</p> <p>Command speed used to rotate spindle motor when orienting spindle in high gear. Units are 5000/256 RPM.</p>
Parameter	74	<p>SP LOW G/MIN SPEED</p> <p>Command speed used to rotate spindle motor when orienting spindle in low gear. Units are 5000/256 RPM.</p>
Parameter	75	<p>GEAR CHANGE SPEED</p> <p>Command speed used to rotate spindle motor when changing gears. Units are 5000/256RPM.</p>

## PARAMETERS

Parameter	76	LOW AIR DELAY Delay allowed after sensing low air pressure before alarm is generated. Alarm skipped if air pressure returns before delay. Units are 1/50 seconds.
Parameter	77	SP LOCK SETTLE TIME Required time in milliseconds that the spindle lock must be in place and stable before spindle orientation is considered complete.
Parameter	78	GEAR CH REV TIME Time in milliseconds before motor direction is reversed while in a gear change.
Parameter	79	SPINDLE STEPS/REV Sets the number of encoder steps per revolution of the spindle. Applies only to hard tapping option.
Parameter	80	MAX SPIN DELAY TIME The maximum delay time control will wait for spindle to get to commanded speed or to get to zero speed. Units are milliseconds.
Parameter	81	M MACRO CALL 09000 M code that will call 09000. Zero causes no call.
Parameter	82	M MACRO CALL 09001 same as 81
Parameter	83	M MACRO CALL 09002 same as 81
Parameter	84	M MACRO CALL 09003 same as 81
Parameter	85	M MACRO CALL 09004 same as 81
Parameter	86	M MACRO CALL 09005 same as 81
Parameter	87	M MACRO CALL 09006 same as 81
Parameter	88	M MACRO CALL 09007 same as 81
Parameter	89	M MACRO CALL 09008 same as 81
Parameter	90	M MACRO CALL 09009 same as 81
Parameter	91	G MACRO CALL 09010 G code that will call 09010. Zero causes no call.
Parameter	92	G MACRO CALL 09011 same as 91
Parameter	93	G MACRO CALL 09012 same as 91
Parameter	94	G MACRO CALL 09013 same as 91
Parameter	95	G MACRO CALL 09014 same as 91
Parameter	96	G MACRO CALL 09015 same as 91
Parameter	97	G MACRO CALL 09016 same as 91
Parameter	98	G MACRO CALL 09017 same as 91
Parameter	99	G MACRO CALL 09018 same as 91
Parameter	100	G MACRO CALL 09019 same as 91
Parameter	101	IN POSITION LIMIT X How close motor must be to endpoint before any move is considered complete when not in exact stop (G09 or G61). Units are encoder steps.

Parameter	102	IN POSITION LIMIT B Same definition as Parameter 101.
Parameter	103	IN POSITION LIMIT Z Same definition as Parameter 101.
Parameter	104	IN POSITION LIMIT A Same definition as Parameter 101.
Parameter	105	HOLDING LIMIT X Fuse level in % of max power to motor. Applies only when motor is stopped.
Parameter	106	HOLDING LIMIT B Same definition as Parameter 105.
Parameter	107	HOLDING LIMIT Z Same definition as Parameter 105.
Parameter	108	HOLDING LIMIT A Same definition as Parameter 105.
Parameter	109	D*D GAIN FOR X Second derivative gain in servo loop.
Parameter	110	D*D GAIN FOR B Second derivative gain in servo loop.
Parameter	111	D*D GAIN FOR Z Second derivative gain in servo loop.
Parameter	112	D*D GAIN FOR A Second derivative gain in servo loop.
Parameter	113	X ACC/DEC T CONST Exponential acceleration time constant. Units are 1/10000 seconds. This parameter provides for a constant ratio between profiling lag and servo velocity. It is also the ratio between velocity and acceleration. In conjunction with Parameter 7, it defines the speed above which exponential accel/decel is not provided. Thus if Parameter 7 is 1200000 steps/sec/sec and this parameter is 750 (0.075 seconds); the maximum velocity for accurate interpolation should be: $1200000 \times 0.075 = 90000 \text{ steps/second}$ For a 2000 line encoder and 6 mm screw, this would be $60 \times 90000 / 33867 = 159$ inches min
Parameter	114	B ACC/DEC T CONST Same definition as Parameter 113
Parameter	115	Z ACC/DEC T CONST Same definition as Parameter 113

## PARAMETERS

Parameter	116	A ACC/DEC T CONST Same definition as Parameter 113
Parameter	117	LUB CYCLE TIME If this is set nonzero, it is the cycle time for the lube pump and the lube pressure switch option is checked for cycling in this time. It is in units of 1/50 seconds.
Parameter	118	SPINDLE REV TIME Time in milliseconds to reverse spindle motor.
Parameter	119	SPINDLE DECEL DELAY Time in milliseconds to decelerate spindle motor.
Parameter	120	SPINDLE ACC/DECEL Accel/decel time constant in steps/ms/ms for spindle motor.
Parameter	121	X BEMF BIAS Back EMF bias for X motor. This is arbitrary units.
Parameter	122	B BEMF BIAS See Parameter 121 for description.
Parameter	123	Z BEMF BIAS See Parameter 121 for description.
Parameter	124	A BEMF BIAS See Parameter 121 for description.
Parameter	125	X GRID OFFSET This parameter shifts the effective position of the encoder Z pulse. It can correct for a positioning error of the motor or home switch.
Parameter	126	B GRID OFFSET See Parameter 125 for description.
Parameter	127	Z GRID OFFSET See Parameter 125 for description.
Parameter	128	A GRID OFFSET See Parameter 125 for description.
Parameter	129	GEAR CH SETTLE TIME Gear change settle time. This is the number of one millisecond samples that the gear status must be stable before considered in gear.
Parameter	130	GEAR STROKE DELAY This parameter controls the delay time to the gear change solenoids when performing a gear change.

Parameter	131	MAX SPINDLE RPM This is the maximum RPM available to the spindle. When this speed is programmed, the D-to-A output will be +10V and the spindle drive must be calibrated to provide this.
Parameter	132	SPIN. X TEMP. COEF. This parameter controls the amount of correction to the X-axis in response to heating of the spindle head. It is 10 times the number of encoder steps per degree F.
Parameter	133	SPIN. Z TEMP. COEF. This parameter controls the amount of correction to the Z-axis in response to heating of the spindle head. It is 10 times the number of encoder steps per degree F.
Parameter	134	X EXACT STOP DIST.
Parameter	135	B EXACT STOP DIST.
Parameter	136	Z EXACT STOP DIST.
Parameter	137	A EXACT STOP DIST. These parameters control how close each axis must be to its end point when exact stop is programmed. They apply only in G09 and G64. They are in units of encoder steps. A value of 34 would give $34/33867 = 0.001$ inch.
Parameter	138	X FRICTION FACTOR
Parameter	139	B FRICTION FACTOR
Parameter	140	Z FRICTION FACTOR
Parameter	141	A FRICTION FACTOR These parameters compensate for friction on each of the four axes. The units are in 0.004V.
Parameter	142	HIGH/LOW GEAR CHANG This parameter sets the spindle speed at which an automatic gear change is performed. Below this parameter, low gear is the default; above this, high gear is the default.
Parameter	143	UNDEFINED Not presently used.
Parameter	144	RIG TAP FINISH DIST This parameter sets the finish tolerance for determining the end point of a hard tapping operation.
Parameter	145	X ACCEL FEED FORWARD This parameter sets the feed forward gain for the X-axis servo. It has no units.
Parameter	146	B ACCEL FEED FORWARD Same as Parameter 145.
Parameter	147	Z ACCEL FEED FORWARD Same as Parameter 145.



### PARAMETERS

Parameter 148	A ACCEL FEED FORWARD Same as Parameter 145.
Parameter 149	UNDEFINED This parameter sets the delay time from pre-charge to tool release. Units are milliseconds.
Parameter 150	MAX SP RPM LOW GEAR Max spindle RPM in low gear.
Parameter 151	UNDEFINED Not presently used.
Parameter 152	UNDEFINED Not presently used.
Parameter 153	SPIN. FAN OFF DELAY Delay for turning the spindle fan off after the spindle has been turned off.
Parameter 209	COMMON SWITCH 2 Parameter 209 is a collection of general purpose single bit flags used to turn some functions on and off. The left and right cursor arrows are used to select the function being changed. All values are 0 or 1 only. The function names are:
LATHE T.C.	Designates control as a lathe.
RST STOPS T.C.	Tool changer can be stopped with RESET button.
M21-28 @ 540	When enabled (1), M21-M28 is installed at cable 540.
ENA CONVEYOR	Enables chip conveyor, if machine is so equipped.
50% RPD KBD	When (1) the control will support the new style keyboards with the 50% rapid traverse key. For controls without a 50% rapid keypad set this bit to (0).
FRONT DOOR	When enabled the control will look for an additional door switch and will generate an operator message.
RESERVED	
RESERVED	
RESERVED	
UNDEFINED	Not presently used.
T SUBROUTINE	Reserved for future use.
SPIN Y ENCDR	For lathe only. When enabled, spindle encoder input is to the Y-axis.
REV CONVEYOR	Reverses the direction of the chip conveyor.
M27-M28 CONVYR	Usually the chip conveyor motor and direction relays are attached to the user relays M21 M22. When this bit is set, the control expects to see the conveyor hooked up to M27 and M28.
LOPH A ONLY	When (0) three discrete inputs are used to detect power phase loss. When (1) only LOPH A is used to detect phase loss.

GREEN BEACON	When (1) user relay M25 is used to flash a beacon. If the control is in a reset state, the beacon will be off. If the control is running normally, the beacon will be steadily on. If the control is in a M00, M01, M02, M30 feedhold, or single block state, then the beacon will flash.
RED BEACON	When (1) user relay M26 is used to flash a beacon. The beacon flashes if the control is experiencing an alarm or emergency stop condition.
CONVY DR OVRD	When (1) the conveyor will continue to run with the door open. When (0) the conveyor will stop when the door is open, but will resume when the door is closed. For safety it is recommended that the bit be set to (0).
RESERVED	Not presently used.
TC FWD CW	Determines the direction that the turret moves as viewed from the spindle, when the turret is commanded forward. When (1), the turret will rotate clockwise for a forward command, and when (0), it will rotate counterclockwise. The default is 1.
RESERVED	Not presently used.
FLOPPY ENABL	Enables an installed floppy disk drive.
UNDEFINED	Not presently used.
MCD RLY BRD	If set to 1, adds 8 additional relays, for a total of 40.
UNDEFINED	Not presently used.
UNDEFINED	Not presently used.
UNDEFINED	Not presently used.
RAPID EXSTOP	Default is 1. When this bit is set to 1, the control will execute an exact stop after all rapid motions, regardless of the next motion. When set to zero, the control will exact stop after a rapid only if the next motion is not a rapid move.
INVERT G.B.	Default is 0. When this bit is set to 1, the sense of the discrete inputs for SP HIG and SP LOW (high and low gear) are inverted.
HYDRAULICS	This bit must be set to 1 if a lathe has the hydraulic chuck clamping option.
STALL DETECT	Enables detection of spindle stall. If spindle stalls, the spindle motor is stopped and an alarm is generated.
CNCR SPINDLE	When set to 0, spindle start occurs at the end of a block, as in normal M code operation. When set to 1, spindle start occurs at the beginning of a block and concurrent with axis motion.

Parameter 215      CAROUSEL OFFSET  
 Parameter used to align tool 1 of tool changing carousel precisely. Units are encoder steps.

## PARAMETERS

Parameter 216	<b>CNVYR RELAY DELAY</b> Delay time in 1/50 seconds required on conveyor relays before another action can be commanded. Default is 5.
Parameter 217	<b>CNVYR IGNORE OC TIM</b> Amount of time in 1/50 seconds before overcurrent is checked after conveyor motor is turned on. Default is 50.
Parameter 218	<b>CONVYR RETRY REV TIM</b> Amount of time that the conveyor is reversed in 1/50 seconds after overcurrent is sensed. Default is 200.
Parameter 219	<b>CONVYR RETRY LIMIT</b> Number of times that the conveyor will cycle through the reverse/forward sequencing when an overcurrent is sensed before the conveyor will shut down. An overcurrent is sensed when chips jam the conveyor. By reversing and then forwarding the conveyor, the chip jam may be broken. Default is 3.
Parameter 220	<b>CONVYR RETRY TIMEOUT</b> Amount of time in 1/50 seconds between consecutive overcurrents in which the overcurrents is considered another retry. If this amount of time passes between overcurrents then the retry count is set to (0). Default is 1500, 30 minutes.
Parameter 221	<b>MAX TIME NO DISPLAY</b> The maximum time (in 1/50 sec.) between screen updates. When executing short blocks at a high feed rate, the control will use the resources available for interpreting G-code and generation of motion blocks. The display may not update until this time is exceeded. For high speed operation, updating of the display may cause the motion queue to become exhausted. This will manifest itself as a pause in motion. See M76 and M77 to disable the display completely.
Parameter 222	<b>LOW HYD. IGNORE TIM</b> The amount of time that the control ignores the LO HYD input bit after servos have been engaged. The hydraulic unit requires a short period of time to come up to pressure. The default value is 50, which is equal to 1 second.
Parameter 226	<b>CIRC MAX FEED CNTRL</b> This parameter is used to limit the feed rate for circles with a small radius. This parameter limits following error to 1/4 the dimension of the radius of the circular arc. The larger the value of this parameter, the more the control will limit feed during circular interpolation.
Parameter 227	<b>FLOPPY DIR NAME</b> When the floppy drive is enabled and a floppy directory is read. The directory listing is placed into a program as comments. The program is then made the current program so the user can read the contents of the floppy drive. This parameter designates what program is used to write the directory listing to. Program o8999 is the default value.
Parameter 228	<b>QUICKCODE FILE</b> This parameter set the program numbers to store in the Quickcode definition.

Parameter 248	<b>CHUCK UNCLAMP RPM</b> The RPM at which the chuck will not operate. If the spindle is spinning faster than this value the chuck will not open, and if it is spinning slower than this value the chuck will open. The default is 0, for safety.
Parameter 249	<b>CHUCK CLAMP DELAY</b> The dwell time that is allowed after clamping the chuck (an M10 command). Program execution will not continue until this time has expired. Units are in milliseconds.
Parameter 250	<b>CHUCK UNCLAMP DELAY</b> The dwell time that is allowed after unclamping the chuck (an M11 command). Program execution will not continue until this time has expired. Units are in milliseconds.
Parameter 252	<b>TAILSTOCK OVERLOAD -</b> Determines the overload limit when the tailstock is traveling in the minus direction, toward the spindle. This is an arbitrary value based on the effective voltage being sent to the tailstock servo motor. If this value is too low, you may not be able to move the tailstock. Increase the value until you are able to move the tailstock. The value for Parameter 232 should be approximately 1/2 the value of Parameter 233. The default is 1500.
Parameter 253	<b>TAILSTOCK OVERLOAD +</b> Determines the overload limit when the tailstock is traveling in the positive direction, away from the spindle. The value for Parameter 233 should be approximately twice the value of Parameter 232. The default is 3000.
Parameter 254	<b>SPINDLE CENTER</b> Reserved for future use.

## MAINTENANCE SCHEDULE AND LUBRICATION CHART FOR THE HL-SERIES LATHE

The following is a list of required regular maintenance for the HAAS HL Series Turning Centers. Listed are the frequency of service, capacities, and type of fluids required. These required specifications must be followed in order to keep your machine in good working order and protect your warranty.

### MAINTENANCE SCHEDULE

<b>DAILY</b>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check coolant level.</li> <li><input type="checkbox"/> Check way lube lubrication tank level.</li> <li><input type="checkbox"/> Clean chips from way covers and bottom pan.</li> <li><input type="checkbox"/> Clean chips from turret and housing.</li> <li><input type="checkbox"/> Check hydraulic unit oil level (DTE-25 ONLY). Capacity - 8 gallons.</li> </ul>
<b>WEEKLY</b>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check automatic dump air line's water trap for proper operation.</li> <li><input type="checkbox"/> Check air gauge/regulator for 85 psi.</li> <li><input type="checkbox"/> Check aluminum air filters on control heat exchanger and at top of spindle motor.</li> <li><input type="checkbox"/> Clean exterior surfaces with mild cleaner. DO NOT use solvents.</li> </ul>
<b>MONTHLY</b>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Inspect way covers for proper operation and lubricate with light oil, if necessary.</li> <li><input type="checkbox"/> Clean the screen on the coolant tank. Remove the plate on the tank and remove any sediment inside the tank. CAUTION! Be careful to disconnect the coolant pump from the controller and to POWER OFF the control before working on the coolant tank.</li> <li><input type="checkbox"/> Dump the oil drain bucket.</li> </ul>
<b>SIX MONTHS</b>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Replace coolant and thoroughly clean the coolant tank.</li> <li><input type="checkbox"/> Replace hydraulic unit oil filter.</li> <li><input type="checkbox"/> Check all hoses and lubrication lines for cracking.</li> </ul>
<b>ANNUALLY</b>	<ul style="list-style-type: none"> <li><input type="checkbox"/> With the air pressure OFF, disassemble and clean the small filter at end of lubricator (right side of machine).</li> <li><input type="checkbox"/> Check oil filter and clean out residue at bottom of filter.</li> </ul>


**LUBRICATION CHART AND CHUCK MAINTENANCE**

ITEM	CAPACITY	FLUID TYPE
COOLANT	30 gallons (40 for HL-3/4)	Water soluble, synthetic, or cutting oil.
WAY LUBE	Approx. 1 quart	Vactra #2 or equivalent

**CHUCK MAINTENANCE**

Ensure all moving parts are thoroughly greased  
Check for excessive wear on jaws. Ensure all moving parts are thoroughly greased.  
Check T- nuts for excessive wear.  
Check front retaining bolts for damage.  
Chucks should be broken in according to the manufacturers' specifications.

# **PCB'S CABLE LOCATIONS AND BOARD DIAGRAMS**




## POWER PCB 32-5010



## POWER PCB 32-5010 CABLE CONNECTIONS

### POWER


PLUG#	CABLE#	SIGNAL NAME	→ TO:	LOCATION	PLUG#
P1	—	190-260VAC INPUT	→ TO:	CB1	—
P3	—	K1 COIL	→ TO:	K1 CONTACTOR	—
P4	170	AUTO OFF	→ TO:	I/O PCB	P8
P5	PRI-SEC	PRI-SEC/T5	→ TO:	T5	—
P6	930	230VAC/COOLANT PUMP	→ TO:	I/O PCB	P6
P7	910	115VAC CB/SOLENOID	→ TO:	I/O PCB	P28
P8	90	115VAC/T1	→ TO:	I/O PCB	P36
P9	860	LOW VOLTAGE	→ TO:	POWER	—
P10	860	LOW VOLTAGE	→ TO:	POWER	—
P11	860	LOW VOLTAGE	→ TO:	POWER	—
P12	860	LOW VOLTAGE	→ TO:	POWER	—
P13	860	LOW VOLTAGE	→ TO:	POWER	—
P14	800A	OP LAMP TO SWITCH	→ TO:	OP LAMP SWITCH	—
P15	70	230VAC/K1 CONTACTORS	→ TO:	K1 CONTACTOR	—
P17	860A	I/O +12VDC	→ TO:	POWER	—
P19	290	230VAC/T4	→ TO:	T4	—
P21	PORT 1&2	-12VDC PORT 1 & 2	→ TO:	PROCESSOR PCB	P3
P22	—	-12VDC	→ TO:	—	—
P24	SPARE	SPARE	→ TO:	SPARE	N/A
P26	860	LOW VOLTAGE	→ TO:	POWER	—
P27	860	LOW VOLTAGE	→ TO:	POWER	—
P30	800	12VAC/OP LAMP	→ TO:	OPERATORS LAMP	—
P31	860A	+12VDC	→ TO:	POWER	—
TB1	—	115VAC IN	→ TO:	T1 - SECONDARY	—
TB2	—	115VAC OUT	→ TO:	—	—
POWER ON/OFF	—	740 POWER ON/OFF	→ TO:	ON/OFF SWITCH	—



**MICRO PROCESSOR PCB 32-3090**

## MICRO PROCESSOR PCB 32-3090 CABLE CONNECTIONS

PROC. PLUG#	CABLE#	SIGNAL NAME	→TO:	LOCATION	PLUG#
ADDRESS & DATA		ADDRESS BUSS	→TO:	VIDEO PCB	----
P3	860	DATA BUSS	→TO:	MOTIF PCB	----
P6	N/A	LOW VOLTAGE	→TO:	POWER SUPPLY PCB	----
PORT 1	850	EXTERNAL BATTERY	→TO:	(EXT. BATTERY) ----	
PORT 2	850A	SERIAL PORT #1	→TO:	SERIAL PORT #1 ----	
		SERIAL PORT #2	→TO:	SERIAL PORT #2 ----	




## I/O PCB 32-3080

### CABLE LOCATIONS

## I/O PCB P/N 32-3080 CABLE CONNECTIONS LATHE


I/O PLUG#	CABLE#	→T0:	LOCATION	PLUG#
P1	510	→T0:	MOTIF PCB	P11
P2	520	→T0:	MOTIF PCB	P12
P3	540	→T0:	MOTIF PCB	P14
P4	550	→T0:	MOTIF PCB	P10
P5	110	→T0:	SDIST PCB	P11
P6	930	→T0:	POWER PCB	P6
P7	940	→T0:	COOL PUMP	---
P8	170	→T0:	POWER PCB	P4
P9	710	→T0:	SPINDLE DRIVE	---
P10	300	→T0:	SP.FAN/GEAR BOX	---
P11	860A	→T0:	POWER	---
P12	880A	→T0:	CHUCK AIR SOLENOID	---
P13	820	→T0:	TURRET	---
P14	900	→T0:	COOLANT TANK	---
P15	890	→T0:	JUMPER 2,3 & 5,6	---
P16	770	→T0:	E-STOP SWITCH	---
P17	960	→T0:	AIR/OIL	---
P18	970	→T0:	SDIST PCB	P12
P19	950	→T0:	AIR/OIL	---
P20	830	→T0:	REGEN RESISTORS	---
P21	780	→T0:	SPINDLE DRIVE	---
P22	100	→T0:	(EXTERNAL)	---
P23	190	→T0:	FOOT SWITCH	---
P24	---	→T0:	---	N/A
P25	---	→T0:	---	N/A
P26	M21-24	→T0:	(EXTERNAL)	---
P28	910	→T0:	POWER PCB	P7
P29	390	→T0:	(EXTERNAL)	---
P30	---	→T0:	---	N/A
P31	160	→T0:	CHIP CONVEYOR	---
P32	80	→T0:	SDIST PCB	P8
P33	90	→T0:	T1	---
P34	90A	→T0:	CRT	---
P35	90B	→T0:	FANS	---
P36	90C	→T0:	POWER PCB	P8
P37	870	→T0:	RED & GRN LAMPS	---
P38	1050	→T0:	DOOR SWITCH	---
P39	---	→T0:	---	N/A
P40	---	→T0:	---	N/A
P43	1060	→T0:	SDIST PCB	P13
P44	---	→T0:	---	N/A
P46	---	→T0:	---	---
P47	---	→T0:	---	N/A
P48	---	→T0:	---	N/A
P49	---	→T0:	---	N/A
P50	---	→T0:	---	N/A
P51	530	→T0:	MOTIF PCB	P13
P52	---	→T0:	---	N/A
P53	---	→T0:	---	N/A
P54	---	→T0:	---	N/A
P57	M25-28	→T0:	(EXTERNAL)	---



## SERVO DISTRIBUTION PCB 32-5020

## SERVO DISTRIBUTION (SDIST)PCB 32-5020 CABLE CONNECTIONS

I/O PLUG# PLUG#	CABLE#		→T0:	LOCATION	
P1	570	X DRIVER LOW VOLTAGE	→T0:	X SERVO DRIVER	P1
P2	580	Y DRIVER LOW VOLTAGE	→T0:	Y SERVO DRIVER	P1
P3	590	Z DRIVER LOW VOLTAGE	→T0:	Z SERVO DRIVER	P1
P4	600	A DRIVER LOW VOLTAGE	→T0:	A SERVO DRIVER	P1
P5	860A	12VDC	→T0:	POWER SUPPLY PCB	----
P7	FAN	FAN VOLTAGE	→T0:	FAN (SERVO)	----
P8	80	160VDC	→T0:	I/O PCB	P32
P9	980	VOLTAGE MONITOR	→T0:	MOTIF PCB	P17
P10	920	REGEN RESISTORS	→T0:	REGEN RESISTORS	----
P11	110	SERVO POWER	→T0:	I/O PCB	P5
P12	970	0V V	→T0:	I/O PCB	P18
P13	1060	GND FAULT			



(SIDE VIEW)

## SERVO DRIVER PCB'S 32-4070




## SERVO DRIVER PCB's - P/N 32-4070

### CABLE CONNECTIONS

### LATHE


DRIVER PLUG#	CABLE#	SIGNAL NAME	→ TO:	LOCATION	PLUG#
<b>X AXIS</b>					
P1	570	LOW VOLTAGE	→ TO:	SDIST PCB	P1
P2	-----	MOTOR DRIVE	→ TO:	X SERVO MOTOR	-----
P3	610	X DRIVE SIGNAL	→ TO:	MOTIF PCB	P2
P8	-----	+160VDC	→ TO:	SDIST PCB	TB2
<b>Y AXIS</b>					
P1	580	LOW VOLTAGE	→ TO:	SDIST PCB	P2
P2	-----	MOTOR DRIVE	→ TO:	B SERVO MOTOR (TAIL STOCK)	-----
P3	620	X DRIVE SIGNAL	→ TO:	MOTIF PCB	P3
P8	-----	+160VDC	→ TO:	SDIST PCB	TB2
<b>Z AXIS</b>					
P1	590	LOW VOLTAGE	→ TO:	SDIST PCB	P3
P2	-----	MOTOR DRIVE	→ TO:	Z SERVO MOTOR	-----
P3	630	X DRIVE SIGNAL	→ TO:	MOTIF PCB	P4
P8	-----	+160VDC	→ TO:	SDIST PCB	TB2
<b>A AXIS</b>					
P1	600	LOW VOLTAGE	→ TO:	SDIST PCB	P4
P2	-----	MOTOR DRIVE	→ TO:	TURRET MOTOR	-----
P3	640	X DRIVE SIGNAL	→ TO:	MOTIF PCB	P5
P8	-----	+160VDC	→ TO:	SDIST PCB	TB2



## MOTIF PCB 32-4020

## MOTIF PCB 32-4020 CABLE CONNECTIONS


MOTIF PLUG#	CABLE#	→TO:	LOCATION	PLUG#
ADDRESS & DATA	ADDRESS BUSS	→TO:	VIDEO PCB	---
	DATA BUSS	→TO:	MICRO PROC. PCB	---
P2	610 X DRIVE SIGNAL	→TO:	X SERVO DRIVE	P3
P3	620 Y DRIVE SIGNAL	→TO:	Y SERVO DRIVE	P3
P4	630 Z DRIVE SIGNAL	→TO:	Z SERVO DRIVE	P3
P5	640 A DRIVE SIGNAL	→TO:	A SERVO DRIVE	P3
P6	660 X ENCODER OUTPUT	→TO:	X ENCODER	---
P7	670 Y ENCODER OUTPUT	→TO:	Y ENCODER	---
P8	680 Z ENCODER OUTPUT	→TO:	Z ENCODER	---
P9	690 A ENCODER OUTPUT	→TO:	A ENCODER	---
P10	550 MOTIF INPUTS/I/O OUTPUTS	→TO:	I/O PCB	P4
P11	510 I/O RELAYS 1-8	→TO:	I/O PCB	P1
P12	520 I/O RELAYS 9-16	→TO:	I/O PCB	P2
P13	530 I/O RELAYS 17-24	→TO:	I/O PCB	P51
P14	540 I/O RELAYS 25-32	→TO:	I/O PCB	P3
P15	860 LOW VOLTAGE	→TO:	POWER SUPPLY PCB	---
P16	720 SP. SPEED COMMAND	→TO:	SPINDLE DRIVE	---
P17	980 VOLTAGE MONITOR	→TO:	SDIST PCB	P9
P18	750 JOG INFO.	→TO:	JOG HANDLE	---
P20	1000 SP. ENCODER OUTPUT	→TO:	SPINDLE ENCODER	---
P21	1020 SP. TEMP	→TO:	SPINDLE	---
P22	730B SP. DRIVE LOAD	→TO:	SPINDLE DRIVE	---
P24	990 HOME SENSORS	→TO:	X, Y & Z LIMIT SW.	---



## VIDEO & KEYBOARD PCB 32-3201

## VIDEO & KEYBOARD PCB 32-3201 WITH FLOPPY DRIVE CABLE CONNECTIONS

VIDEO PLUG#	CABLE#		→TO:	LOCATION	PLUG#
P1	860	LOW VOLTAGE	→TO:	POWER SUPPLY PCB	----
P3	700	KEYBOARD INFO.	→TO:	KEYBOARD INT.	----
P4	----	ADDRESS BUSS	→TO:	MICRO PROC.PCB	----
P5	----	DATA BUSS		MOTIF PCB	----
P10	----	FLOPPY DR. POWER	→TO:	FLOPPY DRIVE	----
P11	----	SPARE	→TO:	N/A	N/A
P12	----	FLOPPY DR. SIGNAL	→TO:	FLOPPY DRIVE	----
P13	760	VIDEO SIGNAL	→TO:	CRT	----
P14	----	RS422 B	→TO:	N/A	N/A
P15	----	RS422 A	→TO:	N/A	N/A




**MOCON PCB 32-4023 C**

## MOCON PCB 32-4023 C CABLE CONNECTIONS

### MOCON

PLUG#	CABLE	SIGNAL NAME	→T0:	LOCATION	PLUG#
P1		DATA BUSS	→T0:	VIDEO PCB	---
			→T0:	MICRO PROC. PCB	---
P2	610	X DRIVE SIGNAL	→T0:	X SERVO DRIVE AMP.	P
P3	620	Y DRIVE SIGNAL	→T0:	Y SERVO DRIVE AMP.	P
P4	630	Z DRIVE SIGNAL	→T0:	Z SERVO DRIVE AMP.	P
P5	640	A DRIVE SIGNAL	→T0:	A SERVO DRIVE AMP.	P
	640B	B DRIVE SIGNAL	→T0:	B SERVO DRIVE AMP.	P
P6	660	X ENCODER OUTPUT	→T0:	X ENCODER	---
P7	670	Y ENCODER OUTPUT	→T0:	Y ENCODER	---
P8	680	Z ENCODER OUTPUT	→T0:	Z ENCODER	---
P9	690	A ENCODER OUTPUT	→T0:	A ENCODER	---
	690B	B ENCODER OUTPUT	→T0:	B ENCODER	---
P10	550	MOTIF INPUTS/ I/O OUTPUTS	→T0:	I/O PCB	P4
P11	510	I/O RELAYS 1-8	→T0:	I/O PCB	P1
P12	520	I/O RELAYS 9-16	→T0:	I/O PCB	P2
P13	530	I/O RELAYS 17-24	→T0:	I/O PCB	P51
P14	540	I/O RELAYS 25-32	→T0:	I/O PCB	P3
P15	860	LOW VOLTAGE	→T0:	POWER SUPPLY PCB	---
P16	720	SP. SPEED COMMAND	→T0:	SPINDLE DRIVE	---
P18	750	JOG INFO	→T0:	JOG HANDLE	---
P19		ADDRESS BUSS	→T0:	VIDEO PCB	---
			→T0:	MICRO PROC. PCB	---
P20	1000	SP. ENCODER OUTPUT	→T0:	SPINDLE ENCODER	---
P21	980	VOLTAGE MONITOR	→T0:	N/A	N/A
P22	730B	SP. DRIVE LOAD	→T0:	SPINDLE DRIVE	---
P24	990	HOME SENSORS	→T0:	X, Y & Z LIMIT	---




## BRUSHLESS SERVO AMPLIFIER 32-5550



## BRUSHLESS SERVO AMPLIFIER 32-5550 (REV C) CABLE CONNECTIONS

DRIVER PLUG#	CABLE #	SIGNAL NAME	→T0:	LOCATION	PLUG#
X AXIS AMP P	570	LOW VOLTAGE	→T0:	L. V. POWER SUPPLY	----
TB A, B, C	----	MOTOR DRIVE	→T0:	X SERVO MOTOR	----
P	610	X DRIVE SIGNAL	→T0:	MOCON PCB	P2
TB -HV +HV	----	320VDC	→T0:	SPINDLE DRIVE	----
Y AXIS AMP P	580	LOW VOLTAGE	→T0:	L. V. POWER SUPPLY	----
TB A, B, C	----	MOTOR DRIVE	→T0:	X SERVO MOTOR	----
P	620	X DRIVE SIGNAL	→T0:	MOCON PCB	P3
TB -HV +HV	----	320VDC	→T0:	SPINDLE DRIVE	----
Z AXIS AMP P	590	LOW VOLTAGE	→T0:	L. V. POWER SUPPLY	----
TB A, B, C	----	MOTOR DRIVE	→T0:	X SERVO MOTOR	----
P	630	X DRIVE SIGNAL	→T0:	MOCON PCB	P4
TB -HV +HV	----	320VDC	→T0:	SPINDLE DRIVE	----
A AXIS AMP P	600	LOW VOLTAGE	→T0:	L. V. POWER SUPPLY	----
TB A, B, C	----	MOTOR DRIVE	→T0:	X SERVO MOTOR	----
P	640	X DRIVE SIGNAL	→T0:	MOCON PCB	P5
TB -HV +HV	----	320VDC	→T0:	SPINDLE DRIVE	----

# CABLE LOCATION DIAGRAM





# CABLE LIST

The following is a summary of the cables used in the wiring of this control:

WIRE/

TERMINAL FUNCTION NAME:

NUMBER

GND INCOMING EARTH GROUND #8  
 -FROM INCOMING POWER GROUND  
 -TO CHASSIS GROUND  
 -TO 160 VDC RETURN  
 -TO SHIELD OF ALL BULK CABLES  
 -TO LOGIC RETURN (D GROUND 65)

L1 INCOMING 230VAC, PHASE 1, TO CB1-1 #10  
 L2 INCOMING 230VAC, PHASE 2, TO CB1-2 #10  
 L3 INCOMING 230VAC, PHASE 3, TO CB1-3 #10  
 L4 230VAC, PHASE 1, CB1 TO K1-1 #10  
 L5 230VAC, PHASE 2, CB1 TO K1-2 #10  
 L6 230VAC, PHASE 3, CB1 TO K1-3 #10

R/L7 230VAC FROM K1 TO SPINDLE DRIVE, PHASE 1 #10  
 S/L8 230VAC FROM K1 TO SPINDLE DRIVE, PHASE 2 #10  
 T/L9 230VAC FROM K1 TO SPINDLE DRIVE, PHASE 3 #10

71/L4 FUSED 230 VAC (FROM MAIN CB1-4 TO K1-1) #10  
 72/L5 FUSED 230 VAC (FROM MAIN CB1-5 TO K1-2) #10  
 73/L6 FUSED 230 VAC (FROM MAIN CB1-6 TO K1-3) #10

74/R 230 VAC (FROM MAIN CONTACTOR K1-4) #12  
 75/S 230 VAC (FROM MAIN CONTACTOR K1-5) #12  
 76/T 230 VAC (FROM MAIN CONTACTOR K1-6) #12

77 230VAC FUSED 12A TO 3 PH XFORMER T1 #12  
 78 230VAC FUSED 12A TO 3 PH XFORMER T1 #12  
 79 230VAC FUSED 12A TO 3 PH XFORMER T1 #12

80 DISTRIBUTED 160 VDC - SHIELD +2  
 81 +160 VDC HIGH VOLTAGE SUPPLY #16  
 82 160 VDC RETURN #16

90 115 VAC FROM TRANSFORMER T1  
 91/U STEPPED-DOWN 115 VAC (FROM XFRMER T1) #12  
 92/V STEPPED-DOWN 115 VAC (FROM XFRMER T1) #12  
 93/W STEPPED-DOWN 115 VAC (FROM XFRMER T1) #12

90A 115 VAC TO CRT - SHIELD +2

**CABLE LIST**

- 92 LEG 1 #16
- 93 LEG 2 #16
  
- 90B 115 VAC TO HEAT EXCHANGER - SHIELD +2
- 91 LEG 1 #16
- 93 LEG 2 #16
  
- 90C 115 VAC TO CB4 - SHIELD +2
- 91 LEG 1 #16
- 92 LEG 2 #16
  
- 100 M-FIN (IOASM TO SIDE OF BOX)
- 101 LEG 1 #16
- 102 LEG 2 #16
  
- 110 SERVO POWER CONTROL - SHIELD +2
- 111 GROUND RETURN
- 112 RELAY DRIVER SINKS 12VDC TO GROUND
  
- 120 CHIP CONVEYOR COMMAND CABLE SHIELD +4 #20  
(REMOVED IN REV J IOPCB)
  
- 130 OVERCURRENT SENSE FROM CHIP CONVEYOR  
(REMOVED IN REV J IOPCB)
  
- 140 230VAC 3PH POWER TO CHIP CONVEYOR MOTOR (5 +SHIELD)
- 141 PHASE A 230VAC
- 142 PHASE B 230VAC
- 143 PHASE C 230VAC
- 144 STARTING WINDING 230VAC
- 145 STARTING WINDING 230VAC
  
- 140A 230VAC 3PH POWER IN CONDUIT TO CHIP CONVEYOR
  
- 150 12VDC TO CHIP CONVEYOR CONTROL PCB  
(REMOVED IN REV J IOPCB)
  
- 160 3PH 230VAC TO CHIP CONVEYOR CONTROLLER
- 161 PHASE A 230VAC
- 162 PHASE B 230VAC
- 163 PHASE C 230VAC
  
- 170 AUTO OFF FUNCTION - SHIELD +2
- 172 RELAY 1-7 COMMON (C7) ; AUTO OFF
- 173 RELAY 1-7 N.O.
  
- 180 COOLANT SPIGOT DETENT SWITCH
- 181 SIGNAL
- 182 COMMON
  
- 190 UNCLAMP FROM SPINDLE HEAD TO IOASM

- 191 INPUT 25
- 192 DIGITAL RETURN
  
- 200 COOLANT SPIGOT MOTOR (12VDC)
- 201 MOTOR +
- 202 MOTOR -
  
- 210 DATA CABLE TO 3" FLOPPY DISK DRIVE (40 PINS)
  
- 220 SERVO BRAKE 115VAC - SHIELD +2
- 221 115VAC COMMON
- 222 115VAC SWITCHED
  
- 230 5'th AXIS BRAKE - SHIELD +2
- 231 115VAC COMMON
- 232 115VAC SWITCHED
  
- 240 SPARE INPUTS FROM IOPCB P25
- 241 COMMON
- 242 SPARE 3
- 243 SPARE 4
  
- 250 HORIZONTAL TOOL CHANGER SHUTTLE VALVE - SHIELD +2
- 251 COMMON 115VAC
- 252 SWITCHED 115VAC
  
- 260 K210 CABLING FOR EC
  
- 270 K111 CABLING FOR EC
  
- 280 RED/GREEN STATUS LIGHT WIRING
- 281 RED LAMP 115VAC
- 282 GREEN LAMP 115VAC
- 283 COMMON 115VAC
  
- 290 230VAC TO TRANSFORMER T2 (deleted 1-Aug-90)
  
- 300 115VAC TO SPINDLE MOTOR FAN/OIL PUMP/OILER
- 301 LEG 1 115VAC FUSED AT 3 A #18
- 302 LEG 2 115VAC FUSED AT 3 A #18
  
- 310 SOLENOIDS OUTPUT TO HORIZONTAL PALLET CHANGER
- 311 115VAC COMMON
- 312 UNSCREW
- 313 SCREW
- 314 DB DOWN
- 315 PALLET UP
- 316 PALLET CW
- 317 PALLET CCW
  
- 320 SWITCH INPUTS FROM HORIZONTAL PALLET CHANGER

**CABLE LIST**

- 321 SWITCHES COMMON
- 322 DB DOWN
- 323 PALLET UP
- 324 PALLET DOWN
- 325 PALLET CW
- 326 PALLET CCW
- 327 SCREW IN \*
- 328 FIXTURE CLAMPED \*
  
- 330 230V 3PH FROM CB6 TO K2 (LATHE HYDRAULICS)
- 331
- 332
- 333
  
- 340 230V 3PH FROM K2 TO HYDRAULIC PUMP (LATHE)
- 341
- 342
- 343
  
- 350 SERVO BRAKE RELEASE 115VAC - SHIELD +2
- 351 LEG 1 COMMON
- 352 LEG 2 SWITCHED
  
- 360-389 RESERVED
  
- 390 115VAC TO 4'TH AXIS BRAKE (LATHE PART DOOR) - SHIELD +2
- 391 LEG 1 #18
- 392 LEG 2 SWITCHED #18
  
- 400 SPINDLE DRIVE COAST COMMAND - SHIELD +2
- 401 LOGIC COMMON #20
- 402 SPINDLE COAST COMMAND #20
  
- 410-483 reserved
  
- 490 ALL WIRES CARRYING SERVO MOTOR DRIVE POWER (all #14)
- 491 X-AXIS FUSED MOTOR POWER + (P1-E)
- 492 X-AXIS FUSED MOTOR POWER - (P1-F)
- 493 Y-AXIS FUSED MOTOR POWER + (P2-E) (LATHE T.S)
- 494 Y-AXIS FUSED MOTOR POWER - (P2-F) (LATHE T.S)
- 495 Z-AXIS FUSED MOTOR POWER + (P3-E)
- 496 Z-AXIS FUSED MOTOR POWER - (P3-F)
- 497 A-AXIS FUSED MOTOR POWER + (P4-E)
- 498 A-AXIS FUSED MOTOR POWER - (P4-F)
  
- 500 OVERTEMP SENSOR FROM SPINDLE MOTOR - SHIELD +2
- 501 OVERTEMP WIRE 1 #20 (N.C.)
- 502 OVERTEMP WIRE 2 #20
  
- 510 RELAY CARD 1 DRIVE CABLE - 16 WIRE RIBBON #24

- 520 RELAY CARD 2 DRIVE CABLE - 16 WIRE RIBBON #24
- 530 RELAY CARD 3 DRIVE CABLE - 16 WIRE RIBBON #24
- 540 RELAY CARD 4 DRIVE CABLE - 16 WIRE RIBBON #24
- 550 INPUTS CARD CABLE (MOTIF-P10) 34 WIRE RIBBON #24
- 560 TO MICROPROCESSOR P8 (REMOVED NOV-94)
- 561 -12V FROM 862 AT SUPPLY TO P8-1 #24
- 562 Gnd FROM 865 AT SUPPLY TO P8-4 #24
- 570 X AXIS DRIVER LOW VOLTAGE POWER - 6 WIRE RIBBON
- 571 14 VAC LEG 1 (DRIVER P2-1) #24
- 572 14 VAC LEG 2 (DRIVER P2-2) #24
- 573 16 VAC LEG 1 (DRIVER P2-3) #24
- 574 16 VAC LEG 2 (DRIVER P2-4) #24
- 575 CHASSIS GROUND (DRIVER P2-5) #24
- 576 CHASSIS GROUND (DRIVER P2-6) #24
- 580 Y AXIS DRIVER LOW VOLTAGE POWER (LATHE T.S)  
(SAME AS 571 to 576)
- 590 Z AXIS DRIVER LOW VOLTAGE POWER  
(SAME AS 571 to 576)
- 600 A AXIS DRIVER LOW VOLTAGE POWER  
(SAME AS 571 to 576)
- 610 X AXIS DRIVER CONTROL CABLE - SHIELD +6
- 611 LOW ENABLE\* (MOTIF P2-1) #24
- 612 HIGH ENABLE\* (MOTIF P2-2) #24
- 613 DRIVE DIRECTION (MOTIF P2-3) #24
- 614 +5 VDC (MOTIF P2-4) #24
- 615 OVERCURRENT SIGNAL (MOTIF P2-5) #24
- 616 LOGIC RETURN (MOTIF P2-6) #24
- 620 Y AXIS DRIVER CONTROL CABLE - SHIELD +6 (LATHE T.S)  
(SAME AS 611-616)
- 630 Z AXIS DRIVER CONTROL CABLE - SHIELD +6  
(SAME AS 611-616)
- 640 A AXIS DRIVER CONTROL CABLE - SHIELD +6  
(SAME AS 611-616)
- 650 THREE PHASE POWER TO SPINDLE MOTOR - SHIELD +3
- 651 LEG 1 OF 230VAC #14
- 652 LEG 2 #14
- 653 LEG 3 #14



## CABLE LIST

- 660 X-ENCODER CABLE - SHIELD +7
- 661 LOGIC RETURN (D GROUND) #24
- 662 ENCODER A CHANNEL #24
- 663 ENCODER B CHANNEL #24
- 664 +5 VDC #24
- 665 ENCODER Z CHANNEL #24
- 666 HOME/LIMIT SW #24
- 667 OVERHEAT SWITCH #24
- 668 ENCODER A\*
- 669 ENCODER B\*
- 66T ENCODER Z\*
  
- 670 Y-ENCODER CABLE - SHIELD +7 (LATHE SPINDLE ENCODER)  
(SAME AS 661-66T)
  
- 680 Z-ENCODER CABLE - SHIELD +7  
(SAME AS 661-66T)
  
- 690 A-ENCODER CABLE - SHIELD +7  
(SAME AS 661-66T)
  
- 700 KEYBOARD CABLE - 34 WIRE RIBBON WITH IDC  
(FROM VIDEO P4 TO KBIF P1)
  
- 710 FORWARD/REVERSE/RESET TO SPINDLE - SHIELD +4
- 711 FORWARD COMMAND (SP DR CN1-18 TO IO P9-4) #24
- 712 REVERSE COMMAND (CN1-19 TO IO P9-3) #24
- 713 RESET COMMAND (CN1-21 TO IO P9-2) #24
- 714 COMMON (CN1-14 TO IO P9-1) #24
  
- 720 ANALOG SPEED COMMAND TO SPINDLE - SHIELD +2
- 721 0 TO +10 VOLTS SPEED COMMAND (SPINDLE DRIVE CN1-1) #24
- 722 SPEED COMMAND REFERENCE (A GROUND) (CN1-17) #24
  
- 730 POWER METER FROM SPINDLE DRIVE TO KBIF - SHIELD +2
- 731 METER + (SPINDLE DRIVE CN1-5 TO KBIF) #24
- 732 METER - (CN1-6 TO KBIF) #24
  
- 730A POWER METER FROM KBIF TO METER - SHIELD +2
- 733 METER + AFTER TRIM POT (KBIF TO METER) #24
- 734 METER - AFTER TRIM POT (KBIF TO METER) #24
  
- 730B ANALOG SIGNAL FROM SPINDLE DRIVE LOAD MONITOR
- 731 SIGNAL 0..5V
- 732 GROUND
  
- 740 POWER ON/OFF CABLE TO FRONT PANEL - SHIELD +4
- 741 POWER ON SWITCH LEG 1 (24 VAC) #24
- 742 POWER ON SWITCH LEG 2 #24 N.O.
- 743 POWER OFF SWITCH LEG 1 (24 VAC) #24

- 744 POWER OFF SWITCH LEG 2 #24 N.C.
  
- 750 JOG-CRANK DATA CABLE - SHIELD +4
- 751 LOGIC RETURN (D GROUND) (65) #24
- 752 ENCODER A CHANNEL #24
- 753 ENCODER B CHANNEL #24
- 754 +5 VDC #24
  
- 760 MONITOR VIDEO DATA CABLE - SHIELD +9 (all #24)  
(FROM VIDEO P3 TO CRT)
  
- 770 EMERGENCY STOP INPUT CABLE - SHIELD +2
- 771 SIGNAL (INPUT 8) #20
- 772 RETURN (D GROUND) (65) #20
  
- 770A SECOND E-STOP INPUT FOR HORIZONTAL
  
- 780 STATUS CABLE FROM SPINDLE DRIVE - SHIELD +4
- 781 +12 VDC (SPINDLE DRIVE CN1-25) #24
- 782 FAULT (INPUT 18 TO CN1-24) #24
- 783 AT SPEED (INPUT 20 TO CN1-23) #24
- 784 STOPPED (INPUT 19 TO CN1-22) #24
  
- 790 SPARE INPUTS FROM IOPCB P24
- 791 SPARE 1
- 792 SPARE 2
- 793 COMMON
  
- 800 12VAC TO LAMP - SHIELD +2
- 801 UNSWITCHED LEG 1 #20
- 802 SWITCHED LEG 2 #20
  
- 800A CABLE FOR LAMP SWITCH - SHIELD +2
  
- 800B CABLE WITH 10VAC FROM TRANSFORMER T2 - SHIELD +2
  
- 810 TOOL CHANGER MOTORS - SHIELD +2 #20
- 811 TURRET MOTOR + (IO P30-2 TO P6-J) #14
- 812 TURRET MOTOR - (IO P30-1 TO P6-I) #14
  
- 810A TOOL CHANGER MOTORS - SHIELD +2 #20
- 813 SHUTTLE MOTOR - (IO P30-4 TO P6-A) #14
- 814 SHUTTLE MOTOR + (IO P30-3 TO P6-B) #14
  
- 820 TOOL CHANGER STATUS - SHIELD +7
- 821 LOGIC RETURN (D GROUND) (P6-F/H/L/M) #24
- 822 GENEVA MARK (INPUT 5 TO P6-G) #24 (LATHE PART DOOR)
- 823 TOOL #1 (INPUT 3 TO P6-E) #24
- 824 SHUTTLE IN (INPUT 1 TO P6-C) #24 (LATHE TURRET CLAMPED)
- 825 SHUTTLE OUT (INPUT 2 TO P6-D) #24 (LATHE TURRET UNCLAMPED)

**CABLE LIST**

- 830 OVERHEAT THERMOSTAT - SHIELD +2
- 831 OVERHEAT SIGNAL (INPUT 14) #20
- 832 OVERHEAT RETURN (D GROUND) (65) #20
  
- 840 CIRCUIT BREAKER FOR 160 VDC - SHIELD +2
- 841 LEG 1 (TO 81) #14
- 842 LEG 2 #14
  
- 850 SERIAL PORT #1 INTERFACE CABLE (16 WIRE RIBBON #24)
  
- 850A SERIAL PORT #2 INTERFACE CABLE (16 WIRE RIBBON #24)
  
- 860 +12V/+5V/Gnd POWER CABLES - 4 WIRE (all #18)
- 861 +12 VOLTS
- 862 -12 VOLTS FROM LOW V SUPPLY TO 68020 PCB
- 863 +5 VOLTS
- 864 -5 VOLTS
- 865 LOGIC POWER RETURN (D GROUND)
- 866 POWER GOOD SIGNAL FROM SUPPLY
  
- 860A 12 VOLT POWER TO IOPCB - SHIELD +2
- 861 +12 VOLTS
- 865 LOGIC POWER RETURN (D GROUND)
  
- 860B +5 POWER TO 3" FLOPPY DRIVE
  
- 860C +5,+12,-12 POWER TO 68030
  
- 870 115VAC TO OILER - SHIELD +2
- 871 115VAC LEG 1 #18
- 872 115VAC LEG 2 #18
  
- 880A HIGH/LOW GEAR UNCLAMP/LOCK SOLENOID POWER - SHIELD +6
- 881 115 VAC SOLENOID COMMON (IO P12-5) #18
- 882 HIGH GEAR SOLENOID (IO P12-4) #18
- 883 LOW GEAR SOLENOID (IO P12-3) #18
- 884 TOOL UNCLAMP SOLENOID (IO P12-2) #18
- 885 SPINDLE LOCK SOLENOID (IO P12-1) #18
- 886 PRE-CHARGE SOLENOID #18 (IO P12-7)
  
- 880B TRANSMISSION HIGH/LOW GEAR SOLENOIDS FOR LATHE
- 881 115 VAC SOLENOID COMMON (IO P12-5) #18
- 882 HIGH GEAR SOLENOID (IO P12-4) #18
- 883 LOW GEAR SOLENOID (IO P12-3) #18
  
- 890 SPINDLE STATUS SWITCHES SHIELD +6
- 891 SIGNAL RETURN (D GROUND) (65) #24
- 892 HIGH GEAR (INPUT 6) #24
- 893 LOW GEAR (INPUT 7) #24
- 894 TOOL UNCLAMPED (INPUT 15) #24
- 895 TOOL CLAMPED (INPUT 16) #24


- 896 SPINDLE LOCKED (INPUT 17) #24
  
- 900 LOW COOLANT STATUS - SHIELD +2
- 901 LOW COOLANT SIGNAL (INPUT 4 TO P7-C) #20
- 902 LOW COOLANT RETURN (D GROUND) (65 TO P7-D) #20
  
- 910 115 VAC CIRCUIT BREAKER TO SOLENOIDS - SHIELD +2
- 911 LEG 1 #18
- 912 LEG 2 #18
  
- 920 REGENERATIVE LOAD RESISTOR FOR SERVO - SHIELD +2
- 921 LEG 1 #18
- 922 LEG 2 #18
  
- 930 FUSED 230 VAC FOR COOLANT PUMP - SHIELD +2
- 931 LEG 1 #14
- 932 LEG 2 #14
  
- 940 230 VAC TO COOLANT PUMP - SHIELD +2
- 941 LEG 1 (P7-A) #14
- 942 LEG 2 (P7-F) #14
  
- 950 LOW AIR PRESSURE SENSOR - SHIELD +3
- 951 LOW AIR SIGNAL (INPUT 12) #20
- 952 LOW AIR/OIL RETURN (D GROUND) (65) #20
- 953 LOW OIL PRESSURE SWITCH FOR VERTICAL TRANSMISSION #20
  
- 950A LOW HYDRAULIC PRESSURE SWITCH FOR LATHE - SHIELD +2
- 952 LOW HYDRAULIC RETURN (D GROUND) (65) #20
- 953 LOW HYD PRESSURE SWITCH FOR VERTICAL TRANSMISSION #20
  
- 960 LOW LUB/DOOR OPEN SENSORS - SHIELD +4
- 961 LOW LUB SIGNAL (INPUT 13) #24
- 962 LOW LUB RETURN (D GROUND) (65) #24
- 963 DOOR OPEN SIGNAL (INPUT 9) #24 (OBSOLETE OPTION)
- 964 DOOR OPEN RETURN (D GROUND) (65) #24 (OBSOLETE OPTION)
  
- 970 LOW VOLTAGE SENSOR - SHIELD +2
- 971 LOW VOL SIGNAL (INPUT 11 FROM PMON P9-3) #24
- 972 LOW VOL RETURN (D GROUND) (PMON P9-4) #24
  
- 980 VOLTAGE MONITOR - SHIELD +2
- 981 VOLTAGE MONITOR 0 TO +5 (PMON P9-1 / MOTIF P17-1) #24
- 982 VOLTAGE MON RET (A GND) (PMON P9-2 / MOTIF P17-2) #24
  
- 990 HOME SENSORS - SHIELD +4
- 991 X HOME SWITCH (MOTIF P24-2 TO P5-B) #24
- 992 Y HOME SWITCH (MOTIF P24-3 TO P5-D) #24 (LATHE TAIL STOCK)
- 993 Z HOME SWITCH (MOTIF P24-4 TO P5-L) #24
- 994 HOME SWITCH RETURN (MOTIF P24-1 TO P5-C) #24

**CABLE LIST**

- 1000 SPINDLE ENCODER CABLE - SHIELD +5 (LATHE TAIL STOCK)
- 1001 LOGIC RETURN (D GROUND) (TO MOTIF P20-1) #24
- 1002 ENCODER A CHANNEL (TO MOTIF P20-2) #24
- 1003 ENCODER B CHANNEL (TO MOTIF P20-3) #24
- 1004 +5 VDC (TO MOTIF P20-4) #24
- 1005 ENCODER Z CHANNEL (TO MOTIF P20-5) #24
  
- 1010 KEYBOARD INPUTS FROM HORIZONTAL OPERATOR PANEL
- 1011 CYCLE START
- 1012 CYCLE START
- 1013 FEED HOLD
- 1014 FEED HOLD
- 1015 PART READY
- 1016 FIXTURE ROTATE
- 1017 PART RDY/FIX ROT COMMON
  
- 1020 SPINDLE TEMPERATURE SENSOR CABLE - SHIELD +3
- 1021 SIGNAL
- 1022 ANALOG RETURN
- 1023 +5 VOLTS TO SENSOR
- 1024 SHIELD GROUND
  
- 1030 SPINDLE LOAD RESISTOR - SHIELD +2
- 1031 REGEN LOAD RESISTOR FOR SPINDLE DRIVE (B1) #18
- 1032 REGEN LOAD RESISTOR FOR SPINDLE DRIVE (B2) #18
  
- 1040 Y160 (MIKRON DOOR LOCK OR HORIZONTAL PART READY LAMP)
- 1041 SWITCHED RELAY CONTACT
- 1042 SWITCHED RELAY CONTACT
  
- 1050 DOOR SWITCH WIRING THRU SUPPORT ARM - SHIELD +2
- 1051 DOOR OPEN SIGNAL (INPUT 9) #24
- 1052 DOOR OPEN RETURN (D GROUND) (65) #24
  
- 1060 GROUND FAULT DETECTION SENSE INPUT
- 1061 + INPUT FROM SENSE RESISTOR
- 1062 - INPUT FROM SENSE RESISTOR
  
- 1070 SKIP INPUT FROM SENSOR - SHIELD +2
- 1071 LOGIC COMMON
- 1072 SKIP SIGNAL


# **LATHE**

## **ASSEMBLY DRAWINGS**



- 1 - 20-9095 - BUMPER
- 2 - 20-9096 - BUMPER
- 3 - 25-7042 - COVER PLATE, LEAD SCREW


## X-AXIS LEADSCREW ASSEMBLY



- 1 - 20-9057 - BUMPER
- 2 - 20-9058 - BUMPER
- 3 - 25-7042 - COVER PLATE, LEAD SCREW


## Y-AXIS LEADSCREW ASSEMBLY






- 1 - 3D-1210 - LEAD SCREW ASSEMBLY
- 2 - 3D-8717 - OIL LINE ASSEMBLY
- 3 - 32-1600 - Y AXIS MOTOR ASSEMBLY
- 4 - 32-2040 - TELEMECHANIQUE SWITCH /

### HL-2 BASE ASSEMBLY




- 1 - 30-1230 - LEAD SCREW ASSEMBLY, TAILSTOCK
- 2 - 32-1700 - Z AXIS MOTOR ASSEMBLY
- 3 - 30-2042 - TELEMECHANIQUE SYNCH ASSEMBLY

### HL-2 BASE ASSEMBLY (SIDE VIEW)




- 1 - 30-1710 - LEAD SCREW ASSEMBLY
- 2 - 30-8717 - Z AXIS LUBRICATION LINE ASSEMBLY
- 3 - 32-1800 - Y AXIS MOTOR ASSEMBLY
- 4 - 32-2031 - TELEMECHANIQUE SWITCH ASSEMBLY

### HL-1 BASE ASSEMBLY (TOP VIEW)




- 1 - 30-1290P - LEAD SCREW ASSEMBLY
- 2 - 30-8716 - WEDGE LUBRICATION SYSTEM
- 3 - 32-1600 - Y AXIS MOTOR ASSEMBLY
- 4 - 32-2051 - TELEMECHANIQUE SWITCH ASSEMBLY

## **HL-1 BASE ASSEMBLY (SIDE VIEW)**




## SPINDLE ASSEMBLY



- 1 - 30-3630 - SPINDLE ASSEMBLY  
2 - 30-3640 - SPINDLE MOTOR ASSEMBLY

## SPINDLE MOTOR



- 1 - 30-1220P - COUPLING ASSEMBLY
- 2 - 32-1308 - TURRET MOTOR ASSEMBLY
- 3 - 32-2010 - TELEMECHANIQUE SWITCH ASSEMBLY
- 4 - 32-2051 - TELEMECHANIQUE SWITCH ASSEMBLY

## TURRET HOUSING