

STATYS

Ethernet Connection

ENICOM Operating manual 



INDEX

1. PRESENTATION	3
1. 1. INTRODUCTION	3
1. 2. TOOLS AND SOFTWARE	3
1. 3. NETWORK CONNECTION	3
2. IP ADDRESS CONFIGURATION	4
2. 1. ENIFINDER	4
2. 2. ENIFINDER INSTALLATION	4
2. 3. IP SETTINGS	5
3. WEB PAGES	6
3. 1. OVERVIEW	6
3. 2. LOGO BAR	6
3. 3. TOP BAR	6
3. 4. MENU	8
3. 5. SYNOPTIC	8
3. 6. NETWORK CONFIGURATION	12
3. 7. SNMP	13
3. 8. SMTP CONFIGURATION	16
3. 9. EMAIL CONFIGURATION	17
3. 10. TEXTS INPUT	17
3. 11. ADMIN	18
4. STATYS DATA BASE	19
4. 1. STATE : ADDRESS MODBUS 0x0140 - 3 WORDS	19
4. 2. ALARM : ADDRESS MODBUS 0x0148 - 3 WORDS	20
4. 3. MEASUREMENT - ADDRESS MODBUS 0x0220 - 64 WORDS	20
5. FIRMWARE UPDATE	22
5. 1. UPDATE BOTH (FW + CONFIG)	22
5. 2. UPLOAD CONFIG FILES	22
6. VERIFICATION DES LED ENICOM	22

1. PRESENTATION

1. 1. INTRODUCTION

This document describes the configuration and the function of the Ethernet connection for STATYS range.

Functions available:

- MODBUS TCP
- SNMP agent
- E-mail
- Remote monitoring via embedded Web server

1. 2. TOOLS AND SOFTWARE

The configuration is done via a PC running under WINDOWS. A specific tool (ENIFinder.exe) needs to be copied to the computer.

The PC should be connected to the same Network as STATYS. It's also possible to use an Ethernet cross and point to point cable, for commissioning.

1. 3. NETWORK CONNECTION

The RJ45 connector is located on the front of STATYS's panel. For cabinet, it's necessary to open the door, to access on the connector.



2. IP ADDRESS CONFIGURATION

DHCP service is enabled as default configuration.


2. 1. ENIFINDER

This tool is used to configure the TCP IP network parameters, to upload firmware, and configuration files. It detects automatically all STATYS connected on Network.


2. 2. ENIFINDER INSTALLATION

Copy the entire ENICOM directory on a local WINDOWS PC. Installation procedure is not needed.

Local ENICOM directory contains (example):



After running ENIFinder.exe program, the main window is displaying:



Example of a Statys Network


STATYS detected on the network are automatically displayed in the window.

Double-clicking a row opens the web page for the corresponding STATYS.

2. 3. IP SETTINGS

Select  to change network parameters.

Select DHCP or set fixed IP Address, mask and gateway if necessary.



Set IP Address



Assign an IP Address, subnet mask and gateway to your device. Contact your network administrator if you do not know this information.

Product : STS RACK 1
MAC Address : 00:40:9D:39:C6:D7

☐ Automatically obtain network setting via DHCP
☒ **Manually configure network setting**

IP Address: 172._23._16.180
Subnet Mask: 255.255._0._0
Default Gateway: 172._23._13._1

Status: Ready

 ENIFinder sends these new parameters, ENICOM reboots automatically.


=> wait for 1 minute

=> the list of connected STATYS will be updated with New parameters.


3. WEB PAGES

3. 1. OVERVIEW

The Statys interface is accessible via a web browser (Internet Explorer, Firefox) by informing the corresponding IP address



3. 2. LOGO BAR



3. 3. TOP BAR




3. 3.1. Information

Give information about this Statys.

Exemple

> STS REFERENCE	
Identification :	STS RACK 1
Description :	STATYS MONO
Serial Number :	0920348001
Nominal Amps :	63
SW Version :	E503915D 151209a

3. 3.2. Window alarms



The list is updated automatically every 10 seconds. It is available only if the button “alarm” is present.

3. 3.3. STATYS status bar

COLOUR	CONDITION
GREEN	on preferred source
YELLOW	on auxiliary source
	on bypass maintenance 1 or 2
RED	Load not supplied
	arrest imminent
GRAY	undefined


3. 3.4. Mode

MODE	DISPLAYED TEXTS
Normal	normal
Maintenance	Service

3. 3.5. Current supplied


Displays the output STATYS current measuring (Max of 3 phases).

3. 4. MENU
















3. 5. SYNOPTIC MENU

Back to the synoptic display.



3. 5.1. Animation of synoptic

SYMBOL	CONDITION
Priority Source 	Positioned next to the priority source (1 or 2)
Input 1 	Gray = no network Blue = network present
CS1 	White = not conducting Green = conducting Yellow = conducting and on fault
Output CS1 	Gray = CS1 not conducting Blue = CS1 conducting
Output 	Q3 closed and a CS lead
Load 	Indicates the loading rate: 120% - yellow 110% - yellow 100% .. 30%
Input 2 	Gray = no network Blue = network present
CS2 	White = not conducting Green = conducting Yellow = conducting and on fault
Output CS2 	Gray = CS2 not conducting Blue = CS2 conducting
	Impossible transfer
	Sources Synchronous
	Sources sliding
	On maintenance bypass (1 or 2)

3. 5.2. Data Page

STATYS status page: active states and current measures

Accessible via the button "Status Bar" in the "Space Bar"

ON PREFERRED

S STATUS AND MEASUREMENTS		
STATES	MEASUREMENTS	
Source 1 Absent	Output voltage L1 (V)	231
PowerPath 1 OK	Output voltage L2 (V)	0
Source 2 OK	Output voltage L3 (V)	0
PowerPath 2 OK	Output voltage U12 (V)	0
Srcs perm. Not Synchron.	Output voltage U23 (V)	0
On Preferred Source	Output voltage U31 (V)	0
On S2	Output frequency (Hz)	49.9
Output OK	Output current I1 (A)	0
Q42 closed	Output current I2 (A)	0
Q43 closed	Output current I3 (A)	0
Q44 closed	Output current IN (A)	0
mode	Output load rate (%)	0
	Output Apparent P. L1 (kVA)	0
	Output Apparent P. L2 (kVA)	0
	Output Apparent P. L3 (kVA)	0
	Output load rate L1 (%)	0
	Output load rate L2 (%)	0
	Output load rate L3 (%)	0

CS 1 Page



Accessible by clicking on the symbol of CS1

> S1 STATUS AND MEASUREMENTS		
STATES	ALARMS	MEASUREMENTS
Source 1 Absent		S1 voltage L1N (V) 0
PowerPath 1 OK		S1 voltage L2N (V) 0
Srcs perm. Not Synchron.		S1 voltage L3N (V) 0
		S1 voltage U12 (V) 0
		S1 voltage U23 (V) 0
		S1 voltage U31 (V) 0
		S1 frequency (Hz) 0.0
		SS1 temperature (°C) 21
		S1-S2 phase shift (°) 0.0

CS 2 Page



Accessible by clicking on the symbol of CS2

> S2 STATUS AND MEASUREMENTS		
STATES	ALARMS	MEASUREMENTS
Source 2 OK		S2 voltage L1 (V) 230
PowerPath 2 OK		S2 voltage L2 (V) 0
Srcs perm. Not Synchron.		S2 voltage L3 (V) 0
Q42 closed		S2 voltage U12 (V) 0
SS2 closed		S2 voltage U23 (V) 0
		S2 voltage U31 (V) 0
		S2 frequency (Hz) 49.9
		SS2 temperature (°C) 21
		S1-S2 phase shift (°) 0.0

Output page

Accessible by clicking the exit of the STATYS



> OUTPUT STATUS AND MEASUREMENTS

STATES

Load on Preferred Source
Load on S2
Output OK
Q30 closed

ALARMS

Transfer Impossible

MEASUREMENTS

Output voltage L1 (V)	231
Output voltage L2 (V)	0
Output voltage L3 (V)	0
Output voltage U12 (V)	0
Output voltage U23 (V)	0
Output voltage U31 (V)	0
Output frequency (Hz)	49.9
Output current I1 (A)	0
Output current I2 (A)	0
Output current I3 (A)	0
Output current IN (A)	0
Output load rate (%)	0
Output Apparent P. L1 (kVA)	0
Output Apparent P. L2 (kVA)	0
Output Apparent P. L3 (kVA)	0
Output Power factor L1	0.00
Output Power factor L2	0.00
Output Power factor L3	0.00
Output crest factor L1	0.0
Output crest factor L2	0.0
Output crest factor L3	0.0
Output crest factor N	0.0
Ambient temperature (°C)	32
Output Active Power L1 (kW)	0
Output Active Power L2 (kW)	0
Output Active Power L3 (kW)	0
Output load rate L1 (%)	0
Output load rate L2 (%)	0
Output load rate L3 (%)	0
Output load rate N (%)	0



In the case of a STATYS phase, measurements of phases 2 and 3 are 0

3. 6. NETWORK CONFIGURATION MENU

3. 6.1. Password Protection




Default login: **admin**


Password default: **public**

Each configuration page is protected by password
The password is stored throughout the session

3. 6.2. Network Configuration

Used to activate the DHCP or assign a static IP

Click to  save the configuration



The screenshot displays the Socomec web interface for 'STS RACK 1'. The header includes the Socomec logo and the tagline 'Innovative Power Solutions'. A navigation menu on the left lists various configuration options: SYNOPSIS, NETWORK CONFIG. (selected), SNMP AGENT, EMAIL SETTINGS, SMTP CONFIG, AUX INPUTS TEXTES, ADIBOX, and ADMIN. The main content area is titled '> NETWORK CONFIGURATION'. It features a status bar at the top with 'STS', an information icon, a warning icon, and a green 'ON PREFERRED' button, followed by 'Normal' and '0 A' buttons. Below this, the DHCP status is set to 'Enabled' via a dropdown menu. The IP Address is '168.192.7.18', Subnet Mask is '255.255.0.0', Gateway Address is '0.0.0.0', and MAC Address is '00:40:9D:36:A5:28'. A 'Submit' button is located at the bottom of the configuration fields.

3. 7. SNMP MENU

3. 7.1. Configuration

STS Rack 1

SYNOPSIS
NETWORK CONFIG.
SNMP AGENT
EMAIL SETTINGS
SMTP CONFIG
AUX. INPUTS TEXTES
ADIBOX
ADMIN

STS **ON PREFERRED** Normal 0 A

> SNMP ACCESS CONTROL

SNMP Support : v1 Download MIB file

1

5

3

Index	IP Sink Address	Description	Trap
1	172.23.21.245	SHOW ROOM	Yes
2			No
3			No
4			No
5			No
6			No
7			No
8			No

2

4

Submit

- 1 Select version: V1 only
- 2 Enabling or disabling the function of TRAP: if the TRAP function is disabled, reading the OID via the GET function is activated
- 3 NMS IP Addresses: put the IP address of the NMS

Community



Public - read by default. No configuration possible


4

Save the settings by clicking: **Submit**

3. 7.2. MIB download

5

Click the button **Download MIB file** to reload the MIB file:



3. 7.3. List of OIDs of the MIB STATYS

STATYS Identification	STATYS INFORMATION (§ DATA BASE)
stsIdentModel	
stsIdentSerialNumber	
stsIdentFirmwareVersion	
stsIdentAgentSoftwareVersion	
STATYS Source 1	
stsSource1Status	
unknown(1),	
source1OK(2),	S000
source1Critical(3),	S001
source1OutTol(4),	S002
source1Absent(5)	S003
stsSource1Preferred	
no(1),	
yes(2)	S016
stsSource1Frequency	M006
stsSource1Voltage	M000 - M002
STATYS Source 2	
stsSource2Status	
unknown(1),	
source2OK(2),	S006
source2Critical(3),	S007
source2OutTol(4),	S008
source2Absent(5)	S009
stsSource2Preferred	
no(1),	
yes(2)	!S016
stsSource2Frequency	M014
stsSource2Voltage	M008 - M009 - M010
STATYS Sources Interaction	
stsSourcesInteraction	
unknown(1),	
synchron(2),	S012
sliding(3),	S013
asynchron(4)	S014

STATYS Output			
stsOutputLoadStatus			
unknown(1),			
outputLoadOnPreferredSource(2),			S017
outputLoadOnAlternateSource(3),			S018
outputLoadOFF(4),			S019
outputLoadOnMBP1(5),			S020
outputLoadOnMBP2(6)			S021
stsOutputStatus			
unknown(1),			
outputOnSwitch1(2),			S023
outputOnSwitch2(3),			S024
outputOFF(4)			!S023 & !S024
stsOutputFrequency			M022
stsOutputLoadRate			M029
stsOutputVoltage			M016 - M017 - M018
stsOutputCurrent			M024 - M025 - M026
stsOutputkVA			M032 - M033 - M034
stsOutputkW			M048 - M049 - M050
stsOutputCrestFactor			M040 - M041 - M042
stsOutputPowerFactor			M035 - M036 - M037
STATYS Alarms / Alerts			
stsImminentStop	no (1)	yes (2)	A000
stsTransferImpossible	no (1)	yes (2)	A007
stsConsecutiveDetection	no (1)	yes (2)	A005
stsOverload	no (1)	yes (2)	A003
stsString1Alarm	no (1)	yes (2)	A011
stsString2Alarm	no (1)	yes (2)	A015
stsPreventiveMaintenance	no (1)	yes (2)	S046
stsGeneralAlarm	no (1)	yes (2)	A031
stsCustomInputAlarm	no (1)	yes (2)	A029

3. 7.4. SNMP TRAPS (TRAPS management)

LISTE DES TRAPS	STATYS INFORMATION (§ DATA BASE)
stsTrapImminentStop	A000
stsTrapOverload	A003
stsTrapSwitchOnPreferredSource	S017
stsTrapSwitchOnAlternateSource	S018
stsTrapSource1PreferredSource	S016
stsTrapOutputLoadOFF	S019
stsTrapGeneralAlarm	A031
NormalSituation	

3. 8. SMTP CONFIGURATION MENU

The e-mails are only sent if the SMTP server has been configured in advance.

The screenshot displays the Socomec web interface for 'STS RACK 1'. The left sidebar contains a menu with options: SYNOPSIS, NETWORK CONFIG., SNMP AGENT, EMAIL SETTINGS, SMTP CONFIG (highlighted), AUX INPUTS TEXTES, ADIBOX, and ADMIN. The main content area shows the 'SMTP CONFIGURATION' settings. At the top, there are status indicators: 'STS' with an information icon, a warning icon, a green 'ON PREFERRED' button, and 'Normal' and '0 A' labels. The configuration fields are numbered 1 through 4: 1. eMail Server Address: 172.23.14.82; 2. SMTP Port: 25; 3. eMail Account: 16A MONO STS; 4. SMTP Authentication: Disabled (dropdown menu). An 'Account Password' field is also present but empty. A 'Submit' button is located at the bottom left of the configuration area.

- 1 The IP address of mail server
- 2 Port number to 25 by default (modifiable)
- 3 Identifies the sender of the mail
- 4 Required based on the mail server used

3. 9. EMAIL CONFIGURATION MENU

- 1 Selected events will trigger the sending of mail.
- 2 Tempo in which events must be active to generate the sending of email.
- 3 Interval in hours of rehearsal for sending email if the event or events are always enabled
- 4 Up to 8 addresses. (field description is given only by way of info, it is not transmitted with the message)
- 5 Free text (in the body of the message)
- 6 Save the configuration by clicking **Submit**
- 7 Sending a test email




Configuration must be saved the before you can send a test email

3. 10. TEXTS INPUT MENU

This feature is only available if the graphics screen is present on STATYS.
It allows assigning texts to the auxiliary input if the cards I/O (ADC) are installed


3. 11. ADMIN MENU

3. 11.1. Managing password



The screenshot shows the Socomec web interface. The top header features the Socomec logo and the text "Innovative Power Solutions" on the left, and "STS RACK 1" on the right. A navigation menu on the left lists: SYNOPSIS, NETWORK CONFIG., SNMP AGENT, EMAIL SETTINGS, SMTP CONFIG, AUX. INPUTS TEXTES, ADIBOX, and ADMIN (highlighted). The main content area has a status bar with "STS", an information icon, a warning icon, a green "ON PREFERRED" button, and "Normal" and "0 A" indicators. Below this, the "ADMIN CONFIGURATION" section is active, showing fields for "New Password:", "Confirm Password:", and "Equipment identification:" (pre-filled with "STS RACK 1"). A "Submit" button is at the bottom.

Allows you to change the password to access the configuration pages ("public" by default):
The password is requested for all pages of configurations:



The screenshot shows a Windows-style login dialog box titled "Connecter à 172.23.21.244". It features a blue header with a question mark and close button. Below the header is a key icon and the text "NA-HTTP AWS Realm". The login fields include "Nom d'utilisateur :" with a dropdown menu showing "admin", and "Mot de passe :" with a text input field. A checkbox labeled "Mémoriser mon mot de passe" is present. At the bottom are "OK" and "Annuler" buttons.

4. STATYS DATA BASE

Accessibles via Modbus TCP ou RTU (RS485)

4. 1. STATE : ADDRESS MODBUS 0x0140 - 3 WORDS

S000	Source 1 OK
S001	Source 1 critical
S002	Source 1 out of tolerance
S003	Source 1 absent
S004	PowerPath 1 OK
S005	
S006	Source 2 OK
S007	Source 2 critical
S008	Source 2 out of tolerance
S009	Source 2 absent
S010	PowerPath 2 OK
S011	
S012	Srcs perm. Synchronised
S013	Sliding Sources
S014	Srcs perm. Not Synchron.
S015	Srcs Instant. Synchron.
S016	S1 is preferred source
S017	Load on preferred source
S018	Load on auxiliary source
S019	Load not supplied
S020	Load on manual by-pass1
S021	Load on manual by-pass2
S022	
S023	Load on S1
S024	Load on S2
S025	
S026	Transfer locked ext.
S027	
S028	Output OK
S029	Output out of tolerance
S030	Output absent
S031	
S032	ESD input active
S033	Q41 closed
S034	Q42 closed
S035	SS1 closed
S036	SS2 closed
S037	Q30 closed
S038	Q51 closed
S039	Q52 closed
S040	
S041	Access profile 1
S042	Access profile 2
S043	
S044	
S045	Remote controls enabled
S046	Maintenance alert
S047	User mode

4. 2. ALARM : ADDRESS MODBUS 0x0148 - 2 WORDS

A000	Imminent stop
A001	Output Isc detection
A002	Manual By-Pass
A003	Overload
A004	
A005	Consecutive Detections
A006	Switchback impossible
A007	Transfer impossible
A008	
A009	PowerPath1 deteriorated
A010	PowerPath1 short circuit
A011	PowerPath1 in failure
A012	
A013	PowerPath2 deteriorated
A014	PowerPath2 short circuit
A015	PowerPath2 in failure
A016	Backfeed1 protection open
A017	Backfeed2 protection open
A018	Ambient temperature max
A019	
A020	Insufficient resources
A021	
A022	
A023	
A024	
A025	Preventive alarm
A026	Configurartion Alarm
A027	HMI Alarm
A028	Electronics
A029	Custom input alarm
A030	Maintenance Alalrm
A031	General Alarm

4. 3. MEASUREMENT - ADDRESS MODBUS 0x0220 - 64 WORDS

M000	S1 voltage L1N	(V)
M001	S1 voltage L2N	(V)
M002	S1 voltage L3N	(V)
M003	S1 voltage U12	(V)
M004	S1 voltage U23	(V)
M005	S1 voltage U31	(V)
M006	S1 frequency	(Hz)
M007		
M008	S2 voltage L1	(V)
M009	S2 voltage L2	(V)
M010	S2 voltage L3	(V)
M011	S2 voltage U12	(V)
M012	S2 voltage U23	(V)
M013	S2 voltage U31	(V)
M014	S2 frequency	(Hz)
M015		

M016 Output voltage L1 (V)
 M017 Output voltage L2 (V)
 M018 Output voltage L3 (V)
 M019 Output voltage U12 (V)
 M020 Output voltage U23 (V)
 M021 Output voltage U31 (V)
 M022 Output frequency (Hz)
 M023
 M024 Output current I1 (A)
 M025 Output current I2 (A)
 M026 Output current I3 (A)
 M027 Output current IN (A)
 M028
 M029 Output load rate (%)
 M030
 M031 S1-S2 phase shift (°)


M032 Output Apparent P. L1 KVA
 M033 Output Apparent P. L2 KVA
 M034 Output Apparent P. L3 KVA
 M035 Output Power factor L1
 M036 Output Power factor L2
 M037 Output Power factor L3
 M038
 M039
 M040 Output crest factor L1
 M041 Output crest factor L2
 M042 Output crest factor L3
 M043 Output crest factor N
 M044
 M045
 M046
 M047 Ambient temperature (°C)

M048 Output Active Power L1 KW
 M049 Output Active Power L2 KW
 M050 Output Active Power L3 KW
 M051
 M052
 M053
 M054
 M055
 M056 Output load rate L1 (%)
 M057 Output load rate L2 (%)
 M058 Output load rate L3 (%)
 M059 Output load rate N (%)
 M060
 M061
 M062
 M063

5. FIRMWARE UPDATE

This utility can also update the firmware, configuration files and files of different languages

5. 1. UPDATE ALL (FW + CONFIG)



5. 2. UPLOAD CONFIG FILES

Is done automatically if the option “Both” has been chosen.

6. VERIFICATION DES LED ENICOM

Yellow LED = ENICOM fed

Green LED during the configuration phase



Green LED slow blinking: normal operation:



Green LED blinking fast: configuration file absent:



No Ethernet connection, the 2 LEDs are off. If the network connection is present, but the device is not programmed, the green LED indicates network traffic.

Socomec UPS worldwide

IN EUROPE

BELGIUM

Schaatsstraat, 30 rue du Patinage
B - 1190 Bruxelles
Tel. +32 (0)2 340 02 34
Fax +32 (0)2 346 16 69
be.ups.sales@socomec.com

FRANCE

95, rue Pierre Grange
F - 94132 Fontenay-sous-Bois Cedex
Tel. +33 (0)1 45 14 63 90
Fax +33 (0)1 48 77 31 12
ups.paris.dcm@socomec.com

GERMANY

Heppenheimerstraße 57
D - 68309 Mannheim
Tel. +49 (0) 621 71 68 40
Fax +49 (0) 621 71 68 44 4
de.ups.all@socomec.com

ITALY

Via Leone Tolstoj, 73 - Zivido
20098 San Giuliano Milanese (MI)
Tel. +39 02 98 242 942
Fax +39 02 98 240 723
siconmi@socomec.com

NETHERLANDS

Bergveste 2F
NL - 3992DE Houten
Tel. +31 (0)30 63 71 504
Fax +31 (0)30 63 72 166
info@socomec.nl

POLAND

Nowowiejska St 21/25
00-665 Warszawa
Tel. +48 (0)22 2345 223
Fax +48 (0)22 2345 223
ups.poland@socomec.com

PORTUGAL

Rua Moinho do Cuco
Bloco A
Lj. Dta. - Paz
2640-566 MAFRA
Tel. +351 261 812 599
Fax +351 261 812 570
portugal@socomec.com

RUSSIA

Kutuzovsky pr. 13, 44-45
121248 - Moscow
Tel. +7 495 775 19 85
Fax +7 495 775 19 85
ups.russia@socomec.com

SLOVENIA

Saviže 89
SI - 1000 Ljubljana
Tel. +386 1 5807 860
Fax +386 1 5611 173
si.ups.info@socomec.com

SPAIN

C/Nord, 22 Pol. Ind. Buvisa
E - 08329 Teià (Barcelona)
Tel. +34 935 407 575
Fax +34 935 407 576
info@socomec-arón.com

UNITED KINGDOM

Units 7-9 Lakeside Business Park
Broadway Lane - South Cerney
Cirencester - GL7 5XL
Tel. +44 (0)1285 863300
Fax +44 (0)1285 862304
uk.ups.sales@socomec.com

IN ASIA

CHINA

No.1 Yuanda Road Haidian District, Beijing, 100097
Golden Resource Times Shopping Mall
No. 1001 section B the 2nd issue of business building
Tel. +86 10 8889 2202
Fax +86 10 8889 2150
socomec@socomec.com.cn

INDIA

B1, 11nd Floor, Thiru-Vi-Ka-Industrial Estate
Guindy
Chennai - 600 032
Tel. +91 44 3921 5400
Fax +91 44 3921 5450 — 51
sales@socomec-ups.co.in

MALAYSIA

31 Jalan SS 25/41 - Mayang Industrial Park
47301 Petaling Jaya - Selangor, Malaysia
Tel. +603 7804 1153
Fax +603 7803 8901
sales@cspm.com.my

SINGAPORE

31 Ubi Road 1, Aztech Building
01-00 (Annex) - SG - Singapore 408694
Tel. +65 6745 7555
Fax +65 6458 7377
sg.ups.sales@socomec.com

THAILAND

No.9 Soi Vibhavadirangsit 42
Vibhavadirangsit Rd, Ladyao
Chatujak Bangkok 10900
Tel. +66 2 941-1644-7
Fax. +66 2 941-1650
info@socomec-th.com

HEAD OFFICE

SOCOMECS GROUP

S.A. SOCOMEC capital 11 102 300 € - R.C.S. Strasbourg B 548 500 149
B.P. 60010 - 1, rue de Westhouse - F-67235 Benfeld Cedex

SOCOMECS UPS Strasbourg

11, route de Strasbourg - B.P. 10050 - F-67235 Huttenheim Cedex - FRANCE
Tel. +33 (0)3 88 57 45 45 - Fax +33 (0)3 88 74 07 90
ups.benfeld.admin@socomec.com

SOCOMECS UPS Isola Vicentina

Via Sila, 1/3 - I - 36033 Isola Vicentina (VI) - ITALY
Tel. +39 0444 598611 - Fax +39 0444 598622
info.it.ups@socomec.com

SALES, MARKETING AND SERVICE MANAGEMENT

SOCOMECS UPS Paris

95, rue Pierre Grange
F-94132 Fontenay-sous-Bois Cedex - FRANCE
Tel. +33 (0)1 45 14 63 90 - Fax +33 (0)1 48 77 31 12
ups.paris.dcm@socomec.com

www.socomec.com

Non contractual document. © 2008, Socomec SA. All rights reserved.



socomec
Innovative Power Solutions **UPS**