

# IPDU Operation Manual

## Contents

|  |           |
|--|-----------|
| <b>1 Brief introduction</b>                          | <b>3</b>  |
| <b>2 Hardware introduction</b>                       | <b>3</b>  |
| <b>3 Software introduction</b>                       | <b>4</b>  |
| <b>3.1 Http visiting</b>                             | <b>5</b>  |
| <b>3.2 The home page displays</b>                    | <b>5</b>  |
| <b>3.3 Threshold configuration</b>                   | <b>6</b>  |
| <b>3.4 Sensor Configuration</b>                      | <b>6</b>  |
| <b>3.5 The electricity Consumption configuration</b> | <b>7</b>  |
| <b>3.6 System configuration</b>                      | <b>7</b>  |
| <b>3.7 Mail Service</b>                              | <b>8</b>  |
| <b>3.8 SNMP configuration</b>                        | <b>9</b>  |
| <b>3.9 Telnet configuration</b>                      | <b>9</b>  |
| <b>3.10 Device Configuration</b>                     | <b>10</b> |
| <b>3.11 User Management</b>                          | <b>10</b> |
| <b>3.12 Device reboot</b>                            | <b>11</b> |
| <b>3.13 SNMP visit</b>                               | <b>11</b> |
| <b>3.14 Telnet visit</b>                             | <b>12</b> |
| <b>4 Technical Parameters</b>                        | <b>13</b> |
| <b>5 Quality Assurance</b>                           | <b>14</b> |

## 1 Brief introduction

**Product Name:** Remote monitoring and management of power distribution system


### 1.1 Definition :

Remote monitoring and management of power distribution system, this product is according to the international development trend of the power distribution management technology, combined with data center application environment of technology and market demand, using the latest core technology with completely independent intellectual property rights. It is a standard system with network communication, monitoring and detection, power distribution, hot swap etc. function.


### 1.2 Main function:

- A, the total load current monitoring;
- B, the input voltage monitoring;
- C, the load power monitoring;
- D, total electricity consumption monitoring;
- E, input flow monitoring;
- F, input overvoltage monitoring;
- G, environmental temperature and humidity monitoring

## 2,Hardware introduction



- 1- LCD
- 2-RUN
- 3- RESET
- 4- ALARM
- 5-MENU
- 6-DOWN
- 7-UP
- 8-NET
- 9-SENEOR
- 10-RS485
- 11-LINK



## 2.1 Boot interface

After 9-1 boot countdown, display the first screen

**First screen:** AC L1 total current, total voltage, total power, total electric energy, temperature and humidity

**The second screen:** AC L1 total current, total voltage, total power, power factor , temperature and humidity

**The third screen:** AC L1 total current, total voltage, total power, total electric energy, temperature and humidity

**Fourth screen:** AC L2 total current, total voltage, total power, power factor , temperature and humidity

**Fifth screen:** AC L3 total current, total voltage, total power, power factor , temperature and humidity

**Sixth screen:** AC L3 total current, total voltage, total power, power factor , temperature and humidity

**Seventh screen:** 192 168 0 163

**Eighth screen:** Add M

**Ninth screen:** AC L1 total current limit, total voltage upper limit, temperature and humidity limit

**Tenth screen:** AC L2 total current limit, total voltage upper limit, temperature and humidity limit

**Eleventh screen:** AC L3 total current limit, total voltage upper limit, temperature and humidity limit

## 2.2 Button Operation

**Check Switching:**

Through the UP and DOWN keys to switch with the first to eleventh screen display.

**Host and auxiliary machine settings:**

Through the UP and DOWN key to switch to eighth screen, press the MENU button and hold on 5s and the M will be flashing. through the UP and DOWN keys to switch with M and S; After confirming the change, push and hold the button MENU key for 5S, the device will restart and save the settings value.

Note: M is the host, S is the auxiliary, auxiliary machine can be cascaded through the host.

**Modify the L1, L2, L3 limits;**

Through the UP and DOWN key to switch to the ninth to eleventh screen display, press the button MENU key 5S waiting current limit is flashing .Through DOWN button to switch the total current limit, The upper limit of total voltage ,temperature, humidity is added by UP button (0-9 automatic cycle accumulation), after confirming the change, press the button MENU key 5S, restart the device to save the set value.

## 3 Software introduction

### 3.1 HTTP visit

HTTP login screen, enter the browser address bar 192.168.0.163, enter, as shown:




### 3.2 The home page displays

The total current, the total voltage, the total power, power factor, total electric energy, temperature, humidity;

By selecting PDU switching to view the state of host and the sub-machine.

By choosing Line, switching view L1, L2, L3; three-phase current parameters.




### 3.3 Threshold configuration

Total current setting, the total voltage bound setting(170-276),total current restrictions on the range of (0-32),through the Save button to save the set value.

By selecting PDU switching to view the host and sub- machine and set restrictions.


By choosing Line, switching view L1, L2, L3; three-phase current and voltage limit set;



### 3.4 Sensor Configuration


Only can add a temperature / humidity sensor, you can set the temperature / humidity minimum and maximum values, through the Save button to save the set value;

By selecting PDU switching to view the host and sub- machine and set restrictions.



### 3.5 The electricity Consumption configuration

Check L1, L2, L3 each phase power, clear the Power Recorder by reset button.



### 3.6 System configuration

system message:

Look for the MAC address;

IPV4 address, IPV4 subnet mask, IPV4 default gateway, IPV4 DNS server settings;

NOTE: The factory default

IPV4 address: 192.168.0.163


IPV4 Subnet Mask: 255.255.255.0

IPV4 default gateway: 192.168.0.1

IPV4 DNS server: 202.69.128.86

Please fill in the correct DNS server address, if wrong, will affect the SMTP service;






### 3.7 Mail Service

The default set up SMTP client, exception information can be sent to email after filling out outbox account, password, server and port number.

NOTE: Inbox account please fill in the user profile;


The default set up SMTP client can send ordinary mail message, can't send an encrypted message.



### 3.8 SNMP configuration

Fill in the "Get community, Set community", default read as public, written as private.

SNMP Trap IP: Send exception trap alarm, fill in the alarm accepts computer's IP.



### 3.9 Telnet configuration

Telnet access configuration, drop-down menu, select On or disable the Telnet server.

Open Telnet server, please fill in the Telnet login account password, click Save, through Telnet client login server.

192.168.0.163/home.html#

Home Device manager Administrator

System

Email

SNMP

Telnet

Device

### Telnet Configuration

Telnet Access Configuration

Telnet Server: Disabled

Telnet account: (Account length is 5 characters)

Telnet password: (Password length is 5 characters)

Save


HTTP/1.0 200 OK Content-Type: Content-Length: 19 HTTP/1.0 401 OK

### 3.10 Device Configuration

Switch modes: drop-down menu, select the operating mode, the optional host mode or deputy mode


SNMP Name: Set the device name, can identify the device during the SNMP access.

HTTP access: HTTP access port number, the default is 80;



### 3.11 User Management

The software defaults to single-user mode, account number and password can be modified  
Email: to receive the abnormal infos.




### 3.12 Device reboot

Click the drop-down box to choose reboot or restore the factory settings, click the button to perform.

Firmware Information: Including software version, hardware version, the last update time.

Update Settings: When software have a BUG, can be fed back to the manufacturer. After manufacturer revised and improved it. You can update it by the upgrade tool. Before upgrading need to login, open the update settings.



Note: above configuration info, after finished the setting, you need to reboot device to make them effective.

### 3.13 SNMP visit

Via SNMP visit tools or write your own tools to access the PDU power parameter information, the software defaults to SNMP V1 version

OID correspondence table as below.



| Object name     | OID                     | Object type | Description     |
|-----------------|-------------------------|-------------|-----------------|
| Device Name     | 1.3.6.1.4.1.23273.1.1.1 | String      | Device Name     |
| MasterVoltageL1 | 1.3.6.1.4.1.23273.1.2.1 | Integer     | MasterVoltageL1 |
| MasterCurrentL1 | 1.3.6.1.4.1.23273.1.2.2 | Integer     | MasterCurrentL1 |
| MasterEnergyL1  | 1.3.6.1.4.1.23273.1.2.3 | Integer     | MasterEnergyL1  |
| MasterVoltageL2 | 1.3.6.1.4.1.23273.1.2.4 | Integer     | MasterVoltageL2 |
| MasterCurrentL2 | 1.3.6.1.4.1.23273.1.2.5 | Integer     | MasterCurrentL2 |
| MasterEnergyL2  | 1.3.6.1.4.1.23273.1.2.6 | Integer     | MasterEnergyL2  |

|                 |                          |         |                 |
|-----------------|--------------------------|---------|-----------------|
| MasterVoltageL3 | 1.3.6.1.4.1.23273.1.2.7  | Integer | MasterVoltageL3 |
| MasterCurrentL3 | 1.3.6.1.4.1.23273.1.2.8  | Integer | MasterCurrentL3 |
| MasterEnergyL3  | 1.3.6.1.4.1.23273.1.2.9  | Integer | MasterEnergyL3  |
| SlaveVoltageL1  | 1.3.6.1.4.1.23273.1.2.10 | Integer | SlaveVoltageL1  |
| SlaveCurrentL1  | 1.3.6.1.4.1.23273.1.2.11 | Integer | SlaveCurrentL1  |
| SlaveEnergyL1   | 1.3.6.1.4.1.23273.1.2.12 | Integer | SlaveEnergyL1   |
| SlaveVoltageL2  | 1.3.6.1.4.1.23273.1.2.13 | Integer | SlaveVoltageL2  |
| SlaveCurrentL2  | 1.3.6.1.4.1.23273.1.2.14 | Integer | SlaveCurrentL2  |
| SlaveEnergyL2   | 1.3.6.1.4.1.23273.1.2.15 | Integer | SlaveEnergyL2   |
| SlaveVoltageL3  | 1.3.6.1.4.1.23273.1.2.16 | Integer | SlaveVoltageL3  |
| SlaveCurrentL3  | 1.3.6.1.4.1.23273.1.2.17 | Integer | SlaveCurrentL3  |
| SlaveEnergyL3   | 1.3.6.1.4.1.23273.1.2.18 | Integer | SlaveEnergyL3   |

### 3.14 Telnet visit

Via Telnet Client Tools or write your own tools to access the PDU power parameter information; Telnet client needs to be open firstly, fill out the account password.

Telnet command line of the table as follows:

| command | Description   | Command rollback<br>Screenshot  |
|---------|---|---|
| GET 0/1 | Get device power information through a GET command, 0-1 represents 0 is the host, 1 is the auxiliary machine. |   |
| RESET   | Restore factory settings command  |   |
| REBOOT  | Restart command   |   |
| HELP    | Help Commands   |  |

## 4 Technical Parameters

| No. | performance parameter  |              |                                | technical index |         |
|-----|------------------------|--------------|--------------------------------|-----------------|---------|
| 1   | input characteristics  | Single phase | rated input voltage            | 110/220V        | 50/60HZ |
|     |                        |              | The maximum total load current | 32A             |         |
|     |                        | Three phase  | rated input voltage            | 380V            | 50/60HZ |
|     |                        |              | The maximum total load current | 3×16A           |         |
| 2   | Output characteristics | Single phase | Output voltage                 | 110/220VAC      | 50/60HZ |
|     |                        |              | The maximum total load current | 32A             |         |

|   |                      |   |  |   |  |
|---|----------------------|---|--|---|--|
|   |                      | Three phase   | Output voltage   | 380V    50/60HZ   |  |
|   |                      |   | The maximum total load current   | 3×16A   |  |
| 3 | Display Properties   | Hot-swappable   |  | LCD, it displays the total input voltage, total current, total power etc.               |  |
|   |                      | Display Accuracy  | total voltage  | Full scale:300V    Accuracy:±1 % +2 character resolution ratio:0.1V Response Time:400ms |  |
|   |                      |   | Total current  | Full scale:32A    Accuracy: ±1 % +1 character resolution ratio:0.1A Response Time:400ms |  |
|   |                      |   | Total electric energy  | A constant: 1600imp / kWh    Level: 1 Resolution: 0.1kWh                                |  |
|   |                      |   | Temperature  | resolution ratio: 0.1℃ ；  |  |
|   |                      |   | Humidity   | resolution ratio: 0.1 %；  |  |
| 4 | physical property    | Hot-swappable   |  |   |  |
|   |                      | Shell color   |  |   |  |
| 5 | Installation methods | Vertical fixed installation                             |  |   |  |
| 6 | monitoring function  | the total load current monitoring                       |  |   |  |
|   |                      | the total input voltage monitoring                      |  |   |  |
|   |                      | the total load power monitoring                         |  |   |  |
|   |                      | the total electricity consumption monitoring            |  |   |  |
|   |                      | the environmental temperature and humidity monitoring   |  |   |  |
| 7 | Setting Function     | The total load current upper and lower limit settings   |  |   |  |
|   |                      | temperature and humidity upper and lower limit settings |  |   |  |
|   |                      | address setting of email alarm                          |  |   |  |
|   |                      | HTTP Network service settings                           |  |   |  |
|   |                      | SNMP (v1 ) setting                                      |  |   |  |
|   |                      | Network parameter settings (IP, gateway, mask, DNS)     |  |   |  |
| 8 | Alarm function       | The system alarm  | When the total load current exceeds the rated value                    |   |  |
|   |                      |   | When <i>temperature, humidity exceeds the upper and lower limits</i>   |   |  |
|   |                      | Customize the Alarms                                    | When the total load current exceeds a threshold                        |   |  |
|   |                      |   | <i>Temperature, humidity exceeds the upper and lower limits</i>        |   |  |
|   |                      | Alarm mode  | Buzzer beep  |   |  |
|   |                      |   | LCD digital flash  |   |  |
|   |                      |   | Email is automatically sent to the system administrator                |   |  |
|   |                      |   | SNMP Send alert status information.                                    |   |  |
|   |                      |   | Serial Port Communication background send the alarm status information |   |  |
| 9 | Access method        | WEB access control through IE；                          |  |   |  |

|    |                 |  |             |
|----|-----------------|--|-------------|
|    |                 | SNMP (V1) via standard network management workstation access control |             |
|    |                 | Telnet command line  |             |
| 10 | user management | Set the user name and password                                       |             |
| 11 | cascading       | Can be cascaded for two products                                     |             |
| 12 | environment     | Operating temperature  | 0℃~55℃      |
|    |                 | relative humidity  | 10~90%      |
|    |                 | storage temperature  | -20℃ ~ +70℃ |

## 5 Quality Assurance

The date of product purchase from the customer warranty of two years. During the warranty period of the basic obligations of public companies limited to a replacement, repair or maintenance of the Company to return. During the warranty period generally provide customers with free maintenance. If the product is out of warranty or product is due to the determination of the company due to illegal operation, you will be charged the appropriate fee. Above warranty does not apply to problems caused by the following situations:

1. Because of incorrect or inadequate maintenance by the customer due to a malfunction.
2. Unauthorized alterations, modifications or errors caused by misuse malfunction.
3. In the physical environment outside the scope of the product prescribed use of the environment caused by the fault.

### SERVICE NOTE:

1. For products returned for repair, be sure to use protective hard box packaging, damage in transit not included in the warranty.
2. Please repair product issues and operational procedures to be concise description.
3. Prepaid customers need to return the product of the shipping company, and the payment of all duties and taxes.
4. Please include your name, address and telephone number of a contact can be ready.