

APPENDIX A: CONFIGURING MANAGEUPS VIA SERIAL PORT

ASCII Terminal


You will need an ASCII terminal or terminal emulation program on your PC workstation.

HyperTerminal is a standard terminal emulation program offered with Windows. See *Terminal Settings* on the following page for instructions on how to set up Hyper Terminal to work with ManageUPS.

Serial Connection

Connect a serial port on your PC to the ManageUPS serial configuration port as described in the *Supplemental Installation Note* appropriate for your UPS.

The ManageUPS serial configuration port will be either the UPS communications port on *internal* adapters or the DB9 port marked TERM on *external* adapters.



Location of serial ports on external adapter.

Open a Terminal Session

If your terminal settings are correct, you should see the following dialog in your terminal window after you power up ManageUPS (Entries are case -sensitive)

Type: CONSOLE and press [ENTER]

Type: admin for both username and password

Booting MUN Operating System...

ManageUPSnet - SNMP/Web UPS Network Adapter
Copyright Chloride Power 2004

Type 'CONSOLE' and press Enter to start

User Name : admin
Password : *****

ManageUPSnet - SNMP/Web UPS Network Adapter
Copyright Chloride Power 2004

ManageUPSnet Console

Battery status: Normal	Battery Charge: 100 %
Output source: Normal	UPS Load: 31 %
Current status: Normal Operation	

UPS Name: ACTIVE	IP Address: 192.168.1.34
UPS Model: ACTIVE 3kVA + 1 Bat Pack	MAC Address: 00:52:72:cf:cf:26
UPS S/N: B101010	UPS Firmware: N/A

Location:
Contact:
Attached Devices:

ManageUPSnet Firmware: 0.05.040216 *** BETA ***

U - UPS configuration/control	E - Email configuration
N - Network configuration	A - Administration
S - SNMP configuration	L - Logout/Reboot

Select one of the above options

>

General Terminal Settings


BPS = 1200, 2400 or 9600
(Depends on UPS model family.)

Other settings are standard for all:
Data Bits = 8
Parity = None
Stop Bits = 1
Flow Control = None


ASCII Setup:
Send line ends with line feeds
Echo = Off

Configuring Hyper Terminal


1




2




3



4



5



6

