

Gutor SDC

USER MANUAL — MODBUS Functionality of the Network Management Card (NMC)

Contents

| | | |
|-----|--|---|
| 1. | CONFIGURING MODBUS FUNCTIONALITY | 2 |
| 2. | MODBUS ADDRESSING INFORMATION | 4 |
| 2.1 | Function Call 01: Read Coil Registers Status Table | 4 |
| 2.2 | Function Call 03: Read Holding Registers Table | 5 |

| Rev. | Description of change | Original document #: 7SA9046GB | Issued | Validated | Approved | Date |
|------|--|--------------------------------|--------|-----------|----------|----------|
| 01 | First edition / New design | | mp | LOA | LUS | 13-01-06 |
| 02 | «Read Coil Registers Status Table» updated | | mp | SKI | SKI | 16-11-03 |
| | | | | | | |
| | | | | | | |

Please note:

No part of this document may be reproduced or transmitted in any form or by any means — electronic or mechanical, including photocopying and recording — for whatever reason, without the explicit written permission of **GUTOR Electronic LLC**

1. CONFIGURING MODBUS FUNCTIONALITY

MODBUS/RTU by 4-Wire RS485

The MODBUS / RTU can be either configured by the command line interface or by the web interface (HTTP).

For the MODBUS / RTU connector pinout see 7RG9032GB in section 6.2

Command Line Interface

To manually configure the modbus settings the Network Management Card needs to have a connection to the DC System. If the connection to the DC System is established, the 'modbus' command can be used in the command line interface to change the modbus settings.

| Option | Arguments | Description |
|-------------|-------------------|--|
| ? | | To display the command help. |
| -a | enable disable | To enable or disable the modbus converter functionality. |
| -br | 9600 19200 | To change the MODBUS RS485 baud rate. |
| -pr | even odd none | To change the parity bit setting. |
| -s | 1 – F7 | To change the slave address in the range of 1 – 247 decimal (argument is allowed in hex only). |
| -ResetToDef | | To reset the settings to the default values. |

Example 1: To view the modbus settings of the Network Management Card, type:

```
modbus and press ENTER
```

Example 2: To manually change the baud rate to 19200 baud for the Network Management Card, type:

```
modbus -br 19200
```

Example 3: To manually change the slave address to 243 (0xF3), type the value in hex format:


```
modbus -s
```

Web Interface (HTTP)

By opening the web browser and navigating to the Network Management Card's IP address, the MODBUS / RTU setting can be changed. When the TCP / IP settings are not yet configured, first see the documentation 7RG9032GB in section 4, where it is described how to configure the IP address of the Network Management Card.

- Log in on the page.
- Use **gutor** for the user name and password.
- The MODBUS serial settings can be changed by clicking on:
Administration > Network > Modbus > serial
- There the settings can be changed as shown in the following picture.

MODBUS Functionality of the Network Management Card (NMC)




MODBUS/TCP

By opening the web browser and navigating to the Network Management Card's IP address, the MODBUS / TCP setting can be changed. When the TCP / IP settings are not yet configured, first see the documentation 7RG9032GB in section 4, where it is described how to configure the IP address of the Network Management Card.

- Log in on the page.
- Use **gutor** for the user name and password.
- The MODBUS tcp settings can be changed by clicking on:
Administration > Network > Modbus > tcp
- There the settings can be changed as shown in the following picture.

MODBUS Functionality of the Network Management Card (NMC)



2. MODBUS ADDRESSING INFORMATION

This section outlines the addressing structure used to expose the DC System information to the MODBUS protocol. The following tables are showing, which information can be reached at which address.

2.1 Function Call 01: Read Coil Registers Status Table

The data type for all Read Coil Registers is boolean. The details about the registers are shown in the table below.

| Coil Register | Format | Parameter | Notes |
|---------------|--------|---------------------------|--|
| 00001 | B | High DC Warning | DC is over high DC warning level. |
| 00002 | B | Battery operation | Charger is running on battery. |
| 00004 | B | Low DC Vaux Warning | The DC voltage after serial diode is below DC warning level. |
| 00005 | B | DC voltage high | DC is over high DC warning / shutdown level. |
| 00006 | B | Common fault | Common alarm bit for all alarms in Charger except from Battery current limit and Blocking of boost / initial. If cleared consider as "Charger OK" condition. |
| 00017 | B | Battery not connected | Battery breaker is open. |
| 00018 | B | Battery temperature fault | Battery temperature out of range or sensor fault. |
| 00021 | B | DC voltage low warning | DC voltage is below low DC warning level. |
| 00027 | B | Digital input 1 | If digital input 1 is open, coil register has value 1. |
| 00028 | B | Digital input 2 | If digital input 2 is open, coil register has value 1. |

MODBUS Functionality of the Network Management Card (NMC)

| Coil Register | Format | Parameter | Notes |
|---------------|--------|-------------------------|--|
| 00035 | B | Rectifier mains failure | Phase order not correct, or mains voltage is out of tolerance window, or mains is out of frequency window, or at least one phase is missing. Charger will shut down. |
| 00036 | B | Load MCB Off | Load breaker is open. |
| 00037 | B | Mains MCB Off | Mains breaker is open. |
| 00040 | B | DC fuse blown | The rectifier DC fuse has blown. |
| 00041 | B | Rectifier overcurrent | Current limiter for total DC current is active. |
| 00042 | B | Parallel error | Load sharing differs more than $\pm 10\%$. |
| 00043 | B | Battery defective | Conclusion of battery monitor test. |
| 00044 | B | Battery disconnected | Battery breaker is open. |
| 00045 | B | Earth fault | Earth current is running to positive pole or earth current is running to ground pole. |
| 00047 | B | Control power fault | The DC circuit of the redundant PSU is defective or the AC circuit of the redundant PSU is defective. |
| 00048 | B | Overtemperature | Temp. is over 90° C or temperature signal switch in transformer off or temperature signal switch in choke off or temperature signal switch in diode off. |
| 00049 | B | Fan fault | Fan 1,2,3,4,5,6,7 or 8 is rotating too slowly.(fan pulse signal < 20 Hz) |
| 00051 | B | Option 1 error | Status of Option 1 error. |
| 00052 | B | Option 2 error | Status of Option 2 error. |
| 00053 | B | Option 3 error | Status of Option 3 error. |
| 00054 | B | Option 4 error | Status of Option 4 error. |
| 00055 | B | Option 5 error | Status of Option 5 error. |
| 00056 | B | Option 6 error | Status of Option 6 error. |
| 00057 | B | Option 7 error | Status of Option 7 error. |
| 00058 | B | Option 8 error | Status of Option 8 error. |
| 00059 | B | Battery symmetry fault | Half of the battery voltage is outside of the tolerance window. |
| 00060 | B | Battery weak | Conclusion of battery monitor test. |

GENERAL EXPLANATION:

The delay between the polls should be more than 10 seconds because the update rate of most of the registers is about 10 seconds. All coil registers in the range of 00001 – 00071 which are not mentioned in the table above are reserved.

Coil Register: Number of the Read Coil Register on function call 01. Note that a value of 1 in the Read Coil Registers means that the individual status or alarm mentioned in the column Parameter is active.

Format: Data type format B means Boolean.

Parameter: Boolean name / source.

Notes: Some additional information about the individual parameter.

2.2 **Function Call 03: Read Holding Registers Table**

The data type for all Read Holding Registers is 16-Bit unsigned integer. The details about the registers are shown in the table below.

| Holding Register | Format | Parameter | Unit of measure | Factor | Notes |
|------------------|--------|------------------|-----------------|--------|-----------------------|
| 40004 | FFFF | Mains voltage L1 | V | 1 | Phase L1 to Phase L2. |
| 40005 | FFFF | Mains voltage L2 | V | 1 | Phase L2 to Phase L3. |
| 40006 | FFFF | Mains voltage L3 | V | 1 | Phase L3 to Phase L1. |
| 40010 | FFFF | Mains current L1 | A | 1 | |
| 40011 | FFFF | Mains current L2 | A | 1 | |

MODBUS Functionality of the Network Management Card (NMC)

| Holding Register | Format | Parameter | Unit of measure | Factor | Notes |
|------------------|--------|--------------------------------|-----------------|--------|---|
| 40012 | FFFF | Mains current L3 | A | 1 | |
| 40019 | FFFF | Total DC current | A | 1 | |
| 40020 | FFFF | Battery current | A | 1 | |
| 40022 | FFFF | Operation mode | N/A | 1 | Value reflects the actual operation mode of the system acc. the following scheme: 1 = Initializing after reset. 2 = Standby. 3 = Battery operation. 4 = Float charge. 5 = Boost charge. 6 = Initial charge. |
| 40029 | FFFF | DC voltage | V | 1 | |
| 40031 | FFFF | Active systems | N/A | 1 | 1 = single / 2 = parallel. |
| 40033 | FFFF | DC Vaux. voltage | V | 1 | |
| 40035 | FFFF | Battery temperature | °C or °F | 1 | Temperature sensor is an option; shows Fahrenheit or Celsius value depending on UPS firmware setting. If not mounted this field will show a value of around 226! |
| 40040 | FFFF | System load | % | 1 | Percent of Charger power capacity presently used. |
| 40041 | FFFF | Battery time left | min | 1 | |
| 40045 | FFFF | Firmware version, first digit | N/A | 1 | |
| 40046 | FFFF | Firmware version, second digit | N/A | 1 | |
| 40047 | FFFF | Firmware version, third digit | N/A | 1 | |

GENERAL EXPLANATION:

The delay between the polls should be more than 10 seconds because the update rate of most of the registers is about 10 seconds. Not all registers are used for all system configurations. All read holding registers in the range of 40001 – 40047 which are not mentioned in the table above are reserved.

Holding Register: Number of the Read Holding Register on function call 03.

Format: Data type format is unsigned integer. FFFF means hexadecimal data format value of 4 digits. This corresponds to an absolute range of decimal 0 – 65535.

Parameter: Measurement name/source.

Unit of measure: The unit of measure in which the respective analog value is measured.

Factor: The factor with which the value is multiplied to transfer it. E.g. if a value has a factor of 10 then the real value is 10 times smaller, the last numeric character shows the 10th of the value.

Notes: Some additional information about the individual parameter.