



TMcraft Toolbar API Function Manual

Original Instructions

Software version: 1.20.1000
Document version: 1.0
Release date: 2024-11-01

This Manual contains information of the Techman Robot product series (hereinafter referred to as the TM AI Cobot). The information contained herein is the property of Techman Robot Inc. (hereinafter referred to as the Corporation) and shall not be reproduced in whole or in part without prior authorization from the Corporation. No information contained herein shall be considered an offer or commitment. The information herein is subject to change without notice. The document is periodically reviewed and revised. The Corporation assumes no responsibility for any errors or omissions in the documentation.



 and  logos are registered trademark of TECHMAN ROBOT INC. in Taiwan and other countries and the company reserves the ownership of this manual and its copy and its copyrights.

Table of Content

Manual Revision History.....	5
API Revision History.....	5
1. Overview	7
2. Programming with TMcraft Toolbar API.....	9
3. TMcraft API functions (Toolbar related).....	10
3.1 TMcraftToolbarAPI.....	10
3.1.1 Version.....	10
3.1.2 Close	10
3.1.3 GetErrMsg	10
3.2 ITMcraftToolbarEntry	11
3.2.1 InitializeToolbar	11
3.3 EndButtonEventProvider	11
3.3.1 HasEndButtonEventOwnership.....	11
3.3.2 IsEndButtonBoardcastMode	12
3.3.3 ReleaseEndButtonEventOwnership	12
3.3.4 SetEndButtonEventOwnership.....	12
3.3.5 EndButtonClickEvent	12
3.4 FreebotProvider.....	13
3.4.1 GetFreeBot	13
3.4.2 HoldFreeBotKeyToHandGuide.....	13
3.4.3 KeepFreeBot.....	13
3.4.4 SetFreeBot	14
3.5 IOPProvider	14
3.5.1 GetAllIOData.....	14
3.5.2 ReadAnalogInput	14
3.5.3 ReadAnalogOutput	15
3.5.4 ReadDigitInput	16
3.5.5 ReadDigitOutput	16
3.5.6 SetCameraLight.....	17
3.5.7 WriteDigitOutput.....	17
3.5.8 WriteAnalogOutput.....	18
3.6 RobotJogProvider.....	18
3.6.1 HoldPlayKeyToRun	19
3.6.2 JogByBase	19
3.6.3 JogByJoint	19
3.6.4 JogCircle.....	20
3.6.5 JogRelativeByBase.....	21
3.6.6 JogRelativeByJoint	22
3.6.7 JogRelativeByTool	22

3.6.8 KeepJogging	23
3.6.9 StopJog	23
3.7 RobotStatusProvider	23
3.7.1 GetCurrentBaseName	23
3.7.2 GetCurrentPayload	24
3.7.3 GetCurrentPoseByCurrentBase	24
3.7.4 GetCurrentPoseByJointAngle	24
3.7.5 GetCurrentPoseByRobotBase	25
3.7.6 GetCurrentRobotConfigs	25
3.7.7 GetCurrentTcp	26
3.7.8 GetFlowVersion	26
3.7.9 GetOperationMode	26
3.7.10 GetRobotModelType	26
3.7.11 ProjectEditOrNot	27
3.7.12 ProjectPauseOrNot	27
3.7.13 ProjectRunOrNot	27
3.7.14 RobotErrorOrNot	28
3.7.15 RobotEstopOrNot	28
3.7.16 SetCurrentBase	28
3.7.17 SetCurrentPayload	29
3.7.18 SetCurrentTcp	29
3.7.19 ErrorEvent	29
3.8 SystemProvider	29
3.8.1 GetCurrentLanguageCulture	30
3.8.2 GetTMflowType	30
3.9 TcpProvider	30
3.9.1 ChangeTcpInertia	30
3.9.2 ChangeTcpMass	31
3.9.3 ChangeTcpMassCenter	31
3.9.4 ChangeTcpPose	31
3.9.5 CreateNewTcp	32
3.9.6 DeleteTcp	32
3.9.7 GetProjectVisionTcpList	33
3.9.8 GetTcpInertia	33
3.9.9 GetTcpList	33
3.9.10 GetTcpMass	34
3.9.11 GetTcpMassCenter	34
3.9.12 IsTcpExist	34
3.10 TextFileProvider	35
3.10.1 DeleteTextFile	35

3.10.2 ExportTextFile	35
3.10.3 GetTextFileList	35
3.10.4 ImportTextFile	36
3.10.5 NewTextFile	36
3.10.6 ReadTextFile	36
3.10.7 WriteTextFile	37
3.11 VariableProvider	37
3.11.1 ChangeGlobalVariableValue	37
3.11.2 ChangeProjectVariableValue	38
3.11.3 CreateGlobalVariable	38
3.11.4 DeleteGlobalVariable	38
3.11.5 GetGlobalVariableList	39
3.11.6 GetGlobalVariableValue	39
3.11.7 GetProjectVariableList	39
3.11.8 GetVariableRuntimeValue	40
3.11.9 IsGlobalVariableExist	40
3.11.10 IsProjectVariableExist	40
4. Enumeration types	42
4.1 FreeBotMode	42
4.2 IO_TYPE	42
4.3 MoveMode	42
4.4 RobotEventType	43
4.5 TMcraftErr	44
4.6 TMflowType	44
4.7 VariableType	45
5. Additional class	46
5.1 DeviceIOInfo	46
5.2 DigitIOInfo	46
5.3 ErrorStatus	47
5.4 FreeBotInfo	47
5.5 TCPInfo	48
5.6 VariableInfo	49

Manual Revision History

Revision	Date	Revised Content
1.0	2024-11-01	Original release

API Revision History

Version	Date	Change Note/History
1.14.1200	2023/8	<ul style="list-style-type: none"> ● 1st release
1.16.1400	2024/2	<ul style="list-style-type: none"> ● [Add] class TMcraftShellAPI ● [Add] class TMcraftToolbarAPI ● [Add] interface ITMcraftToolbarEntry ● [Add] class ErrorStatus ● [Add] FreeBotInfo.MoveMode ● [Add] class MoveMode ● [Add] class LogExportSetting ● [Add] RobotEventType.EndButtonFreeBotChanged
1.18.1400	2024/6	<ul style="list-style-type: none"> ● [Add] class TMcraftSetupAPI ● [Add] class TMcraftNodeAPI.TextfileProvider ● [Add] class TMcraftShellAPI.TextfileProvider ● [Add] class TMcraftToolbarAPI.TextfileProvider ● [Add] TMcraftShellAPI.ProjectRunProvider.GetProjectList ● [Add] TMcraftShellAPI.RobotStatusProvider.GetRobotName ● [Add] TMcraftNodeAPI.RobotStatusProvider.GetRobotModelType ● [Add] TMcraftNodeAPI.RobotStatusProvider.GetFlowVersion
1.20.1100	2024/11	<ul style="list-style-type: none"> ● [Add] TMcraftNodeType.dll ● [Add] class TMcraftNodeAPI.FreeBotProvider ● [Add] class TMcraftNodeAPI.EndButtonEventProvider ● [Deprecated] TMcraftNodeAPI.RobotStatusProvider.GetFreeBot ● [Deprecated] TMcraftNodeAPI.RobotStatusProvider.SetFreeBot ● [Deprecated] TMcraftNodeAPI.RobotStatusProvider.EndButtonClickEvent ● [Add] class TMcraftShellAPI.FreeBotProvider ● [Add] class TMcraftShellAPI.EndButtonEventProvider ● [Deprecated] TMcraftShellAPI.RobotStatusProvider.GetFreeBot ● [Deprecated] TMcraftShellAPI.RobotStatusProvider.SetFreeBot ● [Deprecated] TMcraftShellAPI.RobotStatusProvider.EndButtonClickEvent ● [Add] class TMcraftToolbarAPI.FreeBotProvider ● [Add] class TMcraftToolbarAPI.EndButtonEventProvider ● [Deprecated] TMcraftToolbarAPI.RobotStatusProvider.GetFreeBot ● [Deprecated] TMcraftToolbarAPI.RobotStatusProvider.SetFreeBot

		<ul style="list-style-type: none">● [Deprecaded] TMcraftToolbarAPI.RobotStatusProvider.EndButton-ClickEvent● [Add] class TMcraftSetupAPI.FreeBotProvider● [Add] class TMcraftSetupAPI.EndButtonEventProvider● [Deprecaded] TMcraftSetupAPI.RobotStatusProvider.GetFreeBot● [Deprecaded] TMcraftSetupAPI.RobotStatusProvider.SetFreeBot● [Deprecaded] TMcraftSetupAPI.RobotStatusProvider.EndButtonClickEvent
--	--	---

1. Overview

The TMcraft Toolbar, a versatile C#/WPF plugin for TMflow, is designed to enhance user experiences by streamlining tasks and boosting overall efficiency. It is readily accessible to end users at any time within TMflow.

- Device builders can create a TMcraft toolbar as the control interface for their products, facilitating effortless testing of device functions, parameter adjustments, and execution of various tasks.
- System integrators can leverage the TMcraft Toolbar to create helpful tools, such as a lightweight dashboard for monitoring specific parameters or a communication interface to interact with other systems within the application.

This flexibility makes the TMcraft Toolbar an essential tool for improving workflow and system integration.




Figure 1: Architecture of TMcraft Toolbar

Plugins	Node	Shell	Toolbar	Setup
Base (Add/Edit/Delete)	✓			✓
Point (Add/Edit/Delete)	✓			✓
Tool (Add/Edit/Delete)	✓	✓	✓	✓
Digital IO (Read/Write)	✓	✓	✓	✓
Analog IO (Read/Write)	✓	✓	✓	✓
Project Variables (New/Edit)	✓	✓	✓	✓
Global Variables (New/Edit)	✓	✓	✓	✓
Vision Job (Add/Open/Delete)	✓			
Jog the robot	✓	✓	✓	
Freebot (Set/Get)	✓	✓	✓	✓
End Button Event	✓	✓	✓	✓
Get Current Language	✓	✓	✓	✓
Get TMflow Type	✓	✓	✓	✓
Text file (Read/Write)	✓	✓	✓	✓

capabilities \ Plugins	Node	Shell	Toolbar	Setup
TMscript on flow project (Read/Write)	✓			✓
Login/Logout/Get Control		✓		
script Project (Add/Edit/Delete)		✓		
Robot status (Error, Run, etc.)		✓	✓	
Error Event		✓	✓	
Virtual Robot Stick		✓		
Export/Import		✓		
Variables Runtime Value (Read/Write)		✓	Read only	

Table 1: A brief overview of the capabilities of various TMcraft plugin APIs

To develop and implement a TMcraft Toolbar, developers should firstly build it as a User Control Library (dll file, not exe file). Next, generate a TMcraft Toolbar zip with the TMcraft Packer from the TMcraft Development Kit; during the process, the TMcraft Packer compiles the User Control Library into an execution file and zip it with the resource files within the source folder. Finally , import the TMcraft Toolbar zip to TMflow.




Figure 2: Development process of a TMcraft Toolbar

This manual briefly explains the framework of a TMcraft Toolbar Program and outlines all TMcraft Toolbar API functions. Note that this manual does not cover all enums and additional classes in the TMcraft.dll, but the most relevant to TMcraft Toolbar.

2. Programming with TMcraft Toolbar API

To understand the TMcraft Toolbar program structure, refer the sample code below.

```
using TMcraft;

namespace ToolbarSample
{
    public partial class MainPage : UserControl, ITMcraftToolbarEntry
    {
        TMcraftToolbarAPI ToolbarUI;

        public MainPage()
        {
            InitializeComponent();

            private void InitializeToolbar(TMcraftToolbarAPI _tmToolbarEditor)
            {
                TMToolbarEditor = _tmToolbarEditor;
            }

            private void UserControl _Loaded (object sender, RoutedEventArgs e) {}
            private void UserControl _Unloaded (object sender, RoutedEventArgs e) {}
        }
    }
}
```

To create the foundation of a TMcraft Toolbar Program, please remind the following items:

1. Include TMcraft.dll as a reference. Rememeber to import the namespace (`using TMcraft`) onto the program.
2. Declare a global object based on the class `TMcraftToolbarAPI`.
3. When loading the user control of the Toolbar GUI, assign the object, see `UserControl_Loaded`.

The rest of the Program should be all sorts of event functions that can interact with TMflow through TMcraft API functions.

3. TMcraft API functions (Toolbar related)

3.1 TMcraftToolbarAPI

TMcraft.dll is a combination of the APIs of all sort of TMcraft items; for TMcraft Toolbar, please declare an object of the class *TMcraftToolbarAPI* and use the function within. Like other TMcraft API, *TMcraftToolbarAPI* contains different members (or providers) functions in order to interact with TMflow.



IMPORTANT:

TM AI + AOI Edge comes without any robot-related functionality, so it does not support some TMcraft API functions. For TMcraft Toolbar, the unsupported functions include:

- RobotJogProvider: all functions
- RobotStatusProvider: all functions, except GetFlowVersion, GetOperationMode, ProjectEditOrNot, ProjectPauseOrNot, ProjectRunOrNot, and ErrorEvent
- TCPProvider: all functions
- Enumeration types: FreeBotMode, MoveMode, RobotEventType
- Additional class: FreeBotInfo, TCPInfo

3.1.1 Version

Syntax

```
string TMcraftToolbarAPI.Version
```

Description

A member of the TMcraftToolbarAPI class. Returns a *string* represents the version of the current TMcraft.dll and is read-only.

Return

string Version of the current TMcraft API

3.1.2 Close

Syntax

```
void Close()
```

Description

Closes the TMcraft Toolbar.

Parameters

No parameters are required.

Return

None.

3.1.3 GetErrMsg

Syntax

```
TMcraft.TMcraftErr GetErrMsg(  
    unit errorCode,  
    out string ErrorMessage
```

)

Description

Output the error message according to the error code input. This function is used for checking the result of calling Provider functions.

Parameters

errorCode	The unit error code returned by most Provider functions.
errorMessage	Response the associated error message by the input error code.

Return

[TMcraft.TMcraftErr](#) Returns [TMcraftErr.OK](#) if the function works properly; otherwise, returns the corresponding TMcraftErr. For more detail, please check [enum TMcraft.TMcraftErr](#).

3.2 ITMcraftToolBarEntry

[ITMcraftToolBarEntry](#) is an Interface provided by TMcraft API which defines a contract of being a TMcraft Toolbar. Any class that implements this contract must provide an implementation of a specific member function: [InitializeToolBar\(\)](#).

3.2.1 InitializeToolBar

Syntax

```
void InitializeToolBar(
    TMcraftToolBarAPI tMToolBarEditor
)
```

Description

Initializes the Toolbar with user-defined actions.

Parameters

tMToolBarEditor	The TMcraftToolBarAPI object connects the TMcraft Toolbar with TMflow.
-----------------	--

Return

None.

3.3 EndButtonEventProvider

[EndButtonEventProvider](#) contains functions related to the end button event.

3.3.1 HasEndButtonEventOwnership

Syntax

```
uint HasEndButtonEventOwnership()
```

Description

TMcraft plugin can call this function to check if it has the end button event ownership or not. If yes, this TMcraft plugin is the only one who can receive the end button event signal.

Parameters

None

Return**bool**

Returns True if the TMcraft plugin has the end button event ownership; otherwise, returns Fail.

3.3.2 IsEndButtonBoardcastMode**Syntax****uint IsEndButtonBoardcastMode()****Description**

TMcraft plugin can call this function to check if the end button event is currently in boardcast mode. If yes, that means all TMcraft plugins can receive the event signal; otherwise, one of the TMcraft plugin has the ownership. i.e. other plugins receive no signal from the event.

Parameters

None

Return**bool**

Returns True if the end button event is currently in boardcast mode; otherwise, returns Fail.

3.3.3 ReleaseEndButtonEventOwnership**Syntax****uint ReleaseEndButtonEventOwnership()****Description**

TMcraft plugin can call this function to release the button event ownership.

Parameters

None

Return**uint**

The error code that represents the result of the function calling.

3.3.4 SetEndButtonEventOwnership**Syntax****uint SetEndButtonEventOwnership()****Description**

TMcraft plugin can call this function to get the end button event ownership.

Parameters

None

Return**uint**

The error code that represents the result of the function calling.

3.3.5 EndButtonClickEvent**Description**

An event type denotes to the click event occurred on the buttons of the End Module. Function

can be linked to this event so that it will be activated once the event is triggered.

3.4 FreebotProvider

[FreeBotProvider](#) provides functions related to freebot.

3.4.1 GetFreeBot

Syntax

```
uint GetFreeBot(
    out FreeBotInfo freeBot
)
```

Description

Gets the value of the current FreeBot settings.

Parameters

freeBot	Value of the current FreeBot settings defined by FreeBotInfo.
---------	---

Return

uint	The error code that represents the result of the function calling.
------	--

3.4.2 HoldFreeBotKeyToHandGuide

Syntax

```
uint HoldFreeBotKeyToHandGuide(
    bool holdKey
)
```

Description

Mimics holding the freebot button to enter hand guide mode. Note that, calling this function alone is not enough, another function KeepFreeBot should be running at the same time.

Parameters

holdKey	True means to activate the hand guide mode; false means to deactivate.
---------	--

Return

uint	The error code that represents the result of the function calling.
------	--

3.4.3 KeepFreeBot

Syntax

```
uint KeepFreeBot()
```

Description

Keep the current hand guide mode. After sending HoldFreeBotKeyToHandGuide, this function should be keep sending every 100 - 500 ms until the hand guiding ends, otherwise, the robot will leave hand guide mode.

Parameters

None

Return`uint`

The error code that represents the result of the function calling.

3.4.4 SetFreeBot**Syntax**

```
uint SetFreeBot(
    FreeBotInfo freeBot
)
```

Description

Sets FreeBot settings.

Parameters`freeBot`

A FreeBotInfo being assigned as FreeBot settings.

Return`uint`

The error code that represents the result of the function calling.

3.5 IOProvider`IOProvider` provides functions for TMcraft item to interact with system I/O.**3.5.1 GetAllIOData****Syntax**

```
UInt GetAllIOData(
    out List<DeviceIOInfo> ioData
)
```

Description

Gets all IO status.

Parameters`ioData`

A List of DeviceIOInfo objects that denotes all IO status data.

Return`UInt`

The error code that represents the result of the function calling.

3.5.2 ReadAnalogInput**Syntax**

```
UInt ReadAnalogInput(
    IO_TYPE type,
    int deviceSerialNum,
    int channelNum,
    out float value
)
```

Description

Read the status of a specific Analog Input.

Parameters

type	The <code>IO_TYPE</code> enum that defines which device the target Analog Input belongs to.
deviceSerialNum	Device serial number, which always starts from 0 and is more meaningful if the target device is an external IO module because there might be multiple external IO module devices within the system. The number is 0 if the target device is the Control box IO board or end module IO board because there are only one Control box IO board and one end module IO board.
channelNum	Channel number.
value	Analog Input value, ranged from -10V to 10V.

Return

<code>UInt</code>	The error code that represents the result of the function calling.
-------------------	--

3.5.3 ReadAnalogOutput**Syntax**

```
UInt ReadAnalogOutput(
    IO_TYPE type,
    int deviceSerialNum,
    int channelNum,
    out float value
)
```

Description

Read the status of a specific Analog Output.

Parameters

type	The <code>IO_TYPE</code> enum that defines which device the target Analog Outputs belongs to.
deviceSerialNum	Device serial number, which always starts from 0 and is more meaningful if the target device is an external IO module because there might be multiple external IO module devices within the system. The number is 0 if the target device is the Control box IO board or end module IO board because there are only one Control box IO board and one end module IO board.
channelNum	Channel number.
value	Analog Outputs value, ranged from -10V to 10V.

Return

<code>UInt</code>	The error code that represents the result of the function calling.
-------------------	--

3.5.4 ReadDigitInput

Syntax

```

UInt ReadDigitInput(
    IO_TYPE type,
    int deviceSerialNum,
    int channelNum,
    out float value
)

```

Description

Read the status of a specific Digital Input.

Parameters

type	The IO_TYPE enum that defines which device the target Digital Input belongs to.
deviceSerialNum	Device serial number, which always starts from 0 and is more meaningful if the target device is an external IO module because there might be multiple external IO module devices within the system. The number is 0 if the target device is the Control box IO board or end module IO board because there are only one Control box IO board and one end module IO board.
channelNum	Channel number.
status	Digital Input status, where bool true is HIGH and bool false is LOW.

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.5.5 ReadDigitOutput

Syntax

```

UInt ReadDigitOutput(
    IO_TYPE type,
    int deviceSerialNum,
    int channelNum,
    out float value
)

```

Description

Read the status of a specific Digital Output.

Parameters

type	The IO_TYPE enum that defines which device the target Digital Outputs belongs to.
deviceSerialNum	Device serial number, which always starts from 0 and is more meaningful if the target device is an external IO module because

there might be multiple external IO module devices within the system. The number is 0 if the target device is the Control box IO board or end module IO board because there are only one Control box IO board and one end module IO board.

channelNum

Channel number.

status

Digital Outputs status, where **bool** true is HIGH and **bool** false is LOW.

Return

Uint

The error code that represents the result of the function calling.

3.5.6 SetCameraLight

Syntax

```
Uint SetCameraLight(
    bool status
)
```

Description

Switch the Eye-In-Hand camera light to the ON or OFF status.

Parameters

status

bool true denotes turning the light ON,
bool false denotes turning the light OFF

Return

Uint

The error code that represents the result of the function calling.

3.5.7 WriteDigitOutput

Syntax

```
Uint WriteDigitOutput(
    IO_TYPE type,
    int deviceSerialNum,
    int channelNum,
    bool status
)
```

Description

Change the status of a specific Digital Output.

Parameters

type

The **IO_TYPE** enum that defines which device the target Digital Outputs belongs to.

deviceSerialNum

Device serial number, which always starts from 0 and is more meaningful if the target device is an external IO module because there might be multiple external IO module devices within the system. The number is always 0 if the target device is the Control box

	IO board or end module IO board because there are only one Control box IO board and one end module IO board.
channelNum	Signal channel number.
status	Digital Outputs status, where bool true is HIGH and bool false is LOW.

Return

Uint	The error code that represents the result of the function calling.
-------------	--

3.5.8 WriteAnalogOutput**Syntax**

```
Uint WriteAnalogOutput(
    IO_TYPE type,
    int deviceSerialNum,
    int channelNum,
    float value
)
```

Description

Set the value of a specific Analog Output.

Parameters

type	The IO_TYPE enum that defines which device the target Analog Outputs belongs to.
deviceSerialNum	Device serial number, which always starts from 0 and is more meaningful if the target device is an external IO module because there might be multiple external IO module devices within the system. The number is 0 if the target device is the Control box IO board or end module IO board because there are only one Control box IO board and one end module IO board.
channelNum	Channel number.
value	Analog Outputs value, ranged from -10V to 10V.

Return

Uint	The error code that represents the result of the function calling.
-------------	--

3.6 RobotJogProvider

RobotJogProvider provides functions for TMcraft item to jog the robot.

**IMPORTANT:**

If the TMcraft Toolbar uses any RobotJogProvider functions for motion control, it is the responsibility of the developer to make sure single point of control within ISO 10218-1.

3.6.1 HoldPlayKeyToRun

Syntax

```
uint HoldPlayKeyToRun(
    bool holdKey
)
```

Description

This function mimics the process of holding play key to start jogging motion. Note that, at the same time, **KeepJogging()** should be sent every 100 - 500 ms until the jogging ends, otherwise, the jogging will stop automatically.

Parameters

holdKey	True means to hold the key; false means to release the key.
---------	---

3.6.2 JogByBase

Syntax

```
uint JogByBase(
    float speedPercentage,
    float [] targetCoordinates
)
```

Description

Jogs the robot towards the target's Coordinates (relative to current base and tool) with a 6×1 **float** array {x, y, z, rx, ry ,rz}. This function will not trigger any motion directly, as it requires following by either pressing the PLAY button on the robot stick (may also requires Enabling Switch) or using API functions: **HoldPlayKeyToRun** + **KeepJogging**.

Parameters

speedPercentage	Speed percentage is equivalent to the speed (in percentage) setting on the TMflow Controller, where the current jogging speed should match the max joint speed. The max joint speed of the robot model is multiplied by the speed percentage, and the product (TCP speed) of this multiplication should always be lower than Manual Control mode speed limit (250 mm/s). speedPercentage is expressed in decimals (e.g., 1.5 for 1.5%)..
targetMovementValue	A 6×1 float array {x, y, z, rx, ry ,rz} of target movement value.

Return

uint	The error code that represents the result of the function calling.
-------------	--

3.6.3 JogByJoint

Syntax

```
uint JogByJoint(
    float speedPercentage,
    float[] targetJointAngles
)
```

Description

Jogs the robot towards the targets Joint Angles. This function will not trigger any motion directly, as it requires following by either pressing the PLAY button on the robot stick (may also requires Enabling Switch) or using API functions: **HoldPlayKeyToRun** + **KeepJogging**.

Parameters

speedPercentage	Speed percentage is equivalent to the speed (in percentage) setting on the TMflow Controller, where the current jogging speed should match the max joint speed. The max joint speed of the robot model is multiplied by the speed percentage, and the product (TCP speed) of this multiplication should always be lower than Manual Control mode speed limit (250 mm/s). speedPercentage is expressed in decimals (e.g., 1.5 for 1.5%).
targetJointAngles	A 6×1 float array {J1, J2, J3, J4, J5, J6} which represents the target Joint Angle.

Return

uint	The error code that represents the result of the function calling.
-------------	--

3.6.4 JogCircle

Syntax

```
uint JogCircle(
    float speedPercentage,
    float[] passPoint,
    float[] endPoint,
    int targetAngle
)
```

Description

Jogs the end-effector circularly. Like circle node, the circue is always defined by 3 points: the initial position of the end-effector, a pass point and an end point. This function will not trigger any motion directly, as it requires following by either pressing the PLAY button on the robot stick (may also requires Enabling Switch) or using API functions: **HoldPlayKeyToRun** + **KeepJogging**.

Parameters

speedPercentage	Speed percentage is equivalent to the speed (in percentage) setting on the TMflow Controller, where the current jogging speed
-----------------	---

should match the max joint speed. The max joint speed of the robot model is multiplied by the speed percentage, and the product (TCP speed) of this multiplication should always be lower than Manual Control mode speed limit (250 mm/s). speedPercentage is expressed in decimals (e.g., 1.5 for 1.5%).

passPoint	The 2nd point required to define the circle, described by Cartesian Space.
endpoint	The last point required to define the circle, described by Cartesian Space.
targetAngle	Define how much arc of the circle to be jogged. If the target angle is 0, the trajectory will end at the end point.

Return

uint	The error code that represents the result of the function calling.
------	--

3.6.5 JogRelativeByBase

Syntax

```
uint JogRelativeByBase(
    float speedPercentage,
    float [] targetCoordinates
)
```

Description

Jogs the robot by relative motion according to the current base. This function will not trigger any motion directly, as it requires following by either pressing the PLAY button on the robot stick (may also requires Enabling Switch) or using API functions: **HoldPlayKeyToRun** + **KeepJogging**.

Parameters

speedPercentage	Speed percentage is equivalent to the speed (in percentage) setting on the TMflow Controller, where the current jogging speed should match the max joint speed. The max joint speed of the robot model is multiplied by the speed percentage, and the product (TCP speed) of this multiplication should always be lower than Manual Control mode speed limit (250 mm/s). speedPercentage is expressed in decimals (e.g., 1.5 for 1.5%).
targetCoordinates	A 6x1 float array {x, y, z, rx, ry ,rz} of target movement value.

Return

uint	The error code that represents the result of the function calling.
------	--

3.6.6 JogRelativeByJoint

Syntax

```
uint JogRelativeByJoint(
    float speedPercentage,
    float [] targetJointAngles
)
```

Description

Jogs the robot relatively by given joint angles along with Tool Axes. This function will not trigger any motion directly, as it requires following by either pressing the PLAY button on the robot stick (may also requires Enabling Switch) or using API functions: **HoldPlayKeyToRun** + **KeepJogging**.

Parameters

speedPercentage	Speed percentage is equivalent to the speed (in percentage) setting on the TMflow Controller, where the current jogging speed should match the max joint speed. The max joint speed of the robot model is multiplied by the speed percentage, and the product (TCP speed) of this multiplication should always be lower than Manual Control mode speed limit (250 mm/s). speedPercentage is expressed in decimals (e.g., 1.5 for 1.5%).
targetJointAngles	A 6×1 float array {J1, J2, J3, J4, J5, J6} of target movement value.

Return

uint	The error code that represents the result of the function calling.
-------------	--

3.6.7 JogRelativeByTool

Syntax

```
uint JogRelativeByTool(
    float speedPercentage,
    float [] targetMovementValue
)
```

Description

Jogs the robot along with Tool Axes. Remind that, like using TMflow Controller, users need to use the robot stick (e.g. Enabling Device + PLAY) to start the motion.

Parameters

speedPercentage	Speed percentage is equivalent to the speed (in percentage) setting on the TMflow Controller, where the current jogging speed should match the max joint speed. The max joint speed of the robot model is multiplied by the speed percentage, and the product (TCP
-----------------	--

speed) of this multiplication should always be lower than Manual Control mode speed limit (250 mm/s). speedPercentage is expressed in decimals (e.g., 1.5 for 1.5%).

targetMovementValue A 6x1 float array {x, y, z, rx, ry ,rz} of target movement value.

Return

uint The error code that represents the result of the function calling.

3.6.8 KeepJogging

Syntax

uint KeepJogging()

Description

Keep the current jogging. After sending HoldPlayKeyToRun, this function should be keep sending every 100 - 500 ms until the jogging ends, otherwise, the jogging will stop automatically.

Parameters

No parameters are required.

Return

uint The error code that represents the result of the function calling.

3.6.9 StopJog

Syntax

uint StopJog()

Description

Stops all Jog motion immediately. It is also recommended to call this function before calling Jog motion functions in order to clear the motion buffer

Parameters

No parameters are required.

Return

uint The error code that represents the result of the function calling.

3.7 RobotStatusProvider

RobotStatusProvider provides functions for TMcraft items to access different robot status information.

3.7.1 GetCurrentBaseName

Syntax


```

    Uint GetCurrentBaseName(
        out string baseName
    )

```

Description

Gets the name of the current Base.

Parameters

baseName	Current Base name.
----------	--------------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.2 GetCurrentPayload

Syntax

```

    Uint GetCurrentPayload(
        out float payload
    )

```

Description

Gets the current payload value set to the robot (end-effector).

Parameters

payload	Current payload value being assigned.
---------	---------------------------------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.3 GetCurrentPoseByCurrentBase

Syntax

```

    Uint GetCurrentPoseByCurrentBase(
        out float[] currentPose
    )

```

Description

Gets robot current TCP position defined by the Current Base.

Parameters

currentPose	A 6×1 float array {x, y, z, rx, ry, rz} that denotes the current robot pose.
-------------	--

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.4 GetCurrentPoseByJointAngle

Syntax

```

    UInt GetCurrentPoseByJointAngle(
        out float[] jointAngles
    )

```

Description

Gets all robot current Joint Angles.

Parameters

jointAngles	A 6×1 float array {j1, j2, j3, j4, j5, j6} that denotes the current robot pose.
-------------	--

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.7.5 GetCurrentPoseByRobotBase

Syntax

```

    UInt GetCurrentPoseByRobotBase(
        out float[] currentPose
    )

```

Description

Gets robot current TCP position defined by the Robot Base.

Parameters

currentPose	A 6×1 float array {x, y, z, rx, ry, rz} that denotes the current robot pose.
-------------	---

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.7.6 GetCurrentRobotConfigs

Syntax

```

    UInt GetCurrentRobotConfigs(
        out int[] robotConfigs
    )

```

Description

Gets current Robot Config.

Parameters

robotConfigs	A 3×1 interger array denoting the robot configurations of the point; here is the definition: int [0]: 0 – Right Arm, 1 – Left Arm int [1]: 2 – Above Elbow, 3 – Below Elbow int [2]: 4 – Up Wrist, 5 – Down Wrist
--------------	---

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.7.7 GetCurrentTcp

Syntax

```

    Uint GetCurrentTcp(
        out string tcpName
    )

```

Description

Gets the name of current TCP.

Parameters

tcpName	Current TCP name.
---------	-------------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.8 GetFlowVersion

Syntax

```

    Uint GetFlowVersion(
        out string result
    )

```

Description

Gets the version of TMflow.

Parameters

result	TMflow version.
--------	-----------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.9 GetOperationMode

Syntax

```

    uint GetOperationMode(
        out int mode
    )

```

Description

Gets current operation mode.

Parameters

mode	Current operation mode, which includes: 0 – Manual and 1 – Auto.
------	--

Return

uint	The error code that represents the result of the function calling.
------	--

3.7.10 GetRobotModelType

Syntax

```

    Uint GetRobotModeType(
        out string result
    )

```

Description

Gets the model type of the robot.

Parameters

result	Model Type of the robot.
--------	--------------------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.11 ProjectEditOrNot**Syntax**

```

    Uint ProjectEditOrNot(
        out bool result
    )

```

Description

Outputs if any project is under editing or not.

Parameters

result	If any project is under editing or not.
--------	---

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.12 ProjectPauseOrNot**Syntax**

```

    Uint ProjectPauseOrNot(
        out bool result
    )

```

Description

Outputs if the current project is paused or not.

Parameters

result	If the current project is paused or not. It would be True only if there is a running project and it is in pause status.
--------	---

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.13 ProjectRunOrNot**Syntax**

```

    Uint ProjectRunOrNot(
        out bool result
    )

```

)

Description

Outputs if any project is running or not.

Parameters

result	If any project is running or not.
--------	-----------------------------------

Return

<div style="color: blue;">UInt</div>	The error code that represents the result of the function calling.
--------------------------------------	--

3.7.14 RobotErrorOrNot

Syntax

```


UInt

 RobotErrorOrNot(
    

out bool

 result
)

```

Description

Outputs if the robot is in error status or not.

Parameters

result	If the robot is in error status or not.
--------	---

Return

<div style="color: blue;">UInt</div>	The error code that represents the result of the function calling.
--------------------------------------	--

3.7.15 RobotEstopOrNot

Syntax

```


UInt

 RobotEstopOrNot(
    

out bool

 result
)

```

Description

Outputs if any project is under Estop status or not.

Parameters

result	If any project is under editing or not.
--------	---

Return

<div style="color: blue;">UInt</div>	The error code that represents the result of the function calling.
--------------------------------------	--

3.7.16 SetCurrentBase

Syntax

```


UInt

 SetCurrentBase(
    

string

 baseName
)

```

Description

Assigns a specific Base as the current base.

Parameters

baseName	Name of the base being assigned.
----------	----------------------------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.17 SetCurrentPayload**Syntax**

```

Uint SetCurrentPayload(
    float payload
)

```

Description

Sets a payload value to the robot (end-effector).

Parameters

payload	Payload value being assigned.
---------	-------------------------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.18 SetCurrentTcp**Syntax**

```

Uint SetCurrentTcp(
    string tcpName
)

```

Description

Assigns a specific TCP as the current TCP.

Parameters

tcpName	Name of the TCP being assigned.
---------	---------------------------------

Return

Uint	The error code that represents the result of the function calling.
------	--

3.7.19 ErrorEvent**Description**

An event type denotes to the error event occurred on the robot. Function can be linked to this event so that it will be activated once the event is triggered.

3.8 SystemProvider

SystemProvider provides functions for TMcraft item to interact with TMflow System Settings.

3.8.1 GetCurrentLanguageCulture

Syntax

```

    Uint GetCurrentLanguageCulture(
        out string language
    )

```

Description

Gets the current language setting of the system.

Parameters

language	Current System language, e.g., en-US, zh-TW, zh-CN, ja-JP, de-DE, ko-KR
----------	---

Return

Uint	The error code that represents the result of the function calling.
------	--

3.8.2 GetTMflowType

Syntax

```

    Uint GetTMflowType(
        out TMflowType type
    )

```

Description

Gets the current TMflow type of the system.

Parameters

type	Represent the TMflow type (e.g. Robot, AOIEdge, etc.) of the current system. For more detail, check the description of enum TMflowType.
------	---

Return

Uint	The error code that represents the result of the function calling.
------	--

3.9 TcpProvider

[TcpProvider](#) provides functions for TMcraft to access or modify TCPs with the robot.

3.9.1 ChangeTcpInertia

Syntax

```

    Uint ChangeTcpInertia(
        string tcpName,
        float[] inertiaValue
    )

```

Description

Modifies the inertia value of a specific TCP.

Parameters

tcpName	Name of the target TCP.
inertiaValue	A 3×1 float array {lxx, lyy, lzz} of inertia value being assigned.

Return

Uint	The error code that represents the result of the function calling.
-------------	--

3.9.2 ChangeTcpMass**Syntax**

```
Uint ChangeTcpMass(
    string tcpName,
    float mass
)
```

Description

Modifies the mass value (kg) of a specific TCP.

Parameters

tcpName	Name of the target TCP.
mass	Mass value (kg) to be assigned.

Return

Uint	The error code that represents the result of the function calling.
-------------	--

3.9.3 ChangeTcpMassCenter**Syntax**

```
Uint ChangeTcpMassCenter(
    string tcpName,
    float[] massCenter
)
```

Description

Modifies the Mass Center value of a specific TCP.

Parameters

tcpName	Name of the target TCP.
massCenter	A 6×1 float array {x, y, z, rx, ry, rz} that denotes the location of the mass center of the TCP.

Return

Uint	The error code that represents the result of the function calling.
-------------	--

3.9.4 ChangeTcpPose**Syntax**


```

    UInt ChangeTcpPose(
        string tcpName,
        float[] toolCenterPoint
    )

```

Description

Modifies the tool center point of a specific TCP by a 6×1 **float** array {x, y, z, rx, ry, rz} referring to Flange Base.

Parameters

tcpName	Name of the target TCP being modified.
toolCenterPoint	A 6×1 float array[6] {x, y, z, rx, ry, rz} of new Pose value referring to Flange Base.

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.9.5 CreateNewTcp

Syntax

```

    UInt CreateNewTcp(
        TCPInfo tcpData
    )

```

Description

Create a new TCP by using a **TCPInfo** Type as input.

Parameters

tcpData	TCPInfo type assigned for the new TCP.
---------	--

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.9.6 DeleteTcp

Syntax

```

    UInt DeleteTcp(
        string tcpName
    )

```

Description

Delete a specific TCP file.

Parameters

tcpName	Name of the TCP being deleted.
---------	--------------------------------

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.9.7 GetProjectVisionTcpList

Syntax

```

UInt GetProjectVisionTcpList(
    out List<string> visionTcpList
)

```

Description

Gets the list of Vision TCP Names from the current Project.

Parameters

visionTcpList	A List of vision TCP names.
---------------	------------------------------------

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.9.8 GetTcpInertia

Syntax

```

UInt GetTcpInertia(
    string tcpName,
    out float[] inertiaValue
)

```

Description

Gets the inertia value of a specific TCP.

Parameters

tcpName	Name of the target TCP.
inertiaValue	A 3×1 float array {lxx, lyy, lzz} that denotes the inertia value of the target TCP.

Return

UInt	The error code that represents the result of the function calling.
-------------	--

3.9.9 GetTcpList

Syntax

```

UInt GetTcpList(
    out List<TCPIInfo> tcpList
)

```

Description

Gets the list of all TCPs (with data) within the robot.

Parameters

tcpList	A List of TCPIInfo type that denotes all TCPs within the robot.
---------	---

Return

UInt

The error code that represents the result of the function calling.

3.9.10 GetTcpMass

Syntax

```

UInt GetTcpMass(
    string tcpName,
    out float mass
)

```

Description

Gets the value of mass (kg) from a specific TCP.

Parameters

tcpName	Name of the target TCP.
mass	Mass value (kg) of the target TCP.

Return

UInt The error code that represents the result of the function calling.

3.9.11 GetTcpMassCenter

Syntax

```

UInt GetTcpMassCenter(
    string tcpName,
    out float[] massCenter
)

```

Description

Gets the Mass Center value of a specific TCP.

Parameters

tcpName	Name of the target TCP.
massCenter	A 6×1 float array {x, y, z, rx, ry, rz} that denotes the location of the mass center of the TCP.

Return

UInt The error code that represents the result of the function calling.

3.9.12 IsTcpExist

Syntax

```

bool IsTcpExist(
    string tcpName
)

```

Description

Checks if a specific tcp exists or not.

Parameters

tcpName	Name of the tcp being checked.
---------	--------------------------------

Return

bool	True if exists, false if not.
------	-------------------------------

3.10 TextFileProvider

TextFileProvider provides functions for TMcraft plugin to manipulate Textfiles within TMflow.

3.10.1 DeleteTextFile

Syntax

```
uint DeleteTextFile (
    string fileName
)
```

Description

Deletes a specific Textfile.

Parameters

fileName	Name of the file being deleted.
----------	---------------------------------

Return

uint	The error code that represents the result of the function calling.
------	--

3.10.2 ExportTextFile

Syntax

```
uint ExportTextFile (
    string fileName
)
```

Description

Exports a specific Textfile to the USB.

Parameters

fileName	Name of the file being exported.
----------	----------------------------------

Return

uint	The error code that represents the result of the function calling.
------	--

3.10.3 GetTextFileList

Syntax

```
uint GetTextFileList (
    out string list
)
```

Description

Gets the list of Textfile names within the current system.

Parameters

list	A list of Textfile names within the current system
------	--

Return

uint	The error code that represents the result of the function calling.
------	--

3.10.4 ImportTextFile**Syntax**

```
uint ImportTextFile (
    string robotName,
    string fileName
)
```

Description

Import a Textfile to the robot.

Parameters

robotName	Name of the folder where the system can find the item to be imported.
fileName	Name of the file being imported.

Return

uint	The error code that represents the result of the function calling.
------	--

3.10.5 NewTextFile**Syntax**

```
uint NewTextFile (
    string filename,
    string fileContent
)
```

Description

Create a new Textfile.

Parameters

fileName	Name of the file being created.
fileContent	Content of the Textfile to be assigned.

Return

uint	The error code that represents the result of the function calling.
------	--

3.10.6 ReadTextFile**Syntax**

```
uint ReadTextFile (
    string filename,
    out string fileContent
)
```

Description

Read the content of a specific Textfile.

Parameters

fileName	Name of the file being read.
fileContent	Content of the Textfile to be read.

Return

uint	The error code that represents the result of the function calling.
------	--

3.10.7 WriteTextFile

Syntax

```
uint WriteTextFile (
    string filename,
    string fileContent
)
```

Description

Write content to a specific Textfile.

Parameters

fileName	Name of the file being written.
fileContent	Content of the Textfile to be written.

Return

uint	The error code that represents the result of the function calling.
------	--

3.11 VariableProvider

[VariableProvider](#) provides functions for TMcraft to access or modify the variables of the robot.

3.11.1 ChangeGlobalVariableValue

Syntax

```
UInt ChangeGlobalVariableValue(
    List<string[]> value
)
```

Description

Sets the value of a specific Global Variables.

Parameters

value	A list of global variables being modified; each element within this list should be a 2x1 string array {varName, varValue}, where varName is the name of the target variable and varValue is the value being assigned.
-------	---

Return

UInt	The error code that represents the result of the function calling.
------	--

3.11.2 ChangeProjectVariableValue

Syntax

```

UInt ChangeProjectVariableValue(
    string varName,
    string value
)

```

Description

Changes the initial value of a specific project variable. Note that this function only works if there is a project currently under editing.

Parameters

varName	Represents the name of the project variable to be changed.
value	Represents the value to be assigned.

Return

UInt The error code that represents the result of the function calling.

3.11.3 CreateGlobalVariable

Syntax

```

UInt CreateGlobalVariable(
    string name,
    VariableType type,
    string value
)

```

Description

Creates a new global variable by the input parameters.

Parameters

name	Name of the variable being created.
type	Type of variable being created.
value	Value being assigned to the new variable.

Return

UInt The error code that represents the result of the function calling.

3.11.4 DeleteGlobalVariable

Syntax

```

UInt DeleteGlobalVariable(
    string name
)

```

Description

Deletes a specific global variable from the robot.

Parameters

name	Name of the global variable being deleted.
------	--

Return

Uint

The error code that represents the result of the function calling.

3.11.5 GetGlobalVariableList

Syntax

```


      Uint
     GetGlobalVariableList(
      
        ref List<VariableInfo>
       variables
    )
  
```

Description

Gets all Global Variables (**VariableInfo** Type) from the robot and overwrites the input **List**.

Parameters

variables	A List of Variable Info type that contains all global variables within the robot.
-----------	--

Return

Uint

The error code that represents the result of the function calling.

3.11.6 GetGlobalVariableValue

Syntax

```


      Uint
     GetGlobalVariableValue(
      
        string
       varName,
      
        out string
       value
    )
  
```

Description

Gets the value of a specific global variable.

Parameters

varName	Represents the name of the target global variable.
value	Outputs the value of {varName}

Return

Uint

The error code that represents the result of the function calling.

3.11.7 GetProjectVariableList

Syntax

```


      Uint
     GetProjectVariableList(
      
        ref List<VariableInfo>
       variables
    )
  
```

Description

Gets all Project Variables (**VariableInfo** Type) from the current TMflow Project and overwrites the input **List**. Note that this function only works if there is a project currently under editing.

Parameters

variables	A List of VariableInfo type that contains all Project Variables within
-----------	--

the current Project.

Return

Uint

The error code that represents the result of the function calling.

3.11.8 GetVariableRuntimeValue

Syntax

```

Uint GetVariableRuntimeValue(
    string varName,
    out string value
)
  
```

Description

Gets the runtime value of a specific variable. Note that this function only works if there is a project currently running.

Parameters

varName	Represents the name of the target variable.
value	Outputs the value of {varName}

Return

Uint

The error code that represents the result of the function calling.

3.11.9 IsGlobalVariableExist

Syntax

```

bool IsGlobalVariableExist(
    string varName
)
  
```

Description

Checks if a specific Global Variable exists or not.

Parameters

varName	Name of the Global Variable being checked.
---------	--

Return

bool

True if exists, false if not.

3.11.10 IsProjectVariableExist

Syntax

```

bool IsProjectVariableExist(
    string varName
)
  
```

Description

Checks if a specific Project Variable exists or not. Note that this function only works if there is a project currently under editing.

Parameters

Return	varName	Name of the Project Variable being checked.
	bool	True if exists, false if not.

4. Enumeration types

4.1 FreeBotMode

```
public enum FreeBotMode
{
    All_Joints,
    Custom,
    RXYZ,
    SCARA_Like,
    XYZ
}
```

Description

Enum [FreeBotMode](#), which is used as a member of the class [TMcraftToolbarAPI.FreeBotInfo](#) and represents the FreeBot mode setting.

Items

FreeBotMode.All_Joints	Represents free all joints mode.
FreeBotMode.Custom	Represents custom FreeBot mode.
FreeBotMode.RXYZ	Represents free RXYZ (Rx, Ry, Rz) mode.
FreeBotMode.SCARA_Like	Represents SCARA-like FreeBot mode.
FreeBotMode.XYZ	Represents free XYZ mode.

4.2 IO_TYPE

```
public enum IO_TYPE
{
    UNKNOWN,
    CONTROL_BOX,
    END_MODULE,
    EXT_MODULE
}
```

Description

Enum [IO_TYPE](#), paired with [TMcraftToolbarAPI.IOProvider](#) functions such as [WriteDigitOutput\(\)](#), defines the IO device within TM robot.

Items

IO_TYPE.UNKNOWN	Represents an unknown device detected. When using IOProvider.GetAllIOData() , if there is any unknown device detected, IO_TYPE.UNKNOWN will be found within the DeviceIOInfo data
IO_TYPE.CONTROL_BOX	Control Box I/O.
IO_TYPE.END_MODULE	End Module I/O (Tool End I/O Interface).
IO_TYPE.EXT_MODULE	External I/O Device(s) connected to the robot.

4.3 MoveMode

```
public enum MoveMode
{
    Accurate,
    Fast,
    Normal
}
```

Description

Enum [MoveMode](#), which is used as one of the parameters of the class [TMcraftToolbarAPI.FreeBotInfo](#). Move Mode is for users to adjust the initial damping of joints with modes of Accurate, Normal, and Fast. Damping increases the hand guide weight allowing faster stoppage while releasing the FREE button. For easier dragging, joint damping decreases proportionally as TCP speed increases during the hand guide. Once damping drops to zero, it stays at zero until the FREE button is released.

Items

MoveMode.Accurate	The highest joint damping. For the high initial force requirement with fast stoppage while releasing the FREE button.
MoveMode.Fast	The zero joint damping. For the low initial force requirement for dragging.
MoveMode.Normal	The low joint damping. For the medium initial force requirement with reasonable accuracy while stopping.

4.4 RobotEventType

```
public enum RobotEventType
{
    EndButtonFreeBotChanged,
    EndButtonGripperChanged,
    EndButtonPointChanged,
    EndButtonVisionChanged
}
```

Description

Enum [RobotEventType](#), paired with [TMcraftToolbarAPI.RobotStatusProvider](#)'s event [EndButtonClickEvent](#), defines the click event occurred on the buttons of the End Module.

Items

EndButtonFreeBotChanged	Represents the click event of the Free Button on the End Module. True denotes FreeBot is triggered while False denotes that the Free Button is either released or over-pressed.
EndButtonGripperChanged	Represents the click event of the Gripper Button on the End Module. True denotes the button is pressed while False denotes that pressing is released.
EndButtonPointChanged	Represents the click event of the Point Button on the End Module. True denotes the button is pressed while False denotes that pressing is released.

EndButtonVisionChanged

Represents the click event of the Vision Button on the End Module. True denotes the button is pressed while False denotes that pressing is released.

4.5 TMCraftErr

```
public enum TMCraftErr
{
    ConnectionFail,
    DevResponseError,
    ExceptionError
    InvalidParameter,
    NodeCloseFail,
    OK
}
```

Description

Enum [TMCraftErr](#) represents the possible error that may occurred not from TMflow, but TMCraft API itself. TMCraftErr is used as the object type returned by the functions [TMCraft-ToolbarAPI.GetErrMsg](#) and [TMCraftToolbarAPI.InitialTMCraftToolbar](#).

Items

TMCraftErr.ConnectionFail	TMcraft API failed to connect with TMflow.
TMCraftErr.DevResponseError	Unexpected error on TMcraft API. Please contact Techman Inc. for further analysis.
TMCraftErr.ExceptionError	Exception happended on TMCraft API. Please contact Techman Inc. for further analysis.
TMCraftErr.InvalidParameter	TMcraft API detects invalid parameters when calling provider functions. For example, empty string or incorrect array size.
TMCraftErr.NodeCloseFail	Failure happened when closing TMcraft Node on TMflow.
TMCraftErr.OK	No error.

4.6 TMflowType

```
public enum TMflowType
{
    AOIEdge,
    Client,
    OLP,
    Robot,
    Unknown
}
```

Description

Enum [TMflowType](#), which is the Outputs of [SystemProvider.GetTMflowType](#), represents the TMflow type of the current system, or more specifically, of where the [GetTMflowType](#) function is called.

Items

[TMflowType.AOIEdge](#)
[TMflowType.Client](#)
[TMflowType.OLP](#)
[TMflowType.Robot](#)
[TMflowType.Unknown](#)

Represents that the current system is AOI Edge.
 Represents that the current system is client TMflow.
 Represents that the current system is TMstudio Pro.
 Represents that the current system is on the robot.
 Represents that the current system is not recognizable as one of the TMflow type.

4.7 VariableType

`public enum VariableType`

```

{
    Integer,
    Float,
    Double,
    String,
    Byte,
    Boolean,
    IntegrArray,
    FloatArray,
    DoubleArray,
    StringArray,
    ByteArray,
    BooleanArray,
    Null
}

```

Description

Enum [VariableType](#), paired with [TMcraftToolbarAPI.VariableProvider](#) function [CreateGlobalVariable\(\)](#), defines variable types on TMflow.

5. Additional class

5.1 DeviceIOInfo

```
public class DeviceIOInfo
{
    public IO_TYPE type;
    public int deviceSerialNum;
    public List<DigitIOInfo> DICollection;
    public List<DigitIOInfo> DOCollection;
    public List<float> AOCollection;
    public List<float> AICollection;
}
```

Description

The [TMcraftToolbarAPI.DeviceIOInfo](#) describes all sorts of information related to a specific IO Device of the robot.

Members

Type	IO device that this information describes.
deviceSerialNum	Device serial number, which always starts from 0 and is more meaningful if the target device is an external IO module because there might be multiple external IO module devices within the system. The number is 0 if the target device is the Control box IO board or end module IO board because there is always one Control box IO board and one end module IO board.
DICollection	A List of DigitIOInfo Type, which represents all Digital Inputs within the IO Device and should be empty if there are no Digital Inputs. Please note that the index of the list represents the channel number.
DOCollection	A List of DigitIOInfo Type that represents all Digital Outputs within the IO Device and should be empty if there are no Digital Outputs. Please note that the index of the list represents the channel number.
AOCollection	A List of float Type that represents all Analog Outputs within the IO Device and should be empty if there are no Analog Outputs. Please note that the index of the list represents the channel number.
AICollection	A List of float Type that represents all Analog Inputs within the IO Device and should be empty if there are no Analog Inputs. Please note that the index of the list represents the channel number.

5.2 DigitIOInfo

```
public class DigitIOInfo
{
    public bool value;
    public bool isUserDefined;
```

}

Description

[DigitalIOInfo](#) describes the information of a Digital I/O channel which is used as the [List](#) data type of [TMcraftToolbarAPI.DeviceIOInfo.DICollection](#) and [TMcraftToolbarAPI.DeviceIOInfo.DOCollection](#).

Members

value	True denotes HIGH while false denotes LOW.
isUserDefined	True denotes this Digital Channel is set as a User-Defined IO (that triggers a signal to a button of the Robot Stick, reads the signal from a stick button, or detects if an error occurs in the system).

5.3 ErrorStatus

```
public class ErrorStatus
{
    public uint Error_Code;
    public uint[] Error_Codes;
    public string Error_Time;
    public uint Last_Error_Code;
    public uint[] Last_Error_Codes;
    public uint Last_Error_Time;
}
```

Description

[ErrorStatus](#) denotes the structure of the data return by [RobotStatusProvider.ErrorEvent](#). Note that the [ErrorEvent](#) does not return this object type directly, but a json string instead that can be converted to the [ErrorStatus](#) type.

Members

Error_Code	The major error code of the current error event, which should be the first item of Error_Codes , i.e. Error_Codes[0] . Note that Error_Code would be cleared after reset.
Error_Codes	All error codes related to the current error event. Note that Error_Codes would be cleared after reset.
Error_Time	Time stamp of Error_Code .
Last_Error_Code	The major error code of the last error event recorded, which should be the first item of Last_Error_Codes , i.e. Last_Error_Codes[0] . Note that Last_Error_Code would not be cleared after reset, but would be refreshed when another error event happens.
Last_Error_Codes	All error codes related to the last error event. Note that Last_Error_Codes would not be cleared after reset, but would be refreshed when another error event happens.
Last_Error_Time	Time stamp of Last_Error_Code .

5.4 FreeBotInfo


```

public class FreeBotInfo
{
    public FreeBotMode Mode;
    public MoveMode MoveMode;
    public bool isBaseMode;
    public bool isFreeX;
    public bool isFreeY;
    public bool isFreeZ;
    public bool isFreeRX;
    public bool isFreeRY;
    public bool isFreeRZ;
}

```

Description

[TMcraftToolbarAPI.FreeBotInfo](#) is a TMcraft class that defines the FreeRobot configuration and is applied by 2 of the [TMcraftToolbarAPI.RobotStatusProvider](#) functions, [GetFreeBot\(\)](#) and [SetFreeBot\(\)](#). Note that if the member, Mode, is not [FreeBotMode.Custom](#), the rest of the members is meaningless.

Members

Mode	Represents the FreeBot mode; for more detail, please check TMcraft enum FreeBotMode
MoveMode	Represents the Move Mode setting of current Freebot; for more detail, please check TMcraft enum MoveMode .
isBaseMode	True means FreeBot Custom settings being defined by the current base; false means FreeBot Custom settings being defined by the current tool base.
isFreeX	Represents if the FreeBot Custom Setting has freed X axis or not.
isFreeY	Represents if the FreeBot Custom Setting has freed Y axis or not.
isFreeZ	Represents if the FreeBot Custom Setting has freed Z axis or not.
isFreeRX	Represents if the FreeBot Custom Setting has freed Rx axis or not.
isFreeRY	Represents if the FreeBot Custom Setting has freed Ry axis or not.
isFreeRZ	Represents if the FreeBot Custom Setting has freed Rz axis or not.

5.5 TCPInfo

```

public class TCPInfo
{
    public float[] data;
    public string name;
}

```

Description

[TMcraftToolbarAPI.TCPInfo](#), which describes the basic information of a TCP, is the element type of the Outputs [List](#) of [TMcraftToolbarAPI.TCPProvider](#).[GetTcpList\(\)](#).

Members

data	Tool Center Point, which defines a float [6] {x, y, z, Rx, Ry, Rz}
------	--

name	relative to the Flange base. Name of the TCP.
------	--

5.6 VariableInfo

```
public class VariableInfo
{
    public string Name;
    public VariableType Type;
    public string value;
    public bool isGlobal;
}
```

Description

[VariableInfo](#), paired with [TMcraftToolbarAPI.VariableProvider](#) functions such as [GetGlobalVariableList\(\)](#), describes all the information of a variable.

Members

Name	Name of the variable.
type	Data type of the variable.
value	Value of the variable.
isGlobal	True if it is a global variable; false if it is a Project Variable.

