

ABM2, ABM4 SERIES, ABMM SERIES

Line 1: **TUH**

Line 2: **P/N ZY X**

TUH Frequency

T = First "ten" digit of frequency

U = First "unit" digit of frequency

H = First "tenth" digit of frequency

P/N Part number

Z: Month letter (A to L)

Y: Last digit of year

X: Traceability code (A to Z)

Example:

10.000MHz **100**

Feb. 2002 ABM2 B2E

14.31818MHZ **143**

March 2002 ABM4A C2S