

[Command Reference](#) > [SCPI Command Reference](#) > [INITiate Commands](#) > INITiate<Ch>[:IMMEDIATE]:SCOPE

INITiate<Ch>[:IMMEDIATE]:SCOPE <Scope>

Selects the scope of the single sweep sequence. The setting is applied in single sweep mode only ([INITiate<Ch>:CONTinuous](#)OFF).

This command is needed in the "ZVR" and "ZVABT" compatibility modes only ([SYSTem:LANGuage](#)'ZVR' | 'ZVABT').

Suffix:

<Ch> Channel number. The channel is ignored because the command affects all channels.

Parameters:

<Scope> ALL | SINGLE
[INITiate<Ch>\[:IMMEDIATE\]\[:DUMMY\]](#) starts a single sweep in all channels or in the referenced channel <Ch> only.

Example: See [INITiate<Ch>:CONTinuous](#)

Manual operation: See ["Sweep All Channels"](#)

[Top](#)