

[Command Reference](#) > [SCPI Command Reference](#) > [HCOPy Commands](#) > HCOPy:PAGE:WINDow

HCOPy:PAGE:WINDow <PrintDiagram>

Defines how the diagrams shall be printed (using [HCOPy\[:IMMediate\]](#)).

Parameters:

<PrintDiagram> ALL | SINGLE | ACTive | HARDcopy | NONE
NONE - print no diagram at all.
ALL - all diagrams are printed on one page.
SINGLE - one diagram per page.
ACTive - print only active diagram.
HARDcopy - print a screenshot of the diagram area, preserving layout
and colors ("real screenshot")
*RST: n/a (*RST does not affect the printer configuration)

Example:

```
HCOP:PAGE:WIND SING; :HCOP
```

Select one diagram per page and start printing.

[Top](#)