

[Command Reference](#) > [SCPI Command Reference](#) > [HCOPy Commands](#) > HCOPy[:IMMEDIATE]

HCOPy[:IMMEDIATE]

Initializes the print according to the current HCOPy . . . configuration.

Example: HCOP:DEST '<Printer_name>'
Select the printer for the output of screen data.
HCOP
Start printing.

Usage: Event

Manual operation: See "[Print \(<Printer>\)](#)"

[Top](#)