



- | | | | |
|---|------------------|---|----------------|
| 2 | Cover | 5 | Window seal |
| 4 | Side wall lining | 7 | Expansion clip |
| 6 | Mounting clamp | | |

- 8 Velcro strip

P68.30-3005-08



P68.30-3006-02

		Remove/install	
 			
1		Remove paneling (2) from rear pillar	AR68.30-P-4505GW
2		Remove rubber door seal in area of side wall paneling (4).	
3		Remove rear seat belt	AR91.40-P-0681GW
4		Press mounting clips (6) on side wall paneling (4) off of door bead	i Installation: Remove mounting clips (6) from side wall paneling (4) and install on door bead, then install side wall paneling (4)
5		Remove side wall paneling (4) from side wall at bottom and rear (arrows)	w The side wall paneling (4) is fastened with expansion clips (7) and must be removed carefully. This prevents damage occurring. i Installation: Replace expansion clips (7).
6		Pull side wall paneling (4) out of window seal (5) starting at bottom	w Carefully pull out side wall paneling (4). Danger of breakage. Do not damage connections in window antennas
7		Remove side wall lining (4)	i The side wall paneling (4) is fastened above with the window with a Velcro strip (8) and inserted below the roof paneling in the front area.
8		Pull belt out of side wall paneling (4)	
9		Install in the reverse order	