

MAINTENANCE

Inspect units at regular intervals. Keep units clean and ventilation openings clear of dust, dirt or other. **WARNING:** Disconnect all power sources to the unit and discharge all parts which may retain an electrical charge before attempting any maintenance or repair. Screen and covers must be maintained in place when unit is in operation. Failure to observe this warning may result in personal injury. All actions connected with installations of the motor shall be made by a qualified person.

GREASE LUBRICATION INSTRUCTIONS

Units are prelubricated at the factory and do not require any additional lubrication

BEARING LIST

**eLINE Frame size
Bearing Type DE & ODE**

ELT 140
6205 2Z C3

ELT 180
6306 2Z C3

ELT 210
6308 2Z C3

ELT 250
6309 2Z C3

ELT 280
6311 2Z C3