

[Software Development Kit](#) > [nRF5 SDK](#) > [nRF5 SDK v11.0.0-2.alpha](#) > [Examples](#) > [DFU bootloader examples](#) > [BLE & HCI/UART Bootloader/DFU](#) > [Adding DFU Service support to an application](#)


nRF5 SDK v11.0.0-2.alpha

Switching to bootloader/DFU mode

*This information applies to the following SoftDevices: **S130, S132***

After programming both DFU bootloader and application on the device and starting the application, you can switch to bootloader/DFU mode at any time by writing to the control point of the DFU Service.

The following flow chart shows the process of switching from a BLE application to bootloader/DFU mode:



First, you must write the value 0100 to the CCCD for the DFU Control Point characteristic to enable DFU notifications. Next, you must write the value 01-XX (where XX is the code for the type of image, see [DFU Control Point](#)) to the DFU Control Point to start a DFU procedure. The application will then disconnect and reset into bootloader/DFU mode. Note that no acknowledgement will be sent when writing to the Control Point, but the application sends a GAP disconnect on the link to tell the peer that the link is closed. You can then transfer the firmware image.

For more information about the message format and available commands, see [DFU Control Point](#).

This document was last updated on Fri Dec 18 2015.

Please send us your [feedback](#) about the documentation! For technical questions, visit the [Nordic Developer Zone](#) <<https://devzone.nordicsemi.com/questions/>>.