


Pixhawk Pilot Support Package (PSP) User Guide

Version 1.2

ISSUE DATE: 22 April 2015



MathWorks

Pilot Engineering Group

1	Product Description	4
1.1	Acronyms/Definitions	4
1.2	Contact Information	4
2	Document History	4
3	System Requirements.....	5
3.1	Required	5
4	Installation.....	5
4.1	Pixhawk Toolchain Install.....	5
4.2	Pixhawk Toolchain MathWorks PSP Install.....	6
4.3	Pixhawk Toolchain Firmware Download and Compilation.....	6
5	Getting Started	7
5.1	Pixhawk Environment.....	7
5.2	Firmware Startup Preparation	11
5.3	Simulink Block Library.....	12
5.3.1	Pixhawk Target Block: input_rc	12
5.3.2	Pixhawk Target Block: PWM_output.....	14
5.3.3	Pixhawk Target Block: Speaker_Tune	16
5.3.4	Pixhawk Target Block: RGB_LED	17
5.3.5	Pixhawk Target Block: sensor_combined	18
5.3.6	Pixhawk Target Block: vehicle_attitude	20
5.3.7	Pixhawk Target Block: vehicle_gps	22
5.3.8	Pixhawk Target Block: Battery_measure	23
5.3.9	Pixhawk Target Block: Binary Logger	24
5.3.10	Pixhawk Target Block: Example Print Function	25
5.4	Basic Models	26
5.4.1	px4demo_input_rc.slx.....	26
5.4.2	px4demo_rgbled.slx.....	26
5.4.3	px4demo_tune.slx	27
5.4.4	px4demo_gps.slx	27
5.4.5	px4demo_attitude_plant.slx	28
5.4.6	px4demo_attitude_control.slx.....	29
5.4.7	px4demo_attitude_system.slx	30
5.5	Code Generation.....	30
5.5.1	Simulink Settings	30
5.5.2	Coder Target Settings	32
5.5.3	Building the Firmware	33
5.5.4	Firmware	34
6	Limitations	36
7	External mode	36
8	Updating to a new version of Pixhawk PSP	36
9	Using External Mode with the Pixhawk PSP	37
9.1	What is External Mode?.....	37
9.2	Some important considerations:	38
10	External Mode Tutorial Part 1: 38Viewing Signals from the generated Code	38
11	External Mode Tutorial Part 2: External Mode Control Panel	42

12	External Mode Tutorial Part 3: Tuning parameters	45
----	--	----

1 Product Description

The Pixhawk Pilot Support Package (PSP) feature allows users to use Simulink models to generate code targeted for the Pixhawk FMU (Flight Management Unit). The PSP provides the ability to incorporate the Pixhawk Toolchain for complete firmware build and download to the px4fmu Version 2 unit. It does not provide exact function behavior blocks for other services running on the Pixhawk (e.g. Attitude Estimation using EKF or SOF). The user will need to use blocks from the base Simulink or possibly the Aerospace blockset for simulating their flight control system model. Once the flight control system (FCS) has been successfully modeled, simulated and verified, the Pixhawk Target can be used to deploy the control system onto the PX4 hardware.

The Pixhawk Simulink blocks allows users to access sensor data and other calculations available to be used in their Simulink model at runtime. Generated code can then be compiled and executed on the Pixhawk platform controlling a multi-rotor airframe.

1.1 Acronyms/Definitions

Pixhawk (PX4) – the Flight Controller Unit providing various sensor value inputs and PWM outputs as well as an ARM Cortex-M4 microprocessor for flight control and management.

PSP – Pilot Support Package. MathWorks software offering customized feature development or updates that are not yet available in the officially released version of MATLAB/Simulink.

TLC – Target Language Compiler

BTI – Built Tool Integration

FMU – Flight Management Unit

PWM – Pulse Width Modulation

RC – Radio Control

Tx/Rx – Transmitter/Receiver

ESC – Electronic Speed Controller

NED – North-East-Down

1.2 Contact Information

- Steve Kuznicki – MathWorks. steve.kuznicki@mathworks.com
- Daren Lee – MathWorks daren.lee@mathworks.com

2 Document History

Date	Version	Author	Description
1 Oct 2014	1.0	SEK	Initial version.
22 April 2015	1.2	DL	Ver 2 update

3 System Requirements

3.1 Required

- PX4 Toolchain Installer v1.4 for Windows
- MATLAB version R2014b (or later with the appropriate PSP)
- Simulink

To generate code from a Simulink model, the following products are needed:

- Simulink Coder
- Embedded Coder
- Aerospace blockset is needed for some of the example models

To successfully work with the PX4 and deploy the generated firmware to the Pixhawk this additional software is needed

- Pixhawk Toolchain
- QGroundControl

4 Installation

This feature is supported on Win32/64 platforms.

Platform	Installation Program
Windows 32/64	Pixhawk-<MATLAB_VERSION>_v1.x_win64-Install.exe

It is **IMPORTANT** for you to install the PX4 Toolchain software on your machine FIRST. The Pixhawk PSP installer needs to know the Root directory of the Pixhawk Toolchain since it modifies some of its files. The PSP installer is responsible for modifying the tool chain files to fetch files from a forked PX4 repository containing firmware source files. This forked repository contains modifications that are needed to interface with the PSP.

4.1 Pixhawk Toolchain Install

You should download and install the Pixhawk Toolchain from <http://www.pixhawk.org/> under the Downloads section.

This PSP was tested with version 1.4 found here:

http://www.inf.ethz.ch/personal/lomeier/downloads/px4_toolchain_installer_v14_win.exe

For the Pixhawk Toolchain installation:

- Launch the installation program for your operating system.
- Read and accept the licensing agreement
- Specify the location for the Toolchain installation. It is recommended that you choose the default of “c:\px4”

You may also need to install a USB driver if you are using Windows. See the Pixhawk Downloads page for more information [HERE](#).

After downloading and installing the Pixhawk Toolchain you will want to install the Pixhawk PSP described below.

4.2 Pixhawk Toolchain MathWorks PSP Install


For the Pixhawk PSP installation:

- Launch the installation program (e.g. pixhawk-R2014b-v1.2_win64-Install.exe)
- Read and accept the licensing agreement
- Specify the MATLAB Root directory of your R2014b installation (e.g. c:\MATLAB\R2014b)
- Specify the Pixhawk Toolchain Root directory (e.g. c:\px4)
- The Installer will verify the MATLAB Version and the Pixhawk Toolchain directory.
- It will launch MATLAB in the background and run a script to finish the installation (this will take some time, please wait for the *Next*> button to show in the installer dialog).
- If the installation script fails, a MATLAB command window will show any errors that may have occurred. If this happened, please copy and paste this window content and email it back to the Pilot Team for help.
- After installation on a Windows-7 machine, you may get a pop-up dialog asking if the software installed correctly. Simply answer 'Yes' to this dialog. This is just an artifact of using an installer that works on a Win32 machine as well.

The PSP will install itself in the <matlabroot>\toolbox\psp\pixhawk directory. The Simulink Pixhawk Blockset and MATLAB Pixhawk Toolchain BTI functions are now installed and ready to use. You should copy the example models out of the <matlabroot>\toolbox\psp\pixhawk\examples directory to your own working directory.

4.3 Pixhawk Toolchain Firmware Download and Compilation

One last step before being able to use the PSP is to perform a Pixhawk software update and pre-compiling source firmware source files. This is done by choosing the “PX4 Software Download” option in the PX4 Toolchain application Windows folder menu:




This download script has been modified in the PSP installer to download from a Github repository containing a forked stable copy of the PX4 FMU firmware. This stable-release will be revisited from time to time by MathWorks Pilot Engineering to ensure appropriate updates are applied from the official firmware when necessary (ie: bug fixes, feature updates). Please contact us regarding any discrepancies between the forked and the official repo.

IMPORTANT: Please ensure that the instructions followed so far are with a fresh install of the PX4 tool chain. Sometimes, git-related errors can occur if the Firmware directory is already populated with files and will fail to clone files from the repository.

After you do an initial software download you need to build the necessary target files. This can take up to half-hour or longer. This should only need to be done once.

- 1) Choose the “PX4 Console” option from the Windows PX4 Toolchain start menu.
- 2) Once the MINGW32 window appears, change directory to Firmware. e.g. `cd Firmware`
- 3) Build the Archives: `make archives`
- 4) Build all available targets: `make all`



```
MINGW32:/c/px4/Firmware
Welcome to the PX4 Toolchain.
skuznick@MI-SKUZNICK /c/px4
$ cd Firmware
skuznick@MI-SKUZNICK /c/px4/Firmware
$ make archives_
```

The “make archives” and the “make all” commands do take a bit to complete. You are now ready to start using the Pixhawk PSP.

5 Getting Started

5.1 Pixhawk Environment

Using the default firmware available for the Pixhawk, you should test to make sure your hardware is correctly configured and works as intended. This includes the correct motor wiring, placement of the PX4 module and any other sensors you may

be using. You can use QGroundControl to download and flash the necessary firmware for this test.

You can launch a serial terminal program like TerraTerm or PuTTY and connect to the PX4 and manually run the built-in commands using the nuttx shell. NuttX is the OS that is delivered with the Pixhawk toolchain and will be used for running the code generated from your Simulink models.

You can find out which “Builtin” Apps your firmware has by typing “?” at the nuttx shell prompt “nsh>”

```
nsh> ?
help usage:  help [-v] [<cmd>]
             df kill mkrd rm unset ? echo losetup mh rmdir usleep
             cat exec ls mount set xd cd exit mb mv  sh cp free
             mkdir mw sleep cmp help mkfatfs ps test dd hexdump
             mkfifo pwd umount
```

Builtin Apps:

```
sercon
serdis
adc
attitude_estimator_ekf
attitude_estimator_so3
bl_update
blinkm
boardinfo
commander
...
```

Some useful commands are:

- 1) `esc_calib` - to calibrate your ESCs through the command line interface

```
usage:
[-d <device>]    PWM output device (defaults to
                  /dev/pwm_output)
[-l <pwm>]        Low PWM value in us (default: 1000us)
[-h <pwm>]        High PWM value in us (default: 2000us)
[-c <channels>]  Supply channels (e.g. 1234)
[-m <chanmask>] Directly supply channel mask (e.g. 0xF)
[-a]             Use all outputs
```

- 2) `pwm` - to test out your PWM outputs

```
usage:
pwm
arm|disarm|rate|failsafe|disarmed|min|max|test|info  ...
```


arm	Arm output
disarm	Disarm output
rate ...	Configure PWM rates
[-g <channel group>]	Channel group that should update at the alternate rate
[-m <chanmask>]	Directly supply channel mask
[-a]	Configure all outputs
-r <alt_rate>	PWM rate (50 to 400 Hz)
failsafe ...	Configure failsafe PWM values
disarmed ...	Configure disarmed PWM values
min ...	Configure minimum PWM values
max ...	Configure maximum PWM values
[-c <channels>]	Supply channels (e.g. 1234)
[-m <chanmask>]	Directly supply channel mask (e.g. 0xF)
[-a]	Configure all outputs
-p <pwm value>	PWM value
test ...	Directly set PWM values
[-c <channels>]	Supply channels (e.g. 1234)
[-m <chanmask>]	Directly supply channel mask (e.g. 0xF)
[-a]	Configure all outputs
-p <pwm value>	PWM value
info	Print information about the PWM device
-v	Print verbose information
-d <device>	PWM output device (defaults to /dev/pwm_output)

3) tests - run various built-in test on the pixhawk

hardware

nsh> tests help

Available tests:

led

int

float

sensors

gpio

hrt

ppm

servo

ppm_loopback

adc

```

jig_voltages
uart_loopback
uart_baudchange
uart_send
uart_console
hott_telemetry
tone
sleep
time
perf
all
jig
param
bson
file
file2
mixer
rc
conv
mount
mtd
mathlib
help

```

4) top - will list all the NuttX processes running at the time (press 'q' to quit)
Processes: 11 total, 2 running, 9 sleeping
CPU usage: 37.36% tasks, 0.48% sched, 62.16% idle
Uptime: 904.233s total, 561.039s idle

PID	COMMAND	CPU(ms)	CPU(%)
USED/STACK	PRI0(BASE) STATE		
0	Idle Task	561039	62.162 0/
0	0 (0) READY		
1	hpwork	26060	2.799 748/
1992	192 (192) w:sig		
2	lpwork	6784	0.675 628/
1992	50 (50) READY		
85	top	116	1.158 1244/
1696	100 (100) RUN		
7	nshterm	121	0.000 884/
1192	100 (100) w:sem		
9	px4io	9444	0.965 796/
1992	240 (240) w:sem		
26	sensors_task	38995	4.440 1364/
1992	250 (250) w:sem		

```

    38 px4SimTermTask                1  0.000  524/
2040 100 (100)  w:sem
    29 attitude_estimator_ekf        191254 20.945
13004/13992 250 (250)  w:sem
    40 px4SimBaseTask                49428  5.501  1164/
2552 100 (100)  w:sem
    42 px4SimSchedTask                7819  0.868  1028/
2040 100 (100)  READY

```

5) SD card logging - useful for logging data to the SD Card

```

sdlog2: usage: sdlog2 {start|stop|status} [-r <log
rate>] [-b <buffer size>] -e -a -t -x
    -r      Log rate in Hz, 0 means unlimited rate
    -b      Log buffer size in KiB, default is 8
    -e      Enable logging by default (if not, can
be started by command)
    -a      Log only when armed (can be still
overridden by command)
    -t      Use date/time for naming log
directories and files
    -x      Extended logging

```

5.2 Firmware Startup Preparation

Executing the default firmware, there are several processes that get executed at system startup. When deploying a custom flight control system you will need to suppress the execution of these processes and instead, run the application generated by Simulink. This is done by a start-up script put on the micro-SD card used on the PX4. In this way you can control which flight control software you want to run just by changing the contents of this script.

The script's filename is **rc.txt**. It should be copied to the SD-card directory **/etc**. A script sample has been provided by the PSP installation and can be found in your Pixhawk Toolchain installation directory: **c:\px4\Firmware\etc**. By copying this file to your SD-card in the folder **/etc** the Pixhawk will execute the **px4_simulink_app** at system startup. This app is built into the firmware that is flashed onto your PX4 hardware at Simulink Model build time. Simply renaming this file (e.g. rc.txt to rc.txt.simulink) on the SD-card will allow boot-up of the default flight control software.

More information can be found on the Pixhawk website [HERE](http://www.pixhawk.org/dev/system_startup).
www.pixhawk.org/dev/system_startup.

The Pixhawk firmware relies on a publisher-subscriber communication architecture for Inter-Process communication on the PX4. This mechanism is implemented by the uORB or micro-Object-Request-Broker application. It provides the infrastructure that

allows threads and applications to share data between each other. Data is exchanged between participants in what is known as “topics”. Any task can register themselves as a publisher or subscriber of a particular topic. Topic information is exchanged in defined common “C” structures.


More information on uORB can be found here:

<http://pixhawk.org/firmware/apps/uorb>.

In order for the firmware to properly function, the uorb task must be executed upon startup (uorb start). Many of the Simulink Blocks that generate code interacting with the PX4 hardware rely on the uORB mechanism.


5.3 Simulink Block Library

A few Simulink Blocks have been provided for the user to interface to the hardware of the PX4. These allow for **code generation** only and do not provide for plant modeling behavior. It is recommended that your control model be a Model Block in your Simulink simulation model and then be re-used in your implementation model which would tie in these hardware interface blocks. The library filename is called `pixhawk_sllib.slx` and will be available in your Simulink Library browser under **Pixhawk Target Blocks**.



5.3.1 Pixhawk Target Block: input_rc

This block allows the user to access the signals coming from the RC transmitter.



The user has the ability to choose which channels are available as outputs from this block and also some optional outputs. These include

- Channels 1 through 8
 - double data type indicating the PWM value from the controller
 - measured pulse widths for each of the supported channels
- Channel Count
 - uint32 data type of the number of channels which are detected by the PX4
- RC Failsafe


- boolean data types indicating that the RC Tx is sending the FailSafe signal (if equipped and properly setup)
- explicit failsafe flag: true on TX failure or TX out of range , false otherwise.
- Only the true state is reliable, as there are some (PPM) receivers on the market going into failsafe without telling us explicitly.
- RC Input Source
 - Enumeration data type indicating which source the RC input is from.
 - Valid values are found in the ENUM file:
 RC_INPUT_SOURCE_ENUM.m

RCINPUT_SOURCE_UNKNOWN	(0)
RCINPUT_SOURCE_PX4FMU_PPM	(1)
RCINPUT_SOURCE_PX4IO_PPM	(2)
RCINPUT_SOURCE_PX4IO_SPEKTRUM	(3)
RCINPUT_SOURCE_PX4IO_SBUS	(4)
- RSSI - Receive signal strength index
 - receive signal strength indicator (RSSI): < 0: Undefined, 0: no signal, 255: full reception
- RC Lost Connection
 - boolean data type indicating RC receiver connection status
 - True, if no frame has arrived in the expected time, false otherwise.
 - True usually means that the receiver has been disconnected, but can also indicate a radio link loss on "stupid" systems.
 - Will remain false, if a RX with failsafe option continues to transmit frames after a link loss.

Sample Model: px4demo_input_rc.slx

5.3.2 Pixhawk Target Block: PWM_output

This block allows the user to send the appropriate PWM signals out to the PX4 outputs. These are usually connected to the ESCs which control the motor speeds.





In order for the flight control to arm (enable) the output from the software side, the ARM Output input must be held high (boolean TRUE). Only then will the PWM values be sent out the PX4 hardware ports. This is usually a function of the RC Tx in combination with other flight modes programmed in the Simulink model by the user.

The block has 8 available ports (data type double) which can be selectively chosen. These correspond to the 8 PWM output ports on the px4fmu hardware.

5.3.3 Pixhawk Target Block: Speaker_Tune

This block allows the user to control the various tunes that can be emitted by the mini-speaker connected to the px4fmu.



This block accepts 3 input signals.

- **Tune ID** : This is an enumeration data type of pre-defined “tunes” that can be played.

Enumeration members for class 'PX4_TUNE_ENUM':

STOP_TUNE
STARTUP_TUNE
ERROR TUNE



NOTIFY_POSITIVE_TUNE
 NOTIFY_NEUTRAL_TUNE
 NOTIFY_NEGATIVE_TUNE
 ARMING_WARNING_TUNE
 BATTERY_WARNING_SLOW_TUNE
 BATTERY_WARNING_FAST_TUNE
 GPS_WARNING_TUNE
 ARMING_FAILURE_TUNE
 PARACHUTE_RELEASE_TUNE

- Tune Str : This is for defining a custom tune to be played. The user can use a constant block that define the string to play.
- Trigger : This is a trigger signal that indicates when to play the predefined Tune (if Trigger value goes to 1) or the custom Tune (if Trigger value goes to 2). The change in tune will only be *triggered* by a change in this value.

Please see the example model px4demo_tune.slx.

5.3.4 Pixhawk Target Block: RGB_LED

This block gives the user control over various lighting modes of the RGB LED available on the PX4 hardware.



This block accepts 2 inputs: Mode and Color. These are enumeration data types. You can find out what values are valid in the MATLAB command window by typing:

```
>> enumeration('RGBLED_COLOR_ENUM')
```

Enumeration members for class 'RGBLED_COLOR_ENUM':

- COLOR_OFF
- COLOR_RED
- COLOR_YELLOW
- COLOR_PURPLE
- COLOR_GREEN
- COLOR_BLUE
- COLOR_WHITE
- COLOR_AMBER
- COLOR_DIM_RED
- COLOR_DIM_YELLOW
- COLOR_DIM_PURPLE
- COLOR_DIM_GREEN
- COLOR_DIM_BLUE
- COLOR_DIM_WHITE
- COLOR_DIM_AMBER


Enumeration members for class 'RGBLED_MODE_ENUM':

- MODE_OFF
- MODE_ON
- MODE_BLINK_SLOW
- MODE_BLINK_NORMAL
- MODE_BLINK_FAST
- MODE_BREATHE
- MODE_PATTERN

Look at the sample Simulink model: px4demo_rgbled.slx for an example of how to use this block.

5.3.5 Pixhawk Target Block: sensor_combined

This block enables access to the various sensors available on the px4fmu-v2 hardware. The user can use these signals in the Simulink control model. The sample time needs to be provided in the mask dialog. Optional output ports can also be selected. Refer to the sample model: px4demo_attitude_control.slx



Signal definitions:

- Magnetometer (x,y,z) - double values – Magnetic field in NED body frame, in Gauss
- Accelerometer (x,y,z) - double values – Acceleration in NED body frame, in m/s^2
- Gyroscope (p,q,r) - double values – Angular velocity in radians per second
- Barometer (Altitude) - double value – Barometric pressure, already temperature compensated (millibars)

- RunTime (timestamp) - double value – Timestamp in microseconds since boot, from gyro



The sensor_combined block needs to have the px4io service running on the PX4 hardware in order to get valid signal values.

5.3.6 Pixhawk Target Block: vehicle_attitude

This block gives access to the running service that calculates the vehicle's attitude. A uORB topic (vehicle_attitude (attitude measurements)) publisher MUST be running in order for this block to provide valid signal values. The available ones as of v1.3 are:

- [attitude_estimator_ekf](#) – *EKF-Extended Kalman Filter for attitude estimation*
- [attitude_estimator_so3](#) – *SO(3)-attitude estimation by using accelerometer, gyroscopes and magnetometer*

One of these MUST be running on the px4fmu in order for this block to return valid values. Refer to the sample model: px4demo_attitude_control.slx.
Attitude in NED (North-East-Down) body frame in SI units.




Signal definitions:


- Roll – double value, Roll angle (rad, Tait-Bryan, NED)
- Pitch – double value, Pitch angle (rad, Tait-Bryan, NED)
- Yaw – double value, Yaw angle (rad, Tait-Bryan, NED)
- Quaternion (NED) – double values (optional based on the uORB publisher)

5.3.7 Pixhawk Target Block: vehicle_gps

This block will provide GPS signals from the uORB topic publisher: vehicle_gps_position. You must ensure that you have the gps topic executed as part of the start-up script in order to get valid signal values. Refer to the sample model: px4demo_gps.slx



vehicle_gps





Signal definitions:

- Latitude – (int32) global coordinate given in $1e-7$ degrees
- Longitude – (int32) global coordinate given in $1e-7$ degrees
- Position TS – (double) timestamp for position information
- Altitude – (int32) in $1e-3$ meters (millimeters) above MSL (mean sea level)
- GPS TS – (double) timestamp (microseconds in GPS format). This is the timestamp that comes from the GPS module.
- Velocity TS – (double) timestamp for velocity information
- Velocity – (double) GPS ground speed in meters/second
- GPS Fix Type – (uint8) 0-1 = No fix, 2 = 2D fix, 3 = 3D fix
- Num Satellites – (uint8) the number of satellites used in calculations

5.3.8 Pixhawk Target Block: Battery_measure

This block allows the user to monitor the health of the connected battery. It returns battery level measurements from the uORB topic publisher “battery_status”.







The user has the ability to choose which telemetry data are available as outputs from this block.

Signal definitions:

- Voltage – (double) Battery voltage in volts
- Filtered Voltage – (double) Filtered battery voltage in volts
- Current – (double) Battery current in amperes
- mAH – (double) Discharged amount in mAh
- Timestamp– (int32) timestamp of measurement

5.3.9 Pixhawk Target Block: Binary Logger






Log a vector of double data to a file on the SD card. The first enable port must trigger high and then low during the execution of the program for a successful write to disk space. If the enable port does not fall low before the generated code is finished executing the file will be still considered ‘open’ and not accessible. In order for proper SD card data writing ensure that the above directory path points to some place in /fs/microsd/

The data input can be a vector signal concatenated together to allow for multiple signal logging.

Processing Captured Log File

In order to process the binary log file there is a convenient MATLAB function provided. A function `px4_read_binary_file` has been added to the MATLAB path which is used to read in binary files and display the data. The function expects two input arguments, the name of the binary log file (in quotes) and the number of parameters you logged. Please note that this file expects ‘double’ data type so if you logged signals of different data types you will either want to create a new function similar to this one or edit it to use the correct data type.

5.3.10 Pixhawk Target Block: Example Print Function



Print signal data content to the PX4 Nuttx console terminal. Note that this block should be treated as an “example” block and the print message can be constructed anyway the user sees fit. The `coder.ceval()` is a MATLAB Coder function used to evaluate the `printf()` statement to pass in two values. Please note that there is a bug in Nuttx in which sometimes floating numbers cannot be properly displayed. Please use `warnx()` instead of `printf()` of this as a work-around.


5.4 Basic Models

There are several simple “test” models available for you to make sure everything is correctly installed and working. It is recommended to try one of these initial test models before trying a complete flight control system model.

IMPORTANT: Simulink does not allow a user to ‘Build’ under the matlabroot (e.g. c:\MATLAB\R2014b\matlab\toolbox\psp\pixhawk\examples) directory. Therefore it is recommended to COPY the example models to a user working directory outside the MATLAB root. There is a copy of these models made at the c:\px4\SimulinkExamples directory when the PSP is installed. The user can navigate to this directory to work with the Simulink example models.


5.4.1 px4demo_input_rc.slx

This model will test the RC transmitter block. Use the RC Transmitter to control the color and mode of the RGB LED on the pixhawk. Channel 3 is typically the “Thrust” or the left vertical joystick control. Channel 4 is typically the “Yaw” or the right horizontal joystick control.




5.4.2 px4demo_rgbled.slx

A simple model that show how to program the RGB_LED library block. Every second the RGB LED changes from blinking-fast blue color to “breathing” red color.



5.4.3 px4demo_tune.slx

To test various tunes, this model plays all the pre-defined tunes plus a user-custom tune cycling every 10 seconds.



5.4.4 px4demo_gps.slx

A test model has been provided to test out the GPS Block. This model will print out information to a terminal window once a second and the RGB LED will “breathe” Green. You will need to establish a serial terminal connection to the PX4 hardware with a program such as TerraTerm or PuTTY. If you do not manually start the `px4_simulink_app` (rather have it start at boot-up time), then you will need to stop it, then re-start it with these commands (since there is no stdout console available at boot-up time the `printf` statements in the code can’t output any text):

```
nsh> px4_simulink_app stop
```

then



```
nsh> px4_simulink_app start
```

The output will look similar to this:

```
GPS->TS: 145797580 LatLon: [424428886 -834372413] Alt:284975
GPS->TS: 146999228 LatLon: [424428895 -834372410] Alt:285028
GPS->TS: 148394689 LatLon: [424428890 -834372428] Alt:285335
GPS->TS: 149594309 LatLon: [424428903 -834372470] Alt:285481
GPS->TS: 150795017 LatLon: [424428926 -834372550] Alt:285325
GPS->TS: 152191507 LatLon: [424428958 -834372596] Alt:285062
GPS->TS: 153395127 LatLon: [424428963 -834372619] Alt:285384
GPS->TS: 154598715 LatLon: [424428951 -834372553] Alt:286188
GPS->TS: 156001888 LatLon: [424428946 -834372496] Alt:286502
GPS->TS: 157191915 LatLon: [424428954 -834372484] Alt:286525
GPS->TS: 158404578 LatLon: [424428968 -834372459] Alt:286505
GPS->TS: 159805210 LatLon: [424429016 -834372511] Alt:285842
GPS->TS: 161004798 LatLon: [424429026 -834372452] Alt:285885
GPS->TS: 162200302 LatLon: [424429036 -834372406] Alt:285856
```

The top-level model is simple. The Display Subsystem has a MATLAB Block which shows how to print information (text strings) to the console if you want to include


some debug outputs in your model. User should be careful not to run any standard output to the console at the high base rate, but rather put it in a slower rate (e.g. 1 second sample time) as illustrated with the different colors in the model (Red = fast rate, Green = slow rate).



5.4.5 px4demo_attitude_plant.slx


In order to design and simulation your flight control you will need a test-bench model. It is recommended that you create your test bench model that will provide the stimulus and plant/environment/feedback behavior for your flight control and use a Model (Reference) Block for your control system model.

Here is an example of a model to simulate an attitude control system:



5.4.6 px4demo_attitude_control.slx


This model contains the heart of the attitude flight control model. It should have the identical configuration parameters as the parent model.



5.4.7 px4demo_attitude_system.slx

After the flight control system has been successfully simulated, it can be used in an “implementation” model that the user can use to generate code and deploy to the Pixhawk PX4 hardware.

Here is the same Control Model referenced in a system model for deployment. The RED/GREEN colors indicate the different sample rates of the model (RED = 250Hz, GREEN = 2Hz).




5.5 Code Generation

The Pixhawk target uses MathWorks Build Tool Integration (BTI). The system target file needs to be `ert.tlc` (Embedded Real-Time) which is available with Embedded Coder. The user is then able to choose the hardware and toolchain. If the target hardware is set to ‘Pixhawk’, then the appropriate toolchain (Pixhawk) will be chosen automatically.

5.5.1 Simulink Settings


In order for the model to target the PX4 hardware, the Simulink model must be configured to use the appropriate code generation options.



- 1) Under the “**Code Generation**” section on the Model Parameter Configuration (Ctrl-E)
- 2) System Target File must be set to use **ert.tlc**
- 3) Target Hardware must then be set to use “**Pixhawk PX4**”
- 4) Toolchain selection must be set to “**Pixhawk Toolchain**” (automatically set when choosing target hardware as Pixhawk PX4)

There are a few other settings which are required for this version of the PSP. These are:


- 1) Solver Type should be set for Fixed-Step (for embedded code generation)
- 2) Model Optimization Option **Inline Params** must be 'on' for Pixhawk code generation




Inline parameters setting is highly recommended due to the limited resources in global memory and constraints on the Pixhawk target. Inline parameters places all model parameters (ie: gains) as “inline” constants or variables on the function stack rather. You will receive an error if this setting is not adjusted in your model.

5.5.2 Coder Target Settings

There are Coder Target options as well. The user can choose to just ‘Build’ the firmware code or ‘Build, Load and Run’ the generated code. In the Configuration dialog, under Coder Target, the user can set this option:




The only other option at this time is the RTOS Base Rate Task Priority setting. The default is 100. It is advisable to keep this priority. Advanced users may need to change this if other tasks are introduced that require a different (task) priority.




5.5.3 Building the Firmware

The firmware for model can be generated by pressing the 'Build' icon on the toolbar:



The Diagnostic Window will show the progress of the build process. When the firmware is ready and the 'Build, Load, Run' option is selected, the user will be promoted to make sure that the pixhawk is NOT currently plugged into the computer USB port (see pop-up dialog below). Press OK on this pop-up dialog, then plug in the pixhawk into the USB port. This will start the flashing process. When the process is complete, the PX4 will re-boot and you should hear the start-up tune.




IMPORTANT:

Sometimes after building a model the download step after this can fail. This is common behavior and the issue resides inside the python download script. One can manually re-attempt a download by entering a command in the Mingw environment by opening the Px4 Console and typing in:

```
python -u /c/px4/firmware/tools/px_uploader.py --port  
"COM6" /c/px4/firmware/build/px4fmu-  
v2_default.build/firmware.px4
```

Note that in the above example COM6 happened to be the COM port for my Windows machine which is connected to the Px4FMU

A more convenient option is to use a built-in drop-down menu we have added in which will effectively execute this command for you without typing it:



This is found under the Code menu > PX4 PSP: Upload code to Px4FMU. You will be prompted with a pop-up menu prior to programming the device.

5.5.4 Firmware

The Pixhawk PSP generates source code from the model, creates a binary which is then added as a built-in command in the NuttX OS running on the pixhawk. The build-in command is called `px4_simulink_app` and it has a command line interface to control its start and stop condition. This application should be included as part of the boot-up script.

```

nsh> px4_simulink_app help
px4_simulink_app: unrecognized command

px4_simulink_app: usage: px4_simulink_app {start|stop|status} [-p <additional params>]

nsh> px4_simulink_app status
px4_simulink_app: not started

nsh> px4_simulink_app start
**starting the model**
px4_simulink_app: Call to sem_init:termSem returned status (0)
px4_simulink_app: Call to sem_init:stopSem returned status (0)
px4_simulink_app: Call to sem_init:baserateTaskSem returned status (0)
px4_simulink_app: Call to sched_setscheduler returned status (0)
px4_simulink_app: stackSize = 2560 sched_priority = 205
px4_simulink_app: MW_BASERATE_PERIOD = 0.00400 MW_BASERATE_PRIORITY = 40 SIGRTMIN = 0x00000000
px4_simulink_app: Init info.period = 0.00400 sigNo = 0x0011
px4_simulink_app: **creating the terminate thread before calling task_create**
px4_simulink_app: ** Terminate Task ID = 56
px4_simulink_app: **creating the baserate thread before calling task_create**
px4_simulink_app: ** Base Rate Task ID = 57
px4_simulink_app: **creating the scheduler thread before calling task_create**
px4_simulink_app: ** Scheduler Task ID = 59
px4_simulink_app: **DONE! creating simulink task threads**
nsh> **blocking on termSem semaphore in terminateTask**
px4SimSchedTask: Creating POSIX timer
px4SimSchedTask: *** Scheduler Task Entering Loop 1... ***
px4SimBaseTask: * Subscribed to gps topic (fd = 4)*

```

Annotations in the image:

- Red arrow pointing to `px4_simulink_app help`: **get command help**
- Red arrow pointing to `px4_simulink_app status`: **get status**
- Red arrow pointing to `px4_simulink_app start`: **start the application**
- Red arrow pointing to the startup output lines: **startup output**

During execution the `px4_simulink_app` will spawn a task called “Spawn_Thread_Tasks”. When the application initializes it spawns a task which is used to spawn several threads. These threads are the following: base rate thread, subrate thread, a scheduler thread or a terminate thread. The number of subrate threads are dictated by the number of sample-times you have in the model and if the model is set to multi-tasking.

```

Processes: 14 total, 3 running, 11 sleeping
CPU usage: 33.42% tasks, 0.26% sched, 66.32% idle
Uptime: 310.936s total, 210.651s idle

```

PID	COMMAND	CPU(ms)	CPU(%)	USED/STACK	PRIO(BASE)	STATE
0	Idle Task	210651	66.322	0/ 0	0 (0)	READY
1	hpwork	5896	1.894	676/ 1792	192 (192)	w:sig
2	lpwork	992	0.344	580/ 1792	50 (50)	READY
3	init	1472	0.000	1212/ 2992	100 (100)	w:sem
38	<pthread>	23	0.000	508/ 2552	100 (100)	w:sem
8	px4io	2305	0.689	796/ 1792	240 (240)	w:sem
24	sensors_task	7276	2.325	1268/ 1992	250 (250)	w:sem
31	nshterm	2	0.000	780/ 1496	70 (70)	w:sem
27	ekf att pos estimator	82100	26.701	3708/ 7496	215 (215)	w:sem
37	Spawn_Thread_Tasks	17	0.000	732/ 2040	205 (205)	w:sem
39	<pthread>	4	0.000	556/ 2552	99 (99)	w:sem
41	<pthread>	0	0.000	604/ 2552	100 (100)	w:sem
42	<pthread>	44	0.000	708/ 2552	100 (100)	w:sem
43	top	88	1.464	1164/ 1696	100 (100)	RUN

When the application has ended these threads will terminate along with the “Spawn_Thread_Task”.

6 Limitations

Also, the supplied Simulink blocks do not support any simulation behavior. These are merely there to provide code generation to interface the control system to the actual hardware drivers necessary in the firmware. It is advised that you use **Model Referencing** to separate your control system so that you can re-use the model in your simulation as well as the implementation model (used for code generation).

Currently, the optimization option “**Inline Parameters**” must be turned on. This eliminates the use of global data being created which has shown to cause compilation errors due to limited global memory space.

Some possible features we will be addressing in the future include:

- Ability to switch between direct hardware writing versus uORB hand-offs
- Serial logger block to send data back to another machine
- More external mode options (drop-down for tty port selection), better data logging with external mode. Simplified play-button execution (similar to Run-on-Target Hardware support package)
- Processor-in-the-Loop verification
- Selection of Px4 tool chain will automatically choose correct configuration options

7 External mode

Please see the folder within
\\MATLAB\R2014b\toolbox\psp\pixhawk\examples\

For a full document explaining external mode and usage

8 Updating to a new version of Pixhawk PSP


There may be times when a new version of the Pixhawk PSP will need to be installed. This could be based on newer versions of Simulink being released, bug fixes, new blocks or enhancements of both the base product and the PSP.

If you run into any issues with the use of this PSP please contact your MathWorks sales representative or Pilot Engineering group directly. Do not go through

technical support for issues with this PSP. Do go through technical support for issues related to MATLAB/Simulink outside the scope of this PSP.

9 Using External Mode with the Pixhawk PSP

9.1 What is External Mode?



External mode is a way in which one can examine execution and “tune” the generated code from your standard desktop environment. This feature comes with Embedded Coder and can greatly enhance debugging capabilities or interactive testing through tuning of model parameters. For instance, suppose you wanted to know the output value of a certain signal at each time step of the simulation. One could implement this by modifying the generated code to execute a “printf” of that signal value manually or create a block to

do this (we actually provide this for you), however, this can be cumbersome. External mode can alleviate this by not only displaying the value of the signal from the generated code in a scope in the Simulink environment, but it also enables you to log that signal and record it to your host PC as a MAT file as well. One way to think of external mode is that your Simulink model now becomes a “user-interface” that interacts with the generated code during execution, instead of the play button playing a simulation on your host machine the play button now begins execution of embedded code.

This mode is not to be confused with Hardware-in-the-Loop or Processor-in-the-Loop. External mode works by establishing a communication channel between the host PC and the embedded system you are targeting. MathWorks provides all the necessary source files for both TCP/IP and Serial communication – in the case with the Px4FMU we are using serial communication.

The generated code and the Simulink infrastructure have the necessary source files and shared libraries to do this for you without having you manually modify the code itself.

For more information, please see:

http://www.mathworks.com/help/rtw/ug/external-mode-communication_f1028013.html

9.2 Some important considerations:

External mode can be a potentially taxing process since it needs to transfer data back and forth to the PC as well as wait for user commands to start/stop execution of the model as well as tuning of parameters. Because of the limited resources on the Px4FMU, it is highly recommended to NOT use external mode for flight tests. Due to limited RAM on the system, the amount of data transferred back must be reduced considerably at each execution time-step, therefore, some special modifications to some user settings must be made. More detail will be covered on this down below.

Note that if you are just interested in logging data rather than viewing data as the system is running and tuning parameters then you may want to consider data logging. A Simulink block is being developed for this and will be available later in the future – please contact the Mathworks Pilot team for more information on this.

10 External Mode Tutorial Part 1:

10.1 Viewing Signals from the generated Code

Serial port setup:

Before running External Mode, you should be familiar with the serial ports offered by the hardware. The Px4FMUv2 comes with a variety of different options. To see which serial ports you may want to use consult these pages here:

<https://pixhawk.org/users/wiring>

<https://pixhawk.org/dev/wiring>

Note: some serial ports are reserved and cannot/should not be used, such as ttyS0 which is a serial debug console port. Please consult above links for information on this. Suppose you wanted to use the standard USB programming cable for external mode. In this case, ttyACM0 becomes a free serial port to be used by external mode and ttyS6 be a serial console shell. Here is one example of one would modify their rc.txt file to do this:


```
#sercon - in the latest release sercon already gets called
usleep 1000
uorb start
usleep 1000
#nshterm /dev/ttyACM0 & #Disable the USB serial console
usleep 1000
px4io start
usleep 1000
#commander start
#usleep 1000
#mavlink start -d /dev/ttyS1 -b 115200
#usleep 5000
#dataman start
#usleep 1000
#navigator start
#usleep 1000
sh /etc/init.d/rc.sensors
usleep 1000
#sh /etc/init.d/rc.logging
#usleep 1000
#gps start
#usleep 1000
#attitude_estimator_ekf start - the latest release does not use this anymore
ekf_att_pos_estimator start
usleep 1000
#attitude_estimator_so3 start
#usleep 1000
#mavlink start -d /dev/ttyS3 -b 115200
mtd start
usleep 1000
param load /fs/mtd_params
usleep 1000
rgblcd start
usleep 1000
#px4_simulink_app start #disable automatic starting up of the model
nshterm /dev/ttyS6 & #this will make ttyS6 the serial console
exit
```

In the above example, ttyS6 (serial port 4) and the USB port we typically use to access the serial console is now a free serial port we can use to establish data exchange in external mode. Note that in the example I am doing in this tutorial, I have ttyS6 connected to a USB FTDI connector which will allow my Windows machine to access

the serial shell over USB. Other options could include using the telemetry radios to establish external mode which would be different serial ports than the ones mentioned here.—

10.2 - Model Configuration Setup:

The next step after choosing a serial port is to now configure Simulink to use the port of choice. Open up the model `ext_mode_intro.slx`



To configure Windows to talk to the Px4FMU, click on the interfaces section in Code Generation, then click on Interface, then under MEX-file Arguments you want to type in the following syntax

1 <COMPORT#> <BAUDRATE> <TIMEOUT>


The '1' value in the front is to indicate that the generated code will wait for the host before starting execution. This is highly recommended.

<COMPORT#> - this is the COM port of the USB connection which connects the PC and the Px4FMU

<BAUDRATE> - Specify a baud rate here. Note that radios are set to run on 57600

<TIMEOUT> - Specify the amount of time it takes to wait for establishing a connection before timing out. 5 seconds should be sufficient

Next, we want to configure the generated code to use the correct serial port on the firmware. In this example, this is ttyACM0




Click on the Coder Target menu and then select external mode options. Click on the Baud Rate Select button drop-down to select a baud rate and specify the data exchange serial port as 'ttyACM0'


10.3- Running the example model

The next step is to run the model. This involves a couple of steps:

- 1) Pressing the build button (ctrl+B) to generate code, compile it, and then having it transferred to the PX4FMU
- 2) Running the model. Open up the serial shell to access the command line and start the model by typing 'px4_simulink_app start'
The model will not actually begin execution yet until receiving a start packet from external mode, this is done in the next step
- 3) Ensure that the drop-down menu is set to 'External'




After, click on the "Connect To Target" button on the left of the above diagram. This will establish connection after a few seconds. Finally, press the green play button to the right. You will now be able to see data appear in the Simulink model in the generated code.




- 4) To stop the generated code, press the stop button in the model. **If you wish to run external mode again, type ‘reboot’ at the serial console as well.** There is currently a limitation in which external mode code has some issues being treated as re-entrant. This will be fixed in the future – for now, **please reboot the Px4FMU in-between external mode runs.**

11 External Mode Tutorial Part 2: External Mode Control Panel

As mentioned earlier, the PX4FMU runs on a resource constrained environment. External mode can be process intensive at times depending on the circumstances. For instance, if you have a model which contains many (10-30) scopes the amount of data transferred can impact real-time performance. To assist with real-time execution of code, external mode has been automatically configured to run as a back-ground task by default. This option appears in the External Mode Control panel and doesn’t need to be changed by the user. Due to limited memory, the amount of data that can be transferred back needs to be adjusted. This setting dictates a buffer size on the Px4 for each signal you are logging.



When clicking on the “Signal & Triggering” button you get access to all the signals that are attached to display ports. Signals marked with an X are available for viewing in external mode which you can enable/disable with the “ON” and “OFF” radial button on the right. The diagram below has the “select all” option enabled so all display/scopes will be viewable.



The ‘Duration’ value specifies the buffer size to send back to Simulink. The default value of 10000 is rather large, so in this example we have scaled it back down to 1000. A large

value can impact performance of external mode – the real-time code can still run but external mode may not report back on time. Since external mode runs on a lower priority task the generated code from Simulink takes more precedence and can potentially delay external mode's transfer of data to the host machine. To avoid this, choosing a low duration value such as 1000 or 500 samples can help greatly.

Duration value dictates how many samples you'll see at each time step in the Simulink model. Duration value does not apply to all sample times, since it is based on the base-sample rate. In other words, choosing a value of 1000 means one will receive 1000 data 'ticks' of base-rate data. Here is an example:

Suppose we have a model and its fastest-sample time is 250 Hz ($T_s = 0.004$ seconds) and a slower rate 25 Hz ($T_s = 0.04$ seconds)

Suppose we choose a duration value of 400:

This means if we hook a scope up to a 250 Hz signal we will see 400 sample points appear at a time in external mode. Or in other words, ($400 \times 0.004 = 1.6$ seconds) 1.6 seconds of data will appear at a time.

For the lower sample rate (25 Hz), 1.6 seconds of data yields 40 data points ($1.6 / 0.04 = 40$) at a time rather than 400

One should be careful to not choose a duration time that is too low. For instance, suppose I chose a duration time of 1. This means:

250 Hz: Any scope hooked up to this will give you one sample at a time


$1 \times 0.004 = 0.004$ seconds of data

$0.004 / 0.04 = 0$ (round to floor)

A duration size must be selected which is big enough such that each time external mode delivers data back to the PC it has enough sample points for signals running on a lower sample-rate. If we chose a duration value of 1 only the 250 Hz signal will display data and the other signals will show no data (default value of zero)

11.3 Tips for logging fast-rate signals

Sometimes, depending on the model, there will be a noticeable delay when receiving data. This can occur if the signal if you are trying to log is running at a fast sample rate. External mode may deliver data back to the PC at a slower than desirable rate. One way to get-around this is to use a rate transition block to view a signal running at a fast rate at a slower rate. You will get less data back but this will help alleviate slow-downs – considerations and trade-offs will need to be made depending on the situation



In this example I specify a sample rate of the sensor block to 250 Hz.

If you just want sensor data, you can just hook up a scope and start logging away, however, keep in mind that you will not get real-time performance. This means that the Simulink timer associated with the base-rate ticks will not keep up with real-time. Data coming in from the sensors will still update/react to physical stimuli but the time stamp of data will not be in real-time (ie: 2-3 times slower). Other sample rates will suffer as a result and not run on schedule. Performance is affected at the cost of getting more data back into the host PC.

Adding in the rate transition to slow down the sampling will help greatly as shown above.

[**px4demo_attitude_system_multi_task.slx**](#)


12 External Mode Tutorial Part 3: Tuning parameters

Tuning parameters is one way to adjust values of the generated code Simulink while execution. In order for this to be possible, parameters must be set to tunable. Tunable parameters allow parameters to be exposed in the generated code as a global value such that an external program can have more control over it rather than having it inlined.

Due to resource constraints in global memory, parameters all Pixhawk PSP models are set to inline and will error out if you disable the inline parameter option. You can, however, select certain parameters to allow for tuning. This is done by clicking on the configure button in this menu


Configuration Parameters -> signals and parameters -> inline parameters -> configure

The example model for this section is : [**parameter_tune.slx**](#)




From this menu, you can now select parameters you wish to tune. Note that a parameter that requires tuning must have a parameter which exists in the base-workspace. In this example, the parameter is 'TuneGain' which has been selected.

To change the value of this parameter while the Simulink model is running, change the value in the base MATLAB workspace, to update the model and then bring up the External Mode Control panel



Now, press the “Download” button to push updated parameter values onto the generated code with “Batch download” selected



If you have multiple parameters that change, clicking the download button will also update those parameters in one-shot. In the above example I change the TuneGain from -1 to -2 and the generated code receives this update immediately afterwards. **Note a faster method is to also update the model diagram by pressing CTRL+D after changing a parameter in the MATLAB command prompt.**