

4.20 CHOCKS ON

CHOCKS ON will be displayed, when the ground staff has put the chocks in front of the nose wheel and pressed the "CHOCKS ON" button on the operator panel.

A black rectangular box with the words "CHOCK" and "ON" stacked vertically in white, bold, sans-serif capital letters.

4.21 ERROR

If a system error occurs, the message "ERROR" is displayed with an error code. The code is used for maintenance purposes and explained elsewhere.

A black rectangular box with the word "ERROR" in white, bold, sans-serif capital letters.

4.22 SYSTEM BREAKDOWN

In case of a severe system failure, the display will go black, except for a red stop indicator. A manual backup procedure must be used for docking guidance.

4.23 POWER FAILURE

In case of a power failure, the display will be completely black. A manual backup procedure must be used for docking guidance.