

## 2. ARRIVAL

### 1.6.5. OPERATIONAL LIMITATIONS (contd)

- Aircraft code E are not hold on taxilane Y7 in front of taxilane Y when taxiing into stands 103, 104.
- For aircraft with failure of generators (APU):
  - Aircraft with failed APU are not operated stands 23, 24, 25, 26, 27, 28, 41, 42, 43, 44, 45, 46, 48, 49, 53, 54 and aircraft code E at stands 35, 36.
  - In case of unexpected failure of APU: The aircraft must be towed to an appropriate stand following unexpired ATC clearances.

### 2.1. AIRCRAFT OPERATIONAL PROCEDURES

#### Notes:

In case it is necessary to implement differently from the issued aircraft operational procedures as below, pilots follow ATC instructions strictly.

#### Standards from 1 to 8, 1A

For landing aircraft

- Rwy 25L: Rwy 25L/07R - Twy S6/S7/S8/S10 - Twy V/(Twy S - Twy S6/S5/S3 - Twy V) - stands.
- Rwy 25R: Rwy 25R/07L - (Twy P5 - Twy S8)/(Twy P6 - Twy S10)/(Twy P4 - Twy P5 - Twy S8)/P6 - Twy P4 - Twy P5 -Twy S8/P4 -Twy P6 -Twy S10) - Twy V / (Twy S - Twy S6/S5/S3 - Twy V) - stands.
- Rwy 07L: Rwy 07L/25R - Twy P2/P1/(Twy P3 - Twy P2/P1) - Twy S5/S4/S3 - Twy V - stands.
- Rwy 07R: Rwy 07R/25L - Twy S6/S5/S4/S3/S1 - Twy V - stands.

#### Standards from 9 to 16

For landing aircraft

- Rwy 25L: Rwy 25L/07R - Twy S7/S8/S10 - Twy V/(Twy S - Twy S6/S5/S3/S4 - Twy V) - stands.
- Rwy 25R: Rwy 25R/07L - (Twy P5 - Twy S8)/(Twy P6 - Twy S10)/(Twy P4 - Twy P5 - Twy S8) - Twy V/(Twy S - Twy S6/S5/S3 - Twy V) - stands.
- Rwy 07L: Rwy 07L/25R - Twy P2/P1/(Twy P3 - Twy P2/P1) - Twy S5/S4/S3 - Twy V - stands.
- Rwy 07R: Rwy 07R/25L - Twy S5/S4/S3/S1 - Twy V - stands.

#### Standards from 17 to 22

For landing aircraft

- Rwy 25L: Rwy 25L/07R - Twy S7/S8/S10 - Twy V/(Twy S - Twy S6/S5 - Twy V) - Twy S5/(taxilane Y1 - Twy S5) - stands.
- Rwy 25R: Rwy 25R/07L - (Twy P5 - Twy S8)/(Twy P6 - Twy S10)/(Twy P4 - Twy P5 - Twy S8) - Twy V/(Twy S - Twy S6/S5 - Twy V) - Twy S5/(taxilane Y1 - Twy S5) - stands.
- Rwy 07L: Rwy 07L/25R - Twy P2/P1/(Twy P3 - Twy P2/P1) - Twy S5/(Twy S4 - Twy S/V - Twy S5) - stands.
- Rwy 07R: Rwy 07R/25L - Twy S5/S4/S3/S1 - Twy S/V - Twy S5 - stands.

#### Standards from 23 to 28

For landing aircraft

- Rwy 25L: Rwy 25L/07R - Twy S7/S8/S10 - Twy V/(Twy S - Twy V1/S6/S5 - Twy V) - Twy S5/(taxilane Y1 - Twy S5)/(taxilane Y7/Y6 - taxilane Y - taxilane Y1- Twy S5) - taxilane Y2 -stands.
- Rwy 25R: Rwy 25R/07L - (Twy P5 - Twy S8)/(Twy P6 - Twy S10)/(Twy P4 - Twy P5 - Twy S8) - Twy V/(Twy S - Twy V1/S6/S5 - Twy V) - Twy S5/(taxilane Y1 - Twy S5)/ (taxilane Y7/Y6 - taxilane Y - taxilane Y1- Twy S5) - taxilane Y2 - stands.
- Rwy 07L: Rwy 07L/25R - Twy P2/P1/(Twy P3 - Twy P2/P1) - Twy S5/(Twy S4 - Twy S/V - Twy S5) - taxilane Y2 - stands.
- Rwy 07R: Rwy 07R/25L - Twy S5/S4/S3/S1 - Twy S/V - Twy S5 - taxilane Y2 - stands.

#### Standards from 29 to 32

For landing aircraft

- Rwy 25L: Rwy 25L/07R - Twy S7/S8/S10 - Twy V/(Twy S - Twy S6/S5 - Twy V) - Twy S5 / (taxilane Y1 - Twy S5) - stands.
- Rwy 25R: Rwy 25R/07L - (Twy P5 - Twy S8)/(Twy P6 - Twy S10)/(Twy P4 - Twy P5 - Twy S8) - Twy V/(Twy S - Twy S6/S5 - Twy V) - Twy S5/(taxilane Y1- Twy S5) - stands.
- Rwy 07L: Rwy 07L/25R - Twy P2/P1/(Twy P3 - Twy P2/P1) - Twy S5/(Twy S4 - Twy S/V - Twy S5) - stands.
- Rwy 07R: Rwy 07R/25L - Twy S5/S4/S3/S1 - Twy S/V - Twy S5 - stands.