

Rockchip SPI Developer Guide

ID: RK-KF-YF-075

Release Version: V2.1.0

Release Date: 2020-02-13

Security Level: Non-confidential

DISCLAIMER

THIS DOCUMENT IS PROVIDED “AS IS”. FUZHOU ROCKCHIP ELECTRONICS CO., LTD. (“ROCKCHIP”) DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

Trademark Statement

“Rockchip”, “瑞芯微”, “瑞芯” shall be Rockchip’s registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

All rights reserved. ©2019. Fuzhou Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Fuzhou Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: www.rock-chips.com

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

Preface

Overview

This article introduces the Linux SPI driver principle and basic debugging methods.

Product Version

Chipset	Kernel Version
All chips develop in linux4.4	Linux 4.4
All chips develop in linux4.19	Linux 4.19

Intended Audience

This document (this guide) is mainly intended for:

Technical support engineers Software development engineers

Revision History

Version	Author	Date	Change Description
V1.0.0	Huibin Hong	2016-06-29	Initial version
V2.0.0	Dingqiang Lin	2019-12-09	Support Linux 4.19
V2.1.0	Dingqiang Lin	2020-02-13	Adjust SPI slave configuration

Content

Rockchip SPI Developer Guide

- 1 Feature of Rockchip SPI
 - 2 Kernel Software
 - 2.1 Code Path
 - 2.2 Kernel Configuration
 - 2.3 DTS Node Configuration
 - 2.3 SPI Device Driver
 - 2.4 User mode SPI device Configuration
 - 2.4.1 Kernel Configuration
 - 2.4.2 DTS Configuration
 - 2.4.3 Kernel Patch
 - 2.4.4 Using Instruction
 - 2.5 Independent SPI slave configuration
 - 2.5.1 Linux 4.4 configuration
 - 2.5.2 Linux 4.19 configuration
 - Testing
 - 3 SPI Testing Driver in Kernel
 - 3.1 Kernel Driver
 - 3.2 DTS Configuraion
 - 3.3 Driver log
 - 3.4 Test Command
 - 4 FAQ
-

1 Feature of Rockchip SPI

The serial peripheral interface is called SPI, the following are some of the features supported by the Linux 4.4 SPI driver:

- Motorola SPI protocol is used by default
- Supports 8-bit and 16-bit
- Software programmable clock frequency and transfer rate up to 50MHz
- Support 4 transfer mode configurations of SPI
- One or two chips selects per SPI controller

the following are some of the new features supported by the Linux 4.19 SPI driver:

- Support both slave and master mode

2 Kernel Software

2.1 Code Path

```
1 | drivers/spi/spi.c           /* SPI Driver framework */
2 | drivers/spi/spi-rockchip.c  /* RK SPI implement of interface */
3 | drivers/spi/spidev.c        /* Create SPI device node for using */
4 | drivers/spi/spi-rockchip-test.c /* SPI test driver, it needs to add to
   | Makefile compiler manually. */
5 | Documentation/spi/spidev_test.c /* SPI test tool in user state */
```

2.2 Kernel Configuration

```
1 | Device Drivers --->
2 |     [*] SPI support --->
3 |         <*> Rockchip SPI controller driver
```

2.3 DTS Node Configuration

```
1 | &spi1 {                               //Quote SPI controller node
2 |     status = "okay";
3 |     max-freq = <48000000>;             //SPI internal clock
4 |     dma-names = "tx","rx";             //Enable DMA mode, it is not recommended
   | if the general communication byte is less than 32 bytes
5 |     spi_test@10 {
6 |         compatible = "rockchip,spi_test_bus1_cs0"; //The name corresponding
   | to the driver
7 |         reg = <0>;                     //Chip select 0 or 1
8 |         spi-max-frequency = <24000000>; //This is clock frequency of spi clk
   | output, witch does not exceed 50M.
9 |         spi-cpha;                       //If configure it, cpha is 1
10 |        spi-cpo;                        //If configure it, cpol is 1, the clk pin
   | remains high level.
11 |        status = "okay";                //Enable device node
12 |    };
13 |};
```

Typically, SPI can work by only configuring the following properties.

```
1 | spi_test@11 {
2 |     compatible = "rockchip,spi_test_bus1_cs1";
3 |     reg = <1>;
4 |     spi-max-frequency = <24000000>;
5 |     status = "okay";
6 |};
```

Configuration instructions for max-freq and spi-max-frequency:

- spi-max-frequency is the output clock of the SPI, which is output after max-freq was divided, and the relationship between them is $\text{max-freq} \geq 2 * \text{spi-max-frequency}$.
- max-freq should not be lower than 24M, otherwise there may be problems.
- If you need to configure spi-cpha, $\text{max-freq} \leq 6\text{M}$, $1\text{M} \leq \text{spi-max-frequency} \leq 3\text{M}$.

2.3 SPI Device Driver

Register device driver:

```
1  static int spi_test_probe(struct spi_device *spi)
2  {
3      int ret;
4      int id = 0;
5      if(!spi)
6          return -ENOMEM;
7      spi->bits_per_word= 8;
8      ret= spi_setup(spi);
9      if(ret < 0) {
10         dev_err(&spi->dev, "ERR: fail to setup spi\n");
11         return -1;
12     }
13     return ret;
14 }
15 static int spi_test_remove(struct spi_device *spi)
16 {
17     printk("%s\n", __func__);
18     return 0;
19 }
20 static const struct of_device_id spi_test_dt_match[] = {
21     { .compatible = "rockchip,spi_test_bus1_cs0", },
22     { .compatible = "rockchip,spi_test_bus1_cs1", },
23     {},
24 };
25 MODULE_DEVICE_TABLE(of, spi_test_dt_match);
26 static struct spi_driver spi_test_driver = {
27     .driver = {
28         .name = "spi_test",
29         .owner = THIS_MODULE,
30         .of_match_table = of_match_ptr(spi_test_dt_match),
31     },
32     .probe = spi_test_probe,
33     .remove = spi_test_remove,
34 };
35 static int __init spi_test_init(void)
36 {
37     int ret = 0;
38     ret = spi_register_driver(&spi_test_driver);
39     return ret;
40 }
41 device_initcall(spi_test_init);
42 static void __exit spi_test_exit(void)
43 {
44     return spi_unregister_driver(&spi_test_driver);
45 }
46 module_exit(spi_test_exit);
```

For SPI read and write operations, please refer to `include/linux/spi/spi.h`.

```

1 static inline int
2 spi_write(struct spi_device *spi, const void *buf, size_t len)
3 static inline int
4 spi_read(struct spi_device *spi, void *buf, size_t len)
5 static inline int
6 spi_write_and_read(struct spi_device *spi, const void *tx_buf, void *rx_buf,
   size_t len)

```

2.4 User mode SPI device Configuration

User mode SPI device means operating the SPI interface in user space directly, which makes it convenient for many SPI peripheral drivers run in user space.

There is no need to change the kernel to facilitate driver development.

2.4.1 Kernel Configuration

```

1 Device Drivers --->
2     [*] SPI support --->
3         [*] User mode SPI device driver support

```

2.4.2 DTS Configuration

```

1 &spi0 {
2     status = "okay";
3     max-freq = <50000000>;
4     spi_test@00 {
5         compatible = "rockchip,spidev";
6         reg = <0>;
7         spi-max-frequency = <5000000>;
8     };
9 };

```

2.4.3 Kernel Patch

```

1 diff --git a/drivers/spi/spidev.c b/drivers/spi/spidev.c
2 index d0e7dfc..b388c32 100644
3 --- a/drivers/spi/spidev.c
4 +++ b/drivers/spi/spidev.c
5 @@ -695,6 +695,7 @@ static struct class *spidev_class;
6 static const struct of_device_id spidev_dt_ids[] = {
7     { .compatible = "rohm,dh2228fv" },
8     { .compatible = "linear technology, ltc2488" },
9 +     { .compatible = "rockchip,spidev" },
10     {} ,
11 };
12 MODULE_DEVICE_TABLE(of, spidev_dt_ids);

```

Note: The legacy kernels may not have 2.4.1 and 2.4.3 and need to be added manually. If there already have both cores, just add 2.4.2.

2.4.4 Using Instruction

After the driver device is successfully registered, a device like this name will be displayed: /dev/spidev1.1

Please refer to Documentation/spi/spidev_test.c

2.5 Independent SPI slave configuration

The interfaces "spi_read" and "spi_write" of SPI slave are the same as SPI master.

2.5.1 Linux 4.4 configuration

About kernel patch of the slave, please check if your code contains the following patches, if not, please add the patch:

```
1 diff --git a/drivers/spi/spi-rockchip.c b/drivers/spi/spi-rockchip.c
2 index 060806e..38eecd1 100644
3 --- a/drivers/spi/spi-rockchip.c
4 +++ b/drivers/spi/spi-rockchip.c
5 @@ -519,6 +519,8 @@ static void rockchip_spi_config(struct rockchip_spi *rs)
6         cr0 |= ((rs->mode & 0x3) << CR0_SCPH_OFFSET);
7         cr0 |= (rs->tmode << CR0_XFM_OFFSET);
8         cr0 |= (rs->type << CR0_FRF_OFFSET);
9 +         if (rs->mode & SPI_SLAVE_MODE)
10 +             cr0 |= (CR0_OPM_SLAVE << CR0_OPM_OFFSET);
11
12         if (rs->use_dma) {
13             if (rs->tx)
14 @@ -734,7 +736,7 @@ static int rockchip_spi_probe(struct platform_device
15 *pdev)
16
17         master->auto_runtime_pm = true;
18         master->bus_num = pdev->id;
19 -         master->mode_bits = SPI_CPOL | SPI_CPHA | SPI_LOOP;
20 +         master->mode_bits = SPI_CPOL | SPI_CPHA | SPI_LOOP | SPI_SLAVE_MODE;
21         master->num_chipselect = 2;
22         master->dev.of_node = pdev->dev.of_node;
23         master->bits_per_word_mask = SPI_BPW_MASK(16) | SPI_BPW_MASK(8);
24 diff --git a/drivers/spi/spi.c b/drivers/spi/spi.c
25 index de1cb8..4172da1 100644
26 --- a/drivers/spi/spi.c
27 +++ b/drivers/spi/spi.c
28 @@ -1466,6 +1466,8 @@ of_register_spi_device(struct spi_master *master,
29 struct device_node *nc)
30
31         spi->mode |= SPI_3WIRE;
32         if (of_find_property(nc, "spi-lsb-first", NULL))
33             spi->mode |= SPI_LSB_FIRST;
34 +         if (of_find_property(nc, "spi-slave-mode", NULL))
35 +             spi->mode |= SPI_SLAVE_MODE;
36
37         /* Device DUAL/QUAD mode */
38         if (!of_property_read_u32(nc, "spi-tx-bus-width", &value)) {
39 diff --git a/include/linux/spi/spi.h b/include/linux/spi/spi.h
40 index cce80e6..ce2cec6 100644
41 --- a/include/linux/spi/spi.h
42 +++ b/include/linux/spi/spi.h
43 @@ -153,6 +153,7 @@ struct spi_device {
44     #define SPI_TX_QUAD 0x200 /* transmit with 4
45 wires */
46     #define SPI_RX_DUAL 0x400 /* receive with 2
47 wires */
```

```

43 | #define          SPI_RX_QUAD      0x800          /* receive with 4
    | wires */
44 | +#define          SPI_SLAVE_MODE  0x1000          /* enable spi slave
    | mode */
45 |         int                      irq;
46 |         void                    *controller_state;
47 |         void                    *controller_data;

```

DTS configuration:

```

1 |         &spi0 {
2 |             max-freq = <48000000>; //spi internal clk, don't modify
3 |             spi_test@01 {
4 |                 compatible = "rockchip,spi_test_bus0_cs1";
5 |                 id = <1>;
6 |                 reg = <1>;
7 |                 /*"spi-max-frequency = <24000000>; " is no need
8 |                 spi-slave-mode; //if enable slave mode, just modify here
9 |             };
10 |         };

```

Note: max-freq must be more than 6 times larger than master clk, such as max-freq = <48000000>; the clock given by master must be less than 8M.

2.5.2 Linux 4.19 configuration

Owing to the developing of Linux 4.19 SPI slave framework, it support SPI slave after adding related code in spi-rockchip.c:

```

1 | of_property_read_bool(pdev->dev.of_node, "spi-slave")

```

DTS configuration:

```

1 | &spi0 {
2 |     status = "okay";
3 |     max-freq = <48000000>; //spi internal clk, don't modify
4 |     spi-slave; //enable slave mode
5 |     slave { //As spi-bus required, SPI slave sub-node should name start with
        | "slave"
6 |         compatible = "rockchip,spi_test_bus0_cs0";
7 |         id = <0>;
8 |         spi-max-frequency = <24000000>;
9 |     };
10 | };

```

Note: max-freq must be more than 6 times larger than master clk, such as max-freq = <48000000>; the clock given by master must be less than 8M.

Testing

If SPI working as slave, you must start "slave read" and then start "master write". Otherwise, the slave will not finish reading and the master has finished writing.

If it is slave write, then master read, also needs to start slave write first, because only slave sends clock, slave will work, and master will sent or received data immediately.

Based on the third chapter:

First slave: `echo write 0 1 16 > /dev/spi_misc_test`

Then master: `echo read 0 1 16 > /dev/spi_misc_test`

3 SPI Testing Driver in Kernel

3.1 Kernel Driver

drivers/spi/spi-rockchip-test.c You need to add below:

```
1 | drivers/spi/Makefile
2 | += spi-rockchip-test.o
```

3.2 DTS Configuraion

```
1 | &spi0 {
2 |     status = "okay";
3 |     max-freq = <48000000>; //spi internal clk, don't modify
4 |     //dma-names = "tx", "rx"; //enable dma
5 |     pinctrl-names = "default"; //pinctrl according to you board
6 |     pinctrl-0 = <&spi0_clk &spi0_tx &spi0_rx &spi0_cs0 &spi0_cs1>;
7 |     spi_test@00 {
8 |         compatible = "rockchip,spi_test_bus0_cs0";
9 |         id = <0>; //This attribute is used to distinguish
different SPI slave devices in "spi-rockchip-test.c".
10 |         reg = <0>; //chip select 0:cs0 1:cs1
11 |         spi-max-frequency = <24000000>; //spi output clock
12 |     };
13 |
14 |     spi_test@01 {
15 |         compatible = "rockchip,spi_test_bus0_cs1";
16 |         id = <1>;
17 |         reg = <1>;
18 |         spi-max-frequency = <24000000>;
19 |         spi-slave-mode;
20 |     };
21 | };
```

3.3 Driver log

```
1 | [ 0.530204] spi_test spi32766.0: fail to get poll_mode, default set 0
2 | [ 0.530774] spi_test spi32766.0: fail to get type, default set 0
3 | [ 0.531342] spi_test spi32766.0: fail to get enable_dma, default set 0
4 | //If you donnot use it,please ignore it.
5 | [ 0.531929]
rockchip_spi_test_probe:name=spi_test_bus1_cs0,bus_num=32766,cs=0,mode=0,spee
d=5000000
6 | [ 0.532711] rockchip_spi_test_probe:poll_mode=0, type=0, enable_dma=0
7 | //This is the mark of succesful register.
```

3.4 Test Command

```
1 echo write 0 10 255 > /dev/spi_misc_test
2 echo write 0 10 255 init.rc > /dev/spi_misc_test
3 echo read 0 10 255 > /dev/spi_misc_test
4 echo loop 0 10 255 > /dev/spi_misc_test
5 echo setsped 0 1000000 > /dev/spi_misc_test
```

The above means:

Echo type id number of loops transfer length > /dev/spi_misc_test

Echo setsped id frequency (in Hz) > /dev/spi_misc_test

You can modify the test case by yourself if you want.

4 FAQ

- Confirm that the driver is running before debugging
- Ensure that the IOMUX configuration of the SPI 4 pins is correct .
- Confirm that during the TX sending, the TX pin has a normal waveform, CLK has a normal CLOCK signal, and the CS signal is pulled low.
- If the clock frequency is high, considering increasing the drive strength to improve the signal.