

Cinematic

User & Builder Guide

None

None

Table of contents

1. Cinamate Docs	6
2. Quick start	7
2.1 Quick start	7
2.1.1 Hardware requirements	7
2.1.2 Installation	7
3. Using the camera	8
3.1 Simple GUI	9
3.2 Compatible sensors	10
3.3 Audio recording (experimental)	12
3.4 Speed ramping	15
3.4.1 Speed ramping in Cinamate	15
3.4.2 Shutter angle synchronisation	16
3.5 Dual sensors	17
4. Customising your build	18
4.1 Settings file	18
4.1.1 welcome message	18
4.1.2 system	19
4.1.3 geometry	19
4.1.4 output	20
4.1.5 preview	20
4.1.6 anamorphic_preview	20
4.1.7 gpio_output	21
4.1.8 arrays	21
4.1.9 settings	22
4.1.10 analog_controls	22
4.1.11 free_mode	23
4.1.12 buttons	23

4.1.13	two_way_switches	24
4.1.14	rotary_encoders	24
4.1.15	quad_rotary_encoders	24
4.1.16	i2c_oled	25
4.2	CLI user guide	26
4.2.1	Checking available options	26
4.2.2	Camera modes	26
4.2.3	Low-resolution (lores) stream	26
4.2.4	Preview window	27
4.2.5	Tuning files	27
4.2.6	Post processing	27
4.2.7	Cinamate-specific flags	28
4.2.8	Example commands	28
4.3	Commands reference	30
4.3.1	Available Commands	31
4.4	Connecting to the Pi with SSH	36
4.5	Configuring the Wi-Fi hotspot	37
5.	System management	38
5.1	System services	38
5.1.1	cinamate-autostart.service	38
5.1.2	storage-automount.service	38
5.1.3	wifi-hotspot.service	39
5.2	Modifying config.txt	40
5.2.1	Adjusting config.txt for different sensors:	40
5.3	Recompiling cinepi-raw	41
5.4	Overclocking the Pi	42
5.5	Backing up the SD card	43
6.	Reference & troubleshooting	44
6.1	Redis API quick start	44
6.1.1	Redis-cli	44

6.1.2	cp_controls	44
6.1.3	cp_stats	45
6.1.4	Controlling the camera from your own script	46
6.2	Redis key reference	47
6.3	Hardware overview	54
7.	Cinematé builds	57
8.	Development & contributing	59
8.1	Installation	59
8.1.1	Install script	59
8.1.2	Manual install	60
8.1.3	Cinematé	66
8.1.4	Todo	70

1. Cinamate Docs

Welcome to the **Cinamate** project - an open-source boiler plate for building your own digital cinema camera using a Raspberry Pi 5 . It combines a lightweight Python interface with the CinePi-raw recorder by Csaba Nagy for capturing 12-bit CinemaDNG footage.

To begin, follow the steps in Quick start. Later chapters explain how to customise the system to tailor Cinamate to your needs.

For sharing your build with others, inspiration and discussion, make sure to join the CinePi Discord.

Download this documentation in pdf format for easy offline reference.

2. Quick start

2.1 Quick start

2.1.1 Hardware requirements

- Raspberry Pi 5
- Official HQ or Global Shutter camera
- HDMI monitor or a phone/tablet for monitoring

2.1.2 Installation

- 1 . **Burn the Cinamate image** to an SD card (8 GB or larger).
- 2 . **Connect the Pi and the camera sensor board.**
 - Important:** Ensure the Pi is powered off before attaching the camera ribbon cable. Hot-swapping the cable is not advised.
- 3 . **Boot the Pi.** CineMate should start automatically.
- 4 . **Previewing the image**
- 5 . Plug in an HDMI monitor **or** connect your phone/tablet to the Wi-Fi network **CinePi** (password **11111111**).
- 6 . Open a browser and go to **cinempi.local:5000** to see the interface. A clean video feed without the GUI is available at **cinempi.local:8000/stream** .
- 7 . **Recording footage**
- 8 . Attach a high-speed drive: an **SSD** (Samsung T 7 recommended), an **NVMe drive**, or the **CFE Hat**.
- 9 . Format the drive as **ext4** and give it the label **RAW** .
- 10 . Connect a button between **GPIO 5** and **GND** (or briefly short these pins with a paper clip). When using the phone preview, you can also start/stop recording by tapping the preview.

That's it—your bare-bones CineMate build is ready!

Remember to power everything down before disconnecting hardware!

3. Using the camera

TBA

3.1 Simple GUI

Simple GUI is available via browser and/or attached HDMI monitor.

- Red color means camera is recording.
- Purple color means camera detected a drop frame
- Green color means camera is writing buffered frames to disk. You can still start recording at this stage, but any buffered frames from the last recording will be lost.

Buffer meter in the lower left indicates number of frames in buffer. Useful when testing storage media.

When a compatible USB microphone is connected, VU meters appear on the right side of the GUI so you can monitor audio levels.

3.2 Compatible sensors

Sensor	Cinamate sensor mode	Resolution	Aspect Ratio	Bit Depth	Max FPS ★	Film Size (M)
IMX 2 8 3	0	2 7 3 6 x 1 5 3 8	1 . 8 0	1 2	4 0	7
	1	2 7 3 6 x 1 8 2 4	1 . 5 3	1 2	3 4	8
IMX 2 9 6	0	1 4 5 6 x 1 0 8 8	1 . 3 3	1 2	6 0	2
IMX 4 7 7	0	2 0 2 8 x 1 0 8 0	1 . 8 7	1 2	5 0	4
	1	2 0 2 8 x 1 5 2 0	1 . 3 3	1 2	4 0	5
	2	1 3 3 2 x 9 9 0	1 . 3 4	1 0	1 2 0	2
IMX 5 8 5	0	1 9 2 8 x 1 0 9 0	1 . 7 7	1 2	8 7	4
	1	3 8 4 0 x 2 1 6 0	1 . 7 7	1 2	3 4	4

Note that maximum fps will vary according to disk write speed. For the specific fps values for your setup, make test recordings and monitor the output. Purple background in the monitor/web browser indicates drop frames. You can cap Cinemates max fps values for your specific build by editing the file

```
cinemate/src/module/sensor_detect.py
```

3.3 Audio recording (experimental)

Cinamate records audio alongside the image sequence. Support is currently limited to a few USB microphones with hard coded configurations: - **RØDE VideoMic NTG** – recorded in stereo at 24-bit/ 48 kHz. - **USB PnP microphones** – recorded in mono at 16-bit/ 48 kHz.

Audio is written as `.wav` files into the same folder as the `.dng` frames. The implementation is still experimental and audio/video synchronization needs further investigation.

.asoundrc Setup

For `dsnoop` support, create a `~/.asoundrc` in home directory:

```
nano ~/.asoundrc
```

Paste this into the file:

```
pcm.dsnoop_24bit {
    type dsnoop
    ipc_key 2048
    slave {
        pcm "hw:Device,0"
        channels 2
        rate 48000
        format S24_3LE
        period_size 1024
        buffer_size 4096
    }
}

pcm.dsnoop_16bit {
    type dsnoop
    ipc_key 2049
    slave {
        pcm "hw:Device,0"
        channels 1
        rate 48000
        format S16_LE
        period_size 1024
        buffer_size 4096
    }
}

pcm.mic_24bit {
    type plug
    slave.pcm "dsnoop_24bit"
}

pcm.mic_16bit {
    type plug
    slave.pcm "dsnoop_16bit"
}
```

Exit nano editor using ctrl+x.

3.4 Speed ramping

Speed ramping is the process of changing the camera's frame rate during a shot so that playback speed varies once the footage is conformed to a constant frame rate in post production. Ramping up the frame rate produces slow motion while ramping down speeds up the action.

3.4.1 Speed ramping in Cinamate

Cinamate exposes frame rate control through the `CinePiController` class. The simplest way to change speed on the fly is the CLI command:

```
set fps <value>
```

For quick $2 \times$ changes Cinamate also implements `set_fps_double` which toggles between the current FPS and twice that value. This can be used for designing a slow-motion button. Here is how you would to it in the settings file, button section:

```
{
  "pin": 18,
  "pull_up": true,
  "debounce_time": 0.1,
  "press_action": {"method": "set_fps_double"}
}
```

No argument is needed here. For methods such as `set_fps_double`, calling the method without an argument will simply toggle the control, in this case turning the slow motion on and off. If the user provides an argument, the control will be set explicitly to that value.

The controller contains an experimental `_ramp_fps` helper that gradually steps the frame rate up or down using `ramp_up_speed` and `ramp_down_speed` delays. This can be adapted if smoother transitions are desired.

3.4.2 Shutter angle synchronisation

When frame rate changes the shutter angle can either remain fixed (preserving motion blur) or adjust to keep the exposure time constant. This behaviour is controlled by `shutter_a_sync_mode`.

Mode `0` keeps the **motion blur consistent** because the physical shutter angle does not change. As the FPS increases the exposure time gets shorter, resulting in a darker image.

Mode `1` stores the current exposure time and recalculates the shutter angle whenever the FPS is adjusted so that **exposure time** stays the same.

Cinamate updates the nominal exposure time when the user sets a new angle. FPS is recalculated from the stored exposure time:

3.5 Dual sensors

CineMate automatically detects each camera connected to the Raspberry Pi and spawns a separate `cinempi-raw` process per sensor. By default:

- **Primary camera** (first detected) displays its preview on HDMI port `0`.
- **Secondary cameras** run with `--nopreview` and map to subsequent HDMI outputs (cam `1` → HDMI `1`, cam `2` → HDMI `2`, etc.).
- Preview windows are centered and sized according to your `geometry` settings.

Cameras are synchronized with cam `0` being the server and cam `1` being the client.

You can override default HDMI mappings in `settings.json` under the `output` section.

4. Customising your build

4.1 Settings file

This file controls how the camera behaves and how your buttons, switches and displays are mapped. It lives in `~/cinamate/src/settings.json` on the Raspberry Pi. You can edit it with any text editor; the settings take effect the next time you start CineMate.

The configuration is structured as JSON. Each top-level key describes a feature area of the system. Below is a tour of every section and what the options do.

4.1.1 welcome message

Text or image displayed briefly when Cinamate starts.

```
"welcome_image": null  
"welcome_message": "THIS IS A COOL MACHINE",
```

Set `welcome_image` to the path of a bitmap file to show a logo instead of text.

Example path: `/home/pi/welcome_image.bmp`.

If `welcome_image` path is set, this will override the text message.

4.1.2 system

```
"system": {  
  "wifi_hotspot": {  
    "name": "CinePi",  
    "password": "11111111",  
    "enabled": false  
  }  
}
```

- **name** – the Wi-Fi network name (SSID) broadcast by the Pi when hotspot mode is enabled.
- **password** – password for joining the hotspot.
- **enabled** – set to `true` to start the hotspot automatically on boot. If set to `false`, CineMate will still start its web ui but stream it on whatever network the Pi is connected to.

4.1.3 geometry

Controls image orientation for each camera port (`cam0`, `cam1`, etc.). These settings let you mount cameras in any orientation and still get an upright preview and recording. Example:

```
"geometry": {  
  "cam0": { "rotate_180": false, "horizontal_flip": false, "vertical_f  
lip": false },  
  "cam1": { "rotate_180": false, "horizontal_flip": false, "vertical_f  
lip": false }  
}
```

- **rotate_180** – flip the image upside-down.
- **horizontal_flip** – mirror the image left/right.
- **vertical_flip** – mirror the image top/bottom.

4.1.4 output

Maps each camera to an HDMI connector. Use `-1` for automatic selection.

```
"output": {  
  "cam0": { "hdmi_port": 0 },  
  "cam1": { "hdmi_port": 1 }  
}
```

4.1.5 preview

Adjusts zoom levels for the HDMI/browser preview.

```
"preview": {  
  "default_zoom": 1.0,  
  "zoom_steps": [1.0, 1.5, 2.0]  
}
```

- **default_zoom** – magnification factor used at startup.
- **zoom_steps** – list of zoom factors you can cycle through with the `set_zoom_step` command.

4.1.6 anamorphic_preview

For stretching the preview when using anamorphic lenses.

```
"anamorphic_preview": {  
  "default_anamorphic_factor": 1,  
  "anamorphic_steps": [1, 1.33, 2.0]  
}
```

- **default_anamorphic_factor** – factor loaded when Cinamate starts.
- **anamorphic_steps** – selectable squeeze factors; values above `1.0` widen the image.

4.1.7 gpio_output

Defines pins used for visual feedback or sync signals.

```
"gpio_output": {  
  "pwm_pin": 19,  
  "rec_out_pin": [6, 21]  
}
```

- **pwm_pin** – outputs a strobe for shutter sync or external devices.
- **rec_out_pin** – list of pins pulled high while recording (useful for tally LEDs).

4.1.8 arrays

Preset lists for exposure and frame-rate settings. Cinamate will step through these values unless you enable free mode, either in the settings file or during runtime.

```
"arrays": {  
  "iso_steps": [100, 200, 400, 640, 800, 1200, 1600, 2500, 3200],  
  "shutter_a_steps": [1, 45, 90, 135, 172.8, 180, 225, 270, 315,  
346.6, 360],  
  "fps_steps": [1, 2, 4, 8, 12, 16, 18, 24, 25, 33, 40, 50],  
  "wb_steps": [3200, 4400, 5600]  
}
```

4.1.9 settings

General options for runtime behaviour.

```
"settings": {  
  "light_hz": [50, 60],  
  "conform_frame_rate": 24  
}
```

- **light_hz** – list of mains frequencies used to calculate flicker-free shutter angles. These are added to the shutter angle array and also dynamically calculated upon each fps change. This way, there is always a flicker free shutter angle value close by, when toggling through shutter angles, either via the cli or using buttons/pots/rotary encoder.
- **conform_frame_rate** – frame rate intended for project conforming in post. This setting is not really used by CineMate except for calculating the recording timecode tracker in redis but might be used in future updates.

4.1.10 analog_controls

Maps Grove Base HAT ADC channels to analogue dials (potentiometers). Use `null` to disable a dial.

```
"analog_controls": {  
  "iso_pot": 0,  
  "shutter_a_pot": 2,  
  "fps_pot": 4,  
  "wb_pot": 6  
}
```

Note that even if you are using a Grove Base Hat, it might be useful to disable the dials not connected to pots, since noise from these connectors might trigger false readings.

4.1.11 free_mode

When enabled, ignores the preset arrays and exposes the full range supported by the sensor.

```
"free_mode": {
  "iso_free": false,
  "shutter_a_free": false,
  "fps_free": true,
  "wb_free": false
}
```

4.1.12 buttons

Defines GPIO push buttons. Each entry describes one button and the actions it triggers.

```
{
  "pin": 5,
  "pull_up": true,
  "debounce_time": 0.1,
  "press_action": {"method": "rec"}
}
```

- **pin** – BCM pin number the button is connected to.
- **pull_up** – set `true` if the pin idles high (internal pull-up). Use `false` for pull-down wiring.
- **debounce_time** – ignore additional presses within this time window (seconds).
- **press_action, single_click_action, double_click_action, triple_click_action, hold_action** – actions to perform for each type of interaction. Actions call Cinamate CLI commands with optional `args`.

Automatic detection of inverse push buttons

Some push-buttons are wired closed = logic `1` and open = `0`. At start-up, CineMate automatically detects buttons in state `true` and reverses them. This way the user can use any type of push buttons, both `1 - 0 - 1` and `0 - 1 - 0` types.

4.1.13 two_way_switches

Latching on/off switches. Cinamate triggers an action whenever the state changes.

```
{
  "pin": 27,
  "state_on_action": {"method": "set_all_lock", "args": [1]},
  "state_off_action": {"method": "set_all_lock", "args": [0]}
}
```

4.1.14 rotary_encoders

Rotary encoders used for fine adjustment of settings. These can be wired straight to the GPIO pins of the Pi.

```
{
  "clk_pin": 9,
  "dt_pin": 11,
  "encoder_actions": {
    "rotate_clockwise": {"method": "inc_iso"},
    "rotate_counterclockwise": {"method": "dec_iso"}
  }
}
```

- **clk_pin** and **dt_pin** – the two pins of the encoder.
- **encoder_actions** – commands to run when turning the dial.

4.1.15 quad_rotary_encoders

Support for the Adafruit Neopixel Quad I 2 C rotary encoder breakout with four dials. Each entry assigns a dial to a setting and clones the behaviour of a button pin.

```
"quad_rotary_encoders": {
  "0": {"setting_name": "iso", "gpio_pin": 5},
  "1": {"setting_name": "shutter_a", "gpio_pin": 16},
  "2": {"setting_name": "fps", "gpio_pin": 26},
  "3": {"setting_name": "wb", "gpio_pin": 5}
}
```


4.1.16 i2c_oled

Configuration for the optional OLED status screen. This can be useful for presenting extra information appart from the HDMI/web display.

```
"i2c_oled": {  
  "enabled": true,  
  "width": 128,  
  "height": 64,  
  "font_size": 30,  
  "values": ["write_speed_to_drive"]  
}
```

- **enabled** – turn the OLED display on or off.
- **width / height** – pixel dimensions of your screen.
- **font_size** – size of the displayed text.
- **values** – list of Redis keys or pseudo-keys to show (for example `cpu_temp`).

Available keys come from `src/module/i2c_oled.py`. Here are some examples:

- `iso`, `fps` – basic camera settings.
- `shutter_a` – shown as **SHUTTER** with a `°` suffix.
- `wb_user` – shown as **WB** with a trailing `K`.
- `space_left` – displayed as **SPACE** in gigabytes.
- `write_speed_to_drive` – write speed in MB/s.
- `resolution` – prints `width×height@bit_depth` on the first line.
- `is_recording` – draws a bullet `●` when recording.
- `cpu_load`, `cpu_temp`, `memory_usage` – Pi system statistics.

Other keys will display their name in uppercase and the raw value from Redis.

4.2 CLI user guide

Here is how you can operate **CinePi-raw** from the command line.

4.2.1 Checking available options

Before running the program you can view all command-line flags with:

```
cinepi-raw -h
```

This prints a long list of options supported by the application. It includes the standard parameters from `rpikam-apps` (such as resolution and exposure settings) plus additional flags specific to the Cinamate.

4.2.2 Camera modes

CinePi-raw uses **Libcamera** to talk to your Raspberry Pi camera module. Each sensor supports one or more *modes*, which define the resolution and bit depth of the RAW images that the sensor can produce. A mode is written as:

```
--mode 2028:1080:12:U
```

- `width` and `height` select the active pixel area of the sensor.
- `bit-depth` is usually `1 2` or `1 6` bits per pixel.
- `packing` can be `P` for packed or `U` for unpacked data.

The mode must match the sensor you are using. For example, an IMX 4 7 7 camera can run at `4056:3040:12` (full sensor) or at smaller cropped resolutions. When specifying a mode you typically also set the output `--width` and `--height` which control the size of the image written to disk. These can be equal to the mode values or smaller when scaling is applied.

4.2.3 Low-resolution (lores) stream

```
--lores-width 1280 --lores-height 720
```

CinePi-raw can produce a secondary low-resolution stream alongside the full-resolution RAW frames.

4.2.4 Preview window

By default the program opens an HDMI preview so you can see what the camera captures. The size and position of this window are controlled with:

```
-p 0,30,1920,1020
```

This positions the preview 30 pixels from the top of the screen with a 1920 × 1020 window.

4.2.5 Tuning files

```
--tuning-file /home/pi/cinamate/resources/tuning_files/imx477.json
```

Describes the camera's colour and lens characteristics. Point to a file supplied with Libcamera (for example `imx477.json` for the HQ camera)

4.2.6 Post processing

```
--post-process-file /home/pi/post-processing.json
```

For cinepi-raw, this file defines the port used by cpp-mjpeg-streamer (default cinepi.local: 8000)

If you have more than one camera connected to the Pi, and activated in `boot/firmware/config.txt`, the camera connected to physical cam 0 will use `/home/pi/post-processing 0.json` and the camera connected to cam 1 will use `/home/pi/post-processing 1.json`

4.2.7 Cinematé-specific flags

The Cinematé fork introduces several extra options:

Flag	Argument	Description
<code>--cam-port</code>	<code>cam0</code> <code>cam1</code>	Select which CSI camera port to use.
<code>--hdmi-port</code>	<code>0</code> <code>1</code> <code>-1</code>	Choose the HDMI connector for the preview (<code>0</code> = HDMI- 0 , <code>1</code> = HDMI- 1 , <code>-1</code> = auto-detect).
<code>--same-hdmi</code>	<i>(none)</i>	Force both capture and controller GUI to share the same HDMI output.
<code>--keep16</code>	<code>true</code> <code>false</code>	Save full 16-bit DNGs instead of 12-bit packed files.

At this moment though, Cinematé is 12 bit only. The flag is for future updates of the IMX 585 16 bit clear HDR modes.

4.2.8 Example commands

Below are sample commands for different sensors and modes.

IMX477 (12-bit, full width)

```
cinempi-raw --mode 4056:2160:12 --width 4056 --height 2160 \  
  --lores-width 1280 --lores-height 720 \  
  -p 0,30,1920,1020 \  
  --post-process-file /home/pi/post-processing.json \  
  --tuning-file /home/pi/libcamera/src/ipa/rpi/pisp/data/  
imx477.json \  

```

IMX585 (12-bit unpacked)

```
cinempi-raw --mode 1928:1090:12:U --width 1928 --height 1090 \  
    --lores-width 1280 --lores-height 720 \  
    -p 0,30,1920,1020 \  
    --post-process-file /home/pi/post-processing.json \  
    --tuning-file /home/pi/libcamera/src/ipa/rpi/pisp/data/  
imx585.json \  

```

Now, with an SSH shell running redis-cli you should be able to capture RAW footage from the command line!

```
redis-cli  
> set is_recording 1  
> publish cp_controls is_recording
```

4.3 Commands reference

Cinematé doesn't use a real shell parser. Instead, a background thread reads simple text commands from SSH or the serial port and calls the corresponding controller methods.

4.3.1 Available Commands

Command	Input type	Example
<code>rec</code> / <code>stop</code>	none	<code>rec</code>
<code>set iso <value></code>	int	<code>set iso 800</code>
<code>inc iso</code> / <code>dec iso</code>	none	<code>inc iso</code>
<code>set shutter a <angle></code>	float	<code>set shutter a 180</code>
<code>inc shutter a</code> / <code>dec shutter a</code>	none	<code>inc shutter a</code>
<code>set shutter a nom <angle></code>	float	<code>set shutter a nom 180</code>
<code>inc shutter a nom</code> / <code>dec shutter a nom</code>	none	<code>inc shutter a nom</code>
<code>set fps <value></code>	float	<code>set fps 24</code>
<code>inc fps</code> / <code>dec fps</code>	none	<code>inc fps</code>

Command	Input type	Example
<code>set wb [<Kelvin>]</code>	int or none	<code>set wb 5600</code>
<code>inc wb</code> / <code>dec wb</code>	none	<code>inc wb</code>
<code>set resolution [<mode>]</code>	int or none	<code>set resolution 2</code>
<code>set anamorphic factor [<float>]</code>	float or none	<code>set anamorphic factor 1.33</code>
<code>set zoom [<float>]</code>	float or none	<code>set zoom 2</code>
<code>inc zoom</code> / <code>dec zoom</code>	none	<code>inc zoom</code>
<code>mount</code> / <code>unmount</code>	none	<code>mount</code>
<code>toggle mount</code>	none	<code>toggle mount</code>
<code>time</code>	none	<code>time</code>
<code>set rtc time</code>	none	<code>set rtc time</code>

Command	Input type	Example
<code>space</code>	none	<code>space</code>
<code>get</code>	none	<code>get</code>
<code>set shutter a sync [0/1]</code>	0 / 1 or none	<code>set shutter a sync 1</code>
<code>set iso lock [0/1]</code>	0 / 1 or none	<code>set iso lock</code>
<code>set shutter a nom lock [0/1]</code>	0 / 1 or none	<code>set shutter a nom lock</code>
<code>set shutter a nom fps lock [0/1]</code>	0 / 1 or none	<code>set shutter a nom fps lock</code>
<code>set fps lock [0/1]</code>	0 / 1 or none	<code>set fps lock 1</code>
<code>set all lock [0/1]</code>	0 / 1 or none	<code>set all lock 0</code>
<code>set fps double [0/1]</code>	0 / 1 or none	<code>set fps double</code>

Command	Input type	Example
<code>reboot</code> / <code>shutdown</code>	none	<code>reboot</code>
<code>restart camera</code>	none	<code>restart camera</code>
<code>restart cinemate</code>	none	<code>restart cinemate</code>
<code>set iso free [0/1]</code>	0 / 1 or none	<code>set iso free 1</code>
<code>set shutter a free [0/1]</code>	0 / 1 or none	<code>set shutter a free 0</code>
<code>set fps free [0/1]</code>	0 / 1 or none	<code>set fps free 1</code>
<code>set wb free [0/1]</code>	0 / 1 or none	<code>set wb free</code>
<code>set filter <0/1></code>	0 / 1	<code>set filter 1</code>

Commands without an explicit argument will toggle the current state when possible (e.g. `set fps lock` flips the lock; `set fps lock 1` forces it on).

4.4 Connecting to the Pi with SSH

Connect your computer and the Pi to the same network. If you are using the preinstalled image file, the system automatically starts a built-in hotspot: join the **CinePi** Wi-Fi with password `11111111`.

You can change this behaviour later in the settings file.

Open a terminal (on Windows you can use PowerShell).

Try the hostname first:

```
ssh pi@cinapi.local
```

If this fails you can list devices on the network:

```
arp -a
```

Look for an entry labelled `cinapi` or note the new IP address that appears.

Use the hostname or IP address with SSH:

```
ssh pi@cinapi.local  
# or  
ssh pi@<ip-address>
```

When asked about the host key, type `yes`. Enter the default password `1` when prompted.

You will now see the `pi@cinapi` prompt, meaning you are logged in.

If you are installing Cinamate manually, the hostname has not yet been set to cinapi. Then you will have to identify which ip address on the network is actually the Raspberry Pi and use that ip address.

From here you can run `cinamate` to start the interface or use `make` commands to manage the service. For security you should change the password with `passwd` after the first login.

4.5 Configuring the Wi-Fi hotspot

If `wifi_hotspot` in `settings.json` is `true` and no hotspot is active, Cinamate starts its own hotspot `nmcli device wifi hotspot` using your chosen SSID and password. If the Pi is already connected to wifi (for example WiFi settings set with `sudo raspi-config`) this connection will be replaced by Cinamates hotspot. Set `enabled: false` to keep wlan 0 free for regular Wi-Fi use.

Note that Cinamate still streams its web gui on whatever network the Pi is connected to, with GUI at : 5 0 0 0 and clean preview without GUI on : 8 0 0 0 /stream

5. System management

5.1 System services

5.1.1 cinamate-autostart.service

```
make install    # copy service file
make enable     # start on boot
make start      # launch now
make stop       # stop it
make status     # check status
make disable    # disable autostart
make clean      # remove the service
```

Note that in order for the web ui to work properly you have to run `make install` once in the `/home/pi/cinamate` folder, even if you are not using the autostart service.

5.1.2 storage-automount.service

`storage-automount` is a systemd service that watches for removable drives and mounts them automatically. The accompanying Python script reacts to udev events and the CFE-HAT eject button so drives can be attached or detached safely.

It understands `ext4`, `ntfs` and `exfat` filesystems. Partitions labelled `RAW` are mounted at `/media/RAW`; any other label is mounted under `/media/<LABEL>` after sanitising the name. This applies to USB SSDs, NVMe drives and the CFE-HAT slot.

To manually install and enable the service:

```
cd cinamate/services/storage-automount
sudo make install
sudo make enable
```

You can stop or disable it later with:

```
sudo make stop  
sudo make disable
```

5.1.3 wifi-hotspot.service

`wifi-hotspot` keeps a small access point running with the help of NetworkManager so you can always reach the web interface. The SSID and password are read from `/home/pi/cinamate/src/settings.json` under `system.wifi_hotspot`.

Install and enable it with:

```
cd cinamate/services/wifi-hotspot  
sudo make install  
sudo make enable
```

As with `storage-automount`, you can stop or disable the hotspot with `make stop` and `make disable`.

5.2 Modifying config.txt

5.2.1 Adjusting config.txt for different sensors:

```
sudo nano /boot/firmware/config.txt
```

Uncomment the section for the sensor being used, and make sure to comment out the others. Reboot the Pi for changes to take effect.

Exit the editor by pressing Ctrl+C

5.3 Recompiling cinepi-raw

Compiling cinepi-raw

For easy later rebuilding and installation of cinepi-raw you can create the file compile-raw.sh.

```
nano compile-raw.sh
```

Paste this into the file

```
sudo meson install -C build
```

Exit by pressing Ctrl+C

Make it exectutable:

```
sudo chmod +x compile-raw.sh
```

Now, from the same folder, to build and install cinepi-raw:

```
./compile-raw.sh
```

5.4 Overclocking the Pi

5.5 Backing up the SD card

Create a compressed image:

```
sudo dd if=/dev/mmcblk0 bs=4M conv=sparse,noerror status=progress | \
gzip -c > /media/RAW/Cinamate_$(date +%Y%m%d_%H%M%S).img.gz
```

Or use PiShrink for a smaller file:

```
sudo bash -euo pipefail -c '
  ts=$(date +%Y%m%d_%H%M%S)
  raw="/media/RAW/Cinamate_${ts}.img"
  final="/media/RAW/Cinamate_${ts}.img.gz"
  dd if=/dev/mmcblk0 of="$raw" bs=4M conv=sparse,noerror
status=progress
  pishrink.sh -v -z "$raw" "$final"
  rm -f "$raw"
'
```

6. Reference & troubleshooting

6.1 Redis API quick start

6.1.1 Redis-cli

```
# List all keys
redis-cli KEYS '*'

# Read the current ISO value
redis-cli GET iso

# Start a recording (same as pressing the Rec button)
redis-cli SET is_recording 1
redis-cli PUBLISH cp_controls is_recording
```

You can also type:

```
redis-cli
```

This will open the redis cli.

6.1.2 cp_controls

Both CinePi-raw and Cinamate writes values and immediately publish the key name. The recorder only reacts when it receives that publish event.

Any key may be sent this way. For example, to adjust the preview zoom:

```
# Set preview zoom level

redis-cli SET zoom 1.5
redis-cli PUBLISH cp_controls zoom
```

Note that for the **is_recording** key Cinamate stops recording upon edge detection (the variable changes from **0** to **1** or vice versa). The reason for this exception has to do with how the CinePi-raw fork handles recording with multiple cameras

```
# Start recording
redis-cli SET is_recording 1                # triggers 0 → 1 edge

# Stop recording
redis-cli SET is_recording 0                # triggers 1 → 0 edge
```

6.1.3 cp_stats

Every frame, cinepi-raw sends a small JSON object containing live statistics.

```
Json::Value data;
Json::Value histo;
data["framerate"] = completed_request->framerate;
data["colorTemp"] = info.colorTemp;
data["focus"] = info.focus;
data["frameCount"] = app_->GetEncoder()->getFrameCount();
data["bufferSize"] = app_->GetEncoder()->bufferSize();
redis_->publish(CHANNEL_STATS, data.toStyledString());
```

CineMate's `RedisListener` parses these messages and updates Redis keys like `framecount`, `BUFFER` and `fps_actual`.

6.1.4 Controlling the camera from your own script

Below is a very small example using `redis-py`.

```
import redis
r = redis.Redis(host='localhost', port=6379, db=0)

# toggle recording
current = r.get('is_recording')
new_value = b'0' if current == b'1' else b'1'
r.set('is_recording', new_value)
r.publish('cp_controls', 'is_recording')
```

Note that in this example, the publishing of the `is_recording` key is not strictly needed for recording to start/stop, but for formality's sake I think we should keep the publish command.

Info

This is basically what Cinematé does: it keeps track of variables being set by `cinapi-raw`, and also sets variables itself.

6.2 Redis key reference

This page lists all Redis keys used by Cinematé and CinePi-raw. Values are simple strings so you can read or write them with `redis-cli`.

Each entry explains which component normally writes the key and what happens when you change it manually.

Key	Written by	Description	Safe to change manually?
anamorphic_factor	Cinamate	Preview squeeze for anamorphic lenses	Yes (publish key to apply)
iso	Cinamate → CinePi-raw	Sensor gain in ISO	Yes
shutter_a	Cinamate → CinePi-raw	Actual shutter angle in degrees	Yes
shutter_angle_nom	Cinamate	Desired shutter angle before sync/free adjustments	Yes
shutter_a_sync_mode	Cinamate	Keep exposure constant when changing FPS	Yes
fps	Cinamate → CinePi-raw	Target frames per second	Yes
sensor_mode	Cinamate → CinePi-raw startup	Active sensor resolution/mode	Yes (causes pipeline restart)
wb	Cinamate → CinePi-raw	White-balance temperature (Kelvin)	Yes
zoom	Cinamate	Digital zoom for preview streams	Yes

Key	Written by	Description	Safe to change manually?
ir_filter	Cinamate → CinePi-raw	Toggle IR-cut filter (IMX 5 8 5 only)	Yes
rec / is_recording	Cinamate → CinePi-raw	Start/stop recording when toggled	Yes (edge-triggered)
bit_depth	Cinamate → CinePi-raw startup	Sensor bit depth (1 0 or 1 2)	No (set at startup)
height / width	Cinamate → CinePi-raw startup	Active sensor resolution	No
lores_width / lores_height	CinePi-raw startup	Preview stream resolution	No
cg_rb	Cinamate → CinePi-raw	White-balance gain pair " 1 /R, 1 /B"	Yes (advanced)
fps_user	Cinamate	Temporary storage for the UI slider	No
fps_last	Cinamate	Previous stable fps from stats	No
fps_actual	CinePi-raw → Cinamate	Measured FPS from pipeline	No
framecount	CinePi-raw → Cinamate	Total frames recorded	No

Key	Written by	Description	Safe to change manually?
buffer	CinePi-raw → Cinamate	Raw frames currently in RAM	No
buffer_size	CinePi-raw → Cinamate	Size of RAM buffer in frames	No
is_buffering	CinePi-raw → Cinamate	1 while buffer pre-fills	No
is_writing	CinePi-raw → Cinamate	1 while frames are flushing to disk	No
is_writing_buf	Cinamate	Internal countdown after recording stops	No
is_mounted	Cinamate (SSD monitor)	1 when storage is mounted	No
storage_type	Cinamate (SSD monitor)	Drive type (NVME/USB/SD)	No
space_left	Cinamate (SSD monitor)	Remaining space in GB	No
write_speed_to_drive	Cinamate (SSD monitor)	Current write speed MB/s	No
file_size	Cinamate	Bytes per frame for current mode	No

Key	Written by	Description	Safe to change manually?
last_dng_cam 0 / 1	CinePi-raw → Cinematé	Path to last written DNG frame	No
recording_time	Cinematé	HH:MM:SS:FF timer while recording	No
memory_alert	Cinematé	1 if RAM usage high	No
cam_init	CinePi-raw	Internal flag during startup	No
cameras	CinePi-raw	JSON list of detected cameras	No
gui_layout	Cinematé	Path to GUI layout preset	No
pi_model	Cinematé	Raspberry Pi model string	No
sensor	CinePi-raw	Active camera model	No
tc_cam 0 /tc_cam 1	CinePi-raw → Cinematé	SMPTE time code per camera	No
shutter_angle_actual	Cinematé	Calculated shutter angle applied after clamping or sync	No
shutter_angle_transient	Cinematé	Temporary value during ramping	No

Key	Written by	Description	Safe to change manually?
exposure_time	Cinematé	Current exposure time in seconds	No
wb_user	Cinematé	Kelvin value set before converting to cg_rb	No

6.3 Hardware overview

CineMate image file comes pre-installed with: - StarlightEye - CFE Hat - Grove Base HAT

7. Cinematé builds

TBA

8. Development & contributing

8.1 Installation

Here is how you can manually install libcamera, cinepi-raw, cinamate and accompanying software on the Raspberry Pi.

Although Raspberry Pi 4 (and even 3) has been known to work with the stack below, a Raspberrry Pi 5 B or Compute Module 5 is recommended. Also note that for high speed USB 3, a Raspberry Pi 4 or 5 is needed.

This guide assumes fresh Raspbery Pi Bookworm installation running kernel 6.1.2.20+.

If you run Raspberry Pi OS Lite, begin by installing the following packages:

8.1.1 Install script

```
sudo apt install -y python-pip git python3-jinja2
```

This installer script combines the below install processes of CinePi-Raw and Cinamate.

```
wget -O cinamate-stack-installer.sh https://raw.githubusercontent.com/Tiramisioux/cinamate/cinamate-3.1/cinamate-stack-installer.sh
chmod +x cinamate-stack-installer.sh
sudo bash cinamate-stack-installer.sh
```

Start the script by type:

```
./cinamate-stack-installer.sh
```

Watch it work by opening up another ssh window and typing:

```
sudo journalctl -fu cinamate-installer.service
```

8.1.2 Manual install

libcamera 1.7.0

```
git clone https://github.com/raspberrypi/libcamera && \  
sudo find ~/libcamera -type f \( -name '*.py' -o -name '*.sh' \) -  
exec chmod +x {} \; && \  
cd libcamera && \  
sudo meson setup build --buildtype=release \  
-Dpipelines=rpi/vc4,rpi/pisp \  
-Dipas=rpi/vc4,rpi/pisp \  
-Dv4l2=true \  
-Dgstreamer=enabled \  
-Dtest=false \  
-Dlc-compliance=disabled \  
-Dcam=disabled \  
-Dqcam=disabled \  
-Ddocumentation=disabled \  
-Dpycamera=enabled && \  
sudo ninja -C build install && \  
cd
```

```
cd ~/libcamera/utils && sudo chmod +x *.py *.sh && sudo chmod +x ~/libcamera/src/ipa/ipa-sign.sh && cd ~/libcamera && sudo ninja -C build install
```

```
sudo apt-get install --reinstall libtiff5-dev && sudo ln -sf $(find /usr/lib -name "libtiff.so" | head -n 1) /usr/lib/aarch64-linux-gnu/libtiff.so.5 && export LD_LIBRARY_PATH=/usr/lib/aarch64-linux-gnu:$LD_LIBRARY_PATH && sudo ldconfig
```

```
sudo apt install -y python3-pip git python3-jinja2 libboost-dev libgnutls28-dev openssl pybind11-dev qtbase5-dev libqt5core5a meson cmake python3-yaml python3-ply libglib2.0-dev libgstreamer-plugins-base1.0-dev libgstreamer1.0-dev libavdevice59
```

cpp-mjpeg-streamer cinamate fork

```
sudo apt install -y libspdlog-dev libjsoncpp-dev
cd /home/pi
git clone https://github.com/Tiramisioux/cpp-mjpeg-streamer.git --
branch cinamate
cd cpp-mjpeg-streamer && mkdir build && cd build
cmake .. && make
make install-here
```

Cinamate uses a custom fork of cpp-mjpeg-streamer. If you plan to use only cinepi-raw, you can use the original app found at <https://github.com/nadjieb/cpp-mjpeg-streamer>

CinePi-raw cinamate fork

```
sudo apt install -y cmake libepoxy-dev libavdevice-dev build-essential
cmake libboost-program-options-dev libdrm-dev libexif-dev libcamera-
dev libjpeg-dev libtiff5-dev libpng-dev redis-server libhiredis-dev
libasound2-dev libjsoncpp-dev libpng-dev meson ninja-build libavcodec-
dev libavdevice-dev libavformat-dev libswresample-dev && sudo apt-get
install libjsoncpp-dev && cd ~ && git clone https://github.com/
sewenew/redis-plus-plus.git && cd redis-plus-plus && mkdir build && cd
build && cmake .. && make && sudo make install && cd ~
```

```
git clone https://github.com/Tiramisioux/cinepi-raw.git --branch
rpicam-apps_1.7_custom_encoder
cd /home/pi/cinepi-raw
sudo rm -rf build (if you have a previous build)
export PKG_CONFIG_PATH=/home/pi/cpp-mjpeg-streamer/build:$PKG_CONFIG_P
ATH
sudo meson setup build
sudo ninja -C build
sudo meson install -C build
```

Cinamate depends on a custom branch of cinepi-raw created by Csaba Nagy. If you plan to use the original version you can find it adapted for rpicam-apps

0 . 7 here: https://github.com/Tiramisioux/cinepi-raw/tree/rpicam-apps_1.7

imx585 driver cinamate fork

```
sudo apt install linux-headers dkms git
```

```
git clone https://github.com/Tiramisioux/imx585-v4l2-driver.git
cd imx585-v4l2-driver/
./setup.sh
```

The imx 5 8 5 is written by Will Whang. For original drivers and startup guides, visit <https://github.com/will127534/StarlightEye>

imx283 driver cinamate fork

```
sudo apt install linux-headers dkms git
```

```
git clone https://github.com/Tiramisioux/imx283-v4l2-driver.git
cd imx283-v4l2-driver/
./setup.sh
```

The imx 2 8 3 is written by Will Whang. For original drivers and startup guides, visit <https://github.com/will127534/imx283-v4l2-driver>

Enabling I²C

```
sudo apt update && apt upgrade
sudo raspi-config nonint do_i2c 0
```

Enabling I²C is needed for using the camera modules.

Setting hostname

```
sudo hostnamectl set-hostname cinepi
```

You will find the pi as `cinepi.local` on the local network, or at the hotspot Cinamate creates

Add camera modules to config.txt

```
sudo nano /boot/firmware/config.txt
```

Paste this into your file, and uncomment the sensor you are using.

Also specify which physical camera port you have connected your sensor to.

```
# Raspberry Pi HQ camera
#camera_auto_detect=1
#dtoverlay=imx477,cam0

# Raspberry Pi GS camera
#camera_auto_detect=1
#dtoverlay=imx296,cam0

# OneInchEye
#camera_auto_detect=0
#dtoverlay=imx283,cam0

# StarlightEye
camera_auto_detect=0
dtoverlay=imx585,cam0

# StarlightEye Mono
camera_auto_detect=0
#dtoverlay=imx585,cam1,mono

# CFE Hat (pi 5 only)
dtparam=pciex1
dtparam=pciex1_gen=3

dtoverlay=disable-bt
```

And at the very bottom of the file:

```
[all]
avoid_warnings=1
disable_splash=1
```

Add the IMX585 tuning file (optional)

```
curl -L -o /home/pi/libcamera/src/ipa/rpi/pisp/data/imx585.json \  
  https://raw.githubusercontent.com/will127534/libcamera/master/src/  
ipa/rpi/pisp/data/imx585.json  
sed -i '8s/"black_level": *[0-9]\+/"black_level": 0/' /home/pi/  
libcamera/src/ipa/rpi/pisp/data/imx585.json  
# cp /home/pi/libcamera/src/ipa/rpi/pisp/data/imx585.json /usr/local/  
share/libcamera/ipa/rpi/pisp/
```

For the mono sensor use `imx585_mono.json` instead.

IR filter switch script (optional)

```
wget https://raw.githubusercontent.com/will127534/StarlightEye/master/  
software/IRFilter -O /usr/local/bin/IRFilter  
sudo chmod +x /usr/local/bin/IRFilter
```

Cinamate has its own way of handling the IR switch but the installation above can be convenient for use outside of Cinamate

Change the console font (optional)

```
sudi apt update  
sudo apt install console-setup kbd  
sudo dpkg-reconfigure console-setup # choose Terminus / 16x32
```

Verify `/etc/default/console-setup` contains:

```
FONTFACE="Terminus"  
FONTSIZE="16x32"
```

Then enable the service:

```
sudo systemctl enable console-setup.service  
sudo systemctl start console-setup.service
```

This can be useful if running the Pi on a small HD field monitor

Create post-processing configs

Paste this into the terminal and hit enter:

```
sudo bash -c 'cat > post-processing.json << EOF
{
  "sharedContext": {},
  "mjpegPreview": {
    "port": 8000
  }
}
EOF' && \
sudo chmod +x post-processing.json && \
sudo bash -c 'cat > post-processing0.json << EOF
{
  "sharedContext": {},
  "mjpegPreview": {
    "port": 8000
  }
}
EOF' && \
sudo chmod +x post-processing0.json && \
sudo bash -c 'cat > post-processing1.json << EOF
{
  "sharedContext": {},
  "mjpegPreview": {
    "port": 8001
  }
}
EOF' && \
sudo chmod +x post-processing1.json
```

Install PiShrink

```
wget https://raw.githubusercontent.com/Drewsif/PiShrink/master/
pishrink.sh
sudo install -m755 pishrink.sh /usr/local/bin/pishrink
```

PiShrink is a great tool for compressing SD image file backups of the SD card.
See [here](#) for instructions

Reboot before installing Cinamate:

```
reboot
```

You should now have a working install of cinepi-raw. To try it out, see this section.

8.1.3 Cinamate

Create a Python virtual environment

```
sudo apt update && apt install -y python3-venv
python3 -m venv /home/pi/.cinamate-env
echo "source /home/pi/.cinamate-env/bin/activate" >> ~/.bashrc
source /home/pi/.cinamate-env/bin/activate
```

Grant sudo privileges and enable I²C

```
echo "pi ALL=(ALL) NOPASSWD: /home/pi/.cinamate-env/bin/*" | sudo
tee /etc/sudoers.d/cinamate-env
sudo chown -R pi:pi /home/pi/.cinamate-env
sudo chown -R pi:pi /media && chmod 755 /media
sudo usermod -aG i2c pi
sudo modprobe i2c-dev && echo i2c-dev | sudo tee -a /etc/modules
echo "pi ALL=(ALL) NOPASSWD: /home/pi/run_cinamate.sh" | sudo tee -a /
etc/sudoers.d/pi_cinamate
```

Reboot so the group changes take effect:

```
reboot
```

Dependencies

```
source /home/pi/.cinamate-env/bin/activate
python3 -m pip install --upgrade pip setuptools wheel
sudo apt-get install -y i2c-tools portaudio19-dev build-essential python3-dev python3-pip python3-smbus python3-serial git
pip3 install adafruit-circuitpython-ssd1306 watchdog psutil Pillow redis keyboard pyudev sounddevice smbus2 gpiozero RPi.GPIO evdev termcolor pyserial inotify_simple numpy rpi_hardware_pwm
pip3 uninstall -y Pillow && pip3 install Pillow
pip3 install sugarpie flask_socketio board adafruit-blinka adafruit-circuitpython-seesaw luma.oled grove.py pigpio-encoder gpiod
sudo apt install python3-systemd e2fsprogs ntfs-3g exfatprogs console-terminus
```

Replace RPi.GPIO with lgpio

```
sudo apt install -y swig python3-dev build-essential git
git clone https://github.com/joan2937/lg
cd lg && make
sudo make install
cd .. && pip install lgpio
```

Clone the Cinamate repo

```
git clone https://github.com/Tiramisioux/cinamate.git
```

Allow Cinamate to run with sudo

Edit the sudoers file:

```
sudo visudo
```

add this to the end of the file:

```
pi ALL=(ALL) NOPASSWD: /home/pi/cinamate/src/main.py
pi ALL=(ALL) NOPASSWD: /bin/mount, /bin/umount, /usr/bin/ntfs-3g
pi ALL=(ALL) NOPASSWD: /home/pi/cinamate/src/logs/system.log
pi ALL=(ALL) NOPASSWD: /sbin/mount.ext4
```

Enable NetworkManager

```
sudo systemctl enable NetworkManager --now
```

Rotate logs

Paste this into the terminal and hit enter:

```
# tee /etc/logrotate.d/general_logs <<'EOP'
/var/log/*.log {
    size 100M
    rotate 5
    compress
    missingok
    notifempty
}
EOP
```

Seed Redis with default keys

```
redis-cli <<'EOF'
SET anamorphic_factor 1.0
PUBLISH cp_controls anamorphic_factor
SET bit_depth 12
PUBLISH cp_controls bit_depth
...
EOF
```

(See the settings guide for the full list.)

Add a convenience alias

Append to `~/.bashrc`:

```
alias cinamate='python3 /home/pi/Cinamate/src/main.py'
```

Then, inside `cinamate` folder:

```
make install
```

Cinamate services

Cinamate with two small helper services under `services/`:

storage-automount

Mounts and unmounts removable drives such as SSDs, NVMe enclosures and the CFE HAT. Partitions named `RAW` are attached at `/media/RAW`; all others are mounted under `/media/<LABEL>`.

wifi-hotspot

keeps a simple Wi-Fi hotspot running via NetworkManager so you can reach the web UI even without other networking. The SSID and password come from the `system.wifi_hotspot` section of `settings.json`.

Install and enable both services with:

```
cd /home/pi/cinamate/services

sudo make install
sudo make enable
```

Starting Cinamate

If you are not using the service file for autostart, anywhere in the terminal, type:

```
cinamate
```

Make sure things are running smoothly and then move on to enabling the cinamate-autostart service:

cinamate-autostart.service

```
cd /home/pi/cinamate/

sudo make install    # copy service file
sudo make enable     # start on boot
make start           # launch now
```

After enabling the service, Cinamate should autostart on boot.

8.1.4 Todo

- simple_gui.py adaptive layout for non 1920x1080 screens
- 16 bit modes for imx585
- support for imx294
- overclocking of ISP
- optional auto-exposure
- hardware sync of sensor frame capture, perhaps via a pico
- rendering mode, for creating proxy files in camera (using https://github.com/mrjulesfletcher/dng_to_video)
- automatic detection of attached sensor and dynamic dtoverlay

