



8-bit **AVR**<sup>®</sup>  
Microcontrollers

## Application Note

# AVR282: USB Firmware Upgrade for AT90USB

## Features

- Supported by Atmel FLIP program on all Microsoft<sup>®</sup> O/S from Windows<sup>®</sup> 98SE and later
- FLIP 3.2.1 or greater supports Linux
- Default on chip USB bootloader
- In-System programming through the USB interface/No external hardware needed
- Up to 32Kbytes/s

## 1. Introduction

The aim of this document is to describe how to perform the firmware upgrade of the AT90USB products using the on-chip bootloader and FLIP software.


## 2. Description

The AT90USB products are delivered with an on-chip bootloader. This bootloader allows the user to program the FLASH/EEPROM memories through the USB interface.

To perform firmware upgrade, Atmel has developed an application called “**FLIP**”. This software is a flexible application which lets you program and configure Atmel's microcontroller devices in their final environment without needing any dedicated hardware.

The latest release of FLIP offers the following capabilities:

- Perform In-System Programming through RS232, **USB** or CAN interfaces.
- May be used through its intuitive Graphical User Interface or launched from a DOS window, from an embedded software IDE (AVR Studio), or even from your own application
- Buffer editing capabilities: fill, search, copy, reset, modify, goto address.
- Target device memory control: erase, blank check, program, verify, read, security level and special bytes reading and setting.
- Parts serialization capability (from *batchisp* only).
- ISP hardware conditions may be set by software.



Rev. 7769A-AVR-01/08



### 3. Hardware Requirements

1. AVR USB evaluation board (ATSTK525/STK526, AT90USBKey or any kit for the AT90USB family)
2. AT90USB microcontroller
3. USB cable (Standard A to Mini B)
4. PC running on Windows (98SE, ME, 2000, XP) with USB support.


### 4. Software Requirement

The software needed for this application include:

- FLIP software (Device Firmware Upgrade tool) **version 3.2.0 or above.**

### 5. Bootloader Process

Figure 5-1. Bootloader Process



As shown in the above figure, the AT90USB products have a new fuse bit (Comparing to a standard AVR device). This fuse bit is the HWBE, it is enabled by default. Adding to this new fuse bit, the AT90USB products have a new pin: the HWB. This pin should be active low under RESET to launch the bootloader.

To allow the user to perform the bootloader function, all AT90USB kits have two buttons: RST to active the reset and the HWB to active the HWB pin.

## 6. Device Firmware Upgrade

The “Flip” software is the tool used to upgrade the firmware (available freely in the USB CD-ROM or Atmel website).


The following steps should be completed to allow the device starting DFU mode (bootloader), and program the FLASH or the EEPROM memory:

1. Install Flip software (Flip version 3.0 or above is required).
2. Connect the AT90USB board (STK525, AT90USBKey...) to the PC using the USB cable (Standard A to Mini B).
3. Push the HWB (Hardware Bootloader) button
4. Push the RST (Reset) button
5. Release the RST button
6. Release the HWB button
7. If your hardware conditions explained above are correct, a new device detection wizard will be displayed. Please follow the instructions (the INF file is located in the USB subdirectory from Flip installation: “install path:\ATMEL\FLIP\FLIPx.x.x\usb”). The new device detection wizard may not appear if the suitable hardware is already installed, you can jump to step 8.


**Figure 6-1.** New Device Detection Wizard



**Figure 6-2.** Driver Location




**Figure 6-3.** Driver selection



8. Check the Device Manager Figure 6-4. and you should see the same icon (Atmel DFU icon) as shown in the figure below. If not, repeat step 2.


**Figure 6-4.** Device Manager




Once your device is in DFU mode, launch the Flip software and follow the instructions explained below, Figure 6-5.

1. Select AT90USB device

**Figure 6-5.** Device Selection




2. Select USB as communication mode
  - a. USB Communication Mode



3. Open the communication


**Figure 6-6.** Open the USB Communication






4. Choose the HEX file to load:

**Figure 6-7.** HEX File to Load




5. Load the HEX file (*Check Erase, Blank Check, Program and Verify, then Push Run button*)

**Figure 6-8.** HEX File Loading



6. Start the application

**Figure 6-9.** Start Application



**Note:** The AT90USB bootloader will detach and jump into the user application when “Start Application” button is pressed.

## 7. FAQs

1. After programming my device using the JTAGICE MKII or the AVRISP, I cannot start the bootloader anymore?
  - When you use the JTAGICE MKII or AVRISP, the first instruction performed is the full chip erase. This instruction erases the whole of the flash memory and deletes the bootloader. You have to load the bootloader HEX file again using the JTAGICE MKII or the AVRISP to be able to use flip software to program the device.
2. I have a Flip 2.4.x/3.0.x version on my computer. I installed Flip 3.1.y, When I start the bootloader, I cannot see the Amel DFU icon in my device manager window as shown in the figure 6.4, I still have the Jungo icon?
  - Flip 2.4.x and Flip 3.1.y are not using the same USB driver. You have to update the driver used for the bootloader:
    - Open the device manager
    - Right-click on the AT90USB Jungo icon
    - Select Update Driver
    - Continue as described in the section 6 (Device Firmware Upgrade)
3. Can I modify the fuse bits using Flip?
  - No, Flip cannot modify the fuse bits. To modify the fuse bit you can use either the JTAG ICE MKII, the AVRISP MKII, or parallel programming.
4. What is the difference between starting the application with the Reset box checked off or not?
  - If you start the application with the Reset box checked off, the device will start after a Watchdog reset and this watchdog will remain active. You need to disable the Watchdog in your application. Resetting the device, ensures there is no side effect from resources used by the boot-loader before starting the user application.

## 8. Related Documents

- USB DFU Bootloader Datasheet (doc 7618)
- Help content of Flip



## Headquarters

---

**Atmel Corporation**  
2325 Orchard Parkway  
San Jose, CA 95131  
USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 487-2600

## International

---

**Atmel Asia**  
Room 1219  
Chinachem Golden Plaza  
77 Mody Road Tsimshatsui  
East Kowloon  
Hong Kong  
Tel: (852) 2721-9778  
Fax: (852) 2722-1369

**Atmel Europe**  
Le Krebs  
8, Rue Jean-Pierre Timbaud  
BP 309  
78054 Saint-Quentin-en-  
Yvelines Cedex  
France  
Tel: (33) 1-30-60-70-00  
Fax: (33) 1-30-60-71-11

**Atmel Japan**  
9F, Tonetsu Shinkawa Bldg.  
1-24-8 Shinkawa  
Chuo-ku, Tokyo 104-0033  
Japan  
Tel: (81) 3-3523-3551  
Fax: (81) 3-3523-7581

## Product Contact

---

**Web Site**  
[www.atmel.com](http://www.atmel.com)

**Technical Support**  
Enter Product Line E-mail

**Sales Contact**  
[www.atmel.com/contacts](http://www.atmel.com/contacts)

**Literature Requests**  
[www.atmel.com/literature](http://www.atmel.com/literature)

---

**Disclaimer:** The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. **EXCEPT AS SET FORTH IN ATMEL'S TERMS AND CONDITIONS OF SALE LOCATED ON ATMEL'S WEB SITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.** Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel's products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

© 2008 Atmel Corporation. All rights reserved. Atmel®, logo and combinations thereof, and others are registered trademarks or trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be trademarks of others.