

Interpreter) Press Key B and the screen will clear. Start the tape. When the program has been entered, control is automatically given back to DISASSEMBLER-7, and your program will appear on the screen. (Don't forget to stop the tape.)

At this point you have several options:

- 1) Page forward -- Pressing Key C will cause the program to be displayed from the address immediately following the previously displayed last address on screen. Paging past the third page of your program will cause a wrap-around to the beginning.
- 2) Enter Show From Address -- Press Key D, then the address you wish to show from. The selected function ("SHOW FROM") and the address are displayed on the screen. If you enter an address out of range of the 3 pages in your program, an "ERROR-RETRY" message is displayed and the program is redisplayed. (Try entering FFFF to examine this feature.)

If when viewing the very last page of your program, you enter a new show from address that is not in range, the program will start from a faulty location displaying only a single address on screen (0300 if your program began at 0000.) This can easily be rectified by simply entering a correct show from address (Key D, then the address.)