

end of a page. You do not have to press the CONTROL key down to use any of the specially-marked keys. To execute LINE FEED for example, simply touch that key.

In order to select the second bank of functions, the Escape Functions, you only have to press the ESCAPE key on the keyboard. A tone will be heard (from the VIP speaker) indicating that the next keypress will select one of the Escape Functions. If you are using Modification #1, the next keypress after the tone is heard must be on the VIP hexpad. The same numbers are used for these functions (Tape Read, Cursor On/Off, etc.) as described in the instructions to Text Editor 21. (See the second half of the function list beginning with (C)-0 to (C)-F.)

The ESCAPE key on the keyboard simply replaces what Key C used to do on the hexpad. To return control to the keyboard without performing a function, press the hexpad's Key 0. Return to the keyboard is automatic after any function has been performed so you may easily continue typing.

To summarize the operation of Modification #1:

- 1) Hold the CONTROL key down while pressing the indicated key for all One Key type functions.