

CONFIDENTIAL

Ethernet AVB Software Start-Up Guide

User's Manual: Software

R-Car H3/M3/M3N/E3/D3 Series

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan

www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/.

CONFIDENTIAL

Trademark

- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Arm is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.
- Windows and Windows Media are registered trademarks of Microsoft Corporation in the United States and other countries.
- Other company names and product names mentioned herein are registered trademarks or trademarks of their respective owners.
- Registered trademark and trademark symbols (® and ™) are omitted in this document

How to Use This Manual

- **[Readers]**

This manual is intended for engineers who develop products which use the R-Car H3/M3/M3N/E3 processor.

- **[Purpose]**

This manual is intended to give users an understanding of the functions of the R-Car H3/M3/M3N/E3 processor device driver and to serve as a reference for developing hardware and software for systems that use this driver.

- **[How to Read This Manual]**

It is assumed that the readers of this manual have general knowledge in the fields of electrical

— engineering, logic circuits, microcontrollers, and Linux.

→ Read this manual in the order of the CONTENTS.

— To understand the functions of a multimedia processor for R-Car H3/M3/M3N/E3

→ See the R-Car H3/M3/M3N/E3 User's Manual.

— To know the electrical specifications of the multimedia processor for R-Car H3/M3/M3N/E3

→ See the R-Car H3/M3/M3N/E3 Data Sheet.

- **[Conventions]**

The following symbols are used in this manual.

Data significance: Higher digits on the left and lower digits on the right

Note: Footnote for item marked with Note in the text

Caution: Information requiring particular attention

Remark: Supplementary information

Numeric representation: Binary ... 0bxxxx, or xxxxB

Decimal ... xxxx

Hexadecimal ... 0xxxxx or xxxxH

Data type: Double word ... 64 bits

Word ... 32 bits

Half word ... 16 bits

Byte ... 8 bits

CONFIDENTIAL

Table of Contents

1. Overview	1
1.1 Overview.....	1
1.2 Composition of this Ethernet AVB Software.....	1
1.3 Hardware environment.....	2
1.4 Reference	3
2. Environmental requirement	4
2.1 Software relationship	4
2.2 Build process.....	5
3. Build the kernel and rootfs.....	6
4. Demo Applications	7
4.1 Preparation before execution	8
4.2 How to execute the application	9
4.2.1 How to execute Simple application with Launcher application	9
4.2.2 How to send PCM audio data using MSE with Launcher application	10
4.2.3 How to send H.264 video data using MSE with Launcher application	11
4.2.4 How to send MJPEG data using MSE with Launcher application	12
4.2.5 How to send MPEG2TS data using MSE with Launcher application	13
5. Notice	14
6. Appendix	15
6.1 How to start Linux using a USB Ethernet adapter	15
6.2 Recommended connection with MOTU AVB Switch	17
6.3 About the setup of Summit X430/X440.....	18

CONFIDENTIAL

LIST OF FIGURES

Figure 1.1 Recommended Environment 2

Figure 2.1 Software relationship 4

Figure 2.2 Build process 5

Figure 4.1 Simple application schematic diagram 7

Figure 4.2 Launcher application schematic diagram 7

Figure 6.1 Recommended connection with MOTU AVB Switch 17

LIST OF TABLES

Table 1.1 Hardware environment (R-Car H3/M3/M3N/E3/D3) 2

Table 1.2 Reference..... 3

Table 4.1 List of demo applications..... 7

1. Overview

1.1 Overview

This document explains Ethernet AVB Software, applications and installation for the R-Car H3/M3/M3N/E3/D3 System Evaluation Board which R-Car H3/M3/M3N/E3/D3 Yocto recipe is installed. Please read this document before using this Ethernet AVB Software.

Please contact Renesas Electronics person who provided this Ethernet AVB Software to you in case of questions. Please use always latest version about U-Boot, MMP and Linux Kernel.

1.2 Composition of this Ethernet AVB Software

The following shows the composition of this Ethernet AVB Software.

- Documents
- AVB Streaming driver
- AVB Media Streaming Engine
- AVB Media Clock Recovery Handler
- Application
- Renesas Yocto Recipe (include in meta-renesas)

1.3 Hardware environment

The following table lists the hardware needed to use this module.

Table 1.1 Hardware environment (R-Car H3/M3/M3N/E3/D3)

Name	Manufacture
R-Car H3-SiP System Evaluation Board Salvator-X	Renesas Electronics
R-Car M3-SiP System Evaluation Board Salvator-X	Renesas Electronics
R-Car H3-SiP/M3-SiP/M3N-SiP System Evaluation Board Salvator-XS	Renesas Electronics
R-Car E3 System Evaluation Board Ebisu-4D	Renesas Electronics
R-CarD3 System Evaluation Board Draak	Renesas Electronics
MOTU AVB Switch	MOTU
Summit X430/X440	Extreme Networks
Linux Host PC	-
Windows Host PC	-
Ethernet cable	-
USB cable (type A to micro B)	-




Figure 1.1 Recommended Environment

Note) In the case of Figure 1.1, AVB and Non AVB traffic are in the same network. If you want to separate each traffic, please refer to the Chapter 6.1.

Note) When using MOTU AVB Switch, we recommend updating to the latest version of FW. Please refer to the web site (<http://motu.com/avb>) about the firmware updating.

When using MOTU AVB switch, should be enable SRP and gPTP protocols. Because MOTU AVB Switch discard

the AVTP streaming traffic if not using these protocols.

Also notice the role of each port. For details, see Chapter 6.2.

Note) When using Summit X430/X440, we recommend updating to the latest version of FW. Please refer to the web site (https://gtacknowledge.extremenetworks.com/articles/How_To/How-to-Obtain-and-Upgrade-EXOS) about the firmware updating.

Also the switch needs several setting. For details, see Chapter 6.3.

1.4 Reference

Table 1.2 Reference

document name	version
Linux Interface Specification Yocto recipe Start-Up Guide User's Manual: Software	Rev 5.9.0
Ethernet AVB Software Simple Application Application Note	Rev.2.30
Ethernet AVB Software Launcher Application Application Note	Rev.2.30
Ethernet AVB Software Media Streaming Engine User's Manual: Software	Rev.2.30
Linux Interface Specification U-Boot User's Manual: Software	Rev.2.55

2. Environmental requirement

2.1 Software relationship

Figure 2.1 shows the software relationship of this Ethernet AVB Software and others.




Figure 2.1 Software relationship

2.2 Build process

Figure 2.2 shows the build flow from setup to execution of application. Please perform the setup of Linux BSP and MMP with reference to "Linux Interface Specification Yocto recipe Start-Up Guide". This document treats a region which is covered by a dot-line. To setup Ethernet AVB, please change build procedure to the R-Car H3/M3/M3N/E3/D3 Yocto environment.




Figure 2.2 Build process

3. Build the kernel and rootfs

Step 1 Execute source command

Please execute source command with oe-init-build-env for setting environment.

```
# cd $WORK
# source poky/oe-init-build-env
```

Step 2 Enable "avb" distro feature in configuration file

Modify local configuration (\$WORK/build/conf/local.conf) like a following.

```
...
# AVB Software Package for Linux
DISTRO_FEATURES_append = " avb"
... .
```

Step 3 Building with bitbake

Please build as follows. The root file system images and kernel image are created in \$WORK/build/tmp/deploy/images/<supported board name>/ directory.

```
# cd $WORK/build
# bitbake core-image-weston
```

Step 4 Install the file system

Please extract file system on your Root file system.

```
# tar xf $WORK/build/tmp/deploy/images/<supported board name>/core-image-weston-<supported board name>.tar.bz2 -C /export/rfs/
```

4. Demo Applications

This software includes some application software. The list of application and the outline of the function are shown Table 4.1. For details, please refer to the application note. Please see Table 1.2.

Table 4.1 List of demo applications

NO.	Application	Name	Outline
1	simple	simple_talker	Ethernet frames are created from the file specified by user. And transmits Ethernet frames by Ethernet AVB driver.
2	simple	simple_listener	Receives Ethernet frames. And payload data are save at the file.
3	launcher	avblauncher	Provides functions to work together the application for protocol processing and streaming processing.
4	mrpdummy	mrpdummy	Application for bandwidth reservation.




Figure 4.1 Simple application schematic diagram




Figure 4.2 Launcher application schematic diagram

4.1 Preparation before execution

Step 1 Prepare U-Boot environment variables

Please start U-Boot by board reset, please set environment variables as follows.

```
=> setenv ethaddr XX:XX:XX:XX:XX:XX
=> setenv ipaddr 192.168.0.20
=> setenv serverip 192.168.0.1
=> setenv bootcmd 'tftp 48080000 Image; tftp 48000000 Image-r8a7795-salvator-x.dtb; booti 48080000 - 48000000'
```

Note) All devices in local area network should be configured that it has a completely different MAC address.

Note) About dtb file in bootcmd is an example for R-Car H3 Ver.2.0. That is should be configured for your device and board.

Step 2 change the bootargs by U-Boot

To change bootargs which passed to the kernel in boot sequence, please modify it as follows.

```
=> setenv bootargs 'consoleblank=0 ip=${ipaddr}:${serverip}:::eth0 root=/dev/nfs rw nfsroot=/export/rfs'
```

Step 3 Start Linux

Please execute the following commands manually, without reset.

```
=> run bootcmd
```

4.2 How to execute the application

This chapter shows an example about how to perform application. Please connect target board, Windows Host PC with terminal software for console. Then please confirm normal starting of U-Boot and Linux. After booting, please run as these.

4.2.1 How to execute Simple application with Launcher application

Launcher application (avblauncher) provides functions to work together the application for protocol processing and streaming processing. In this chapter, introduce an example. For more information, please refer to application note of Launcher application.

Step 1 Load AVB kernel modules


```
# modprobe -a ravb-streaming
```

Step 2 Edit the Configuration file (For Listener)

Please change StreamID according to your environment.

Edit /etc/avblauncher/simple_listener.ini

```
; Stream ID for Listener (xx:xx:xx:xx:xx:xx:xx:xx)
STREAM_ID = 76:90:50:00:00:00:00:01
```



Step 3 Execute the application

Step 3.1 Execute application (For Listener)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/simple_listener.ini
```

Step 3.2 Execute application (For Talker)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/simple_talker.ini
```

4.2.2 How to send PCM audio data using MSE with Launcher application

This chapter described how to transport the Wave PCM file via the Ethernet AVB network.

For more information, please refer to user's manual of Media Streaming Engine.

In this chapter, it shows the case of the AAF_PCM format. If you want to use the IEC61883-6 format, please replace the INI file ("/etc/avblauncher/mse_iec61883_6_listener.ini" and "/etc/avblauncher/mse_iec61883_6_talker.ini").

Step 1 Load AVB kernel modules

```
# modprobe -a ravb-streaming mch_core mse_core mse_adapter_eavb mse_adapter_alsa mse_adapter_v4l2
mse_adapter_mch
```

Step 2 Edit the Configuration file (For Listener)

Please change StreamID according to your environment.

Edit /etc/avblauncher/mse_aaf_pcm_listener.ini

```
; Stream ID for Listener (xx:xx:xx:xx:xx:xx:xx:xx)
STREAM_ID = 76:90:50:00:00:00:00:01
```

Hardware address
of the Talker
 Unique ID
of the stream

Step 3 Execute the application

Step 3.1 Execute application (For Listener)

```
# amixer sset 'DVC Out' 1%
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_aaf_pcm_listener.ini
```

Step 3.2 Execute application (For Talker)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_aaf_pcm_talker.ini
```


4.2.3 How to send H.264 video data using MSE with Launcher application

This chapter described how to transport the H.264 video data via the Ethernet AVB network.

For more information, please refer to user's manual of Media Streaming Engine.

If you want to use the format of the CVP H.264 Draft13, please replace the INI file

("etc/avblauncher/mse_cvf_h264_d13_listener.ini" and "etc/avblauncher/mse_cvf_h264_d13_talker.ini").

Step 1 Load MMP kernel modules

```
# modprobe -a mmngr mmngrbuf vspm vspm_if vsp2 uvcs_drv
```

Step 2 Load AVB kernel modules

```
# modprobe -a ravb-streaming mch_core mse_core mse_adapter_eavb mse_adapter_alsa mse_adapter_v4l2
mse_adapter_mch
```

Step 3 Edit the Configuration file (For Listener)

Please change StreamID according to your environment.

Edit /etc/avblauncher/mse_cvf_h264_listener.ini

```
; Stream ID for Listener (xx:xx:xx:xx:xx:xx:xx:xx)
STREAM_ID = 76:90:50:00:00:00:00:01
```

Hardware address
of the Talker
 Unique ID
of the stream

Step 4 Execute the application

Step 4.1 Execute application (For Listener)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_cvf_h264_listener.ini
```

Step 4.2 Execute application (For Talker)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_cvf_h264_talker.ini
```

4.2.4 How to send MJPEG data using MSE with Launcher application

This chapter described how to transport the MJPEG data via the Ethernet AVB network. For more information, please refer to user's manual of Media Streaming Engine.

Step 1 Load MMP kernel modules

```
# modprobe -a mmngr mmngrbuf vspn vspn_if vsp2 uvcs_drv
```

Step 2 Load AVB kernel modules

```
# modprobe -a ravb-streaming mch_core mse_core mse_adapter_eavb mse_adapter_alsa mse_adapter_v4l2
mse_adapter_mch
```

Step 3 Edit the Configuration file (For Listener)

Please change StreamID according to your environment.

Edit /etc/avblauncher/mse_cvf_mjpeg_listener.ini

```
; Stream ID for Listener (xx:xx:xx:xx:xx:xx:xx:xx)
STREAM_ID = 76:90:50:00:00:00:00:01
```

Hardware address of the Talker Unique ID of the stream

Step 4 Execute the application

Step 4.1 Execute application (For Listener)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_cvf_mjpeg_listener.ini
```

Step 4.2 Execute application (For Talker)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_cvf_mjpeg_talker.ini
```

4.2.5 How to send MPEG2TS data using MSE with Launcher application

This chapter described how to transport the MPEG2TS data via the Ethernet AVB network. For more information, please refer to user's manual of Media Streaming Engine.

Step 1 Prepare MPEG2TS data (For Talker)

The example script assumes that there was the MPEG2TS file contains H.264 video and AAC-LC Audio. Therefore if using the example script without customize, It is necessary to prepare the MPEG2TS file in advance. Media Streaming Engine and Launcher Application has no limitation depends on some specific codec.

Step 2 Load MMP kernel modules

```
# modprobe -a mmngr mmngrbuf vspm vspm_if vsp2 uvcs_drv
```

Step 3 Load AVB kernel modules


```
# modprobe -a ravb-streaming mch_core mse_core mse_adapter_eavb mse_adapter_alsa mse_adapter_v4l2
mse_adapter_mch
```

Step 4 Edit the Configuration file (For Listener)

Please change StreamID according to your environment.

Edit /etc/avblauncher/mse_iec61883_4_listener.ini

```
; Stream ID for Listener (xx:xx:xx:xx:xx:xx:xx:xx)
STREAM_ID = 76:90:50:00:00:00:00:01
```



Step 5 Execute the application

Step 5.1 Execute application (For Listener)

```
# amixer sset 'DVC Out' 1%
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_iec61883_4_listener.ini
```

Step 5.2 Execute application (For Talker)

```
# avblauncher -g /etc/daemon_cl/gptp_cfg.ini -a -m -i eth0 /etc/avblauncher/mse_iec61883_4_talker.ini
```

5. Notice

Nothing.

6. Appendix

6.1 How to start Linux using a USB Ethernet adapter

Step 1 Change the U-Boot configuration and rebuild

Please refer to "Chapter 1.5 Notice" in "Linux Interface Specification U-Boot User's Manual: Software". And please rebuild the U-Boot and update U-Boot on the target board.

Step 2 Enable the USB Ethernet Kernel configuration and rebuild the Kernel

Step 2.1 Enable the USB Ethernet.

Please enable CONFIG_USB_USBNET[=y] in Kernel configuration and enable all Kernel configuration affected by the CONFIG_USB_USBNET[=y]. Please change the Kernel configuration by the following way.

Edit \$WORK/meta-renesas/meta-rcar-gen3/recipes-kernel/linux/linux-renesas/defconfig

```
# CONFIG_USB_LAN78XX is not set
CONFIG_USB_USBNET=y
CONFIG_USB_NET_AX8817X=m
```

change to y

Step 2.2 Enable the USB Ethernet adapter driver.

Please enable the kernel configuration of the driver that corresponds to your USB Ethernet adapter.

Edit \$WORK/meta-renesas/meta-rcar-gen3/recipes-kernel/linux/linux-renesas/defconfig.

The following description is an example.

```
# CONFIG_USB_LAN78XX is not set
CONFIG_USB_USBNET=y
CONFIG_USB_NET_AX8817X=y
```

change to y

Step 2.3 Rebuild the Kernel.

```
# bitbake -c cleansstate linux-renesas
# bitbake linux-renesas
```

Step 3 Prepare U-Boot environment variables

Please start U-Boot by board reset, please set environment variables as follows.

```
=> usb start
=> setenv ethact asx0
=> setenv ethaddr XX:XX:XX:XX:XX:XX
=> setenv ipaddr 192.168.0.20
=> setenv serverip 192.168.0.1
=> setenv bootcmd 'tftp 48080000 Image; tftp 48000000 Image-r8a7795-salvator-x.dtb; booti 48080000 - 48000000'
```

Note) All devices in local area network should be configured that it has a completely different MAC address.

Note) About dtb file in bootcmd is an example for R-Car H3 Ver.2.0. That is should be configured for your device and board.

Step 4 change the bootargs by U-Boot

To change bootargs which passed to the kernel in boot sequence, please modify it as follows.

```
=> setenv bootargs 'consoleblank=0 ip=${ipaddr}:${serverip}:::eth1 root=/dev/nfs rw nfsroot=/export/rfs'
```

Step 5 Start Linux

Please execute the following commands manually, without reset.

```
=> run bootcmd
```

Step 6 Enable "eth0" device.

Please execute the following commands manually, and enable "eth0" device.

```
# ifconfig eth0 up
```

6.2 Recommended connection with MOTU AVB Switch

MOTU AVB Switch has 6 ports, the ETHERNET port cannot using AVB. It recommend the connection as shown in Figure 6.1.




Figure 6.1 Recommended connection with MOTU AVB Switch

6.3 About the setup of Summit X430/X440

This chapter describes a setup in the case of using Summit X430/X440 of Extreme Networks. Please connect with the serial port of PC and execute the following command from a serial console.

Step 1 Enable AVB

```
# enable avb
```

Step 2 Enable gPTP

```
# enable network-clock gtp ports all
```

Step 3 Enable MSRP

If using the Static SRP mode, skip this step.

```
# enable msrp ports all
```

Step 4 Setting VLAN Tag 2

```
# create vlan avb_vlan tag 2  
# configure "avb_vlan" add ports all tagged
```

Step 5 Enable RSTP

```
# configure stpd s0 mode dot1w  
# enable stpd s0
```

Step 6 Disable Pause-Frame

```
# disable flow-control tx-pause ports all  
# disable flow-control rx-pause ports all
```


CONFIDENTIAL

REVISION HISTORY	Ethernet AVB Start-Up Guide User's Manual: Software
-------------------------	--

Rev.	Date	Description	
		Page	Summary
0.10	Oct. 26, 2015	-	First edition issued
0.11	Dec. 18, 2015	-	Update version to v2.1.0
0.12	Mar. 11, 2016	1	1.2 Composition of this Ethernet AVB Software - Update based yocto recipe package version to v2.7.0
		6	3. Build the kernel and rootfs - Remove step of the meta-openemebbed recipe clone.
		6	3. Build the kernel and rootfs step 1 - Update Ethernet AVB software version to v2.2.0
		6	3. Build the kernel and rootfs step 3 - Remove highlight line of the meta-openembedded recipe.
		9	4.1 Preparation before execution Step 2 - Remove "console" setting in bootargs.
		12	6.1 How to start Linux using a USB Ethernet adapter Step 4 - Remove "console" setting in bootargs
0.20	Apr. 22, 2016	1	1.2 Composition of this Ethernet AVB Software - Update based yocto recipe package version to v2.8.0
		2-3	1.4 Reference - Update reference document version
		6	3. Build the kernel and rootfs step 4 - Remove edit configuration file, this version is install to all packages.
		9	4.2.1 Setup before execution the application Step 1 - Add loading AVB Streaming driver module. - Remove describe to avbtool.conf.
0.30	May. 20, 2016	1	1.1 Overview - Add M3 support
		1	1.2 Composition of this Ethernet AVB Software - Change describe to Github URLs of each component.
		2	1.3 Hardware environment - Add M3 support in Table 1.1
		3	1.4 Reference - Update the version of related document in Table 1.2
		4	2.1 Software relationship - Remove of Figure 2.2 Directory of Ethernet AVB Software
		5	2.2 Build process - Add M3 support - Remove "Extract this software" in Figure 2.2 Build process

CONFIDENTIAL

		6	3. Build the kernel and rootfs - Remove "Step 1 Extract files" - In Step 2, Description update to enable avb distro features in Yocto local configuration file
0.40	Aug. 24, 2016	1	1.2 Composition of this Ethernet AVB Software - Add AVB Media Clock Recovery Handler - Remove the URL information of github
		3	1.4 Reference - Update reference document version - Add application note of Launcher Application - Add user's manual of Media Streaming Engine
		4	2.1 Software relationship - Update Figure2.1
		7,9-12	4. Demo Applications - Add a description related to the Launcher Application - Add the operation verification method of MSE
		14	6.1 How to start Linux using a USB Ethernet adapter - Update the "step 2" to the latest procedure
0.50	Jan. 13, 2017	3	1.4 Reference - Update reference document version
		4	2.1 Software relation ship - Update Figure 2.1
		7	4. Demo Applications - Update Figure 4.2
		8	4.1 Preparation before execution - In Step 1, Reneame "Image-r8a7795-salvator-x.dtb" to "Image-r8a7795-es1-salvator-x.dtb".
		10	4.2.2 How to send PCM audio data using MSE with Launcher application - In Step 3.1, Add "amixer sset 'DVC Out'1%"
		12	4.2.4 How to send MJPEG data using MSE with Launcher application - In Step 3, Rename "mymovie.mjpg" to "movie.mjpeg"
		13	4.2.5 How to send MPEG2TS data using MSE with Launcher application - Add description related MPEG2TS usecase.
		15-16	6.1 How to start Linux using a USB Ethernet adapter - In Step 3, Reneame "Image-r8a7795-salvator-x.dtb" to "Image-r8a7795-es1-salvator-x.dtb".
0.60	Mar. 15, 2017	3	1.4 Reference - Update reference document version
		12	4.2.4 How to send MJPEG data using MSE with Launcher application - In Step 3, Fixes copy and paste problem of example of the command related gst-launch-1.0.
1.00	Jul. 12, 2017	3	1.4 Reference - Update reference document version
		8	4.1 Preparation before execution - In Step 1, Reneame "Image-r8a7795-es1-salvator-x.dtb" to "Image-r8a7795-salvator-x.dtb".
		15-16	6.1 How to start Linux using a USB Ethernet adapter - In Step 3, Reneame "Image-r8a7795-es1-salvator-x.dtb" to "Image-r8a7795-salvator-x.dtb".

CONFIDENTIAL

1.10	Nov. 14, 2017	All	Add R-Car M3N support.
		2	1.3 Hardware environment - Add notice about MOTU AVB Switch and Summit X430/X440 firmware updating.
		3	1.4 Reference - Update reference document version.
1.20	Jan. 29, 2018	-	Update Arm trademark
		3	1.4 Reference - Update reference document version.
		9	4.2.1 How to execute Simple application with Launcher application - Remove notice about selection of configuration file of daemon_cl affected by link speed.
		10	4.2.2 How to send PCM audio data using MSE with Launcher application - Remove notice about selection of configuration file of daemon_cl affected by link speed.
		12	4.2.4 How to send MJPEG data using MSE with Launcher application - Remove "Step3 Create MJPEG data (For Talker)".
1.30	Feb. 22, 2018	All	Add R-Car E3 support.
		2	1.3 Hardware environment - Add R-Car E3 System Evaluation Board (EBISU).
		3	1.4 Reference - Update reference document version.
1.40	Apr.11, 2018	2	1.3 Hardware environment - Add notice that MOTU AVB Switch require using AVB protocols.
		3	1.4 Reference - Update reference document version.
1.50	Oct. 5, 2018	3	1.4 Reference - Update reference document version.
		10	4.2.2 How to send PCM audio data using MSE with Launcher application - In Step 2, Add loading MCH and MCH Adapter modules.
		11	4.2.3 How to send H.264 video data using MSE with Launcher application - In Step 2, Add loading MCH and MCH Adapter modules.
		12	4.2.4 How to send MJPEG data using MSE with Launcher application - In Step 2, Add loading MCH and MCH Adapter modules.
		13	4.2.5 How to send MPEG2TS data using MSE with Launcher application - In Step 2, Add loading MCH and MCH Adapter modules.
2.00	Dec. 25, 2018	2	1.3 Hardware environment - Add R-Car M3-SiP System Evaluation Board Salvator-X. - Add R-Car H3-SiP/M3-SiP/M3N-SiP System Evaluation Board Salvator-XS.
		3	1.4 Reference - Update reference document version.
		15	6.1 How to start Linux using a USB Ethernet adapter - In Step 2.1, Remove "<supported board name>/" from defconfig file path. - In Step 2.2, Remove "<supported board name>/" from defconfig file path.
2.10	Apr. 06, 2021	-	Update AddressList
2.20	Aug. 16, 2021	1-2,5	Add R-Car D3 support
		3	Table 1.2 Reference - Update version for Reference
2.30	Dec. 01, 2021	-	Update Notice page

CONFIDENTIAL

Ethernet AVB Start-Up Guide
User's Manual: Software

Publication Date: Rev.0.10 Oct. 26, 2015
Rev.2.30 Dec. 01, 2021

Published by: Renesas Electronics Corporation



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics Corporation

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

Renesas Electronics America Inc. Milpitas Campus

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.
Tel: +1-408-432-8888, Fax: +1-408-434-5351

Renesas Electronics America Inc. San Jose Campus

6024 Silver Creek Valley Road, San Jose, CA 95138, USA
Tel: +1-408-284-8200, Fax: +1-408-284-2775

Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3
Tel: +1-905-237-2004

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

Room 101-T01, Floor 1, Building 7, Yard No. 7, 8th Street, Shangdi, Haidian District, Beijing 100085, China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai 200333, China
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, #06-02 Singapore 339949
Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.

Unit No 3A-1 Level 3A Tower 8 UOA Business Park, No 1 Jalan Pengaturcara U1/51A, Seksyen U1, 40150 Shah Alam, Selangor, Malaysia
Tel: +60-3-5022-1288, Fax: +60-3-5022-1290

Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India
Tel: +91-80-67208700

Renesas Electronics Korea Co., Ltd.

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5338



ルネサスエレクトロニクス株式会社

■営業お問合せ窓口

<http://www.renesas.com>

※営業お問合せ窓口の住所は変更になることがあります。最新情報につきましては、弊社ホームページをご覧ください。

ルネサス エレクトロニクス株式会社 〒135-0061 東京都江東区豊洲3-2-24（豊洲フォレシア）

■技術的なお問合せおよび資料のご請求は下記へどうぞ。
総合お問合せ窓口：<https://www.renesas.com/contact/>

Ethernet AVB Software Start-Up Guide



Renesas Electronics Corporation