

# OILLESS


(Oilless Triple)

## QUICK MAINTENANCE


**1. Always disconnect power before performing any maintenance.**

### 2. Change Coalescing Filter

- Push up on bowl ("A") to Remove Coalescing Filter from the attaching bracket
- Twist cannister to the left ("B") and pull down to expose the filter.
- Remove coned restraining nut ("C") below filter element and remove old filter.
- Slide New filter element (TW part# CFEO-375) into place and replace coned restraining nut.
- Reverse steps a and b to re-attach cannister to the bowl and then replace entire Coalescing Filter assembly back into it's bracket.




Filter Assembly on rear of each motor head




### 3. Change Motor Filters

- Twist each filter cover ("D") counter-clockwise to access filter. (two per motor)
- Replace with new filter (TW part #TIF-100) and replace filter cover .




Back of Compressor



### 4. Replace Air Intake Filter

- Remove outer casing ("E") by twisting counter clockwise and pulling gently.
- Remove old intake filter and replace with new intake filter ("F"). (TW part # TIF-100)
- Push casing together gently while turning clockwise to lock it in place.



### 5. Desiccant Dryer Maintenance

- Remove Desiccant Air Dryer Assy. and bracket ("G") from the compressor.
- Remove top filter ("G"). Turn counter-clockwise and lift. Remove hose assy. from bottom ("H").
- Turn Dessicant tank upside down and remove all contents.
- Add new filtering crystals to tank. Reverse steps a-b to complete maintenance of Desiccant Dryer.

