


# OWL TOUCH SYSTEM



---

The OWL Touch incorporates a new full color touch screen display to provide easy control of your dental utility room equipment. Simple, easy to understand screen layouts make navigation of this powerful device a cinch.

Four different categories of devices can be controlled through a single OWL Touch panel:

#### Vacuum Units

RAMVAC brand vacuum units with the new S2 control can be easily plugged into the OWL Touch and will display maintenance notifications, fault messages and other system data. However even non-RAMVAC vacuum units can be controlled via an OWL Interface Control attached to the OWL Touch.

#### Air Compressors

RAMVAC Osprey air compressors featuring the new C2 control (Smart Control) are easily connected and will provide similar information for the compressor units. Osprey compressors with a Basic control or non-RAMVAC brand compressors can also be connected via the OWL Interface Control.

#### Water Valve

Any type of master water control valve utilizing a 24 volt solenoid valve can be easily turned on and off with an OWL Interface Control.

#### Auxiliary Devices

Any type of system that can be turned on and off with a switch can be controlled by an OWL Interface Control (up to 10 amps). Systems such as lighting, stereo or intercom can be attached to the OWL Touch and turned on and off either manually or with the schedule.

#### Features

- Home screen provides the ability to choose Manual or by Schedule run mode for the equipment and includes a Master Shutdown button.
- Manual mode allows the user to turn on or off each individual type of device, similar to a standard remote switch panel.
- Schedule mode automatically turns on or off all devices by a saved user defined weekly schedule.
- Master Shutdown turns off the entire utility room when activated. Simply push this button and your utility room stays off until either the manual or Schedule mode is selected.
- OWL Touch models are available with either a four, eight or sixteen port OWL Hub device.
- Entire configuration from device, to hub, to OWL is easily connected with cat 6 shielded cables.



## OWL Hub



OWL Hub Assembly comes in four port, eight port and sixteen port versions.  
This is the number of devices that can be connected to the system.

---

## SYSTEM INSTALLATION

### Parts List









Qty 1 OWL Touch Display with junction box. Mounts to standard 2-gang electrical box (not included).

Qty 1 OWL Hub


Qty 1 Power Supply

Note: RAMVAC offers shielded CAT6 Ethernet cables in various lengths for non-plenum installations.


- **IMPORTANT:** Ethernet wiring terminated by installers should follow TIA/EIA-568B pin-out convention for Ethernet patch cables. Incorrect pin-out termination may damage this hardware.

TIA/EIA-568-B T568B Wiring		
Pin	Wire	Colour
1	1	 white/orange
2	2	 orange
3	1	 white/green
4	2	 blue
5	1	 white/blue
6	2	 green
7	1	 white/brown
8	2	 brown

**TOP:**



**FRONT:**



- Mount the OWL Hub in the utility room in a location central to all equipment being connected to the system. **Carefully follow the cable connection sequence below in order to prevent damage due to electrostatic discharge.**



---

## CABLE CONNECTION SEQUENCE

**STEP 1:** Plug in the power supply and connect to the Owl Hub. The Owl hub requires a 115 volt outlet.


**STEP 2:** Connect CAT6 Shielded Ethernet cables (standard RJ-45 connectors) to the Owl Hub for all devices being controlled by the system as well as the cable running from the office area for the Owl Touch panel. **DO NOT CONNECT THE CABLE AT THE TOUCH PANEL IN THE OFFICE AT THIS TIME.**

**STEP 3:** Next connect Ethernet cables to the COM port on device(s) being controlled by the Owl system: C2 Control, S2 Control or Interface Control.

**STEP 4:** Finally, connect the Ethernet cable to the Owl Touch panel located in the office area.

**See the diagram below for an overview of system wiring and connection sequence.**

**STEP 4**  
**CONNECT**  
**ETHERNET CABLE**  
**TO OWL TOUCH**



**STEP 1**  
**PLUG IN**  
**POWER SUPPLY &**  
**CONNECT TO HUB**



**STEP 2**  
**CONNECT ALL**  
**CABLES TO HUB**  
**PORTS**



**STEP 3**  
**CONNECT CABLES TO**  
**DEVICE "COM" PORTS**

- WATER VALVE
- NON-RAMVAC VACUUM PUMP
- NON-RAMVAC AIR COMPRESSOR
- AUXILIARY DEVICE



---



## TOUCH PANEL MOUNTING

**ATTENTION!!! DELICATE GLASS**




Do not over-tighten mounting screws. Tighten carefully only until unit is secure.

Touch panel enclosure mounts to standard two-gang wall box with 4 included screws.



Ethernet cable connection will be at the bottom of the box for proper screen orientation.

- If an Interface Control is included in the system the dip switch settings will need to be selected to tell the OWL system what type of device is being controlled. Remove the four screws holding the front cover on the Interface Control. The dip switch selector has two switches that can be configured for AIR, VAC, WATER or AUX.



### Owl Interface Control PCB Board


Follow the position settings printed on the circuit board to set the device to the appropriate setting. Reinstall the cover. Connect the two-pin "RLY" terminals to the circuit that controls the on/off functionality of the device being controlled.

- Power up all equipment being controlled by the OWL System so that they are in a stand-by non-running state. The LCD screen on RAMVAC compressors and vacuum units should light up. Each vacuum or compressor should display "Local Standby" on the C2 or S2 Control LCD screen. Also ensure the screen is illuminated on the OWL Touch Display in the office area. The system is now ready to be programmed.



## BASELINE PROGRAMMING

- Once all equipment has been connected and powered on, remove the front cover from the OWL Hub. Locate the grey "Baseline" button on the circuit board. This is the only button on the Hub circuit board.




Owl Hub PCB Board

Press and hold Baseline button for **10 seconds**. All equipment is now ready to be operated by the OWL Touch system. All C2 and S2 screens should display "OWL Stand-by".

- IMPORTANT:** All air compressors are to be connected to the same air piping network and should not be isolated pneumatically. Compressors controlled by the Owl Touch system will run simultaneously to maintain a common system air pressure.


## OWL TOUCH PROGRAMMING



## HOME SCREEN

### Initial Setup

Dealer name and phone number can be programmed so that it is displayed on the bottom of the home screen. Touch the "System Setup" button from the home screen. The screen below is now shown.



Select Dealer Name and Dealer Phone to access the keyboard and type in the appropriate dealer information. Select Exit from the keyboard screen to store the information.

The date and time of day will need to be set in the OWL Touch.

- From the System Setup screen and select "Set Time". The screen below will now be shown



### Set Time

10 /26 /12

Fri 8: 57: 34 AM

Get Current Time

Exit

Save

- The date and time is adjusted by simply pressing each field shown on the screen. Once the date and time are correct select Save and then Exit.

The daily schedule in the OWL Touch will need to be programmed next. Each day of the week can be set. Note this is an optional feature that allows the OWL system to activate all connected equipment on the programmed schedule. Alternatively the system can be operated in "Manual" mode from the "Home" screen if desired.

- From the System Setup screen select "Set Schedule". The screen below is now shown.

	System On	System Off	
Sunday	12:00 AM	12:00 AM	
Monday	12:00 AM	12:00 AM	
Tuesday	12:00 AM	12:00 AM	
Wednesday	12:00 AM	12:00 AM	
Thursday	12:00 AM	12:00 AM	
Friday	12:00 AM	12:00 AM	
Saturday	12:00 AM	12:00 AM	Exit

- Select each day of the week to set the time the system should turn on and off. When selecting a day of the week the following screen is displayed.

Monday		
	System On	System Off
Off Day	7:00 AM	5:00 PM
	Clear	Clear
	Exit	Save

- Each field can be touched to adjust the desired "System On" and "System Off" time. If the current day being programmed is a non-work day, select the "Off Day" button to set the system not to run that day. Select "Save" and "Exit" to return to the weekly calendar. Continue through each day of the week to set the desired work schedule.
- Confirm the "System On" and "System Off" times on the weekly schedule screen then select "Exit" to return the "System Setup" screen.

### Setup for Multiple Vacuum Systems

The following procedure is used to set the "Low Vacuum Set Point" for systems with more than one RAMVAC power unit. The OWL uses this parameter to automatically turn on more power units when vacuum level drops below the set level. When vacuum level is higher than the "Low Vacuum Set Point", the OWL system runs only one power unit to conserve power and optimize runtime.

- **IMPORTANT:** Verify that all vacuum devices inside the clinic are closed and that no vacuum will be used during the following setup procedure.
- From the home screen select "Manual" in the blue "Run Mode" box.
- Select the grey "Vac Off" button which will turn blue and then display "Vac On". One or more vacuum units should now be running.
- Select "System Setup" from the home screen



- Select "Vac Set". The menu below is now shown.

### LOW VACUUM SET POINT

This setting applies to systems with more than one vacuum unit.  
See Vacuum user guide for vacuum level adjustment of individual units.

**Current Vacuum** 0.0 in Hg

Additional vacuum units come on line at this vacuum level

**Low Setpoint** 0.0 in Hg

+

-

SAVE

Current Cyclor Port 0

Number Units Running 0

BACK

- The current vacuum level is indicated in the top field.
- Notice the number of units currently running on the bottom of the screen. If more than 1 unit is running, use the "-" button to adjust the "Low Set point" value so that it is several inches Hg lower than the Current Vacuum level and then select "Save".
- **IMPORTANT:** Verify the number of units now running is 1.
- After verifying that only 1 unit is running, use the "+" and "-" buttons to adjust the "Low Set point" to 1" Hg less than the "Current Vacuum" level. For example if the "Current Vacuum" level is 8.5" Hg, the low set point value should be 7.5" Hg.
- Select "Save" and then "Back" to return to the "System Setup" screen. Select "Home".

OWL Programming is now complete.

---

## OWL SYSTEM OPERATION

Two "Run Modes" are available from the OWL Touch "Home Screen". The system can be operated in either "Manual" or "By Schedule" modes to turn on connected equipment.

### MANUAL MODE

This mode allows connected equipment to be turned off and on using the four ON/OFF buttons directly above the run mode box. These buttons are comparable to traditional wall panel push buttons that simply turn equipment on or off.

### BY SCHEDULE

Select this mode to have all connected equipment turn on and off automatically per the weekly schedule that was programmed earlier in this procedure.

### MASTER SHUTDOWN

When "Master Shutdown" is selected the button will turn red which indicates the system is off and will not run according to the Schedule. Devices also cannot be operated using the on/off buttons as when in manual mode. All RAMVAC vacuum pumps and compressors will remain in stand-by until one of the two run modes is activated. **Note this is not a safety interlock.** See vacuum unit and/or compressor user manual for guidelines on electrical and pneumatic isolation for maintenance procedures.





212 North Main Street  
(800) 5-RAMVAC

Spearfish, SD 57783  
FAX (605) 642-3776

[www.ramvac.com](http://www.ramvac.com)

© Copyright 2012 RAMVAC Dental Products. All rights reserved.

No part of this publication may be copied or distributed,  
transmitted or transcribed in any form or by any means  
without the expressed written permission of  
RAMVAC Dental Products, Spearfish, SD 57783

EXCLUSIVELY FROM



**ISO 13485 Certified**

212 North Main Street, SPEARFISH, SD 57783

TOLL FREE: **800-5-RAMVAC** (800-572-6822)

PHONE: (605) 642-4614 • FAX (605) 642-3776

e-mail: [ramvac@ramvac.com](mailto:ramvac@ramvac.com)

website: [www.ramvac.com](http://www.ramvac.com)



The Integrated Supplier

PHONE: (866-DTE-INFO)

Website: [www.dentalez.com](http://www.dentalez.com)