

BA Falcon Wiring Diagrams

Group 1 – General Information

General Information

Introduction	100-00-00-3
Troubleshooting	100-00-00-4
Symbols	100-00-00-8

Group 2 – Chassis

Brake system

Hydraulic brake actuation – Adjustable Pedals	206-00-00-1
Anti lock control	206-09-00-1

Group 3 – Powertrain

Engine

Engine cooling	303-03A-00-1
Starting system	303-06-00-1
Powertrain control module – I6-1	303-14-00-1
Powertrain control module – V8-1	303-14-00-2
Powertrain control module – I6-2	303-14-00-3
Powertrain control module – V8-2	303-14-00-4
Powertrain control module – LPG	303-14-00-5
Powertrain control module – Turbo	303-14-00-6
Powertrain control management – Vehicle	
Speed control (Cruise Control)	303-14-00-7

Automatic Transmission

Automatic Transmission/Transaxle – I6	307-01-00-1
Automatic Transmission/Transaxle – V8	307-01-00-2
Automatic Transmission/Transaxle External Controls – Sequential Sports shift	307-05-00-1
Automatic Transmission/Transaxle External Controls – Column switch	307-05-00-2

Group 4 – Electrical

Memory module – Seat, Mirror & Pedal	400-00-00-1
--------------------------------------	-------------

Climate control system

Climate control system	412-00-00-1
------------------------	-------------

Instrumentation and Warning system

Instrument cluster	413-01-00-1
Horn	413-06-00-1

Clock	413-07-00-1
Parking aid	413-13-00-1

Audio Systems

Entertainment system	415-00-00-1
----------------------	-------------

Lighting systems

Exterior lighting – Sedan	417-01-00-1
Exterior lighting – XR series	417-01-00-2
Exterior lighting – Wagon	417-01-00-3
Exterior lighting – Ute	417-01-00-4
Exterior lighting – Lo	417-01-00-5
Exterior lighting – Hi	417-01-00-6
Exterior lighting – Turn/Hazard – Sedan	417-01-00-7
Exterior lighting – Turn/Hazard – Wagon	417-01-00-8
Exterior lighting – Turn/Hazard – Ute	417-01-00-9
Exterior lighting – Stop/Backup – Sedan	417-01-00-10
Exterior lighting – Stop/Backup – Wagon	417-01-00-11
Exterior lighting – Stop/Backup – Ute	417-01-00-12
Interior Lighting – Courtesy Illumination – Sedan	417-02-00-1
Interior Lighting – Courtesy Illumination – Wagon	417-02-00-2
Interior Lighting – Courtesy Illumination – Ute	417-02-00-3

Electrical Distribution

Module Communications network	418-00-00-1
-------------------------------	-------------

Electronic Features group

Navigation system	419-07-00-1
Cellular phone	419-08-00-1
Body electronics module – Lo Series	419-10-00-1
Body electronics module – Hi Series	419-10-00-2

Group 5 – Body and Paint

Body

Body system – Trailer – Sedan	501-00-00-1
Body system – Trailer – Wagon	501-00-00-2
Body system – Trailer – Ute	501-00-00-3
Rear view mirrors	501-09-00-1
Seating	501-10-00-1
Glass, Frames and Mechanisms – Rear	
Demister	501-11-00-1
Glass, Frames and Mechanisms – Power	
Windows – Sedan & Wagon	501-11-00-2

Glass, Frames and Mechanisms – Power	
Windows – Ute	501-11-00-2
Instrument panel – Cigar Lighter	501-12-00-1
Handles, Locks, Latches and entry systems – Sedan	501-14-00-1
Handles, Locks, Latches and entry systems – Wagon	501-14-00-2
Handles, Locks, Latches and entry systems – Ute	501-14-00-3
Wipers and washers	501-16-00-1
Occupant restraints – Passive	501-20B-00-1

Group 7 – General Wiring Information

Power Distribution	700-02-00-
Ground Distribution	700-03-00-
Component Location Views	700-06-00-
Connector Views	700-07-00-

Introduction

Schematics

The wiring circuits shown in this section represent the various electrical components, with the relevant wiring connections and the colour codes used.


To enable a particular wire to be followed more easily or to make provision for reference to the same wire illustrated in another wiring diagram each wire circuit is numbered.

Joining blocks, plugs and terminals accompany each schematic (where applicable) and are shown as viewed from the mating surface end. A description of the area where the connection is made is also provided.

In addition to the schematics provided, illustrations have been included which highlight the relative position of the harness in the vehicle body.

Wire Colour Code (Harness Symbol)

- Two-colour wires are indicated by a two-letter symbol. The first indicates the base colour of the wire, the second the colour of the stripe. For example:
 - W-R is a white wire with a red strip
 - BR-Y is a brown wire with a yellow strip



B	BLACK
BR	BROWN
GR	GREY
L	BLUE
R	RED
W	WHITE
Y	YELLOW
G	GREEN
O	ORANGE
P	PINK
V	VIOLET
SB	SKY BLUE
LG	LIGHT GREEN
T	TAN


eg. GR.....GREY
 G-R.....GREEN-RED
 BR-Y.....BROWN-YELLOW

Troubleshooting

Precautions to take when servicing an electrical system


NOTE: The following items when servicing the electrical system.

- Do not alter the wiring or electrical equipment in any way; this may damage the vehicle or cause a fire from shortcircuiting a circuit or overloading it.
- The negative (-) battery cable must be removed first and installed last.




⚠ CAUTION: Be sure that the ignition and other switches are off before disconnecting or connecting the battery cables. Failure to do so may damage the semiconductor components.

- Secure harnesses with provided clamps to take up slack.




⚠ CAUTION: Clamp all harnesses near vibrating components (for example, the engine) to remove slack and to prevent contact resulting from vibration.

- Do not handle electrical components roughly or drop them.




- Do not replace with fuses exceeding specified capacity.




⚠ CAUTION: Replacing a fuse with one of a larger capacity than designated may damage components or cause a fire.









- Tape areas of the harness that may rub or bump against sharp edges to protect it from damage.
- When mounting components, be sure the harness is not caught or damaged.























- Disconnect heat-sensitive parts (for example, relays and ECU) when performing maintenance (such as welding) where temperatures may exceed 80°C (176°F).
- Make sure that the connectors are securely connected when installed.



Using Electrical Measuring Equipment

Equipment	Use	Operation	Handling Precautions
<p>Jumper wire</p> 	<p>Used to create a temporary circuit.</p>	<ul style="list-style-type: none"> Connect the jumper wire between the terminals of a circuit to bypass a switch. 	<ul style="list-style-type: none"> Do not connect the jumper wire from the power source line to a ground; this may cause burning or other damage to harnesses or electronic components.
<p>Voltmeter</p> 	<p>Used for measuring the voltage of a circuit to find possible opens or shorts.</p>	<ul style="list-style-type: none"> Connect the positive (+) probe to the point where voltage is to be measured and the negative (-) probe to a ground. 	<ul style="list-style-type: none"> Connect the voltmeter in parallel with the circuit. Set the range to the desired voltage. Use the service hole when measuring the voltage at the diagnosis connector. Tie a thin wire to the positive (+) probe to access narrow terminals.
<p>Ohmmeter</p> 	<p>Used to find opens and shorts in the circuit, to confirm continuity and to measure resistance.</p>	<ul style="list-style-type: none"> Zero the ohmmeter. Verify that voltage is not applied to the circuit. Connect the probes between two points in a circuit. 	<ul style="list-style-type: none"> Zero the meter after switching to the measuring range. Before using the ohmmeter, make sure the ignition switch is off or the negative (-) battery cable is disconnected to prevent burning or otherwise damaging the ohmmeter.
<p>Ammeter</p> 	<p>Used to check alternator output, current supplied to the starter, and dark current within a circuit.</p> <p>Note Dark current is the constant flow of current while the ignition switch is OFF.</p>	<ul style="list-style-type: none"> Connect the ammeter in series with the circuit by touching the positive (+) probe to the power-side terminal and the negative (-) probe to the ground-side terminal. 	<ul style="list-style-type: none"> Set the range to the desired amperage. Connect the ammeter in series with the circuit. The ammeter may be burned or otherwise damaged if it is connected in parallel.
AUS01550			

Handling Connectors

Connector Removal		Checking Connector Contacts	Checking for loose Terminals	Replacing Terminals
Push type		<div>Caution Be sure to grasp the connectors, not the wires, when disconnecting them.</div> <div>Caution Improperly engaged connectors will cause poor terminal contact.</div> <div></div> <div>When using a matching male terminal, make sure there is no looseness in the female terminal.</div>	<div>Caution A loose terminal will cause poor terminal contact.</div> <div></div> <div>Make sure the terminals are not pushed out of the connector when engaged.</div> <div></div>	<div><ol style="list-style-type: none">1. Raise the rear cover.2. Lift the tab with a thin piece of metal and remove the terminal.</div>
				
				
				
				
				
				
				
Pull-up type			<div>Pull lightly on individual wires to check that they are secured in the terminal.</div>	<div><General connector></div> <div>Lift the tab with a thin piece of metal and remove the terminal.</div>
				
				
				
Lever Type		<div>Press tab down to release and lift lever.</div>		<div>Lift lock and raise tab with a thin piece of metal to remove terminal.</div>

AUS01551

AUS01551

MODULES		MODULE SYMBOLS		MODULE SYMBOLS		MODULE SYMBOLS	
MODULE NAME & NAME POSITION NAME SAME AS WIRE HARNESS DRAWING		BATTERY		CONNECTOR		WIRE TO WIRE	
CIRCUITS		FUSE		MOTOR		WIRE TO WIRE 2 OR MORE TERMINALS	
TERMINAL CONNECTION		FIL MINI FIL		RESISTOR		GROUND	
CIRCUIT NUMBER		RELAY		CHANGE OVER RELAY		SOLENOID	
SPICE		SWITCH		DIODE		HEATER	
BUSBAR		SPEAKER		TRANSISTOR		SENSOR	
BUSBAR CIRCUITS AND NODE		SPEED SENSOR		STEPPER MOTOR		CONNECTOR VIEW/DRAWINGS	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	
MODULE SYMBOLS		WIRE TO WIRE		WIRE TO WIRE		WIRE TO WIRE	