



# Slicing software instructions

## 1. Basic settings



## General

Settings

Printers

Materials

Profiles

## General

## Interface

Language: English Currency: €

Theme: Ultimaker

*You will need to restart the application for these changes to have effect.*☐ Slice automatically

## Viewport behavior

- ☒ Display overhang
- ☒ Display model errors
- ☐ Center camera when item is selected
- ☐ Invert the direction of camera zoom.
- ☐ Zoom toward mouse direction
- ☐ Ensure models are kept apart
- ☒ Automatically drop models to the build plate
- ☒ Caution message in g-code reader
- ☐ Force layer view compatibility mode (restart required)
- ☒ Restore window position on start

Camera rendering:



Perspective

## Opening and saving files


☐ Use a single instance of Cura

Defaults


Close




We provide a reference configuration file, just import the configuration file directly.



Then you can import the model through "File"> "Read Model File" or open the file icon or directly drag the model file into the software. The operation of the model is as follows:







Go to "File">Save gcode to SD card. The file name "XX.gcode" must be English or numbers, and cannot be special characters such as Chinese. Save the sliced file to the SD card then insert SD card into the card slot, and open Power supply, Select "start print" in the main menu, and then select the "XX.gcode" file you just saved, confirm to print.




## 二. Detailed parameter settings



- Layer thickness: 0.1 printing accuracy is relatively high, generally 0.2, if you want to save printing time, you can also use 0.3, the greater the layer thickness, the shorter the printing time.



Left: 0.1mm layer thickness



Right: 0.3mm layer thickness

