




A4988 Stepper Motor Driver Module

The A4988 stepper motor driver carrier is a breakout board for Allegro's A4988 micro-stepping bipolar stepper motor driver. The driver features adjustable current limiting, overcurrent and over-temperature protection, and five different micro-step resolutions (down to 1/16-step). It operates from 8~35V and can deliver up to approximately 1A per phase without a heat sink or forced air flow (it is rated for 2A per coil with sufficient additional cooling).



SKU: [DRV1000](#)


Brief Data:

- Minimum operating voltage: 8V.
- Maximum operating voltage: 35V.
- Continuous current per phase: 1A.
- Maximum current per phase: 2A (with heatsink).
- Minimum logic voltage: 3V.
- Maximum logic voltage: 5.5V
- Micro-step Resolutions: 1, 1/2, 1/4, 1/8, 1/16.
- Size: 0.6" × 0.8" .
- Weight: 1.3g

Functional Diagram:



A4988 with Arduino Application:



```

/* Simple Stepper Motor Control Example Code

* Stepper Motor Driver: A4988

*

*/

// defines pins numbers

const int stepPin = 3;

const int dirPin = 4;


void setup() {

    // Sets the two pins as Outputs
    pinMode(stepPin,OUTPUT);

    pinMode(dirPin,OUTPUT);

}

void loop() {

    digitalWrite(dirPin,HIGH); // Enables the motor to move in a particular direction

    // Makes 200 pulses for making one full cycle rotation
    for(int x = 0; x < 200; x++) {

        digitalWrite(stepPin,HIGH);

        delayMicroseconds(500);

        digitalWrite(stepPin,LOW);

        delayMicroseconds(500);

    }

    delay(1000); // One second delay


    digitalWrite(dirPin,LOW); //Changes the rotations direction

    // Makes 400 pulses for making two full cycle rotation
    for(int x = 0; x < 400; x++) {

        digitalWrite(stepPin,HIGH);

        delayMicroseconds(500);

        digitalWrite(stepPin,LOW);

        delayMicroseconds(500);

    }


    delay(1000);

}

```

3-Axis CNC/Stepper Motor Shield for Arduino

The Arduino CNC Shield makes it easy to get your CNC projects up and running in a few hours. It uses opensource firmware on Arduino to control 4 stepper motors using 4 pieces of A4988 Stepper Motor driver breakout board, with this shield and ArduinoUno/Mega, you can build all kinds of robotics, linear motion project or projects including CNC routers, laser cutters and even pick&place machines.



SKU: [DRV1001](#)

Brief Data:

- GRBL 0.9 compatible. (Open source firmware that runs on an Arduino UNO that turns G-code commands into stepper signals)
- 4-Axis support (X, Y, Z, A-Can duplicate X,Y,Z or do a full 4th axis with custom firmware using pins D12 and D13)
- 2 x End stops for each axis (6 in total)
- Coolant enable
- Uses removable A4988 compatible stepper drivers. (A4988, DRV8825 and others)(Not Included)
- Jumpers to set the Micro-Stepping for the stepper drivers. (Some drivers like the DRV8825 can do up to 1/32 micro-stepping)
- Compact design.
- Stepper Motors can be connected with 4-pin Molex connectors or soldered in place.
- Runs on 12-36VDC. (At the moment only the DRV8825 drivers can handle up to 36V so please consider the operation voltage when powering the board.)


Table of Contents

1. Configuring Micro Stepping for Each Axis.....	6
2. GRBL Control Software/Firmware for Arduino	7

3. Hooking Up the Stepper Motor to CNC Shield.....	10
4. G-Code Sender	11
5. Recommended Driver Board & Accessory	13

1. Configuring Micro Stepping for Each Axis


Each axis has 3 jumpers that can be set to configure the micro stepping for the A4988 plug-in driver board.




Micro-stepping jumper location, before inserting A4988.

In the tables below 'High' indicates that a jumper is insert and 'Low' indicates that no jumper is inserted.

MS0	MS1	MS2	Microstep Resolution
Low	Low	Low	Full Step
High	Low	Low	1/2 Step
Low	High	Low	1/4 Step
High	High	Low	1/8 Step
High	High	High	1/16 Step



After setting the microstep jumper, you can plug-in A4988 driver boards as shown in the photo below. The photo also shown this CNC sit nicely on top of Arduino Uno board, without any external jumper wires.



!!! Beware of the orientation of the A4988 driver boards! You will destroy the A4988 driver board if plug-in with wrong orientation.

2. GRBL Control Software/Firmware for Arduino

Before you can use this CNC shield with Arduino, a control firmware need to be downloaded into Arduino board. We are going to use 'GRBL' to accomplish our job. GRBL is open-source software that runs on an Arduino Uno that takes G-Code commands via Serial and turns the commands into motor signals. Grbl is a no-compromise, high performance, low cost alternative to parallel-port-based motion control for CNC machine. It accepts standards-compliant g-code and has been tested with the output of several CAM tools with no problems. Arcs, circles and helical motion are fully supported, as well as, all other primary g-code commands. Macro functions, variables, and most canned cycles are not supported, but we think GUIs can do a much better job at translating them into straight g-code anyhow.

A copy of this open-source firmware can be downloaded from the below link:

Following the below steps to prepare this CNC Shield board to function properly:

1. Download a copy of GRBL from: <https://github.com/grbl/grbl>

An open source, embedded, high performance g-code-parser and CNC milling controller written in optimized C that will run on a straight Arduino <https://github.com/grbl/grbl/wiki>

631 commits

5 branches

0 releases

24 contributors

GPL-3.0

Branch: master

New pull request

Find file

Clone or download

chamnit Non-CoreXY compiling fix.

build Git fix for empty directory. Makefile updated.

doc Non-CoreXY compiling fix.

grbl Non-CoreXY compiling fix.

.gitignore Merge branch 'edge'

COPYING Homing alarm upon no switch. Licensing update.

Makefile Added restore settings defaults command.

README.md No variable spindle and spindle speed. 2 years ago

Clone with HTTPS

Use Git or checkout with SVN using the web URL.

<https://github.com/grbl/grbl.git>

Open in Desktop

Download ZIP


Click here to download this zip file.

README.md


grbl

Unzip this file into your local hardisk location, you may want to create a special new folder for this purpose for easy locating of all files needed in your project. Locate an Arduino sketch '*grblUpload.ino*' in this folder where you have unzip the files.


Below is the files structures located in my local hardisk:



Open up this sketch '*grblUpload.ino*' and you should see the screen as below:





Click the upload icon as usual to ‘compile/upload’ as you normally upload Arduino sketch. When you see ‘done uploading’, click the ‘Serial Monitor’ on Arduino IDE as shown below:



If you can receive response message “ *Grbl 0.9j ['\$' for help]* ” from your Serial Monitor, congratulation! You have successful uploaded the ‘GRBL’ firmware into your Arduino board.

3. Hooking Up the Stepper Motor to CNC Shield

Connect steppers motor to CNC Shield board as the below block diagram. of the CNC Shield connected to 3-stepper motor:



Your CNC Shield board is now ready to go for a test run, let's try to turn the motor as to our instruction !!

4. G-Code Sender

To send commands to your CNC/3-axis stepper motor driver board you need a g-code sender to send command and instruction.

Before running Java program, please make sure “Java SE Runtime Environment” is installed in your computer. You can down load the “Java SE Runtime Environment” from the below link:


<https://www.oracle.com/technetwork/java/javase/downloads/jre8-downloads-2133155.html>

Download the Universal-G-Code-Sender.


“Universal Gcode Sender” is a Java based GRBL compatible cross platform G-Code sender. Use this program to run a GRBL controlled CNC machine. Once downloaded, connect the UNO board USB to your computer and take note of the COM port it is connected to.

Run the *start-windows.bat* or the *JAR* file directly.

You will be presented with the following screen:



Click the “Machine Control” tab. Select the “Port” number which your Arduino board is attached to. Select 115200 as the Baud rate as this is the speed configured in “GRBL” firmware. Click “Open” button to start the communication for controlling this shield board.



Now, you are ready to control the XYZ stepper motor connected to shield board. Click X+ or X- for example, the stepper motor attached to X terminal will turn in forward or reverse direction.

This will complete our initial setup for driving 3-axis stepper motor connected to this shield board with "GRBL" loaded into Arduino controller board using "Universal G-Code Sender" user interface.

5. Recommended Driver Board & Accessory

- [CNC/3-Axis Stepper Motor Driver Shield for Arduino Board](#)
- [A4988 Stepper Motor Driver Module](#)
- [GT2 Pulley 5mm Bore](#)
- [5mm to 8mm Motor Shaft Coupler](#)



Handsontec.com

We have the parts for your ideas

HandsOn Technology provides a multimedia and interactive platform for everyone interested in electronics. From beginner to diehard, from student to lecturer. Information, education, inspiration and entertainment. Analog and digital, practical and theoretical; software and hardware.



open source
hardware

HandsOn Technology support Open Source Hardware (OSHW)
Development Platform.

Learn : Design : Share

handsontec.com



The Face behind our product quality...

In a world of constant change and continuous technological development, a new or replacement product is never far away – and they all need to be tested.

Many vendors simply import and sell without checks and this cannot be the ultimate interests of anyone, particularly the customer. Every part sell on Handsotec is fully tested. So when buying from Handsontec products range, you can be confident you're getting outstanding quality and value.

We keep adding the new parts so that you can get rolling on your next project.



www.handsontec.com

[Breakout Boards & Modules](#)



[Connectors](#)



[Electro-Mechanical Parts](#)



[Engineering Material](#)



www.handsontec.com

[Mechanical Hardware](#)



[Electronics Components](#)

P



www.handsontec.com

[Power Supply](#)



[Arduino Board & Shield](#)

Tools & Accessory



www.handsontec.com

[Tools & Accessory](#)