

Master BT A2DP Source with AVRCP Example

Version 1.5

September 2018

Redpine Signals, Inc.

2107 North First Street, Suite #540, San Jose, California 95131,

United States of America.

Phone: +1-408-748-3385, Fax: +1-408-705-2019

Email: sales@redpinesignals.com

Website: www.redpinesignals.com

Disclaimer

The information in this document pertains to information related to Redpine Signals, Inc. products. This information is provided as a service to our customers, and may be used for information purposes only.

Redpine assumes no liabilities or responsibilities for errors or omissions in this document. This document may be changed at any time at Redpine's sole discretion without any prior notice to anyone. Redpine is not committed to updating this document in the future.

Copyright © 2018 Redpine Signals, Inc. All rights reserved.

Table of Contents

1	Application Overview.....	4
1.1	Overview	4
1.2	Sequence of Events	4
2	Application Setup.....	5
2.1	Setup Requirements	5
3	Configuration and Execution of the Application	6
3.1	Configuring the Application	6
3.2	Executing the Application.....	7

1 Application Overview

1.1 Overview

A2DP source with AVRCP application is used to transfer the PCM data to remote device (A2DP sink device) in SBC encoded format and acts as a AVRCP target.

1.2 Sequence of Events

Applications explains user how to:

- Configure Redpine device in discoverable and connectable mode
- Configure the remote device in discoverable and connectable mode
- Initialize the physical level connection with remote device
- Initialize A2DP profile level connection with remote device
- Initialize AVRCP profile level connection with remote device
- Transfer the Audio data to the remote device.
- Pause and Play of Audio data will controlled by AVRCP profile based on the Remote device inputs.

2 Application Setup

The WiSeConnect parts require that the host processor is connected to the WiSeConnect using USB host interface. The host processor firmware needs to properly initialize the selected host interface. The Redpine Wireless SAPI framework provides necessary HAL APIs to enable variety of host processors. The WiSeMCU parts offer integrated wireless connectivity and does not require host interface initialization.

2.1 Setup Requirements

- Redpine module
- BT Remote device(A2DP sink device)
- Host platform




Figure 1: Setup Diagram

3 Configuration and Execution of the Application

3.1 Configuring the Application

1. Open **rsi_a2dp_source_avrcp.c** file and update/modify following macros,
RSI_BT_LOCAL_NAME refers name of the Redpine module to appear during scanning by remote devices.

```
#define RSI_BT_LOCAL_NAME "A2DP_AVRCP_SOURCE"
```

RSI_BT_REMOTE_BD_ADDR refers BD address of the Remote device to which redpine device has to connect.

```
#define RSI_BT_REMOTE_BD_ADDR "00:1E:7C:25:E9:6D"
```

PIN_CODE refers four bytes string required for pairing process.

```
#define PIN_CODE "0000"
```

```
#define A2DP_BURST_MODE 0
```

RSI_AUDIO_DATA_TYPE refers input audio file format. Select MP3_AUDIO for .mp3 format, PCM_AUDIO for .wav format, SBC_AUDIO for .sbc format

```
#define PCM_AUDIO 1
#define SBC_AUDIO 2
#define MP3_AUDIO 3
#define RSI_AUDIO_DATA_TYPE MP3_AUDIO
```

RSI_AUDIO_DATA_SRC refers audio source type. Select BIN_FILE, if we have audio files and ARRAY if file system is not supported in host, we can pass buffered data.

```
#define BIN_FILE 1
#define ARRAY 2
#define RSI_AUDIO_DATA_SRC BIN_FILE
```

BIN_FILE_PATH refers input audio file path.

```
#define AUDIO_FILE_PATH "mp3_samples.mp3"
```

Following are the **non-configurable** macros in the application. **BT_GLOBAL_BUFF_LEN** refers to the number of bytes required by the application and the driver.

```
#define BT_GLOBAL_BUFF_LEN 10000
```

```
#define A2DP_BURST_MODE 0
```

2. Open **rsi_wlan_config.h** file and update/modify following macros:

```
#define CONCURRENT_MODE RSI_DISABLE
#define RSI_FEATURE_BIT_MAP FEAT_SECURITY_OPEN
#define RSI_TCP_IP_BYPASS RSI_ENABLE
#define RSI_TCP_IP_FEATURE_BIT_MAP 1
#define RSI_EXT_CUSTOM_FEATURE_BIT_MAP EXT_FEAT_256K_MODE
#define RSI_BAND RSI_BAND_2P4GHZ
```

3.2 Executing the Application

1. Keep Remote device in discoverable and connectable mode.
2. Run the A2DP source AVRCP application
3. Now Redpine module is trying to connect with Remote device.
4. After Successful connection, Redpine device will connect with remote device in A2DP level and AVRCP level
5. After Successful A2DP and AVRCP connections, Redpine device will transfer the Audio data to remote device .
6. Redpine device will also acts as AVRCP target to support the pause and play options from the A2DP sink device(Remote device)

Note

- This can be run in wise-connect mode in linux pc with USB Interface.