

## Booting U-boot from Atmel SPI Serial DataFlash® on the AT91RM9200-DK Board

This Application Note gives a step-by-step guide to store U-boot in Atmel's serial DataFlash connected to the SPI Chip Select 0 on the AT91RM9200-DK Board.

Having U-boot in the Serial DataFlash makes external parallel Flash unnecessary and it can be eliminated.

The procedure is as follows:

1. Download the U-Boot release 1.0.0, available on SourceForge.net:
  - <http://sourceforge.net/projects/u-boot>
2. Download the file `u-boot-DataFlash_1_01.zip` associated with this Application Note on Atmel's website, AT91ARM Thumb - Application Notes:
  - [http://www.atmel.com/dyn/products/app\\_notes.asp?family\\_id=605](http://www.atmel.com/dyn/products/app_notes.asp?family_id=605)
3. Apply the patch "patch-u-boot-AT91RM9200-dataflash.dat" to U-boot that enables booting via the SPI DataFlash. Use the following command to apply the patch:
  - `cat patch-u-boot-AT91RM9200-dataflash.dat | patch -p1 -d u-boot-1.0.0/`
4. Set the flag `CFG_ENV_IS_IN_DATAFLASH` in `../include/configs/at91rm9200dk.h` source file to have the Environment Variables stored in the Serial DataFlash.
5. Set the flag `CONFIG_ENV_OVERWRITE` in `../include/configs/at91rm9200dk.h` source file to obtain the ability to overwrite all Environment Variables.
6. Compile U-boot.

For more details about U-boot compilation refer to the U-boot Developer Manual.

Once U-boot has been patched and rebuilt, perform the following to store it into the serial DataFlash of the AT91RM9200-DK:

- Remove the resistor R159 on the AT91RM9200-DK to start the processor from its internal boot ROM.
- Connect the board to a HyperTerminal Session (115200/8N1) with the DBGU port.
- Power up the board.
- 'C' characters displayed means that the board is prepared to receive data through xmodem transfer.
- Send `RomBoot.bin` by xmodem. `RomBoot.bin` is an application with the correct setting of the 6th ARM vector that allows booting from the AT45DB642 Atmel DataFlash connected on NPCS0.
- Press the Return key on the HyperTerminal several times to disable the checking of a 6th valid vector.

This procedure facilitates stopping automatic startup of U-boot.



**AT91 ARM®  
Thumb®  
Microcontrollers**

## Application Note





**Note:** In the following instructions, the text in gray shows information as displayed on the HyperTerminal.

Once RomBoot.bin has been transferred, the following prompt appears on the HyperTerminal screen:

```
ATMEL LOADER VER 1.01 May 03 2004 14:54:39
```

```
*-----*
```

```
DataFlash:AT45DB128
```

```
Nb pages: 16384
```

```
Page Size: 1056
```

```
Size=17301504 bytes
```

```
Logical address: 0xC0000000
```

```
*-----*
```

```
1: Download Dataflash [addr]
```

```
2: Read Dataflash [addr]
```

```
3: Start U-BOOT [C0008000 => 21F00000]
```

```
*-----*
```

```
Enter:
```

Choose "1" to download to DataFlash and copy the RomBoot.bin file in C0000000:

Enter the following command: 1 c0000000

Then 'C' characters are displayed: CCCCCCCCCC

This indicates that xmodem protocol is enabled, so resend the RomBoot.bin file using HyperTerminal xmodem.

When the download is completed, the following prompt appears:

```
Modification of Arm Vector 6 :841c018
```

```
Write 11776 bytes in DataFlash [0xc0000000]
```

```
Verify Dataflash: OK
```

```
Hit a Key!ESC[2J
```

```
ATMEL LOADER VER 1.01 May 03 2004 14:54:39
```

```
*-----*
```

```
DataFlash:AT45DB128
```

```
Nb pages: 16384
```

```
Page Size: 1056
```

```
Size=17301504 bytes
```

```
Logical address: 0xC0000000
```

```
*-----*
```

```
1: Download Dataflash [addr]
```

# Booting U-boot from Serial DataFlash

2: Read Dataflash [addr]

3: Start U-BOOT [C0008000 => 21F00000]

\*-----\*

Enter:

It is now possible to boot from the DataFlash and copy the desired application into it. In this case, it is to have U-boot in the DataFlash in order to boot from it. Care should be taken to not erase RomBoot.bin in the DataFlash.

Use the U-boot binary image generated as described in point 5. on page 1 to download it into the DataFlash at address 0xC0008000 of the DataFlash.

Choose "1" to download to DataFlash and copy the u-boot.bin file in C0008000:

Enter: 1 C0008000

Then 'C' characters are displayed CCCCCCCCCC

Send the u-boot.bin file using HyperTerminal xmodem transfer.

U-boot is now stored in the Serial DataFlash and can be started up. Reset the board to restart U-boot from the Serial DataFlash.



## Document Details

**Title** Booting U-boot from Atmel SPI Serial DataFlash on the AT91RM9200-DK

**Literature Number** 6067

## Revision History

**Version A** **Publication Date:** 06-Apr-04

**Version B** **Publication Date:** 04-Jun-04

*Page: 1* Step 2. Download Software Zip file changed.

*Page: 2 & 3* HyperTerminal instructions changed.



## Atmel Corporation

2325 Orchard Parkway  
San Jose, CA 95131, USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 487-2600

## Regional Headquarters

### Europe

Atmel Sarl  
Route des Arsenaux 41  
Case Postale 80  
CH-1705 Fribourg  
Switzerland  
Tel: (41) 26-426-5555  
Fax: (41) 26-426-5500

### Asia

Room 1219  
Chinachem Golden Plaza  
77 Mody Road Tsimshatsui  
East Kowloon  
Hong Kong  
Tel: (852) 2721-9778  
Fax: (852) 2722-1369

### Japan

9F, Tonetsu Shinkawa Bldg.  
1-24-8 Shinkawa  
Chuo-ku, Tokyo 104-0033  
Japan  
Tel: (81) 3-3523-3551  
Fax: (81) 3-3523-7581

## Atmel Operations

### Memory

2325 Orchard Parkway  
San Jose, CA 95131, USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 436-4314

### Microcontrollers

2325 Orchard Parkway  
San Jose, CA 95131, USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 436-4314

La Chantrerie  
BP 70602  
44306 Nantes Cedex 3, France  
Tel: (33) 2-40-18-18-18  
Fax: (33) 2-40-18-19-60

### ASIC/ASSP/Smart Cards

Zone Industrielle  
13106 Rousset Cedex, France  
Tel: (33) 4-42-53-60-00  
Fax: (33) 4-42-53-60-01

1150 East Cheyenne Mtn. Blvd.  
Colorado Springs, CO 80906, USA  
Tel: 1(719) 576-3300  
Fax: 1(719) 540-1759

Scottish Enterprise Technology Park  
Maxwell Building  
East Kilbride G75 0QR, Scotland  
Tel: (44) 1355-803-000  
Fax: (44) 1355-242-743

### RF/Automotive

Theresienstrasse 2  
Postfach 3535  
74025 Heilbronn, Germany  
Tel: (49) 71-31-67-0  
Fax: (49) 71-31-67-2340

1150 East Cheyenne Mtn. Blvd.  
Colorado Springs, CO 80906, USA  
Tel: 1(719) 576-3300  
Fax: 1(719) 540-1759

### Biometrics/Imaging/Hi-Rel MPU/ High Speed Converters/RF Datacom

Avenue de Rochepleine  
BP 123  
38521 Saint-Egreve Cedex, France  
Tel: (33) 4-76-58-30-00  
Fax: (33) 4-76-58-34-80



**Disclaimer:** Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's web site. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

© Atmel Corporation 2004. All rights reserved. Atmel® and combinations thereof, and DataFlash® are the registered trademarks of Atmel Corporation or its subsidiaries. ARM®Thumb® and ARM Powered® are the registered trademarks ARM Ltd. Other terms and product names may be the trademarks of others.

## Literature Requests

[www.atmel.com/literature](http://www.atmel.com/literature)



Printed on recycled paper.