

DIP Switch MIDI Mode

MIDI Mode	DIP Switch Nr. 1	DIP Switch Nr. 2	DIP Switch Nr. 3	DIP Switch Nr. 4	MIDI Event
0	OFF	OFF			No MIDI Events will be sent
1	ON	OFF			MIDI Note ON and OFF
2	OFF	ON			MIDI Show Control MSC
3	ON	ON			MIDI Program Change
USB-MIDI			ON		USB-MIDI ON/OFF
MIDI Ch.				ON	MIDI Channel 2 (OFF = Ch.1)
HINT:	In MIDI Mode 1: When the Button once is pressed, it send a Note On Event. By releasing the button a Midi Note Off will be sent.				