

DIP Switch Keyboard Mode

Keyboard Mode	DIP Switch Nr. 1	DIP Switch Nr. 2	DIP Switch Nr. 3	DIP Switch Nr. 4	Key
0	OFF	OFF	OFF	OFF	No Keystrokes will be sent
1	ON	OFF	OFF	OFF	SPACE
2	OFF	ON	OFF	OFF	ENTER
3	ON	ON	OFF	OFF	Arrow. Up
4	OFF	OFF	ON	OFF	Arrow Down
5	ON	OFF	ON	OFF	Arrow Left
6	OFF	ON	ON	OFF	Arrow Right
7	ON	ON	ON	OFF	Page Up
8	OFF	OFF	OFF	ON	Page Down
9	ON	OFF	OFF	ON	A
10	OFF	ON	OFF	ON	1
11	ON	ON	OFF	ON	TAB
12	OFF	OFF	ON	ON	F5
13	ON	OFF	ON	ON	Media Key Start
14	OFF	ON	ON	ON	ALT +CMD +P
15	ON	ON	ON	ON	CMD +SHIFT +ENTER
Hint:	F5 or ALT+CMD+P are used to start the Power Point Presentations. CMD+SHIFT+ENTER are used to start Keynote or the Countdown of PhotoBooth				
MIDI:	In MIDI Mode 1: When the Button once is pressed, it send a Note On Event. By releasing the button a Midi Note Off will be sent.				