




Breathe ideas.

DTV Basic

Day 6 - Audio and Video decoder

Audio and Video Decoder



TDAL AV

- The purpose of the TDAL AV module is to control physical audio and video decoder .
- Decoder can be used in two modes:
 - External audio and video
 - Memory
- Client can be notified about changes on the audio and video decoder (e.g. first frame, audio issue, etc...)
- TDAL AV module has control over audio and video speed - trick modes (PVR case)

TDAL AV - pipeline

- Connect to data source
 - TDAL AV module requires data input (input stream) from demultiplexer (TDAL DMX).
 - TDAL AV must know from which demultiplexer data arrives (e.g. from which “channel” audio and video stream type are needed to be decoded).
 - To identify audio and video component available to the AV module stream handle is used.
 - The stream reference is set as the input to the AV module using function:
“TDAL_AV_InputStreamSet”
- Connect to data display module
 - TDAL AV module requires access to TDAL DISP module to connect video graphics layer on which decoded frame should be written.
 - A layer handle reference is used to identify graphics layers.
 - The reference to the graphics layer is set using function:
“TDAL_AV_VideoDestinationSet”


TDAL AV - instance

- TDAL AV module can use multiple instances of audio and video decoders.
- TDAL AV module in PVR context can control parallel decoding (e.g. PIP/PAP functionality).
- TDAL AV module reserves identifiers [1..4] for up to four instances of video and audio decoders. These instances are logical.

TDAL AV API

Function name	Description
TDAL_AV_Init TDAL_AV_Term	Initialization/Deinitialization AV module
TDAL_AV_CapabilityGet	Get supported audio/video decoders
TDAL_AV_APIRevisionGet TDAL_AV_PlatformRevisionGet	Get API version and platform
TDAL_AV_EventSubscribe TDAL_AV_EventUnsubscribe	Register and Unregister callback function to get status events from decoders.
TDAL_AV_Start TDAL_AV_Stop	Start/Stop decoding.
TDAL_AV_SynchroModeSet	Set sync mode (live input, memory or IP network.
TDAL_AV_SpeedSet	Set decoding speed.
TDAL_AV_InputStreamSet	Set inpit data stream to decoder.

TDAL AV API



NIT

Breathe ideas.

Contact us

Institute for information technologies NIT

Radnicka 30a, 21000 Novi Sad, Serbia

info@nit-institute.com

www.nit-institute.com

+381 64 01 64 724