

15,000 miles or 18 months

- | | |
|---|--|
| <input type="checkbox"/> Add Toyota EFI Tank Additive or equivalent (Hawaii, Puerto Rico and American Samoa only) | <input type="checkbox"/> Inspect wiper blades |
| <input type="checkbox"/> Check installation of driver's floor mat | <input type="checkbox"/> Re-torque propeller shaft bolt (AWD) |
| <input type="checkbox"/> Inspect and adjust all fluid levels ¹ | <input type="checkbox"/> Rotate tires |
| | <input type="checkbox"/> Visually inspect brake linings/drums and brake pads/discs |

NOTE: If 0W-16 (A25A-FKS engine only) or 0W-20 (2GR-FKS engine only) oil WAS NOT used at the last oil change, replace engine oil and oil filter.²

Inspect the following:

- | | |
|--|--|
| <input type="checkbox"/> Ball joints and dust covers | <input type="checkbox"/> Radiator and condenser |
| <input type="checkbox"/> Brake lines and hoses | <input type="checkbox"/> Rear differential oil (AWD) |
| <input type="checkbox"/> Drive shaft boots | <input type="checkbox"/> Steering gear |
| <input type="checkbox"/> Engine coolant ⁵ | <input type="checkbox"/> Steering linkage and boots |
| <input type="checkbox"/> Exhaust pipes and mountings | <input type="checkbox"/> Transfer case oil (AWD) |

Additional Maintenance Items for Special Operating Conditions³

Driving on dirt roads or dusty roads:

- ☐ Inspect engine air filter
- ☐ Replace engine oil and oil filter²
- ☐ Tighten nuts and bolts on chassis and body

Driving while towing, using a car-top carrier, or heavy vehicle loading:⁶

- ☐ Replace engine oil and oil filter²
- ☐ Replace rear differential oil (AWD)
- ☐ Replace transfer case oil (AWD)
- ☐ Tighten nuts and bolts on chassis and body

Repeated trips of less than five miles in temperatures below 32°F / 0°C:

- ☐ Replace engine oil and oil filter²

Extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use:

- ☐ Replace engine oil and oil filter²

DEALER SERVICE VERIFICATION:

DATE:

MILEAGE:

¹ Inspect sealed transmissions, transfer cases and differentials for signs of leakage. If any leakage from a sealed component is suspected, it is recommended that you have the sealed component inspected by a Toyota dealer. Inspect power steering fluid (if equipped) and brake fluid level/condition. Inspect engine and inverter (if equipped) coolant level/condition/freezing point. Your dealer may recommend services (Dealer-Recommended Maintenance) based on inspection results.

² Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after maintenance at every 5,000 miles.

³ Perform these service items only if you drive primarily under the conditions indicated.

⁴ Including operation on road which has road salt applied.

⁵ Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.

⁶ Not all vehicles are designed for towing. Refer to your Vehicle *Owner's Manual* for details.

MAINTENANCE LOG

20,000 miles or 24 months

- ☐ Add Toyota EFI Tank Additive or equivalent (Hawaii, Puerto Rico and American Samoa only)
- ☐ Check installation of driver's floor mat
- ☐ Inspect and adjust all fluid levels¹
- ☐ Inspect wiper blades
- ☐ Replace cabin air filter
- ☐ Replace engine oil and oil filter²
- ☐ Rotate tires
- ☐ Visually inspect brake linings/drums and brake pads/discs

Additional Maintenance Items for Special Operating Conditions³

Driving on dirt roads or dusty roads:

- ☐ Inspect ball joints and dust covers
- ☐ Inspect drive shaft boots
- ☐ Inspect engine air filter
- ☐ Inspect steering linkage and boots
- ☐ Re-torque propeller shaft bolt⁴ (AWD)
- ☐ Tighten nuts and bolts on chassis and body

Driving while towing, using a car-top carrier, or heavy vehicle loading:⁷

- ☐ Re-torque propeller shaft bolt⁴ (AWD)
- ☐ Tighten nuts and bolts on chassis and body

DEALER SERVICE VERIFICATION:

DATE:

MILEAGE:

25,000 miles or 30 months

- ☐ Add Toyota EFI Tank Additive or equivalent (Hawaii, Puerto Rico and American Samoa only)
- ☐ Check installation of driver's floor mat
- ☐ Inspect and adjust all fluid levels¹
- ☐ Inspect wiper blades
- ☐ Rotate tires
- ☐ Visually inspect brake linings/drums and brake pads/discs

NOTE: If 0W-16 (A25A-FKS engine only) or 0W-20 (2GR-FKS engine only) oil WAS NOT used at the last oil change, replace engine oil and oil filter.²

Additional Maintenance Items for Special Operating Conditions³

Driving on dirt roads or dusty roads:

- ☐ Inspect ball joints and dust covers
- ☐ Inspect drive shaft boots
- ☐ Inspect engine air filter
- ☐ Inspect steering linkage and boots
- ☐ Replace engine oil and oil filter²
- ☐ Re-torque propeller shaft bolt⁴ (AWD)
- ☐ Tighten nuts and bolts on chassis and body

Driving while towing, using a car-top carrier, or heavy vehicle loading:⁷

- ☐ Replace engine oil and oil filter²
- ☐ Re-torque propeller shaft bolt⁴ (AWD)
- ☐ Tighten nuts and bolts on chassis and body

Repeated trips of less than five miles in temperatures below 32°F / 0°C:

- ☐ Replace engine oil and oil filter²

Extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use:

- ☐ Replace engine oil and oil filter²

DEALER SERVICE VERIFICATION:

DATE:

MILEAGE:

30,000 miles or 36 months

- | | |
|---|---|
| <input type="checkbox"/> Add Toyota EFI Tank Additive or equivalent (Hawaii, Puerto Rico and American Samoa only) | <input type="checkbox"/> Replace cabin air filter |
| <input type="checkbox"/> Check installation of driver's floor mat | <input type="checkbox"/> Replace engine air filter |
| <input type="checkbox"/> Inspect and adjust all fluid levels ¹ | <input type="checkbox"/> Replace engine oil and oil filter ² |
| <input type="checkbox"/> Inspect wiper blades | <input type="checkbox"/> Re-torque propeller shaft bolt (AWD) |
| | <input type="checkbox"/> Rotate tires |

Inspect the following:

- | | |
|--|---|
| <input type="checkbox"/> Automatic transmission fluid cooler hoses and connections | <input type="checkbox"/> Exhaust pipes and mountings |
| <input type="checkbox"/> Automatic transmission for signs of leakage | <input type="checkbox"/> Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses |
| <input type="checkbox"/> Ball joints and dust covers | <input type="checkbox"/> Fuel tank cap gasket |
| <input type="checkbox"/> Brake lines and hoses | <input type="checkbox"/> Radiator and condenser |
| <input type="checkbox"/> Brake linings/drums and brake pads/discs ⁵ | <input type="checkbox"/> Rear differential oil (AWD) |
| <input type="checkbox"/> Drive shaft boots | <input type="checkbox"/> Steering gear |
| <input type="checkbox"/> Engine coolant ⁶ | <input type="checkbox"/> Steering linkage and boots |
| | <input type="checkbox"/> Transfer case oil (AWD) |

Additional Maintenance Items for Special Operating Conditions³

Driving on dirt roads or dusty roads:

- ☐ Tighten nuts and bolts on chassis and body

Driving while towing, using a car-top carrier, or heavy vehicle loading:⁷

- ☐ Replace rear differential oil (AWD)
- ☐ Replace transfer case oil (AWD)
- ☐ Tighten nuts and bolts on chassis and body

DEALER SERVICE VERIFICATION:

DATE:

MILEAGE:

¹ Inspect sealed transmissions, transfer cases and differentials for signs of leakage. If any leakage from a sealed component is suspected, it is recommended that you have the sealed component inspected by a Toyota dealer. Inspect power steering fluid (if equipped) and brake fluid level/condition. Inspect engine and inverter (if equipped) coolant level/condition/freezing point. Your dealer may recommend services (Dealer-Recommended Maintenance) based on inspection results.

² Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after maintenance at every 5,000 miles.

³ Perform these service items only if you drive primarily under the conditions indicated.

⁴ Including operation on road which has road salt applied.

⁵ Inspect thickness measurement and disc runout.

⁶ Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.

⁷ Not all vehicles are designed for towing. Refer to your Vehicle *Owner's Manual* for details.