




Lufthansa Technical Training

Training Manual B 747-430

ATA 28 PRACTICAL TRAINING HANDBOOK

WF - B12 -.E./.M.





Lufthansa Technical Training

For training purpose and internal use only.

Copyright by Lufthansa Technical Training GmbH.

All rights reserved. No parts of this training manual may be sold or reproduced in any form without permission of:

Lufthansa Technical Training GmbH

Lufthansa Base Frankfurt

D-60546 Frankfurt/Main

Tel. +49 69 / 696 41 78

Fax +49 69 / 696 63 84

Lufthansa Base Hamburg

Weg beim Jäger 193

D-22335 Hamburg

Tel. +49 40 / 5070 24 13

Fax +49 40 / 5070 47 46

ATA 28 FUEL SYSTEM	1
STUDENT PACED PRACTICAL TRAINING ITEMS	1
B1 M QUALIFICATION	1
STUDENT PACED PRACTICAL TRAINING ITEMS	2
B2 M QUALIFICATION	
NO ITEMS LISTED	2
STUDENT PACED PRACTICAL TRAINING ITEMS	3
B1 E QUALIFICATION	3
STUDENT PACED PRACTICAL TRAINING ITEMS	4
B2 E QUALIFICATION	
NO ITEMS LISTED	4
ATA 28-10 STORAGE	5
COMPONENT INDEX AND LOCATION	5
ATA 28-20 PRESSURE FUELING SYSTEM	39
COMPONENT INDEX AND LOCATION	39
ATA 28-22 ENGINE FUEL FEED SYSTEM	52
COMPONENT INDEX AND LOCATION	52
ATA 28-25 APU FUEL FEED SYSTEM	65
COMPONENT INDEX AND LOCATION	65
ATA 28-26 DEFUELING	72
COMPONENT INDEX AND LOCATION	72
ATA 28-31 FUEL JETTISON SYSTEM	76
COMPONENT INDEX AND LOCATION	76
ATA 28-41 FUEL QUANTITY INDICATION SYSTEM	84
COMPONENT INDEX AND LOCATION	84



Bildverzeichnis

Figure 1	28-10 Storage Component Index (Sheet 1)	6
Figure 2	28-10 Storage Component Index (Sheet 2)	7
Figure 3	28-10 Storage Component Index (Sheet 3)	8
Figure 4	28-10 Storage Component Index (Sheet 4)	9
Figure 5	28-10 Storage Component Index (Sheet 5)	10
Figure 6	28-10 Storage Component Index (Sheet 6)	11
Figure 7	28-10 Storage Component Index (Sheet 7)	12
Figure 8	28-10 Storage Component Index (Sheet 8)	13
Figure 9	28-10 Storage Component Location (Sheet 1)	14
Figure 10	28-10 Storage Component Location (Sheet 2)	15
Figure 11	28-10 Storage Component Location (Sheet 3)	16
Figure 12	28-10 Storage Component Location (Sheet 4)	17
Figure 13	28-10 Storage Component Location (Sheet 5)	18
Figure 14	28-10 Storage Component Location (Sheet 6)	19
Figure 15	28-10 Storage Component Location (Sheet 7)	20
Figure 16	28-10 Storage Component Location (Sheet 8)	21
Figure 17	28-10 Storage Component Location (Sheet 9)	22
Figure 18	28-10 Storage Component Location (Sheet 10)	23
Figure 19	28-10 Storage Component Location (Sheet 11)	24
Figure 20	28-10 Storage Component Location (Sheet 12)	25
Figure 21	28-10 Storage Component Location (Sheet 13)	26
Figure 22	28-10 Storage Component Location (Sheet 14)	27
Figure 23	28-10 Storage Component Location (Sheet 15)	28
Figure 24	28-10 Storage Component Location (Sheet 16)	29
Figure 25	28-10 Storage Component Location (Sheet 17)	30
Figure 26	28-10 Storage Component Location (Sheet 18)	31
Figure 27	28-10 Storage Component location (Sheet 19)	32
Figure 28	28-10 Storage Component Location (Sheet 20)	33
Figure 29	28-10 Storage Component Location (Sheet 21)	34
Figure 30	28-10 Storage Component Location (Sheet 22)	35
Figure 31	28-10 Storage Component Location (Sheet 23)	36
Figure 32	28-10 Storage Component Location (Sheet 24)	37
Figure 33	28-10 Storage Component Location (Sheet 25)	38
Figure 34	28-21 Pressure Fueling System Component Index (Sheet 1)	40
Figure 35	28-21 Pressure Fueling System Component Index (Sheet 2)	41
Figure 36	28-21 Pressure Fueling System Component Index (Sheet 3)	42
Figure 37	28-21 Pressure Fueling System Component Index (Sheet 4)	43
Figure 38	28-21 Pressure Fueling System Component Location (Sheet 1)	44
Figure 39	28-21 Pressure Fueling System Component Location (Sheet 2)	45
Figure 40	28-21 Pressure Fueling System Component Location (Sheet 3)	46
Figure 41	28-21 Pressure Fueling System Component Location (Sheet 4)	47
Figure 42	28-21 Pressure Fueling System Component Location (Sheet 5)	48
Figure 43	28-21 Pressure Fueling System Component Location (Sheet 6)	49
Figure 44	28-21 Pressure Fueling System Component Location (Sheet 7)	50
Figure 45	28-21 Pressure Fueling System Component Location (Sheet 8)	51
Figure 46	28-22 Engine Fuel feed System Component Index (Sheet 1)	53
Figure 47	28-22 Engine Fuel Feed System Component Index (Sheet 2)	54
Figure 48	28-22 Engine Fuel Feed System Component Index (Sheet 3)	55
Figure 49	28-22 Engine Fuel Feed System Component Index (Sheet 4)	56
Figure 50	28-22 Engine Fuel Feed System Component Location (Sheet 5)	57
Figure 51	28-22 Engine Fuel Feed System Component Location (Sheet 1)	58
Figure 52	28-22 Engine Fuel Feed System Component Location (Sheet 2)	59
Figure 53	28-22 Engine Fuel Feed System Component Location (Sheet 3)	60
Figure 54	28-22 Engine Fuel Feed System Component Location (Sheet 4)	61



Bildverzeichnis

Figure 55	28-22 Engine Fuel Feed System Component Location (Sheet 5)	62
Figure 56	28-22 Engine Fuel Feed System Component Location (Sheet 6)	63
Figure 57	28-22 Engine Fuel Feed System Component Location (Sheet 7)	64
Figure 58	28-25 APU Fuel Feed System Component Index (Sheet 1)	66
Figure 59	28-25 APU Fuel Feed System Component Index (Sheet 2)	67
Figure 60	28-25 APU Fuel Feed System Component Location (Sheet 1)	68
Figure 61	28-25 APU Fuel Feed System Component Location (Sheet 2)	69
Figure 62	28-25 APU Fuel Feed System Component Location (Sheet 3)	70
Figure 63	28-25 APU Fuel Feed System Component Location (Sheet 4)	71
Figure 64	28-26 Defueling Component Index (Sheet 1)	73
Figure 65	28-26 Defueling Component Location (Sheet 1)	74
Figure 66	28-26 Defueling Component Location (Sheet 2)	75
Figure 67	28-31 Fuel Jettison System Component Index (Sheet 1)	77
Figure 68	28-31 Fuel Jettison System Component Index (Sheet 2)	78
Figure 69	28-31 Fuel Jettison System Component Index (Sheet 3)	79
Figure 70	28-31 Fuel Jettison System Component Index (Sheet 4)	80
Figure 71	28-31 Fuel Jettison System Component Location (Sheet 1)	81
Figure 72	28-31 Fuel Jettison System Component Location (Sheet 2)	82
Figure 73	28-31 Fuel Jettison System Component Location (Sheet 3)	83



ATA 28 FUEL SYSTEM

STUDENT PACED PRACTICAL TRAINING ITEMS

B1 M QUALIFICATION

ATA 28-10 STORAGE
includes 28-11, 28-13, 28-15, 28-16, 28-17

28-11 FUEL TANKS

- Wing Tanks Fuel Sump Drain Valves
- HST Fuel Sump Drain Valves
- HST Sump Drain Control Panel

28-15 CWT SCAVENGE SYSTEM

- Scavenge Pump

28-16 RES & MAIN TANK TRANSFER

- Reserve Tank Transfer Valves
- Main Tank Transfer Valves

28-17 HST FUEL TRANSFER SYSTEM

- HST Transfer Pump Access
- HST Isolation Valves Access

28-21 PRESSURE FUELING SYSTEM

- Fueling Receptacle
- Manual Fueling Shutoff Valves
- Refuel Valves Access
- VTO Override Switch (FQIS Processor)

28-22 ENGINE FUEL FEED SYSTEM

- Engine Fuel Shutoff Valves (SPAR VALVE)
- Crossfeed Valves
- Main Tank Boost Pumps

28-25 APU FUEL FEED SYSTEM

- APU DC Fuel Boost Pump
- APU Fuel Shutoff Valve

28-26 DEFUELING

- Manual Defueling Valve

28-31 FUEL JETTISON SYSTEM

- CWT Jettison / Override Pumps
- Main Tank Jettison / Override Pumps
- Jettison Transfer Valves
- Jettison Nozzle Valves Access

28-41 FUEL QTY INDICATION SYSTEM

- FQIS Processor
- Fueling Qty Indicators (P42)

28-42 FUEL PRESSURE IND SYSTEM

- Low Pressure Switches (all Fuel Pumps)

28-44 FUEL MEASURING STICKS

- Main Tank Fuel Measuring Sticks
- CWT Fuel Measuring Sticks
- HST Fuel Measuring Sticks

STUDENT PACED PRACTICAL TRAINING ITEMS

B2 M QUALIFICATION
NO ITEMS LISTED



STUDENT PACED PRACTICAL TRAINING ITEMS

B1 E QUALIFICATION

ATA 28-10 STORAGE

includes 28-11, 28-13, 28-15, 28-16, 28-17

28-11 FUEL TANKS

- HST Fuel Sump Drain Valves
- HST Sump Drain Control Panel

28-15 CWT SCAVENGE SYSTEM

- Scavenge Pump

28-16 RES & MAIN TANK TRANSFER

- Reserve Tank Transfer Single Point Sensor Card

28-17 HST FUEL TRANSFER SYSTEM

- HST Transfer Pump Access
- HST Isolation Valves Access
- HST Transfer Single Point Sensor Card

28-21 PRESSURE FUELING SYSTEM

- VTO Adjustment Card (FQIS Processor)
- Relay Card (FQIS Processor)

28-22 ENGINE FUEL FEED SYSTEM

- Fuel System Management Cards
- Fuel System EICAS Interface Cards (Main/Slave)
- Valve Position Logic Cards

28-31 FUEL JETTISON SYSTEM

- Jettison Transfer Valves
- Jettison Nozzle Valves Access
- Fuel Jettison Control Cards (A / B)
- Main Tank Transfer Single Point Sensor Card

28-41 FUEL QTY INDICATION SYSTEM

- Fueling Qty Indicators (P42)
- FQIS Processor
 - Individual Fuel Qty Channels
 - Input / Output Cards
- Remote Electronics Unit (REU)

28-42 FUEL PRESSURE IND SYSTEM

- Low Pressure Switches (all Fuel Pumps)

28-43 FUEL TEMP INDICATION SYSTEM

- Fuel Temperature Bulb

STUDENT PACED PRACTICAL TRAINING ITEMS

B2 E QUALIFICATION
NO ITEMS LISTED



ATA 28-10 STORAGE

COMPONENT INDEX AND LOCATION

STORAGE

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - VALVE, INBD NO. 2 RESERVE TANK TRANSFER (2A), V432	17	1	L REAR SPAR TO TRAILING EDGE	28-16-01
ACTUATOR - VALVE, INBD NO. 3 RESERVE TANK TRANSFER (3A), V430	17	1	R REAR SPAR TO TRAILING EDGE	28-16-01
ACTUATOR - VALVE L HORIZONTAL STABILIZER FORWARD ISOLATION, V439	21	1	L WING LANDING GEAR WELL	28-17-01
ACTUATOR - VALVE, L (UPPER) HORIZONTAL STABILIZER AFT ISOLATION, V435	21	1	315A, AREA AFT OF STABILIZER BOX COMPARTMENT	28-17-01
ACTUATOR - VALVE, R (LOWER) HORIZONTAL STABILIZER AFT ISOLATION, V436	21	1	315A, AREA AFT OF STABILIZER BOX COMPARTMENT	28-17-01
ACTUATOR - VALVE, NO. 1 MAIN TANK TRANSFER, V55	17	1	573AB, L REAR SPAR TO INBD AILERON LEADING EDGE	28-16-04
ACTUATOR - VALVE, NO. 4 MAIN TANK TRANSFER, V50	17	1	673AB, R REAR SPAR TO INBD AILERON LEADING EDGE	28-16-04
ACTUATOR - VALVE, OUTBD NO. 2 RESERVE TANK TRANSFER (2B), V433	17	1	L REAR SPAR TO TRAILING EDGE	28-16-01
ACTUATOR - VALVE, OUTBD NO. 3 RESERVE TANK TRANSFER (3B), V431	17	1	R REAR SPAR TO TRAILING EDGE	28-16-01
ACTUATOR - VALVE, R HORIZONTAL STABILIZER FORWARD ISOLATION, V440	21	1	R WING LANDING GEAR WELL	28-17-01
ADAPTER - VALVE, NO. 1 MAIN TANK TRANSFER	17	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK, 573AB, L REAR SPAR TO INBD AILERON LEADING EDGE	28-16-06
ADAPTER - VALVE, NO. 4 MAIN TANK TRANSFER	17	1	645BB, R MIDSPAR TO REAR SPAR INBD MAIN TANK, 673AB, R REAR SPAR INBD AILERON LEADING EDGE	28-16-06
ADAPTER - VALVE (2A), INBD NO. 2 RESERVE TANK TRANSFER	17	1	552GB, L FRONT SPAR TO REAR SPAR RESERVE TANK, L REAR SPAR TO TRAILING EDGE	28-16-03
ADAPTER - VALVE (2B), OUTBD NO. 2 RESERVE TANK TRANSFER	17	1	552GB, L FRONT SPAR TO REAR SPAR RESERVE TANK, L REAR SPAR TO TRAILING EDGE	28-16-03
ADAPTER - VALVE (3A), INBD NO. 3 RESERVE TANK TRANSFER	17	1	652GB, R FRONT SPAR TO REAR SPAR RESERVE TANK, R REAR SPAR TO TRAILING EDGE	28-16-03
ADAPTER - VALVE (3B), OUTBD NO. 3 RESERVE TANK TRANSFER	17	1	652GB, R FRONT SPAR TO REAR SPAR RESERVE TANK, R REAR SPAR TO TRAILING EDGE	28-16-03
ARRESTER - FLAME, HORIZONTAL STABILIZER SURGE TANK	15	1	361AB, R HORIZONTAL STABILIZER SURGE TANK	28-13-1 1
ARRESTER - FLAME, L WING SURGE TANK	15	1	556AB, L FRONT SPAR TO REAR SPAR DRY BAY	28-13-09
ARRESTER - FLAME, R WING SURGE TANK	15	1	656AB, R FRONT SPAR TO REAR SPAR DRY BAY	28-13-09
ASSEMBLY - ADAPTER/SHAFT, LEFT HORIZONTAL STABILIZER FORWARD ISOLATION VALVE	21	1	131AZ, 131BZ, 131CZ, 131DZ, L CENTER SECTION WING BOX, L WING LANDING GEAR WELL	28-17-03
ASSEMBLY - ADAPTER/SHAFT, R (LOWER) HORIZONTAL STABILIZER AFT ISOLATION VALVE	21	1	315A, R STABILIZER TORSION BOX COMPARTMENT, R HORIZONTAL STABILIZER TORSION BOX	28-17-03

Storage - Component Index

Figure 101 (Sheet 1)

580550

Figure 1 28-10 Storage Component Index (Sheet 1)



COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ASSEMBLY - ADAPTER/SHAFT, R HORIZONTAL STABILIZER FORWARD ISOLATION VALVE	21	1	131AZ,131BZ,132AZ,132BZ, CENTER SECTION WING BOX, WING LANDING GEAR WELL	28-17-03
ASSEMBLY - ADAPTER/SHAFT UPPER HORIZONTAL STABILIZER AFT ISOLATION VALVE	21	1	315A, STABILIZER TORSION BOX COMPARTMENT, HORIZONTAL STABILIZER TORSION BOX	28-17-03
ASSEMBLY - INLET/SCREEN, SCAVENGE PUMP	17	1	131AZ,131BZ, L CENTER SECTION WING BOX	28-15-05
BODY - VALVE (2A), INBD NO. 2 RESERVE TANK TRANSFER, V432	17	1	552GB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-16-02
BODY - VALVE (3A), INBD NO. 3 RESERVE TANK TRANSFER, V430	17	1	652GB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-16-02
BODY - VALVE, L HORIZONTAL STABILIZER FORWARD ISOLATION, V439	21	1	131AZ,131BZ,131CZ,131CZ, L CENTER SECTION WING BOX	28-17-02
BODY - VALVE, LOWER HORIZONTAL STABILIZER AFT ISOLATION, V436	21	1	L HORIZONTAL STABILIZER FUEL TANK	28-17-02
BODY - VALVE, NO. 1 MAIN TANK TRANSFER, V55	17	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK, 646AB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-16-05
BODY - VALVE, NO. 4 MAIN TANK TRANSFER, V50	17	1	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK, 646AB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-16-05
BODY - VALVE (2B), OUTBD NO. 2 RESERVE TANK TRANSFER, V433	17	1	552GB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-16-02
BODY - VALVE (3B), OUTBD NO. 3 RESERVE TANK TRANSFER, V431	17	1	652GB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-16-02
BODY - VALVE, R HORIZONTAL STABILIZER FORWARD ISOLATION, V440	21	1	131AZ,131BZ,132AZ,132BZ CENTER SECTION WING BOX	28-17-02
BODY - VALVE, UPPER HORIZONTAL STABILIZER AFT ISOLATION, V435	21	1	L HORIZONTAL STABILIZER FUEL TANK	28-17-02
CARD - FUEL JETTISON CONTROL A, Y5BA7		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL JETTISON CONTROL B, Y5BA8		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM EICAS INTERFACE - MAIN, Y5BA14		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM EICAS INTERFACE - SLAVE, Y5BA15		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARDS - (28-22-00/101)				
FUEL SYSTEM MANAGEMENT A, Y5BA5		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
FUEL SYSTEM MANAGEMENT B, Y5BA10		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - HORIZONTAL STABILIZER SINGLE TRANSFER SINGLE POINT SENSOR CONTROL, Y5BA3		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-17-10

* SEE THE WDM EQUIPMENT LIST

Storage - Component Index
Figure 101 (Sheet 2)

Figure 2 28-10 Storage Component Index (Sheet 2)

580733



Lufthansa
TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CARD - RESERVE TANK SINGLE POINT SENSOR CONTROL, Y5BA2		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-16-08
CARD - (REF 28-22-00, FIG. 101)				
VALVE POSITION LOGIC 1, Y5BA6		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	
VALVE POSITION LOGIC 2, Y5BA9		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	
VALVE POSITION LOGIC 3, Y5BA11		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	
VALVE POSITION LOGIC 4, Y5BA12		1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	
CIRCUIT BREAKERS -			FLT COMPT, P6,P7	
FUEL SYS MGMT CH 1, C10129		1	6F6	
FUEL SYS MGMT CH 2, C10130		1	6F8	
FUEL XFR VALVE MAIN 1, C83		1	7H21	
FUEL XFR VALVE MAIN 4, C1080		1	7H24	
FUEL XFR VALVE RES 2A & 3A, C1968		1	7H22	
FUEL XFR VALVE RES 2B & 3B, C1967		1	7H23	
REFUEL & XFR STAB L, C10125		1	7H25	
REFUEL & XFR STAB R, C10126		1	7H26	
CIRCUIT BREAKERS -			P85	
HORIZ STAB BOOST PUMP ARFT, C3142		1	85 N/A	
HORIZ STAB BOOST PUMP FWD, C3141		1	85 N/A	
CIRCUIT BREAKERS -			117AL, MAIN EQUIP CTR, P180,P414	
SCAV PUMP CONT, C292		1	180H2	
SCAVENGE PUMP, C922		1	414M2	
DOOR - ACCESS, HORIZONTAL STABILIZER TANK	1	1	312A, L AREA AFT OF PRESSURE BULKHEAD	28-11-19
DOOR - ACCESS, INBD HORIZONTAL STABILIZER SURGE TANK	2	1	R HORIZONTAL STABILIZER SURGE TANK	28-11-20
DOOR - ACCESS, L CENTER WING TANK	1	1	131EZ, L FORWARD LOWER HALF WING TO BODY FAIRING	28-11-01
DOOR - ACCESS, L WING RESERVE AND MAIN TANK	1	22	544AB,545AB,545BB,546AB,546BB, 552AB,552BB,552CB,552DB,552EB, 552FB,552GB,553AB,553BB,553CB, 553DB,553EB,553FB,553GB,553HB, 553JB,553KB, L WING	28-11-02
DOOR - ACCESS, L WING SURGE TANK	2	2	555AB,555BB, L FRONT SPAR TO REAR SPAR SURGE TANK	28-11-03
DOOR - ACCESS, R CENTER WING TANK	1	1	132CZ, R FORWARD LOWER HALF WING TO BODY FAIRING	28-11-01
DOOR - ACCESS, R WING RESERVE AND MAIN TANK	1	22	644AB,645AB,645BB,646AB,646BB, 652AB,652BB,652CB,652DB,652EB, 652FB,652GB,653AB,653BB,653CB, 653DB,653EB,653FB,653GB,653HB, 653JB,653KB	28-11-02

Storage - Component Index

Figure 101 (Sheet 3)

580761

Figure 3 28-10 Storage Component Index (Sheet 3)



Lufthansa
TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
DOOR - ACCESS, R WING SURGE TANK	2	2	655AB,655BB, R FRONT SPAR TO REAR SPAR SURGE TANK	28-11-03
DOOR - ACCESS, SPANWISE BEAM MIDSPAR	1	2	131CZ,132AZ, CENTER SECTION WING BOX	28-11-09
DOOR - ACCESS, SPANWISE BEAM NO. 1	1	2	131DZ,132BZ, CENTER SECTION WING BOX	28-11-09
DOOR - ACCESS, SPANWISE BEAM NO. 2	1	1	131BZ, L CENTER SECTION WING BOX	28-11-09
DOOR - ACCESS, SPANWISE BEAM NO. 3	1	1	131AZ, L CENTER SECTION WING BOX	28-11-09
DOOR - ACCESS, OUTBD HORIZONTAL STABILIZER SURGE TANK	1	1	343JZ, R HORIZONTAL STABILIZER SURGE TANK	28-11-20
DOOR - PURGE, CENTER WING TANK	9	1	R WING LANDING GEAR WELL	28-11-06
FILE - FUEL SYSTEM CARD, M7852			117AL, MAIN EQUIP CTR	*
HOUSING - PUMP, LOWER HORIZONTAL STABILIZER TANK FUEL TRANSFER		1	R HORIZONTAL STABILIZER TORSION BOX	28-17-05
HOUSING - PUMP, UPPER HORIZONTAL STABILIZER TANK FUEL TRANSFER		1	R HORIZONTAL STABILIZER TORSION BOX	28-17-05
LINE - AFT HORIZONTAL STABILIZER TANK FUEL TRANSFER		1	315A, R AREA AFT OF STABILIZER BOX COMPARTMENT	28-17-06
LINE - FORWARD HORIZONTAL STABILIZER TANK FUEL TRANSFER		1	312A, L AREA AFT OF PRESSURE BULKHEAD, R CENTER SECTION WING BOX	28-17-06
LINE - MID HORIZONTAL STABILIZER TANK FUEL TRANSFER		1	312A, L AREA AFT OF PRESSURE BULKHEAD, 315A, R AREA AFT OF STABILIZER BOX COMPARTMENT, R STABILIZER TORSION BOX COMPARTMENT	28-17-06
LINE - SCAVENGE SYSTEM FUEL		1	131AZ,131BZ,131CZ,131DZ, L CENTER SECTION WING BOX	28-15-03
MODULE - MISCELLANEOUS DEFUEL, M6599	25	1	FLT COMPT, P461	*
MODULE - (REF 26-11-00, FIG. 101)				
MISCELLANEOUS SWITCHING, M7317				
POPPET - PRIMARY, HORIZONTAL STABILIZER DRIP PAN DRAIN VALVE	4	1	R AREA AFT OF PRESSURE BULKHEAD	28-11-04
POPPET - PRIMARY, HORIZONTAL STABILIZER SURGE TANK FUEL SUMP DRAIN VALVE	4	1	R HORIZONTAL STABILIZER SURGE TANK	28-11-04
POPPET - PRIMARY, L CENTER WING TANK FUEL SUMP DRAIN VALVE	4	1	191GL, L CENTER SECTION WING BOX	28-11-04
POPPET - PRIMARY, L WING SURGE TANK FUEL SUMP DRAIN VALVE	4	1	L FRONT SPAR TO REAR SPAR SURGE TANK	28-11-04
POPPET - PRIMARY, NO. 1 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	L MID SPAR TO REAR SPAR INBD MAIN TANK	28-11-04
POPPET - PRIMARY, NO. 2 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-04
POPPET - PRIMARY, NO. 2 RESERVE TANK FUEL SUMP DRAIN VALVE	5	1	L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-11-04
POPPET - PRIMARY, NO. 3 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-04
POPPET - PRIMARY, NO. 3 RESERVE TANK FUEL SUMP DRAIN VALVE	5	1	R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-11-04
POPPET - PRIMARY, NO. 4 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	R MID SPAR TO REAR SPAR INBD MAIN TANK	28-11-04
POPPET - PRIMARY, R CENTER WING TANK FUEL SUMP DRAIN VALVE	4	1	192GR, R CENTER SECTION WING BOX	28-11-04

* SEE WDM EQUIPMENT LIST

Storage - Component Index

Figure 101 (Sheet 4)

Figure 4 28-10 Storage Component Index (Sheet 4)

580764


Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
POPPET - PRIMARY, R WING SURGE TANK FUEL SUMP DRAIN VALVE	4	1	R FRONT SPAR TO REAR SPAR SURGE TANK	28-11-04
POPPET - SECONDARY, HORIZONTAL STABILIZER DRIP PAN DRAIN VALVE	4	1	312A, L AREA AFT OF PRESSURE BULKHEAD	28-11-07
POPPET - SECONDARY, HORIZONTAL STABILIZER SURGE TANK FUEL SUMP DRAIN VALVE	4	1	338AZ, R HORIZONTAL STABILIZER SURGE TANK	28-11-07
POPPET - SECONDARY, L CENTER WING TANK FUEL SUMP DRAIN VALVE	4	1	131EZ, L CENTER SECTION WING BOX	28-11-07
POPPET - SECONDARY, L WING SURGE TANK FUEL SUMP DRAIN VALVE	4	1	555AB, L FRONT SPAR TO REAR SPAR SURGE TANK	28-11-07
POPPET - SECONDARY, NO. 1 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-11-07
POPPET - SECONDARY, NO. 2 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	544AB, L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-07
POPPET - SECONDARY, NO. 2 RESERVE TANK FUEL SUMP DRAIN VALVE	5	1	552DB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-11-07
POPPET - SECONDARY, NO. 3 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	644AB, R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-07
POPPET - SECONDARY, NO. 3 RESERVE TANK FUEL SUMP DRAIN VALVE	5	1	652DB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-11-07
POPPET - SECONDARY, NO. 4 MAIN TANK FUEL SUMP DRAIN VALVE	5	1	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-11-07
POPPET - SECONDARY, R CENTER WING TANK FUEL SUMP DRAIN VALVE	4	1	131E2, L CENTER SECTION WING BOX	28-11-07
POPPET - SECONDARY, R WING SURGE TANK FUEL SUMP	4	1	655AB, R FRONT SPAR TO REAR SPAR SURGE TANK	28-11-07
PORT - NO. 1 MAIN TANK OVERWING FILL	9	1	546BB, L FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-11-05
PORT - NO. 2 MAIN TANK OVERWING FILL	9	1	544AB, L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-05
PORT - NO. 3 MAIN TANK OVERWING FILL	9	1	655AB, R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-05
PORT - NO. 4 MAIN TANK OVERWING FILL	9	1	646BB, R FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-11-05
PUMP - FUEL SCAVENGE, M810	18	1	131AZ,131BZ,131CZ,131DZ, L CENTER SECTION WING BOX	28-15-00
RECEIVER - SCAVENGE PUMP		1		28-15-02
RELAY - (REF 31-01-36, FIG. 101) MAIN TANK 1 JETTISON TRANSFER VALVE CONTROL, R7388 RESERVE TANK TRANSFER VALVE CONTROL A, R7389 RESERVE TANK TRANSFER VALVE CONTROL B, R7390 SCAVENGE PUMP, R296	18	1	131AZ,131BZ, L CENTER SECTION WING BOX	28-17-09
RELAY - (REF 31-01-39, FIG. 101) MAIN TANK 4 JETTISON TRANSFER VALVE CONTROL, R7387				
SENSOR - FUEL QUANTITY SINGLE POINT		2		
SENSOR - RESERVE TANK TRANSFER SINGLE POINT		2		
SWITCH - FUEL TRANSFER MAIN 1 AND 4, S5		1		
SWITCH - SCAVENGE PUMP PRESSURE		1	FLT COMPT, P5, MISC SWITCH PANEL, M7317	*

* SEE WDM EQUIPMENT LIST

Storage - Component Index
Figure 101 (Sheet 5)

580797

Figure 5 28-10 Storage Component Index (Sheet 5)


Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
TUBE - FUEL VENT, L WING SURGE TANK		1	556AB,556BB, L FRONT SPAR TO REAR SPAR SURGE TANK AND DRY BAY	28-13-03
TUBE - FUEL VENT, R WING SURGE TANK		1	656AB,656BB, R FRONT SPAR TO REAR SPAR SURGE TANK AND DRY BAY	28-13-03
UNIT - CENTER EFIS/EICAS INDICATION, M7352		1	E2-6	31-61-01
UNIT - L EFIS/EICAS INDICATION, M7353		1	E2-6	31-61-01
UNIT - MOTOR/IMPELLER, L HORIZONTAL STABILIZER TANK TRANSFER PUMP, M7862		1	312A, R AREA AFT OF PRESSURE BULKHEAD	28-17-04
UNIT - MOTOR/IMPELLER, R HORIZONTAL STABILIZER TANK TRANSFER PUMP, M7863		1	312A, R AREA AFT OF PRESSURE BULKHEAD	28-17-04
UNIT - MOTOR/IMPELLER, SCAVENGE PUMP, M818		1	L WING LANDING GEAR WELL	28-15-01
UNIT - R EFIS/EICAS INDICATION, M7351		1	E2-6	31-61-01
VALVE - CHECK, HORIZONTAL STABILIZER SURGE TANK DRAIN		1	R HORIZONTAL STABILIZER FUEL TANK	28-13-12
VALVE - CHECK, L WING SURGE TANK DRAIN	15	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-04
VALVE - CHECK, R WING SURGE TANK DRAIN	15	1	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-04
VALVE - CHECK, SCAVENGE DISCHARGE LINE		1	131AZ,131BZ,131CZ,131DZ, L CENTER SECTION WING BOX	28-15-04
VALVE - DRAIN, HORIZONTAL STABILIZER SURGE TANK FUEL SUMP	14	1	361AB, R HORIZONTAL STABILIZER SURGE TANK	28-11-10
VALVE - DRAIN, INBD NO. 1 MAIN TANK FUEL VENT	14	1	546AB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-11-21
VALVE - DRAIN, INBD NO. 2 MAIN TANK FUEL VENT	14	1	544AB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-01
VALVE - DRAIN, INBD NO. 3 MAIN TANK FUEL VENT	14	1	644AB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-01
VALVE - DRAIN, INBD NO. 4 MAIN TANK FUEL VENT	14	1	646AB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-01
VALVE - DRAIN, L CENTER WING TANK FUEL SUMP	14	1	131EZ,131AZ, L CENTER SECTION WING BOX	28-13-01
VALVE - DRAIN, L CENTER WING TANK FUEL VENT	14	1	131EZ,131AZ,131BZ,131CZ, L CENTER SECTION WING BOX	28-13-01
VALVE - DRAIN, L HORIZONTAL STABILIZER TANK FUEL SUMP, V441	14	1	312A, L HORIZONTAL STABILIZER TORSION BOX COMPARTMENT	28-11-10
VALVE - DRAIN, L HORIZONTAL STABILIZER TANK FUEL VENT	14	1	338A2, L HORIZONTAL STABILIZER TORSION BOX	28-13-01
VALVE - DRAIN, L WING SURGE TANK FUEL SUMP	14	1	555AB, L FRONT SPAR TO REAR SPAR SURGE TANK	28-11-10
VALVE - DRAIN, MID NO. 1 MAIN TANK FUEL VENT	14	1	552AB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-01
VALVE - DRAIN, MID NO. 4 MAIN TANK FUEL VENT	14	1	652AB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-01
VALVE - DRAIN, NO. 1 MAIN TANK FUEL SUMP	14	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-11-10
VALVE - DRAIN, NO. 2 MAIN TANK FUEL SUMP	14	1	544AB, L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-10
VALVE - DRAIN, NO. 2 RESERVE TANK FUEL SUMP	14	1	552DB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-11-10
VALVE - DRAIN, NO. 2 RESERVE TANK FUEL VENT	14	1	553AB, L FRONT SPAR TO REAR SPAR RESERVE TANK	28-13-01
VALVE - DRAIN, NO. 3 MAIN TANK FUEL SUMP	14	1	644AB, R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-11-10

Storage - Component Index

Figure 101 (Sheet 6)

580804

Figure 6 28-10 Storage Component Index (Sheet 6)



Lufthansa
TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
VALVE - DRAIN, NO. 3 RESERVE TANK FUEL SUMP	14	1	652DB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-11-10
VALVE - DRAIN, NO. 3 RESERVE TANK FUEL VENT	14	1	653AB, R FRONT SPAR TO REAR SPAR RESERVE TANK	28-13-01
VALVE - DRAIN, NO. 4 MAIN TANK FUEL SUMP	14	1	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-11-10
VALVE - DRAIN, OUTBD NO. 1 MAIN TANK FUEL VENT	14	1	552FB, 552GB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-01
VALVE - DRAIN, OUTBD NO. 2 MAIN TANK FUEL VENT	14	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-01
VALVE - DRAIN, OUTBD NO. 3 MAIN TANK FUEL VENT	14	1	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-01
VALVE - DRAIN, OUTBD NO. 4 MAIN TANK FUEL VENT	14	1	652FB, 652GB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-01
VALVE - DRAIN, R CENTER WING TANK FUEL SUMP	14	1	131EZ, 131AZ, CENTER SECTION WING BOX	28-11-10
VALVE - DRAIN, R CENTER WING TANK FUEL VENT	14	1	131EZ, 131AZ, 131BZ, 132AZ, 132BZ CENTER SECTION WING BOX	28-13-01
VALVE - DRAIN, R HORIZONTAL STABILIZER TANK FUEL SUMP, V463	14	1	312A, R STABILIZER TORSION BOX COMPARTMENT	28-11-21
VALVE - DRAIN, R HORIZONTAL STABILIZER TANK FUEL VENT	14	1	338AZ, R HORIZONTAL STABILIZER TORSION BOX	28-13-01
VALVE - DRAIN, R WING SURGE TANK	14	1	655AB, R FRONT SPAR TO REAR SPAR SURGE TANK	28-11-10
VALVE - FLOAT, HORIZONTAL STABILIZER FUEL VENT CHANNEL	14	1	343JZ, R HORIZONTAL STABILIZER FUEL TANK	28-13-02
VALVE - FLOAT, HORIZONTAL STABILIZER TANK	14	1	338AZ, L HORIZONTAL STABILIZER FUEL TANK	28-13-13
VALVE - FLOAT, L CENTER WING TANK FUEL VENT	14	1	131EZ, 131AZ, 131BZ, 131CZ, L CENTER SECTION WING BOX	28-13-02
VALVE - FLOAT, NO. 2 MAIN TANK FUEL VENT	14	2	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-02
VALVE - FLOAT, NO. 2 RESERVE TANK FUEL VENT	14	1	553KB, L FRONT SPAR TO REAR SPAR RESERVE TANK	28-13-02
VALVE - FLOAT, NO. 3 MAIN TANK FUEL VENT	14	2	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-13-02
VALVE - FLOAT, NO. 3 RESERVE TANK FUEL VENT	14	1	653KB, R FRONT SPAR TO REAR SPAR RESERVE TANK	28-13-02
VALVE - FLOAT, MID NO. 1 MAIN TANK FUEL VENT	14	2	552AB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-02
VALVE - FLOAT, MID NO. 4 MAIN TANK FUEL VENT	14	2	652AB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-02
VALVE - FLOAT, OUTBD NO. 1 MAIN TANK FUEL VENT	14	2	552GB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-02
VALVE - FLOAT, OUTBD NO. 4 MAIN TANK FUEL VENT	14	2	652GB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-13-02
VALVE - PITOT FLOAT	21	2	131AZ, 131BZ, 132AZ, CENTER SECTION WING BOX	28-17-08
VALVE - PRESSURE RELIEF, HORIZONTAL STABILIZER SURGE TANK	3	1	361BB, R HORIZONTAL STABILIZER SURGE TANK	28-13-10
VALVE - PRESSURE RELIEF, L WING SURGE TANK	2	1	555AB, L FRONT SPAR TO REAR SPAR SURGE TANK	28-13-05
VALVE - PRESSURE RELIEF, R WING SURGE TANK	2	1	655AB, R FRONT SPAR TO REAR SPAR SURGE TANK	28-13-05

Storage - Component Index

Figure 101 (Sheet 7)

580853

Figure 7 28-10 Storage Component Index (Sheet 7)



COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
VALVE - REFUEL, L CENTER WING TANK SECONDARY	21	1	131AZ,131BZ,131CZ,131DZ, L CENTER SECTION WING BOX	28-17-07
VALVE - REFUEL, R CENTER WING TANK SECONDARY	21	1	131AZ,131BZ,132AZ,132BZ, R CENTER SECTION WING BOX	28-17-07


Storage - Component Index
Figure 101 (Sheet 8)

Figure 8 28-10 Storage Component Index (Sheet 8)

580857




Lufthansa
TECHNISCHE SCHULUNG



Storage - Component Location
Figure 102 (Sheet 1)

Figure 9 28-10 Storage Component Location (Sheet 1)

719008




Storage - Component Location

Figure 102 (Sheet 2)

Figure 10 28-10 Storage Component Location (Sheet 2)


580926



Storage - Component Location (Details from Sheet 1)
Figure 102 (Sheet 3)

580932


Figure 11 28-10 Storage Component Location (Sheet 3)



Storage - Component Location
Figure 102 (Sheet 4)

Figure 12 28-10 Storage Component Location (Sheet 4)


580935



Storage - Component Location
Figure 102 (Sheet 5)

580940

Figure 13 28-10 Storage Component Location (Sheet 5)





Storage - Component Location
Figure 102 (Sheet 6)

Figure 14 28-10 Storage Component Location (Sheet 6)

580948



Lufthansa
TECHNISCHE SCHULUNG




P211, STABILIZER FUEL SUMP DRAIN PANEL (K)

Storage - Component Location
Figure 102 (Sheet 7)

581295


Figure 15 28-10 Storage Component Location (Sheet 7)



Storage - Compartment Location
Figure 102 (Sheet 8)

Figure 16 28-10 Storage Component Location (Sheet 8)


581297



Storage - Component Location
Figure 102 (Sheet 9)

581299

Figure 17 28-10 Storage Component Location (Sheet 9)




Storage - Component Location
Figure 102 (Sheet 10)

Figure 18 28-10 Storage Component Location (Sheet 10)


719040



Lufthansa
TECHNISCHE SCHULUNG



LEFT OR RIGHT SURGE TANK AND WING TIP DRY BAY



NO. 2 OR NO. 3 RESERVE TANK




Storage - Component Location (Details from Sht 10)
Figure 102 (Sheet 11)

581310

Figure 19 28-10 Storage Component Location (Sheet 11)






Storage - Component Location
Figure 102 (Sheet 12)

Figure 20 28-10 Storage Component Location (Sheet 12)

581319



Lufthansa
TECHNISCHE SCHULUNG




Storage - Component Location (Details From Sht 10)

Figure 102 (Sheet 13)


581325

Figure 21 28-10 Storage Component Location (Sheet 13)




FUEL VENT FLOAT VALVE

(V) FROM SHT 10,11,12, AND 13



FUEL VENT CHANNEL FLOAT VALVE
(INSTALLED IN HORIZONTAL
STABILIZER TANK)

(X) FROM SHT 10



FUEL VENT DRAIN VALVE

(W) FROM SHT 10,11,12 AND 13


Storage - Component Location
Figure 102 (Sheet 14)

Figure 22 28-10 Storage Component Location (Sheet 14)

581327




Lufthansa
TECHNISCHE SCHULUNG



Storage - Component Location
Figure 102 (Sheet 15)

719054

Figure 23 28-10 Storage Component Location (Sheet 15)



Storage - Component Location (Details from Sht 10)


Figure 102 (Sheet 16)

719071

Figure 24 28-10 Storage Component Location (Sheet 16)



Lufthansa
TECHNISCHE SCHULUNG




Storage - Component Location

Figure 102 (Sheet 17)

581340

Figure 25 28-10 Storage Component Location (Sheet 17)
Lufthansa
 TECHNISCHE SCHULUNG




Storage - Component Location (Details from Sht 17)
Figure 102 (Sheet 18)

Figure 26 28-10 Storage Component Location (Sheet 18)

581343





Lufthansa
TECHNISCHE SCHULUNG



Storage - Component Location (Detail from Sht 17)
Figure 102 (Sheet 19)

581346

Figure 27 28-10 Storage Component location (Sheet 19)




Storage - Component Location (Details from Sht 17)

Figure 102 (Sheet 20)

581348

Figure 28 28-10 Storage Component Location (Sheet 20)
Lufthansa
 TECHNISCHE SCHULUNG




Storage - Component Location

Figure 102 (Sheet 21)

Figure 29 28-10 Storage Component Location (Sheet 21)

719086


Lufthansa
 TECHNISCHE SCHULUNG




Storage - Component Location (Details from Sht 21)

Figure 102 (Sheet 22)

Figure 30 28-10 Storage Component Location (Sheet 22)

581357



Lufthansa
 TECHNISCHE SCHULUNG



Storage - Component Location (Details from Sht 21)
Figure 102 (Sheet 23)

581360

Figure 31 28-10 Storage Component Location (Sheet 23)





HORIZONTAL STABILIZER AFT ISOLATION VALVE



Storage - Component Location (Detail from Sht 23)
Figure 102 (Sheet 24)


Figure 32 28-10 Storage Component Location (Sheet 24)

581363



MISCELLANEOUS SWITCHING MODULE, M7317 (REF)

(AS)



MISCELLANEOUS DEFUEL MODULE, M6599

(AT)

Storage - Component Location
Figure 102 (Sheet 25)

Figure 33 28-10 Storage Component Location (Sheet 25)

581365



ATA 28-20 PRESSURE FUELING SYSTEM

COMPONENT INDEX AND LOCATION

PRESSURE FUELING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ADAPTER - LEFT WING FUELING RECEPTACLE		2	521BB, LEFT LEADING EDGE TO FRONT SPAR	28-21-14
ADAPTER - RIGHT WING FUELING RECEPTACLE		2	621BB, RIGHT LEADING EDGE TO FRONT SPAR	28-21-14
CARD - FUEL JETTISON CONTROL A, A12		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL JETTISON CONTROL B, A13		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM EICAS INTERFACE MAIN, A10		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM EICAS INTERFACE SLAVE, A11		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM MANAGEMENT A, A1		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	28-22-13
CARD - FUEL SYSTEM MANAGEMENT B, A2		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	28-22-13
CARD - VALVE POSITION LOGIC 1, A6		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	28-22-14
CARD - VALVE POSITION LOGIC 2, A7		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	28-22-14
CARD - VALVE POSITION LOGIC 3, A8		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	28-22-14
CARD - VALVE POSITION LOGIC 4, A9		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	28-22-14
CIRCUIT BREAKERS - FUEL QTY 1, C10123		1	FLT COMPT, P6	
FUEL QTY 2, C10124		1	6D5	
CIRCUIT BREAKERS - REFUEL & XFR STAB L, C10125		1	6D6	
REFUEL & XFR STAB R, C10126		1	FLT COMPT, P7	
CIRCUIT BREAKERS - FUELING LIGHTS HOT OR FUELING PWR-HOT BAT, C1143		1	7H25	
FUELING LTS PANEL, C10746		1	7H26	
FUELING LTS RECP, C10747		1	117AL, MAIN EQUIP CTR, P180	
FUELING VALVE 2, C86		1	180B2 OR 180M9	
CIRCUIT BREAKERS - LIGHT FUELING OR FUELING PWR, C1142		1	180C25	
FUELING VALVE, C90		1	180C25	
CIRCUIT BREAKER - FUEL OVERFILL CONT, C62		1	180B1 OR 180M8	
FILE, FUEL SYSTEM CARD, M7852		1	117AL, MAIN EQUIP CTR, P414	
		1	414F22	
		1	414F17	
		1	117AL, MAIN EQUIP CTR, P415	
		1	415M14	
		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE	

* SEE THE WDM EQUIPMENT LIST

 IF INSTALLED

Pressure Fueling System - Component Index

Figure 101 (Sheet 1)

a39033

Figure 34 28-21 Pressure Fueling System Component Index (Sheet 1)**Lufthansa**

TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
LIGHT - CENTER WING LEFT FUELING VALVE, L72	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - CENTER WING RIGHT FUELING VALVE, L73	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - FUELING FLOOD PANEL, L67	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - HORIZONTAL STABILIZER FUELING VALVE, L3597	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - HORIZONTAL STABILIZER ISOLATION VALVE, L3600	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - HORIZONTAL STABILIZER POSITION, L3569	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - HORIZONTAL STABILIZER POSITION INDICATOR, (YVXL1)	8	1	FLIGHT DECK FUELING CONTROL PANEL, M5	*
LIGHT - LEFT SECONDARY TEST, L3598	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - M1 FUELING VALVE, L69	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - M2 INBD FUELING VALVE, L71	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - M2 OUTBD FUELING VALVE, L70	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - M3 INBD PRESSURE FUELING VALVE, L74	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - M3 OUTBD PRESSURE FUELING VALVE, L75	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - M4 PRESSURE FUELING VALVE, L76	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - OVERFILL INDICATOR, L3595	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - REFUEL FLOOD, L1149	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - RESERVE 2 FUELING VALVE, L2202	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - RESERVE 3 FUELING VALVE, L2203	7	1	REFUEL CNT PANEL, P42, L WING	*
LIGHT - RIGHT SECONDARY TEST, L3599	7	1	REFUEL CNT PANEL, P42, L WING	*
MODULE - FUEL MANAGEMENT CONTROL, M154		1	FLT COMPT, P5	*
PUMP - LEFT HORIZONTAL STABILIZER, M7862		1		
PUMP - RIGHT HORIZONTAL STABILIZER, M7863		1		
RECEPTACLE - LEFT WING FUELING	2	2	521BB, LEFT LEADING EDGE TO FRONT SPAR	28-21-01
RECEPTACLE - RIGHT WING FUELING	2	2	621BB, RIGHT LEADING EDGE TO FRONT SPAR	28-21-01
RELAYS - (31-01-09/101) FUELING SHUTOFF, R699 HORIZONTAL STABILIZER ISOLATION VALVE REFUEL BATTERY POWER, R7521 HORIZONTAL STABILIZER POSITION, R7392				
HORIZONTAL STABILIZER REFUELING SHUTOFF, R7391				
RELAYS - (31-01-24/101) FUELING GROUND POWER TRANSFER, R7881 POWER GROUND FUELING GAUGE, R996 REFUELING POWER CONTROL, R331				
RELAYS - (31-01-36/101) HORIZONTAL STABILIZER FUEL TRANSFER CONTROL, R7397				
HORIZONTAL STABILIZER LEFT ISOLATION VALVES CONTROL, R7399				
LEFT HORIZONTAL STABILIZER ISOLATION VALVES OPEN, R7396				
NO. 2 VALVE TEST, R7743				
RELAY - HORIZONTAL STABILIZER LEFT PUMP CONTROL, R7401		1	835L, AFT EQUIP CTR, P85	
RELAY - HORIZONTAL STABILIZER RIGHT PUMP CONTROL, R7402		1	835L, AFT EQUIP CTR, P85	

* SEE THE WDM EQUIPMENT LIST

- AIRPLANES WITH A HORIZONTAL STABILIZER TANK
- AIRPLANES WITH STABILIZER FUELING LOCK-OUT SYSTEM

DLH AIRPLANES WITH STABILIZER FUELING LOCK-OUT SYSTEM













Pressure Fueling System - Component Index

Figure 101 (Sheet 2)

993979

Figure 35 28-21 Pressure Fueling System Component Index (Sheet 2)

Lufthansa
TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
RELAYS - (31-01-39/101) HORIZONTAL STABILIZER RIGHT ISOLATION VALVE CONTROL, R7400  JETTISON OVERRIDE, R7393,R7394 RIGHT HORIZONTAL STABILIZER FUEL TRANSFER CONTROL, R7398  RIGHT HORIZONTAL STABILIZER ISOLATION VALVES OPEN, R7396 				
RELAY - FUELING POWER TRANSFER, R4		1	117AL, MAIN EQUIP CTR	28-21-05
SWITCH - ALL VALVES PRESELECT CONTROL, S1874	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - CENTER TANK FUEL CONTROL, S1878	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - CENTER TANK SECONDARY VALVE TEST, S1880 	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - CONTROL, FUELING POWER, S681	2	1	521CB, LEFT LEADING EDGE TO FRONT SPAR	28-21-04
SWITCH - FLOAT, HORIZONTAL STABILIZER SURGE TANK, S1869 	5,6	1	343KB, RIGHT FRONT SPAR TO REAR SPAR, INBD OF SURGE TANK, HORIZONTAL STABILIZER	28-21-29
SWITCH - FLOAT, LEFT WING SURGE TANK, S691	3	1	555AB, LEFT FRONT SPAR TO REAR SPAR SURGE TANK	28-21-12
SWITCH - FLOAT, RIGHT WING SURGE TANK, S690	3	1	655AB, RIGHT FRONT SPAR TO REAR SPAR SURGE TANK	28-21-12
SWITCH - HORIZONTAL STABILIZER FUEL TANK CONTROL, S1873 	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - HORIZONTAL STABILIZER ISOLATION CONTROL VALVE, S1879 	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - HORIZONTAL STABILIZER POSITION, S1875 	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - LEFT SECONDARY REFUEL VALVE PRESSURE, S1877 	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - M1 CONTROL, S81	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - M2 CONTROL, S82	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - M3 CONTROL, S87	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - M4 CONTROL, S88	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - OVERFILL RESET, S1076	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - REFUEL POWER SELECT, S79	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - REFUEL VALVE, YVXS1 	8	1	FLIGHT DECK FUELING CONTROL MODULE, M5	*
SWITCH - RESERVE 2 FUELING VALVE CONTROL, S1263	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - RESERVE 3 FUELING VALVE CONTROL, S1264	7	1	REFUEL CNT PANEL, P42, L WING	*
SWITCH - RIGHT SECONDARY REFUEL VALVE PRESSURE, S1876 	7	1	REFUEL CNT PANEL, P42, L WING	*
UNIT - CONTROL, HORIZONTAL STABILIZER TANK REFUEL VALVE, V434 	6	1	312A, RIGHT AREA AFT OF PRESSURE BULKHEAD	28-21-02
UNIT - CONTROL, INBD NO. 2 MAIN TANK REFUEL VALVE	3	1	571AB, LEFT REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-21-02
UNIT - CONTROL, INBD NO. 3 MAIN TANK REFUEL VALVE	3	1	671AB, RIGHT REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-21-02
UNIT - CONTROL, LEFT CENTER WING TANK REFUEL VALVE	4	1	LEFT WING LANDING GEAR WELL	28-21-02
UNIT - CONTROL, NO. 1 MAIN TANK REFUEL VALVE	3	1	581EB, LEFT SPOILER NO. 2	28-21-02
UNIT - CONTROL, NO. 4 MAIN TANK REFUEL VALVE	3	1	681EB, RIGHT SPOILER NO. 2	28-21-02

* SEE THE WDM EQUIPMENT LIST

 AIRPLANES WITH A HORIZONTAL STABILIZER TANK

 DLH ALL

Pressure Fueling System - Component Index









Figure 101 (Sheet 3)

a38214

Figure 36 28-21 Pressure Fueling System Component Index (Sheet 3)



Lufthansa
TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
UNITS - (31-61-00/101) C EFIS/EICAS INTERFACE, M7352 L EFIS/EICAS INTERFACE, M7353 R EFIS/EICAS INTERFACE, M7351				
UNIT - CONTROL, NO. 2 RESERVE TANK REFUEL VALVE	3	1	591AB, LEFT REAR SPAR TO TRAILING EDGE	28-21-02
UNIT - CONTROL, NO. 3 RESERVE TANK REFUEL VALVE	3	1	691AB, RIGHT REAR SPAR TO TRAILING EDGE	28-21-02
UNIT - CONTROL, OUTBD NO. 2 MAIN TANK REFUEL VALVE	3	1	572GB, LEFT LANDING GEAR SUPPORT BEAM AND REAR SPAR TO TRAILING EDGE	28-21-02
UNIT - CONTROL, OUTBD NO. 3 MAIN TANK REFUEL VALVE	3	1	672GB, RIGHT LANDING GEAR SUPPORT BEAM AND REAR SPAR TO TRAILING EDGE	28-21-02
UNIT - CONTROL, RIGHT CENTER WING TANK REFUEL VALVE	4	1	RIGHT WING LANDING GEAR WELL	28-21-02
UNIT - FUEL QUANTITY PROCESSOR, M7860		1		28-41-13
UNIT - HORIZONTAL STABILIZER FUEL REM ELEC, M7861 		1		*
UNIT - HORIZONTAL STABILIZER TANK REFUEL VALVE 	5	1	RIGHT HORIZONTAL STABILIZER TORSION BOX	28-21-13
UNIT - INBD NO. 2 MAIN TANK REFUEL VALVE, V81	3	1	545AB, LEFT MID SPAR TO REAR SPAR INBD MAIN TANK	28-21-13
UNIT - INBD NO. 3 MAIN TANK REFUEL VALVE, V62	3	1	645AB, RIGHT MID SPAR TO REAR SPAR INBD MAIN TANK	28-21-13
UNIT - LEFT CENTER WING TANK REFUEL VALVE, V60	4	1	131AZ,131BZ,131CZ,131DZ, LEFT CENTER SECTION WING BOX	28-21-13
UNIT - NO. 1 MAIN TANK REFUEL VALVE, V58	3	1	546BB, LEFT MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-21-13
UNIT - NO. 2 RESERVE TANK REFUEL VALVE, V469	3	1	553BB, LEFT FRONT SPAR TO REAR SPAR RESERVE TANK	28-21-13
UNIT - NO. 3 RESERVE TANK REFUEL VALVE, V470	3	1	653BB, RIGHT FRONT SPAR TO REAR SPAR INBD MAIN TANK	28-21-13
UNIT - NO. 4 MAIN TANK REFUEL VALVE, V63	3	1	646BB, RIGHT MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-21-13
UNIT - OUTBD NO. 2 MAIN TANK REFUEL VALVE, V59	3	1	545BB, LEFT MID SPAR TO REAR SPAR INBD MAIN TANK	28-21-13
UNIT - OUTBD NO. 3 MAIN TANK REFUEL VALVE, V82	3	1	645BB, LEFT MID SPAR TO REAR SPAR INBD MAIN TANK	28-21-13
UNIT - RIGHT CENTER WING TANK REFUEL VALVE, V61	4	1	131AZ,131BZ,131CZ,131DZ, RIGHT CENTER SECTION WING BOX	28-21-13
VALVE - LEFT AFT HORIZONTAL STABILIZER ISOLATION, V435 		1		*
VALVE - LEFT FORWARD HORIZONTAL STABILIZER ISOLATION, V439 		1		*
VALVE - LEFT MANIFOLD DRAIN	2	1	LEFT MID SPAR TO REAR SPAR INBD MAIN TANK	28-21-03
VALVE - LEFT REFUEL OVERRIDE, V437 	4	1	131AZ,131BZ,131CZ,131DZ, RIGHT CENTER SECTION WING BOX	28-21-28
VALVE - RIGHT AFT HORIZONTAL STABILIZER ISOLATION, V436 		1		*
VALVE - RIGHT FORWARD HORIZONTAL STABILIZER ISOLATION, V440 		1		*
VALVE - RIGHT MANIFOLD DRAIN	2	1	RIGHT MID SPAR TO REAR SPAR INBD MAIN TANK	28-21-03
VALVE - RIGHT REFUEL OVERRIDE, V438 	4	1	131AZ,131BZ,131CZ,131DZ, RIGHT CENTER SECTION WING BOX	28-21-28

* SEE THE WDM EQUIPMENT LIST


 AIRPLANES WITH A HORIZONTAL STABILIZER TANK

Pressure Fueling System - Component Index

Figure 101 (Sheet 4)

a38217

Figure 37 28-21 Pressure Fueling System Component Index (Sheet 4)**Lufthansa**
TECHNISCHE SCHULUNG



Pressure Fueling System - Component Location


Figure 102 (Sheet 1)

719094

Figure 38 28-21 Pressure Fueling System Component Location (Sheet 1)



Lufthansa
TECHNISCHE SCHULUNG




Pressure Fueling System - Component Location (Details from Sht 1)

Figure 102 (Sheet 2)

579851

Figure 39 28-21 Pressure Fueling System Component Location (Sheet 2)




Pressure Fueling System - Component Location (Details from Sht 1)

Figure 102 (Sheet 3)

579876

Figure 40 28-21 Pressure Fueling System Component Location (Sheet 3)





Pressure Fueling System - Component Location (Details from Sht 1)


Figure 102 (Sheet 4)

a39014

Figure 41 28-21 Pressure Fueling System Component Location (Sheet 4)




Lufthansa
TECHNISCHE SCHULUNG



HORIZONTAL STABILIZER TANK COMPONENTS

(H) FROM SHT 1



(I)

Pressure Fueling System - Component Location



Figure 102 (Sheet 5)

579902

Figure 42 28-21 Pressure Fueling System Component Location (Sheet 5)



Lufthansa
TECHNISCHE SCHULUNG




Pressure Fueling System - Component Location (Details from Sht 1)


Figure 102 (Sheet 6)

579932

Figure 43 28-21 Pressure Fueling System Component Location (Sheet 6)



(AIRPLANES WITH HORIZONTAL STABILIZER FUEL TANK)



(AIRPLANES WITHOUT HORIZONTAL STABILIZER FUEL TANK)



1 AIRPLANES WITH STABILIZER FUELING LOCK-OUT SYSTEM

Pressure Fueling System - Component Location (Detail from Sht 1)

Figure 102 (Sheet 7)

993235

Figure 44 28-21 Pressure Fueling System Component Location (Sheet 7)



- 1 AIRPLANES WITH STABILIZER FUELING LOCK-OUT SYSTEM
- 2 AIRPLANES WITHOUT STABILIZER FUELING LOCK-OUT SYSTEM
- 3 HORIZONTAL STABILIZER POSITION INDICATOR LIGHT PLACARDED INOP ON AIRPLANES WITHOUT HORIZONTAL STABILIZER TANK
- 4 DLH 002 WITH SB 28-2135

Pressure Fueling System - Component Location
Figure 102 (Sheet 8)

854932

Figure 45 28-21 Pressure Fueling System Component Location (Sheet 8)



Lufthansa
TECHNISCHE SCHULUNG

ATA 28-22 ENGINE FUEL FEED SYSTEM

COMPONENT INDEX AND LOCATION

ENGINE FUEL FEED SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - VALVE, NO. 1 ENGINE FUEL SHUTOFF, V13	1	1	L LEADING EDGE TO FRONT SPAR	28-22-01
ACTUATOR - VALVE, NO. 1 FUEL CROSSFEED, V45	1	1	L LEADING EDGE TO FRONT SPAR	28-22-02
ACTUATOR - VALVE, NO. 2 ENGINE FUEL SHUTOFF, V14	1	1	L LEADING EDGE TO FRONT SPAR	28-22-01
ACTUATOR - VALVE, NO. 2 FUEL CROSSFEED, V46	1	1	L LEADING EDGE TO FRONT SPAR	28-22-02
ACTUATOR - VALVE, NO. 3 ENGINE FUEL SHUTOFF, V15	1	1	R LEADING EDGE TO FRONT SPAR	28-22-01
ACTUATOR - VALVE, NO. 3 FUEL CROSSFEED, V47	1	1	R LEADING EDGE TO FRONT SPAR	28-22-02
ACTUATOR - VALVE, NO. 4 ENGINE FUEL SHUTOFF, V16	1	1	R LEADING EDGE TO FRONT SPAR	28-22-01
ACTUATOR - VALVE, NO. 4 FUEL CROSSFEED, V48	1	1	R LEADING EDGE TO FRONT SPAR	28-22-02
ADAPTER - VALVE, NO. 1 ENGINE FUEL SHUTOFF	1	1	546AB, L FRONT SPAR TO MID SPAR OUTBD MAIN TANK, L LEADING EDGE TO FRONT SPAR	28-22-09
ADAPTER - VALVE, NO. 1 FUEL CROSSFEED	1	1	546AB, L FRONT SPAR TO MID SPAR OUTBD MAIN TANK, L LEADING EDGE TO FRONT SPAR	28-22-1 1
ADAPTER - VALVE, NO. 2 ENGINE FUEL SHUTOFF	1	1	545BB, L FRONT SPAR TO MID SPAR INBD MAIN TANK, L LEADING EDGE TO FRONT SPAR	28-22-09
ADAPTER - VALVE, NO. 2 FUEL CROSSFEED	1	1	545AB, L FRONT SPAR TO MID SPAR INBD MAIN TANK, L LEADING EDGE TO FRONT SPAR	28-22-1 1
ADAPTER - VALVE, NO. 3 ENGINE FUEL SHUTOFF	1	1	645BB, R FRONT SPAR TO MID SPAR INBD MAIN TANK, R LEADING EDGE TO FRONT SPAR	28-22-09
ADAPTER - VALVE, NO. 3 FUEL CROSSFEED	1	1	645AB, R FRONT SPAR TO MID SPAR INBD MAIN TANK, R LEADING EDGE TO FRONT SPAR	28-22-1 1
ADAPTER - VALVE, NO. 4 ENGINE FUEL SHUTOFF	1	1	646AB, R FRONT SPAR TO MID SPAR OUTBD MAIN TANK, R LEADING EDGE TO FRONT SPAR	28-22-09
ADAPTER - VALVE, NO. 4 FUEL CROSSFEED	1	1	646AB, R FRONT SPAR TO MID SPAR OUTBD MAIN TANK, R LEADING EDGE TO FRONT SPAR	28-22-1 1
BODY - VALVE, NO. 1 ENGINE FUEL SHUTOFF, V13	1	1	546AB, L FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-22-05
BODY - VALVE, NO. 1 FUEL CROSSFEED, V45	1	1	546AB, L FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-22-10
BODY - VALVE, NO. 2 ENGINE FUEL SHUTOFF, V14	1	1	545BB, L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-05
BODY - VALVE, NO. 2 FUEL CROSSFEED, V46	1	1	545AB, L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-10
BODY - VALVE, NO. 3 ENGINE FUEL SHUTOFF, V15	1	1	645BB, R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-05
BODY - VALVE, NO. 3 FUEL CROSSFEED, V47	1	1	645AB, R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-10
BODY - VALVE, NO. 4 ENGINE FUEL SHUTOFF, V16	1	1	646AB, R FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-22-05
BODY - VALVE, NO. 4 FUEL CROSSFEED, V48	1	1	646AB, R FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-22-10

Engine Fuel Feed System - Component Index

Figure 101 (Sheet 1)

337339

Figure 46 28-22 Engine Fuel feed System Component Index (Sheet 1)
Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CARD - CENTER WING SINGLE POINT SENSOR, A3	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM EICAS INTERFACE MAIN, Y5BA14	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM EICAS INTERFACE SLAVE, Y5BA15	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - FUEL SYSTEM MANAGEMENT A, Y5BA5	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-22-13
CARD - FUEL SYSTEM MANAGEMENT B, Y5B10	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-22-13
CARD - M2/M3 SINGLE POINT SENSOR, A2	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	*
CARD - VALVE POSITION LOGIC 1, Y5BA6	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-22-14
CARD - VALVE POSITION LOGIC 2, Y5BA9	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-22-14
CARD - VALVE POSITION LOGIC 3, Y5BA11	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-22-14
CARD - VALVE POSITION LOGIC 4, Y5BA12	7	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-22-14
CIRCUIT BREAKERS -	6		FLT COMPT P6	
FUEL SHUTOFF VALVE ENG 1, C35		1	6G1	
FUEL SHUTOFF VALVE ENG 2, C36		1	6G2	
FUEL SHUTOFF VALVE ENG 3, C37		1	6G3	
FUEL SHUTOFF VALVE ENG 4, C38		1	6G4	
FUEL SYS MGMT CARD A, C10128		1	6F5	
FUEL SYS MGMT CARD B, C10127		1	6F7	
FUEL XFEED VALVE ENG 1, C76		1	6L14	
FUEL XFEED VALVE ENG 2, C77		1	6L15	
FUEL XFEED VALVE ENG 3, C78		1	6L16	
FUEL XFEED VALVE ENG 4, C79		1	6L17	
CIRCUIT BREAKERS -	--		117AL, MAIN EQUIP CTR, P180	
BOOST PUMP CONT 1 AFT & 4 FWD, C454		1	180E4	
BOOST PUMP CONT 1 FWD & 4 AFT, C293		1	180E19	
BOOST PUMP CONT 2 AFT & 3 FWD, C560		1	180H4	
BOOST PUMP CONT 2 FWD & 3 AFT, C455		1	180H19	
CIRCUIT BREAKERS -	--		117AL, MAIN EQUIP CTR, P414	
FUEL BOOST PUMP MAIN AFT 1, C801		1	414B5	
FUEL BOOST PUMP MAIN AFT 2, C803		1	414R18	
FUEL BOOST PUMP MAIN FWD 3, C809		1	414J5	
FUEL BOOST PUMP MAIN FWD 4, C811		1	414A8	
FUEL BOOST PUMP CONT MN AFT 2, C561		1	414E24	

* SEE THE WDM EQUIPMENT LIST

Engine Fuel Feed System - Component Index

Figure 101 (Sheet 2)

337340

Figure 47 28-22 Engine Fuel Feed System Component Index (Sheet 2)
Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CIRCUIT BREAKERS -	--		117AL, MAIN EQUIP CTR, P415	
FUEL BOOST PUMP MAIN AFT 3, C808		1	415M29	
FUEL BOOST PUMP MAIN AFT 4, C810		1	415A35	
FUEL BOOST PUMP MAIN FWD 1, C802		1	415B35	
FUEL BOOST PUMP MAIN FWD 2, C804		1	415G29	
DIODE - (31-01-36/101) M846				
FILE - FUEL SYSTEM CARD, M7852	7	1	L AREA BETWEEN NOSE GEAR WELL AND FUSELAGE	*
HOUSING - AFT NO. 1 MAIN TANK FUEL BOOST PUMP, M22	2	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-12
HOUSING - AFT NO. 2 MAIN TANK FUEL BOOST PUMP, M23	3	1	544AB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-12
HOUSING - AFT NO. 3 MAIN TANK FUEL BOOST PUMP, M31	3	1	644AB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-12
HOUSING - AFT NO. 4 MAIN TANK FUEL BOOST PUMP, M32	2	1	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-12
HOUSING - FORWARD NO. 1 MAIN TANK FUEL BOOST PUMP, M28	2	1	545BB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-12
HOUSING - FORWARD NO. 2 MAIN TANK FUEL BOOST PUMP, M29	3	1	544AB, L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-12
HOUSING - FORWARD NO. 3 MAIN TANK FUEL BOOST PUMP, M26	3	1	644AB, R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-12
HOUSING - FORWARD NO. 4 MAIN TANK FUEL BOOST PUMP, M27	2	1	645BB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-12
MODULE - ENGINE START LEVER, YBEM01	--	1	FLT COMPT, P8	*
MODULE - FUEL MANAGEMENT CONTROL, M154	6	1	FLT COMPT, P5	*
LINE - L ENGINE FUEL FEED SYSTEM			545AB,545CB,545DB,546BB,552AB, 552BB,552CB,552DB,552EB,552FB, 553BB,553CB,553DB,553EB,553FB, 553GB,553HB,553JB, L WING	28-22-07
LINE - R ENGINE FUEL FEED SYSTEM			645AB,645CB,645DB,646BB,652AB, 652BB,652CB,652DB,652EB,652FB, 653BB,653CB,653DB,653EB,653FB, 653GB,653HB,653JB, R WING	28-22-07
PUMP - EJECTOR, AFT NO. 1 MAIN TANK WATER SCAVENGE	1	1	546AB, L MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-22-08
PUMP - EJECTOR, AFT NO. 2 MAIN TANK WATER SCAVENGE	1	1	544AB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-08
PUMP - EJECTOR, AFT NO. 3 MAIN TANK WATER SCAVENGE	1	1	644AB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-08
PUMP - EJECTOR, AFT NO. 4 MAIN TANK WATER SCAVENGE	1	1	646AB, R MID SPAR TO REAR SPAR OUTBD MAIN TANK	28-22-08
PUMP - EJECTOR, FORWARD NO. 1 MAIN TANK WATER SCAVENGE	1	1	546AB, L FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-22-08
PUMP - EJECTOR, FORWARD NO. 2 MAIN TANK WATER SCAVENGE	1	1	544AB, L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-08
PUMP - EJECTOR, FORWARD NO. 3 MAIN TANK WATER SCAVENGE	1	1	644AB, R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-08
PUMP - EJECTOR, FORWARD NO. 4 MAIN TANK WATER SCAVENGE	1	1	646AB, R FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-22-08

* SEE THE WDM EQUIPMENT LIST

Engine Fuel Feed System - Component Index

Figure 101 (Sheet 3)

337341

Figure 48 28-22 Engine Fuel Feed System Component Index (Sheet 3)



Lufthansa
TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
RELAYS - (31-01-36/101) CROSSFEED VALVE AUTO CONTROL 2, R7403 GROUND SAFETY, R628 MAIN FUEL TANK 1 BOOST PUMP CONTROL AFT, R47 MAIN FUEL TANK 2 BOOST PUMP CONTROL FWD, R49 MAIN FUEL TANK 3 BOOST PUMP CONTROL FWD, R52 MAIN FUEL TANK 4 BOOST PUMP CONTROL FWD, R54 RELAYS - (31-01-39/101) CROSSFEED VALVE AUTO CONTROL 3, R7404 GROUND SAFETY, R637 MAIN FUEL TANK 1 BOOST PUMP CONTROL FWD, R48 MAIN FUEL TANK 2 BOOST PUMP CONTROL FWD, R50 MAIN FUEL TANK 3 BOOST PUMP CONTROL AFT, R51 MAIN FUEL TANK 4 BOOST PUMP CONTROL AFT, R53 SUPPRESSORS - (31-01-36/101) M2143 M2144 M2145 M2146				
SWITCH - AFT NO. 1 MAIN TANK BOOST PUMP, S5	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - AFT NO. 2 MAIN TANK BOOST PUMP, S6	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - AFT NO. 3 MAIN TANK BOOST PUMP, S7	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - AFT NO. 4 MAIN TANK BOOST PUMP, S8	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - FORWARD NO. 1 MAIN TANK BOOST PUMP, S1	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - FORWARD NO. 2 MAIN TANK BOOST PUMP, S2	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - FORWARD NO. 3 MAIN TANK BOOST PUMP, S3	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - FORWARD NO. 4 MAIN TANK BOOST PUMP, S4	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - L CENTER WING TANK OVERRIDE/JETTISON PUMP, S18	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - L HORIZONTAL STABILIZER FUEL TRANSFER PUMP, S14	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - NO. 1 FUEL CONTROL, S211	6	1	FLT COMPT, CONTROL STAND	*
SWITCH - NO. 1 FUEL CROSSFEED VALVE, S9	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - NO. 2 FUEL CONTROL, S212	6	1	FLT COMPT, CONTROL STAND	*
SWITCH - NO. 2 FUEL CROSSFEED VALVE, S10	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*

* SEE THE WDM EQUIPMENT LIST

Engine Fuel Feed System - Component Index

Figure 101 (Sheet 4)

337342

Figure 49 28-22 Engine Fuel Feed System Component Index (Sheet 4)
Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
SWITCH - NO. 3 FUEL CONTROL, S213	6	1	FLT COMPT, CONTROL STAND	*
SWITCH - NO. 3 FUEL CROSSFEED VALVE, S11	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - NO. 4 FUEL CONTROL, S214	6	1	FLT COMPT, CONTROL STAND	*
SWITCH - NO. 4 FUEL CROSSFEED VALVE, S12	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - RIGHT CENTER WING TANK OVERRIDE/ JETTISON PUMP, S19	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - RIGHT HORIZONTAL STABILIZER FUEL TRANSFER PUMP, S15	6	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
UNITS - (31-61-00/101) C EFIS/EICAS INDICATION, M7352 L EFIS/EICAS INDICATION, M7353 R EFIS/EICAS INDICATION, M7351				
UNIT - L FUEL CONTROL, M7881	--	1	117AL, MAIN EQUIP CTR, E2-2	*
UNIT - R FUEL CONTROL, M7879	--	1	117AL, MAIN EQUIP CTR, E2-1	*
UNIT - MOTOR/IMPELLER, AFT NO. 1 MAIN TANK FUEL BOOST PUMP, M22	4	1	545DB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-03
UNIT - MOTOR/IMPELLER, AFT NO. 2 MAIN TANK FUEL BOOST PUMP, M23	4	1	L MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-03
UNIT - MOTOR/IMPELLER, AFT NO. 3 MAIN TANK FUEL BOOST PUMP, M31	4	1	R MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-03
UNIT - MOTOR/IMPELLER, AFT NO. 4 MAIN TANK FUEL BOOST PUMP, M32	4	1	645DB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-03
UNIT - MOTOR/IMPELLER, FORWARD NO. 1 MAIN TANK FUEL BOOST PUMP, M28	4	1	545CB, L MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-03
UNIT - MOTOR/IMPELLER, FORWARD NO. 2 MAIN TANK FUEL BOOST PUMP, M29	4	1	L FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-03
UNIT - MOTOR/IMPELLER, FORWARD NO. 3 MAIN TANK FUEL BOOST PUMP, M26	4	1	R FRONT SPAR TO MID SPAR INBD MAIN TANK	28-22-03
UNIT - MOTOR/IMPELLER, FORWARD NO. 4 MAIN TANK FUEL BOOST PUMP, M27	4	1	645CB, R MID SPAR TO REAR SPAR INBD MAIN TANK	28-22-03
VALVE - FLOW LIMITING, FUEL	5	1	131EZ,131AZ,131BZ, RIGHT CENTER SECTION WING BOX	28-22-04


* SEE THE WDM EQUIPMENT LIST

Engine Fuel Feed System - Component Index

Figure 101 (Sheet 5)

583295

Figure 50 28-22 Engine Fuel Feed System Component Location (Sheet 5)
Lufthansa
 TECHNISCHE SCHULUNG



Engine Fuel Feed System - Component Location


Figure 102 (Sheet 1)

Figure 51 28-22 Engine Fuel Feed System Component Location (Sheet 1)


580693



Lufthansa
TECHNISCHE SCHULUNG



FORWARD AND AFT NO. 1 OR NO. 4 MAIN TANK FUEL BOOST PUMPS AND
FORWARD AND AFT NO. 1 OR NO. 4 MAIN TANK WATER SCAVENGE EJECTOR PUMPS



FORWARD AND AFT NO. 1 OR NO. 4 MAIN TANK FUEL BOOST PUMPS

C

Engine Fuel Feed System - Component Location


Figure 102 (Sheet 2)

580709

Figure 52 28-22 Engine Fuel Feed System Component Location (Sheet 2)




Lufthansa
TECHNISCHE SCHULUNG



AFT NO. 2 OR NO. 3 MAIN TANK FUEL BOOST PUMP
AND AFT NO. 2 OR NO. 3 MAIN TANK WATER SCAVENGE EJECTOR PUMP

(D)



FORWARD NO. 2 OR NO. 3 MAIN TANK FUEL BOOST PUMP
AND FORWARD NO. 2 OR NO. 3 MAIN TANK WATER SCAVENGE EJECTOR PUMP

(E)

Engine Fuel Feed System - Component Location (Details from Sht 1)


Figure 102 (Sheet 3)

580718

Figure 53 28-22 Engine Fuel Feed System Component Location (Sheet 3)



Lufthansa
TECHNISCHE SCHULUNG




Engine Fuel Feed System - Component Location (Details from Shts 2 and 3)

Figure 102 (Sheet 4)

580721

Figure 54 28-22 Engine Fuel Feed System Component Location (Sheet 4)




Engine Fuel Feed System - Component Location (Details From Sht 1)

Figure 102 (Sheet 5)

580725

Figure 55 28-22 Engine Fuel Feed System Component Location (Sheet 5)



Engine Fuel Feed System - Component Location


Figure 102 (Sheet 6)

721493

Figure 56 28-22 Engine Fuel Feed System Component Location (Sheet 6)



Lufthansa
TECHNISCHE SCHULUNG



Engine Fuel Feed System - Component Location
Figure 102 (Sheet 7)

582322

Figure 57 28-22 Engine Fuel Feed System Component Location (Sheet 7)

ATA 28-25 APU FUEL FEED SYSTEM

COMPONENT INDEX AND LOCATION

APU FUEL-FEED SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - VALVE, APU FUEL SHUTOFF, V119	1	1	LEFT REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-25-02
ARRESTER - FLAME, APU FUEL SHROUD DRAIN CARD - (REF 28-22-00, FIG. 101)	2,3	2	RIGHT BODY LANDING GEAR WELL	28-25-00
FUEL SYSTEM EICAS INTERFACE - MAIN, Y5BA14				
FUEL SYSTEM EICAS INTERFACE - SLAVE, Y5BA15				
VALVE POSITION LOGIC 4, Y5BA12				
CIRCUIT BREAKERS -			FLT COMPT, P6	
DC FUEL PUMP APU, C408		1	6H18	*
FUEL SHUTOFF VALVE APU, C406		1	6G5	*
DIODE - (REF 30-01-36, FIG. 101)				
AFT BOOST PUMP 2, M226				
DRAIN - APU FUEL SUPPLY LINE SHROUD	2,3	2	RIGHT BODY LANDING GEAR WELL	28-25-00
FILE - FUEL SYSTEM CARD, M7852		1	LEFT AREA BETWEEN NOSE GEAR WELL AND FUSELAGE	*
LINE - APU FUEL-FEED, FORWARD OF THE REAR SPAR	3		131AZ,131BZ,131CZ,131DZ,544AB, LEFT CENTER SECTION WING BOX, INBD MAIN TANK (PART), LEFT MID SPAR TO REAR SPAR	28-25-04
LINE - APU FUEL-FEED, AFT OF THE REAR SPAR TO THE APU FIREWALL	3		146AZ,312A,315A, RIGHT WING LANDING GEAR WELL, RIGHT AFT CARGO CONTAINER COMPARTMENT, RIGHT AREA AFT OF BULK CARGO COMPARTMENT, RIGHT AREA AFT OF PRESSURE BULKHEAD, RIGHT STABILIZER TORSION BOX COMPART- MENT, RIGHT AREA AFT OF STABILIZER BOX COMPARTMENT	28-25-04
POPPET - PRIMARY, APU FUEL LINE SHROUD DRAIN VALVE	2	1	KEEL BEAM (PART)	28-25-07
POPPET - SECONDARY, APU FUEL LINE SHROUD DRAIN VALVE		1	RIGHT BODY LANDING GEAR WELL	28-25-08
PUMP - APU FUEL BOOST, M713	1,4	1	LEFT REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-25-01
RECEIVER - APU FUEL BOOST PUMP	4	1	544AB, LEFT MID SPAR TO REAR SPAR INBD MAIN TANK	28-25-09
RELAY - (REF 31-01-39, FIG. 101)				
APU FUEL CONT, R7200				
RELAY - (REF 49-11-00, FIG. 101)				
APU FUEL BOOST PUMP CONT, R295				

* SEE THE WDM EQUIPMENT LIST

APU Fuel-Feed System - Component Index

Figure 101 (Sheet 1)

580659

Figure 58 28-25 APU Fuel Feed System Component Index (Sheet 1)
Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
SHROUD - APU FUEL SUPPLY LINE	3		146AZ,312A,315A, RIGHT WING LANDING GEAR WELL, RIGHT AFT CARGO CONTAINER COMPARTMENT, RIGHT AREA AFT OF BULK CARGO COMPARTMENT, RIGHT AREA AFT OF PRESSURE BULKHEAD, RIGHT STABILIZER TORSION BOX COMPART- MENT, RIGHT AREA AFT OF STABILIZER BOX COMPARTMENT	28-25-04
SWITCH - (REF 26-15-00, FIG. 101) APU FIRE, S246				
SWITCH - PRESSURE, APU DC BOOST PUMP, S435	1	1	LEFT REAR SPAR TO LANDING GEAR SUPPORT BEAM	*
SWITCH - PRESSURE, APU FUEL BOOST PUMP CONTROL, S548	1	1	LEFT REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-25-06
UNIT - (REF 31-61-00, FIG. 101) C EFIS/EICAS INTERFACE, M7352 L EFIS/EICAS INTERFACE, M7353 R EFIS/EICAS INTERFACE, M7351				
VALVE - APU FUEL SHUTOFF, V119	1	1	544AB, LEFT MID SPAR TO REAR SPAR INBD MAIN TANK	28-25-10
VALVE - DRAIN, APU FUEL LINE SHROUD	2	1	RIGHT BODY LANDING GEAR WELL	28-25-00

* SEE THE WDM EQUIPMENT LIST

APU Fuel-Feed System - Component Index


Figure 101 (Sheet 2)

580663

Figure 59 28-25 APU Fuel Feed System Component Index (Sheet 2)



Lufthansa
TECHNISCHE SCHULUNG




APU Fuel-Feed System - Component Location

Figure 102 (Sheet 1)

580722

Figure 60 28-25 APU Fuel Feed System Component Location (Sheet 1)

Lufthansa
TECHNISCHE SCHULUNG




APU Fuel-Feed System - Component Location
Figure 102 (Sheet 2)

Figure 61 28-25 APU Fuel Feed System Component Location (Sheet 2)

580964




Lufthansa
TECHNISCHE SCHULUNG



APU Fuel-Feed System - Component Location (Details From Sht 1)
Figure 102 (Sheet 3)

580970

Figure 62 28-25 APU Fuel Feed System Component Location (Sheet 3)



APU Fuel-Feed System - Component Location (Detail From Sht 1)

Figure 102 (Sheet 4)

580974

Figure 63 28-25 APU Fuel Feed System Component Location (Sheet 4)



Lufthansa
TECHNISCHE SCHULUNG

ATA 28-26 DEFUELING

COMPONENT INDEX AND LOCATION



DEFUELING


COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
VALVE - LEFT WING DEFUELING CHECK	2	1	546AB, LEFT FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-26-02
VALVE - LEFT WING MANUAL DEFUELING	2	1	521BB, PRESSURE FUELING STATION	28-26-01
VALVE - RIGHT WING DEFUELING CHECK	2	1	646AB, RIGHT FRONT SPAR TO MID SPAR OUTBD MAIN TANK	28-26-02
VALVE - RIGHT WING MANUAL DEFUELING	2	1	621BB, PRESSURE FUELING STATION	28-26-01

Defueling - Component Index

Figure 101

579919

Figure 64 28-26 Defueling Component Index (Sheet 1)
Lufthansa
 TECHNISCHE SCHULUNG




Defueling - Component Location
Figure 102 (Sheet 1)

579926

Figure 65 28-26 Defueling Component Location (Sheet 1)





Defueling - Component Location (Details From Sht 1)
Figure 102 (Sheet 2)

579930

Figure 66 28-26 Defueling Component Location (Sheet 2)

ATA 28-31 FUEL JETTISON SYSTEM

COMPONENT INDEX AND LOCATION



FUEL JETTISON SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - VALVE, L FUEL JETTISON NOZZLE, V56	1	1	L FRONT SPAR TO REAR SPAR DRY BAY	28-31-05
ACTUATOR - VALVE, R FUEL JETTISON NOZZLE, V49	1	1	R FRONT SPAR TO REAR SPAR DRY BAY	
ACTUATOR - VALVE, L CENTER WING TANK FUEL JETTISON TRANSFER, V53	2	1	L WING LANDING GEAR WELL	28-31-04
ACTUATOR - VALVE, NO. 2 MAIN TANK FUEL JETTISON TRANSFER, V442	1	1	L REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-04
ACTUATOR - VALVE, NO. 3 MAIN TANK FUEL JETTISON TRANSFER, V443	1	1	R REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-04
ACTUATOR - VALVE, R CENTER WING TANK FUEL JETTISON TRANSFER, V52	2	1	R WING LANDING GEAR WELL	28-31-04
ADAPTER - VALVE, NO. 2 MAIN TANK FUEL JETTISON TRANSFER, V442	1	1	544AB, L REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-13
ADAPTER - VALVE, NO. 3 MAIN TANK FUEL JETTISON TRANSFER, V443	1	1	644AB, R REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-03
ASSEMBLY - VALVE, L CENTER WING TANK FUEL JETTISON TRANSFER, V53	--	1	131A2,131B2,131C2,131D2, LEFT CENTER SECTION WING BOX	28-31-06
ASSEMBLY - VALVE, L FUEL JETTISON NOZZLE, V56	--	1	556AB, L FRONT SPAR TO REAR SPAR DRY BAY	28-31-03
ASSEMBLY - VALVE, NO. 2 MAIN TANK FUEL JETTISON TRANSFER, V442	--	1	544AB, LEFT MID SPAR TO REAR SPAR INBD MAIN TANK	28-31-06
ASSEMBLY - VALVE, NO. 3 MAIN TANK FUEL JETTISON TRANSFER, V443	--	1	644AB, RIGHT MID SPAR TO REAR SPAR INBD MAIN TANK	28-31-06
ASSEMBLY - VALVE, CENTER WING TANK FUEL JETTISON TRANSFER, V52	--	1	131A2,131B2,132A2,132B2, RIGHT CENTER SECTION WING BOX	28-31-06
ASSEMBLY - VALVE, R FUEL JETTISON NOZZLE, V49	--	1	656AB, R FRONT SPAR TO REAR SPAR DRY BAY	28-31-03
CARD - FUEL JETTISON CONTROL A, Y5BA7	--	1	117AL, MAIN EQUIP CTR, FUEL SYSTEM CARD FILE, M7852	28-31-15
CARD - FUEL JETTISON CONTROL B, Y5BA8	--	1	L AREA BETWEEN NOSE GEAR WELL AND FUSELAGE, FUEL SYSTEM CARD FILE, M7852	28-31-15
CARD - (REF 28-22-00, FIG. 101) FUEL SYSTEM EICAS INTERFACE MAIN, Y5BA14 FUEL SYSTEM EICAS INTERFACE SLAVE, V5BA15 FUEL SYSTEM MANAGEMENT A, Y5BA5 FUEL SYSTEM MANAGEMENT B, Y5BA10 JET M2/M3 SINGLE POINT SENSOR CONTROL, Y5BA4 VALVE POSITION LOGIC 1, Y5BA6 VALVE POSITION LOGIC 2, Y5BA9 VALVE POSITION LOGIC 3, Y5BA11 VALVE POSITION LOGIC 4, Y5BA12				

Fuel Jettison System - Component Index

Figure 101 (Sheet 1)

581978

Figure 67 28-31 Fuel Jettison System Component Index (Sheet 1)
Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CIRCUIT BREAKERS -	3		FLT COMPT, P6	
CTR L & MAIN 3 JTSN VLV, C10132		1	6F17	*
CTR R & MAIN 2 JTSN VLV, C10133		1	6E17	*
FUEL JTSN PUMP CONT A, C10135		1	6D17	*
FUEL JTSN PUMP CONT B, C10134		1	6C17	*
JTSN NOZZLE VLV CONT L, C85		1	6D18	*
JTSN NOZZLE VLV CONT R, C84		1	6C18	*
CIRCUIT BREAKERS -	--		117AL, MAIN EQUIP CTR, P180	
JTSN PUMP CONT 2 & 3 INBD, C1072		1	180E18	*
JTSN PUMP CONT 2 & 3 OUTBD, C1071		1	180E3	*
OVRD/JTSN PUMP CONT L CTR, C19		1	180E2	*
OVRD/JTSN PUMP CONT R CTR, C20		1	180H18	*
CIRCUIT BREAKERS -	--		117AL, MAIN EQUIP CTR, P414	
FUEL JTSN PUMP FWD 2, C833		1	414C2	*
FUEL JTSN PUMP FWD 3, C838		1	414C5	*
FUEL JTSN/OVRD PUMP CTR LEFT, C835		1	414D2	*
CIRCUIT BREAKERS -	--		117AL, MAIN EQUIP CTR, P415	
FUEL JTSN PUMP AFT 2, C834		1	415A38	*
FUEL JTSN PUMP AFT 3, C837		1	415B38	*
FUEL JTSN/OVRD PUMP CTR RIGHT, C836		1	415M32	*
DETECTOR - FAULT CURRENT, L CENTER WING	--	1	L E&E COMP	28-31-14
TANK FUEL OVERRIDE/JETTISON PUMP, M473				
DETECTOR - FAULT CURRENT, R CENTER WING		1	R E&E COMP	28-31-14
TANK FUEL OVERRIDE/JETTISON PUMP, M472				
DETECTOR - FAULT CURRENT, NO. 2 MAIN TANK	--	1	L E&E COMP	28-31-14
INBD (AFT), M7867				
DETECTOR - FAULT CURRENT, NO. 2 MAIN TANK	--	1	R E&E COMP	28-31-14
OUTBD (FWD), M7869				
DETECTOR - FAULT CURRENT, NO. 3 MAIN TANK	--	1	L E&E COMP	28-31-14
INBD (AFT), M7866				
DETECTOR - FAULT CURRENT, NO. 3 MAIN TANK	--	1	R E&E COMP	28-31-14
OUTBD (FWD), M7868				
FILE - FUEL SYSTEM CARD, M7852	--	1	L AREA BETWEEN NOSE GEAR WELL AND FUSELAGE	*
HOUSING - FUEL OVERRIDE/JETTISON PUMP	1,2	6	ONE PER FUEL OVERRIDE/JETTISON PUMP	28-31-07
MANIFOLD - FUEL JETTISON				
MODULE - FUEL MANAGEMENT CONTROL, M154	3	1	FLT COMPT, P5	
MODULE - JETTISON, M7325	3	1	FLT COMPT, P5	

* SEE THE WDM EQUIPMENT LIST

Fuel Jettison System - Component Index

Figure 101 (Sheet 2)

581982

Figure 68 28-31 Fuel Jettison System Component Index (Sheet 2)
Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
PUMP - L CENTER WING FUEL OVERRIDE JETTISON M224	2	1	131EZ,131AZ,131BZ,131CZ,131DZ, L CTR SECTION WING BOX	
PUMP - NO. 2 MAIN TANK INBD (AFT) FUEL OVERRIDE/JETTISON, M223	1	1	544AB, L MID SPAR TO REAR SPAR INBD MAIN TANK	
PUMP - NO. 2 MAIN TANK OUTBD (FWD) FUEL OVERRIDE/JETTISON, M222	1	1	544AB, L MID SPAR TO REAR SPAR INBD MAIN TANK	
PUMP - NO. 3 MAIN TANK INBD (AFT) FUEL OVERRIDE/JETTISON, M226	1	1	644AB, R MID SPAR TO REAR SPAR INBD MAIN TANK	
PUMP - NO. 3 MAIN TANK OUTBD (FWD) FUEL OVERRIDE/JETTISON, M227	1	1	644AB, R MID SPAR TO REAR SPAR INBD MAIN TANK	
PUMP - R CENTER WING FUEL OVERRIDE/JETTISON, M225	2	1	131EZ,131AZ,131BZ,132AZ,132BZ, R CTR SECTION WING BOX	
RELAY - (REF 31-01-24, FIG. 101) CENTER L JETTISON TRANSFER VALVE CONTROL, R7405				
CENTER R JETTISON TRANSFER VALVE CONTROL, R7406				
MAIN 2 JETTISON TRANSFER VALVE CONTROL, R7407				
MAIN 3 JETTISON TRANSFER VALVE CONTROL, R7408				
RELAY - (REF 31-01-36, FIG. 101) CENTER L FUEL TANK OVERRIDE/JETTISON PUMP, R43				
JETTISON A OVERRIDE, R7409				
JETTISON PUMP 2 OUTBD, R41				
JETTISON PUMP 3 OUTBD, R46				
MANAGEMENT JETTISON SELECT, R7413,R7414				
RELAY - (REF 31-01-39, FIG. 101) CENTER R FUEL TANK OVERRIDE/JETTISON PUMP, R44				
JETTISON B OVERRIDE, R7410				
JETTISON PUMP 2 INBD, R42				
JETTISON PUMP 3 INBD, R45				
MANAGEMENT JETTISON SELECT, R7411,R7412				

Fuel Jettison System - Component Index

Figure 101 (Sheet 3)

581985

Figure 69 28-31 Fuel Jettison System Component Index (Sheet 3)
Lufthansa
 TECHNISCHE SCHULUNG

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
SWITCH - LEFT CENTER WING TANK OVERRIDE/ JETTISON PUMP, S18	3	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - FORWARD NO. 2 MAIN TANK OVERRIDE/ JETTISON PUMP, S13	3	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - FORWARD NO. 3 MAIN TANK OVERRIDE/ JETTISON PUMP, S16	3	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - JETTISON SYSTEM SELECT (S10)	3	1	FLT COMPT, P5, JETTISON MODULE, M7325	*
SWITCH - LEFT FUEL JETTISON NOZZLE VALVE, S8	3	1	FLT COMPT, P5, JETTISON MODULE, M7325	*
SWITCH - AFT NO. 2 MAIN TANK OVERRIDE/ JETTISON PUMP, S17	3	1	FUEL COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - AFT NO. 3 MAIN TANK OVERRIDE/ JETTISON PUMP, S20	3	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
SWITCH - RIGHT CENTER WING TANK OVERRIDE/ JETTISON PUMP, S19	3	1	FLT COMPT, P5, FUEL MANAGEMENT CONTROL MODULE, M154	*
UNITS - (31-61-00/101) EFIS/EICAS INTERFACE, M7352 EFIS/EICAS INTERFACE, M7353 EFIS/EICAS INTERFACE, M7351				
UNIT - MOTOR/IMPELLER, L CENTER WING TANK FUEL OVERRIDE/JETTISON PUMP, M224	2	1	L WING LANDING GEAR WELL	28-31-01
UNIT - MOTOR/IMPELLER, NO. 2 MAIN TANK AFT FUEL OVERRIDE/JETTISON PUMP, M223	1	1	L REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-01
UNIT - MOTOR/IMPELLER, NO. 2 MAIN TANK FORWARD FUEL OVERRIDE/JETTISON PUMP, M222	1	1	L REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-01
UNIT - MOTOR/IMPELLER, NO. 3 MAIN TANK AFT FUEL OVERRIDE/JETTISON PUMP, M226	1	1	R REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-01
UNIT - MOTOR/IMPELLER, NO. 3 MAIN TANK FORWARD FUEL OVERRIDE/JETTISON PUMP, M227	1	1	R REAR SPAR TO LANDING GEAR SUPPORT BEAM	28-31-01
UNIT - MOTOR/IMPELLER, R CENTER WING TANK FUEL OVERRIDE/JETTISON PUMP, M225	2	1	R WING LANDING GEAR WELL	28-31-01
VALVE - CHECK, FUEL OVERRIDE/JETTISON PUMP DISCHARGE	1,2	6	ONE PER FUEL OVERRIDE/JETTISON PUMP	28-31-1 1
VALVE - CHECK, FUEL OVERRIDE/JETTISON PUMP INLET	1,2	6	ONE PER FUEL OVERRIDE/JETTISON PUMP	28-31-12


*SEE THE WDM EQUIPMENT LIST

Fuel Jettison System - Component Index

Figure 101 (Sheet 4)

581994

Figure 70 28-31 Fuel Jettison System Component Index (Sheet 4)
Lufthansa
 TECHNISCHE SCHULUNG




Fuel Jettison System - Component Location

Figure 102 (Sheet 1)


580407

Figure 71 28-31 Fuel Jettison System Component Location (Sheet 1)
Lufthansa
 TECHNISCHE SCHULUNG



LEFT OR RIGHT CENTER WING TANK COMPONENTS

(B)




Fuel Jettison System - Component Location (Details From Sht 1)

Figure 102 (Sheet 2)

580662

Figure 72 28-31 Fuel Jettison System Component Location (Sheet 2)
Lufthansa
 TECHNISCHE SCHULUNG



Fuel Jettison System - Component Location

Figure 102 (Sheet 3)

855138

Figure 73 28-31 Fuel Jettison System Component Location (Sheet 3)



Lufthansa
TECHNISCHE SCHULUNG

ATA 28-41 FUEL QUANTITY INDICATION SYSTEM

COMPONENT INDEX AND LOCATION



