



The configuration of various radio controls is shown graphically below.

Flysky FS-6is

Switches and channels assignment:



Channels reverse:



Rx setting (PWM – i-Bus):



Dual rates D/R channels 2 & 4:



Channel 2:  
D/R 100%



D/R switch A:



D/R 75%





# Frsky horus X10 with ETHOS OS

Switches and channels assignment:

Channel 4:  
D/R 100%



D/R 75%





**Rates conditions channels 2 & 4:**

Channel 2:



D/R 75%



D/R 100%



Channel 4:



D/R 75%



D/R 100%

