

DC 2M MOBILE LABEL/RECEIPT PRINTER



- 1- PRODUCT PACKAGING LIST**
- 2- APPEARANCE AND COMPONENTS**
- 3- TECHNICAL PARAMETERS**
- 4- HOW TO LOAD MEDIA**
- 5- FUNCTION DESCRIPTION OF BUTTON AND INDICATOR LED**
- 6- TROUBLESHOOTING (FAQ)**
- 7- MAINTENANCE & CAUTIONS**

1.PRODUCT PACKAING LIST

1- PRINTER

2- POWER ADAPTER

3- TYPE C DATA CABLE

4- BATTERY

5- USER MANUAL


6- CD



User manual



Printer



Power Adapter



CD



Type C data cable

2.APEARANCE AND COMPONENTS

1- FEED BUTTON

2- POWER BUTTON

3- PAUSE BUTTON

4- STATUS LED INDICATOR

5- ERROR LED INDICATOR

6- BATTERY STATUS LED INDICATOR


7- THERMAL PAPER SLOT

8- PLATEN ROLLER

9- TOP COVER

10- TOP COVER OPEN SWITCH

11- CHARGING INTERFACE



3. TECHNICAL SPECIFICATION

1/2

Printing Features	Label print mode	Receipt print mode
Printing method	Direct thermal	
Resolution	203 DPI	
Print width	Max.48 mm	
Max.print speed	Min. 50.8 mm/s, Max. 101 mm/s	90 mm/s
Media		
Media type	Thermal paper roll /Thermal adhesive paper	Thermal paper
Media width	20mm ~ 60mm	58 mm
Media external diameter	50 mm	
Paper out method	Tearing-off	
Performance Features		
Print head detection	Thermistor	
Print head position detection	Micro Switch	
Media detection	Photoelectric Sensors	
Interface	USB+Bluetooth	
Storage	Flash 576 kb	

TECHNICAL SPECIFICATION

2/2

Fonts/Graphics/Symbologies		
Character size	Font 0 to Font8	Font A: 12x24,Font B: 9x17, CHN: 24*24
1D bar code	CODE128, EAN128, ITF, CODE25, CODE39, CODE39C, CODE39S, CODE93, EAN13, EAN13+2, EAN13+5, EAN8, EAN8+2, EAN8+5, CODABAR, POSTNET, UPC-A, UPCA+2, UPCA+5, UPCE, UPCE+2, UPCE+5, MSI, MSIC, PLESSEY, ITF14, EAN14	UPC-A/UPC-E/JAN13 (EAN13) / JAN8(EAN8)/CODE39/ITF/CODABAR/ CODE93/CODE128
2D bar code	QR CODE	
Rotation	0°、90°、180°、270°	
Physical Features		
Gross weight	122.28*93.99*60.07mm (L*W*H)	
Dimensions	0.343 kg	
Software		
Systems	Windows/Android/iOS	
Power supply		
Battery	DC 7.2V/2500MAH	
Charging input	Standard USB cable charging: 5V / 2A Optional DC adapter charging: 9V / 2A	
Environmental Conditions		
Work environment	0 ~ 45℃, 10 ~ 80%RH no condensing	
Storage environment	-10 ~ 60 ℃, ≤93% RH (40℃) no condensing	

4.HOW TO LOAD MEDIA (THERMAL PAPER)

Follow the below step to load the media -

STEP 1- Open the top cover by pressing the 'Top cover open switch'.

STEP 2- Take a Thermal Paper Roll and place it in 'Thermal Paper Slot'. Ink coated side of paper should be print head side.

STEP 3- Close the 'Top Cover' of printer.



1. INDICATOR LED'S FUNCTION DESCRIPTION-

A. BATTERY STATUS LED INDICATOR-

- If only one indicator LED is blinking , it means that the battery capacity is very low. Please charge it ASAP.
- 25% Battery capacity left if only one LED is ON, 50% battery capacity left if two LED are ON. IF all three LED is on, it means battery is fully Charged.

B. ERROR LED INDICATOR-

- If Error indicator LED blinks slowly, it means Printer is Out of Paper.
- If Error indicator Led blinks quickly, it means Printhead is over heating.

C. STATUS LED INDICATOR-

- If Status Indicator LED is On, it means Bluetooth Communication is Connected.
- If Status Indicator LED is Off, it means there is no Bluetooth Connection or Bluetooth communication is disconnected.

2. BUTTON'S FUNCTION DESCRIPTION-

A. FEED-

Press Feed Button when Printer is On and Error Indicator LED is off, Printer would feed the paper to the front of next label.

B. PAUSE-

Press the Pause Button while the printer is printing and the printing task will be paused, press again to resume printing.

C. POWER ON-

Press the Power Button until the printer beep once to On the printer.

D. PRINTING MODE LABEL/RECEIPT SWITCH-

Follow the step below-

- Make sure the paper has been installed and top cover is closed under power-off status.
- Press and hold Pause button and then press Power Button until printer is power On. Release Power Button after printer ON.
- Release Pause Button when printer beeps twice. Current Printing mode will be printed.
- Press the Feed Button to switch printing Mode and restart printer.

E. PRINTING SEL-TEST PAGE-

Follow the step below

- **Make sure the label has been installed and top cover is closed under power-off status.**
- **Press and hold Feed button and then press Power Button until printer is power On. Release Power Button after printer ON.**
- **Release the feed Button after Error LED gets On.**
- **A self-test page will be printed.**

F. RESET DEFAULT -

Follow the step below

- **Make sure the label has been installed and top cover is closed under power-off status.**
- **Press and hold the feed button and long press the Power Button, All indicator LED will turn On.**
- **After pressing for 25 Second, there will be a beep sound then release the Power and Feed Button.**
- **Printer configuration will be restored to default.**

6.TROUBLESHOOTINGS (FAQ.)

PROBLEM	POSSIBLE CAUSE	SOLUTION
<ul style="list-style-type: none">If printer is not Getting On	<ul style="list-style-type: none">The battery is not properly installed.The battery is dead.	<ul style="list-style-type: none">Reinstall the battery.Charge the battery
<ul style="list-style-type: none">No print out while giving print command.	<ul style="list-style-type: none">Bluetooth Communication may be disconnected	<ul style="list-style-type: none">Check Bluetooth connectivity.
<ul style="list-style-type: none">If Error Indicator LED blinks Slowly.	<ul style="list-style-type: none">Running out of media roll.The media is installed incorrectly.	<ul style="list-style-type: none">* Load new media roll.* Reinstall the media roll.
<ul style="list-style-type: none">Paper Jam issue	<ul style="list-style-type: none">Media may be stuck inside the printer mechanism.Make sure media size is set properly.	<ul style="list-style-type: none">Reinstall the media rollSet media size correctly.
<ul style="list-style-type: none">Poor Print Quality	<ul style="list-style-type: none">Media is loaded incorrectlyDust or adhesive on the print head.Print density is not set properly.	<ul style="list-style-type: none">Reload / change the media Roll.Clean the print head and platen roller.Adjust the print density.
<ul style="list-style-type: none">Missing printing on left & right	<ul style="list-style-type: none">Wrong label size setup.	<ul style="list-style-type: none">Set the correct label size.
<ul style="list-style-type: none">Printer is printing Junk value	<ul style="list-style-type: none">The printer is in Hex Dump mode.Incorrect printing mode	<ul style="list-style-type: none">Restart Printer to exit Hex Dump modeCorrect Printing mode Label/Receipt

7. MAINTENANCE & CAUTIONS

1. **Timely clean the print head to avoid poorer print quality and extend Print head life.**
2. **Perform a routine cleaning of platen roller.**
3. **Please make sure power off when maintaining printer.**
4. **Do not touch or scratch printing head surface and platen roller.**
5. **Do not use and store in locations subject to high temperature, humidity or pollution level.**
6. **Do not print without paper, it may damage platen roller and print head.**
7. **Quality paper roll is recommended for premium printing and product maintenance.**
8. **Avoid water or other materials like metal get into the intern of printer. If it happens, unplug the AC power cord immediately.**

