

Changelog

[1.7.0]

Added

- Added changelog
- [MDCL-96](#) Added io shield templates for di10 and ai2+di5 boards
- [MDCL-52](#) Finished data hub implementation
 - Show adapter state inside ui
 - Added data point enums
- [MDCL-177](#) It's now required to confirm agb's inside the configuration wizard to start the southbound and northbound adapters
- [MDCL-176](#) Added "forgot password" link on login page (documentation page still missing)

Changed

- [MDCL-194](#) Prevent duplicated northbound connector mappings
- [MDCL-183](#) Prevent creation of duplicated virtual data points
- [MDCL-184](#) Prevent creation of southbound data points with duplicated name or address
- [MDCL-181](#) Hide mappings of disabled data sources
- [MDCL-166](#) Data source status is now refreshing every 2 seconds
- [MDCL-172](#) [MDCL-173](#) [MDCL-174](#) Layout adjustments on the login page
- [MDCL-155](#) The user is now able to select his type of siemens device he wants to connect
- [MDCL-169](#) The user is now able to select his type of input board he wants to connect
- [MDCL-157](#) The template wizard now displays more context information about every single step
- [MDCL-139](#) There are now quick links to access the documentation where the user needs some information about what he has to do. More links to be added.
- [MDCL-179](#) Increased default sampling rate of io shield data points to have a threshold chart with higher resolution
- [MDCL-180](#) Increased chart data series from 30 seconds to 5 minutes
- Changed production log level from debug to info
- Updated login documentation the new user and password format (username: User, password:)

Fixed

- [MDCL-129](#) Fixed digital io shield inputs that were unable to switch from blinking to on
- [MDCL-156](#) Fixed minor frontend responsibility fixes
- [MDCL-178](#) Fixed bug where configuration wizard doesn't open automatically after first login
- [MDCL-168](#) Live reloading doesn't break the mtconnect connector anymore