


DX FT8 V1.8 Cheat Sheet Page 1: Boot Up Page



DX FT8 V1.8 Cheat Sheet Page 2: Operating Page

The screenshot shows the DX FT8 V1.8 Operating Page interface. At the top, there's a waterfall display showing frequency. Below it, a horizontal line represents the Time Sync Line. To the right of the sync line, the Base Xmit Frequency is displayed as 14074. Further right, the FT8 Offset Frequency is displayed as 1500. The interface is divided into two main sections: Decoded FT8 Messages on the left and Sent / Received Message Log on the right. The Decoded Messages section shows several messages, including 'CQ POTA W6ZD EL96', 'WA3SCW N5HHS RR73', 'CQ KB2OBF FN02', 'CQ KA0BOJ EN10', and 'CQ K8USN EM90'. The Sent / Received Message Log shows several messages, including 'AB5EO W5BAA EM00', 'W5BAA AB5EO -06', 'AB5EO W5BAA R-4', 'W5BAA AB5EO RRR', 'AB5EO W5BAA RR73', and 'W5BAA AB5EO 73'. At the bottom, there's a row of controls: Clr, QSO, Tune, Rcv, Fixd, Sync, G-, 20, and G+. The RTC Time is displayed as 18:11:24 and the RTC Date as 14:41:07. Various labels with arrows point to these controls and the interface elements.

Touch Waterfall To Move Offset Frequency

Offset Cursor

Time Sync Line

Base Xmit Frequency

FT8 Offset Frequency

Decoded FT8 Messages

Touch Message To Call K8USN

RTC Time

RTC Date

Touch To Adjust Offset Frequency

Sent / Received Message Log

Clr: Touch To Clear Message Log

QSO: Touch For Beacon Mode
Beacon: Touch For QSO Mode

Tune: Touch To Open Tune Page


Rcv: Receive Indicator
Xmit: Xmit Indicator

Fixd: Set Xmit Freq To Offset Frequency In QSO Mode Only
Rcvd: Set Xmit Freq To Target Frequency In QSO Mode Only

Sync: Touch To Time Sync
Sync: Wait For Auto Sync

G- G+: Touch To Adjust Gain

DX FT8 V1.8 Cheat Sheet Page 3: Tune Page



DX FT8 V1.8 Cheat Sheet Page 4: Operation Flow / Slot Chart

DX FT8 Auto Sequence Process Operation

