



TELEDYNE PARADISE DATACOM

A Teledyne Technologies Company



Q-Flex Quick Start Guide

AN_036 Issue 1

1

Satellite service information that you need to know before you start:

1. Satellite service requirements including transmit and receive carrier frequencies, transmit power level, terrestrial data rate, modulation and Forward Error Correction (FEC) rate and system clocking requirements.
2. IP address, if configuring the modem via a web browser.

2

Power-up:

1. Connect the supplied power lead to the modem and apply power.
2. Wait for the modem to complete initialisation.
3. Press the **Main** key on the front panel to go to the main menu.
4. Alternatively, if using a web browser, having connected an Ethernet cable between your web browser and the modem's M&C Ethernet port, enter the IP address of the modem in order to access the modem's web server (user name: **admin**, password: **paradise**).

3

Configuration:

1. From the front panel, select **Edit** and then **All**, which will lead you through the main settings.
2. Alternatively, from the web browser, select the **Edit->Tx-Rx->Service** screen to access the main settings. (If you are not using IP as the traffic interface then you will need to select the appropriate traffic interface on the **Edit->Unit->Interface** screen.)
3. You have now successfully completed the configuration of the modem and are now ready to operate!

4

Further help:

1. An online user manual is available from the modem's web user interface by selecting the **Help** button near the top of the screen.
2. The user manual is also available from the modem documentation section of the Teledyne Paradise Datacom web site at <http://www.paradisedata.com>.

Teledyne Paradise Datacom Ltd.
2&3 The Matchyns, Rivenhall End,
Witham, Essex, CM8 3HA, England.
Tel: +44(0)1376 515636
Fax: +44(0)1376 533764

Teledyne Paradise Datacom LLC
328 Innovation Blvd.
State College, PA 16803, U.S.A.
Tel: +1 814 238 3450
Fax: +1 814 238 3829

<http://www.paradisedata.com>