


GPIO

Signal	Direction	Description
gpio_in[31:0]	input	Transmit Data
gpio_out[31:0]	output	Receive Data
gpio_dir[31:0]	output	Request to Send
gpio_padcfg[5:0] [31:0]	output	Pad Configuration
interrupt	output	Interrupt (Rise or Fall or Level)

PADDIR (Pad Direction)

Address: 0x1A10_1000

Reset Value: 0x0000_0000




Bit 31:0 **PADDIR**: Pad Direction.

Control the direction of each of the GPIO pads. A value of 1 means it is configured as an output, while 0 configures it as an input.

PADIN (Input Values)

Address: 0x1A10_1004

Reset Value: 0x0000_0000




Bit 31:0 **PADIN**: Input Values.

PADOUT (Output Values)

Address: 0x1A10_1008

Reset Value: 0x0000_0000



Bit 31:0 **PADOUT**: Output Values.

INTEN (Interrupt Enable)

Address: 0x1A10_100C

Reset Value: 0x0000_0000

[illegible]

Bit 31:0 **INTEN**: Interrupt Enable.

Interrupt enable per input bit. INTTYPE0 and INTTYPE1 control the interrupt triggering behavior.

There are four triggers available

- INTTYPE0 = 0, INTTYPE1 = 0: Level 1
- INTTYPE0 = 1, INTTYPE1 = 0: Level 0
- INTTYPE0 = 0, INTTYPE1 = 1: Rise
- INTTYPE0 = 1, INTTYPE1 = 1: Fall

INTTYPE0 (Interrupt Type 0)

Address: 0x1A10_1010

Reset Value: 0x0000_0000

INTTYPE0

Bit 31:0 **INTTYPE0**: Interrupt Type 0.

Controls the interrupt trigger behavior together with INTTYPE1. Use INTEN to enable interrupts first.

INTTYPE1 (Interrupt Type 1)

Address: 0x1A10_1014

Reset Value: 0x0000_0000

[illegible]

Bit 31:0 **INTTYPE1**: Interrupt Type 1.

Controls the interrupt trigger behavior together with INTTYPE0. Use INTEN to enable interrupts first.

INTSTATUS (Interrupt Status)

Address: 0x1A10_1018

Reset Value: 0x0000_0000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	INTSTATUS

Bit 31:0 **INTSTATUS**: Interrupt Status.

Contains interrupt status per GPIO line. The status register is cleared when read. Similarly the **interrupt** line is high while a bit is set in interrupt status and will be deasserted when the status register is read.

PADCFG0-7 (Pad Configuration Registers 0-7)

Address: 0x1A10_1020 - 0x1A10_103C

Reset Value: 0x0000_0000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	PADCFG0-7

Bit 31:0 **PADCFG0-7**: Pad Configuration Registers.

The pad configuration registers control various aspects of the pads that are typically used in ASICs, e.g. drive strength, Schmitt-Triggers, Slew Rate, etc. Since those configuration parameters depend on the exact pads used, each implementation is free to use the PADCFG0-7 registers in every way it wants and also leave them unconnected, if unneeded.