

13. Slow Down

SLOW
DOWN

If the speed of the aircraft exceeds the speed set by the system, the crew is reminded to slow down.

14. Line Crossing

TOO
FAR

If the aircraft slides over the stop line, the guidance display screen displays: 'TOO FAR'.

15. Line Not Reached

TOO
SHORT

After the equipment self-check, wait for the aircraft to be docked. When this interface appears, the aircraft can dock.

16. Error Alarm

ERROR
F04

If an error occurs in the system, the boot display will display the error code.

17. Block On Time

AIBT
09:10:11

When the aircraft has been docked, the system will start the wheelblock detection. When the wheelblock is detected to be placed according to the specifications, the guide screen will display the actual time of the wheel block.

18. Block Off Time

AOBT
10:11:12

When the system receives the departure flight plan, the system will start the block detection. When the block is removed according to the specifications, the guide screen will display the actual time of the next block.

19. Standby Mode

STND:
07
TIME:
14:14


When the device is in standby mode, the guidance display screen will display the current stand number and time.

20. Test Mode

TEST

Internal test sign, in this state, the crew shall stop according to the instructions of the flight attendant.

21. Maintenance Mode



Indicates that the equipment is not applicable.

Notes: Available for Stand Nr.113 and Nr.116.

Changes: New chart.